

# EV-DO Forward Link Measurement

Demonstration using Signal Analyzer and Vector Signal Generator

**MX269026A**

EV-DO Forward Link Measurement Software

**MX269026A-001**

All Measure Function

**MS2690A/MS2691A/MS2692A/MS2830A**

Signal Analyzer

**MG3710A**

Vector Signal Generator

## Introduction

This document explains output of the CDMA2000 1xEV-DO Rev. 0 forward link signal from the MG3710A Vector Signal Generator and measurement using the MS2690A/MS2691A/MS2692A/MS2830A Signal Analyzer.

The aim of this guide is to provide an understanding of the following items:

- Output of CDMA2000 1xEV-DO Rev. 0 Forward Link signal using MG3710A Vector Signal Generator and measurement of Tx characteristics using MS2690A/MS2691A/MS2692A/MS2830A Signal Analyzer
- High-speed measurement of CDMA2000 1xEV-DO Rev. 0 Forward Link signal Tx characteristics using All Measure Function

Measurement is performed first in the data sending status and then again in the idle status.


## Preparations

Prepare the following equipment and software for the demonstration.

- MG3710A Vector Signal Generator (Firmware Ver. 2.00.02 or newer)  
Opt-032            1stRF 100 kHz to 2.7 GHz (Opt-034, -036 also OK)
- MS2690A/MS2691A/MS2692A/MS2830A Signal Analyzer (Firmware Ver. 5.05.01 or newer)  
MX269026A            EV-DO Forward Link Measurement Software  
MX269026A-001        All Measure Function  
MS2830A-006            Analysis Bandwidth 10 MHz (using MS2830A)
- RF Cable                            1 pc

The EV-DO Forward Link signal used in the demonstration uses the standard waveform patterns installed in the MG3710A Vector Signal Generator.

Connect the instruments as shown in the following set-up diagram.



*Fig. 1. Connection Set-up*

To simplify the operations described in this application note, the cable attenuation settings and calibration procedures are omitted. To measure more accurately, refer to the operation manual and add the required procedures.

## Outputting Tx Data: Vector Signal Generator Operation

Use the following procedure to output the EV-DO Forward Link signal from the MG3710A Vector Signal Generator.

[Procedure]

1. Press [Preset] -> [F3] Preset All.
2. Press [Load] to display the Waveform List to Load window.
3. Select CDMA2000\_1xEV-DO from the Packages list at the left side of the window.
4. Select FWD\_2457\_6kbps\_1slot from Patterns in Packages list at the right side of the window. This waveform is the 1xEV-DO Revision 0, 2457.6 kbps data rate, 16QAM modulation signal.
5. Press [F6] Load Pattern.
6. Press [Select] to display the Waveform List to Play window.
7. Select CDMA2000\_1xEV-DO from the Packages list at the left side of the window.
8. Select FWD\_2457\_6kbps\_1slot from Patterns in the Packages list at the right side of the window.
9. Press [F6] Select.
10. Press [Frequency] and set the frequency to 870 MHz.
11. Press [Level] and set the level to -10 dBm.
12. Press RF Output [Mod On/Off] and [On/Off] to output the modulation signal.

The above procedure outputs the EV-DO Forward Link signal in the data Tx status from the RF Output of the MG3710A Vector Signal Generator.




Fig. 2. Vector Signal Generator Settings (Data Tx Status)

## Measuring Data Tx Status: Signal Analyzer Operation

Use the following procedure to measure the Tx characteristics of the EV-DO Forward Link signal in the Tx (sending) status using the MS2690A/MS2691A/MS2692A/MS2830A Signal Analyzer.

### Modulation Accuracy Measurement

[Procedure]

1. Press [Application Switch] to select EV-DO Forward.
2. Press [Preset] -> [F1] Preset.
3. Press [Frequency] and set the frequency to 870 MHz.
4. Press [Amplitude] and set the level to -10 dBm.
5. Press [Measure] -> [F1] Code Domain.
6. Press [Single] to start measurement.

The above operations measure the frequency error, modulation accuracy and code domain power.




Fig. 3. Frequency Error/Modulation Accuracy/Code Domain Power Measurement Results (Data Tx Status/MAC Channel Code Domain Power)

The modulation accuracy measurement results are displayed as numerical values in the lower part of the Code Domain screen.

The frequency error is referenced as Frequency Error.

The modulation accuracy is referenced as poverall1, poverall2, and ppilot.

The MAC channel maximum inactive channel power is referenced as Power of Max. MAC Inactive CH Power.

The top of the Code Domain screen displays a graph of the code domain power and the power for each channel.

Display of each I/Q code for the RMAC channel is performed by setting [Trace] -> [F2] Code Domain Channel Type to MAC. Pressing [Marker] to set [F2] Branch and [F3] Code Number can be used to reference the power and  $\rho$  for any code channel.

Display of each I/Q code for the traffic channel is performed by setting [Trace] -> [F2] Code Domain Channel Type to Data. Pressing [Marker] to set [F2] Branch and [F3] Code Number can be used to reference the power and  $\rho$  for any code channel.




Fig. 4. Frequency Error/Modulation Accuracy/Code Domain Power Measurement Results (Data Tx Status/Data Channel Code Domain Power)

## Tx Power Measurement

7. Press [Measure] -> [F2] Power vs Time.
8. Press Function Menu Top -> [F3] Common Setting -> [F2] Slot Type to set Active.
9. Press [Trace] -> [F4] Storage -> [F1] Mode to set On.
10. Press [Trace] -> [F4] Storage -> [F2] Count to set 513.
11. Press [Measure] -> [F2] Power vs Time -> [F6] Display Item to set Average.
12. Press [Single] to start measurement.




Fig. 5. Tx Power Measurement Results (Data Tx Status/Data Channel)

The power during data Tx must be obtained in the range of the average power  $\pm 2.5$  dB. The Tx power is averaged for at least 512 measurements. When the obtained waveform comes within the mask template displayed on the signal analyzer Power vs Time screen, the evaluation result is Pass; otherwise, the result is Fail.

## Occupied Bandwidth Measurement

13. Press [Measure] -> [F7] OBW (FFT) to measure the occupied bandwidth using the signal analyzer function.




Fig. 6. Occupied Bandwidth Measurement Results

## Emissions Measurement

- Press [Measure] -> [->] (Function Menu page 2) -> [F6] Spectrum Emission Mask (Swept) to measure emissions using the spectrum analyzer function.




Fig. 7. Emissions Measurement Results



## Batch Measurement of Tx Characteristics

The signal analyzer All Measure function can be used to measure not only the frequency error, modulation accuracy and code domain power but also for measure power vs time and spectrum measurements. Using this function can shorten the measurement time by selecting each function for each measurement item. There are three measurement units: Modulation Analysis, Occupied Bandwidth, and Spectrum Emission, and measurement can be enabled/disabled for each along with the number of measurement averagings.

[Procedure]

15. Press [Measure] -> [F3] All Measure.
16. Press [F1] Modulation Analysis Setting -> [F2] Storage -> [F1] Mode to set On.
17. Press [F1] Modulation Analysis Setting -> [F2] Storage -> [F2] Count to set 513.
18. Press [Single] to start measurement.

The above procedure measures the modulation accuracy, Tx power, occupied bandwidth, and emissions as a single batch measurement.




Fig. 8. All Measure Function Measurement Results

## Outputting Idle Status: Vector Signal Generator Option

Next, the pilot and MAC channel measurements are made in the idle status. The following MG3710A Vector Signal Generator operation procedure can be executed after the output procedure in the data Tx status.

[Procedure]

1. Press [Load] to display the Waveform List to Load window.
2. Select CDMA2000\_1xEV-DO from the Packages list at the left side of the window.
3. Select FWD\_Idle from the Pattern in Package list at the right side of the window.
4. Press [F6] Load Pattern.
5. Press [Select] to display the Waveform List to Play window.
6. Select CDMA2000\_1xEV-DO from the Packages list at the left side of the window.
7. Select FWD\_Idle from Patterns in the Packages list at the right side of the window.
8. Press [F6] Select.

The above procedure outputs the EV-DO Forward Link signal in the idle status from the RF Output port of the MG3710A Vector Signal Generator.




Fig. 9. Example of Vector Signal Generator Settings (Idle State)

## Measuring Idle State: Signal Analyzer Operation

Use the following procedure to measure the Tx power of the EV-DO Forward Link signal in the Idle state using the MS2690A/MS2691A/MS2692A/MS2830A Signal Analyzer.

### Tx Power Measurement

[Procedure]

1. Press [Measure] -> [F2] Power vs Time.
2. Press Function Menu Top -> [F3] Common Setting -> [F2] Slot Type to set Idle.
3. Press [Trace] -> [F4] Storage -> [F1] Mode to set On.
4. Press [Trace] -> [F4] Storage -> [F2] Count to set 513.
5. Press [Measure] -> [F6] Display Item to set Average.
6. Press [Single] to start measurement.

The above procedure measures the pilot/MAC Channel Tx power.

Setting [Trace] -> [F1] Trace Mode can be used to zoom the Half Slot/On Portion/Ramp displays.




Fig. 10. Tx Power Measurement Results (Idle Status/Pilot/MAC Channel/Half Slot)




Fig. 11. Tx Power Measurement Results (Idle Status/Pilot/MAC Channel, On Portion)




Fig. 12. Tx Power Measurement Results (Idle Status/Pilot/MAC Channel/Ramp Segments)

● **United States**

**Anritsu Company**

1155 East Collins Blvd., Suite 100, Richardson,  
TX 75081, U.S.A.  
Toll Free: 1-800-267-4878  
Phone: +1-972-644-1777  
Fax: +1-972-671-1877

● **Canada**

**Anritsu Electronics Ltd.**

700 Silver Seven Road, Suite 120, Kanata,  
Ontario K2V 1C3, Canada  
Phone: +1-613-591-2003  
Fax: +1-613-591-1006

● **Brazil**

**Anritsu Eletrônica Ltda.**

Praça Amadeu Amaral, 27 - 1 Andar  
01327-010 - Bela Vista - São Paulo - SP - Brazil  
Phone: +55-11-3283-2511  
Fax: +55-11-3288-6940

● **Mexico**

**Anritsu Company, S.A. de C.V.**

Av. Ejército Nacional No. 579 Piso 9, Col. Granada  
11520 México, D.F., México  
Phone: +52-55-1101-2370  
Fax: +52-55-5254-3147

● **United Kingdom**

**Anritsu EMEA Ltd.**

200 Capability Green, Luton, Bedfordshire, LU1 3LU, U.K.  
Phone: +44-1582-433200  
Fax: +44-1582-731303

● **France**

**Anritsu S.A.**

12 avenue du Québec, Bâtiment Iris 1- Silic 612,  
91140 VILLEBON SUR YVETTE, France  
Phone: +33-1-60-92-15-50  
Fax: +33-1-64-46-10-65

● **Germany**

**Anritsu GmbH**

Nemetschek Haus, Konrad-Zuse-Platz 1  
81829 München, Germany  
Phone: +49-89-442308-0  
Fax: +49-89-442308-55

● **Italy**

**Anritsu S.r.l.**

Via Elio Vittorini 129, 00144 Roma, Italy  
Phone: +39-6-509-9711  
Fax: +39-6-502-2425

● **Sweden**

**Anritsu AB**

Borgarfjordsgatan 13A, 164 40 KISTA, Sweden  
Phone: +46-8-534-707-00  
Fax: +46-8-534-707-30

● **Finland**

**Anritsu AB**

Teknobulevardi 3-5, FI-01530 VANTAA, Finland  
Phone: +358-20-741-8100  
Fax: +358-20-741-8111

● **Denmark**

**Anritsu A/S (Service Assurance)**

**Anritsu AB (Test & Measurement)**

Kay Fiskers Plads 9, 2300 Copenhagen S, Denmark  
Phone: +45-7211-2200  
Fax: +45-7211-2210

● **Russia**

**Anritsu EMEA Ltd.**

**Representation Office in Russia**

Tverskaya str. 16/2, bld. 1, 7th floor.

Russia, 125009, Moscow  
Phone: +7-495-363-1694  
Fax: +7-495-935-8962

● **United Arab Emirates**

**Anritsu EMEA Ltd.**

**Dubai Liaison Office**

P O Box 500413 - Dubai Internet City  
Al Thuraya Building, Tower 1, Suit 701, 7th Floor  
Dubai, United Arab Emirates  
Phone: +971-4-3670352  
Fax: +971-4-3688460

● **India**

**Anritsu India Private Limited**

2nd & 3rd Floor, #837/1, Binnamangla 1st Stage,  
Indiranagar, 100ft Road, Bangalore - 560038, India  
Phone: +91-80-4058-1300  
Fax: +91-80-4058-1301

● **Singapore**

**Anritsu Pte. Ltd.**

60 Alexandra Terrace, #02-08, The Comtech (Lobby A)  
Singapore 118502  
Phone: +65-6282-2400  
Fax: +65-6282-2533

● **P.R. China (Shanghai)**

**Anritsu (China) Co., Ltd.**

Room 2701-2705, Tower A,  
New Caohejing International Business Center  
No. 391 Gui Ping Road Shanghai, 200233, P.R. China  
Phone: +86-21-6237-0898  
Fax: +86-21-6237-0899

● **P.R. China (Hong Kong)**

**Anritsu Company Ltd.**

Unit 1006-7, 10/F., Greenfield Tower, Concordia Plaza,  
No. 1 Science Museum Road, Tsim Sha Tsui East,  
Kowloon, Hong Kong, P.R. China  
Phone: +852-2301-4980  
Fax: +852-2301-3545

● **Japan**

**Anritsu Corporation**

8-5, Tamura-cho, Atsugi-shi, Kanagawa, 243-0016 Japan  
Phone: +81-46-296-1221  
Fax: +81-46-296-1238

● **Korea**

**Anritsu Corporation, Ltd.**

502, 5FL H-Square N B/D, 681  
Sampyeong-dong, Bundang-gu, Seongnam-si,  
Gyeonggi-do, 463-400 Korea  
Phone: +82-31-696-7750  
Fax: +82-31-696-7751

● **Australia**

**Anritsu Pty. Ltd.**

Unit 21/270 Ferntree Gully Road, Notting Hill,  
Victoria 3168, Australia  
Phone: +61-3-9558-8177  
Fax: +61-3-9558-8255

● **Taiwan**

**Anritsu Company Inc.**

7F, No. 316, Sec. 1, NeiHu Rd., Taipei 114, Taiwan  
Phone: +886-2-8751-1816  
Fax: +886-2-8751-1817

Please Contact: