

MX183000A High-Speed Serial Data Test Software Operation Manual

15th Edition

- For safety and warning information, please read this manual before attempting to use the equipment.
- Additional safety and warning information is provided in the MP1800A Signal Quality Analyzer Installation Guide, the MP1900A Signal Quality Analyzer-R Operation Manual, and the MT1810A 4 Slot Chassis Installation Guide. Please also refer to them before using the equipment.

ANRITSU CORPORATION

Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

Symbols used in manual



DANGER

This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.



WARNING

This indicates a hazardous procedure that could result in serious injury or death if not performed properly.



CAUTION

This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MX183000A
High-Speed Serial Data Test Software
Operation Manual

1 February 2016 (First Edition)
26 September 2019 (15th Edition)

Copyright © 2016-2019, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

Equipment Certificate

Anritsu Corporation guarantees that this equipment was inspected at shipment and meets the published specifications.

Anritsu Warranty

- During the warranty period, Anritsu Corporation will repair or exchange this software free-of-charge if it proves defective when used as described in the operation manual.
- The warranty period is 6 months from the purchase date.
- The warranty period after repair or exchange will remain 6 months from the original purchase date, or 30 days from the date of repair or exchange, depending on whichever is longer.
- This warranty does not cover damage to this software caused by Acts of God, natural disasters, and misuse or mishandling by the customer.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation shall assume no liability for injury or financial loss of the customer due to the use of or a failure to be able to use this equipment.

Anritsu Corporation Contact

In the event of this equipment malfunctions, contact an Anritsu Service and Sales office. Contact information can be found on the last page of the printed version of this manual, and is available in a separate file on the PDF version.

Notes On Export Management

This product and its manuals may require an Export License/Approval by the Government of the product's country of origin for re-export from your country.

Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not.

When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

Software End-User License Agreement (EULA)

Please read this Software End-User License Agreement (hereafter this EULA) carefully before using (includes executing, copying, registering, etc.) this software (includes programs, databases, scenarios, etc., used to operate, set, etc., Anritsu electronic equipment). By reading this EULA and using this software, you are agreeing to be bound by the terms of its contents and Anritsu Corporation (hereafter Anritsu) hereby grants you the right to use this Software with the Anritsu-specified equipment (hereafter Equipment) for the purposes set out in this EULA.

1. Grant of License and Limitations

1. Regardless of whether this Software was purchased from or provided free-of-charge by Anritsu, you agree not to rent, lease, lend, or otherwise distribute this Software to third parties and further agree not to disassemble, recompile, reverse engineer, modify, or create derivative works of this Software.
2. You may make one copy of this Software for backup purposes only.
3. You are not permitted to reverse engineer this software.
4. This EULA allows you to install one copy of this Software on one piece of Equipment.

2. Disclaimers

To the extent not prohibited by law, in no event shall Anritsu be liable for personal injury, or any incidental, special, indirect or consequential damages whatsoever, including, without limitation, damages for loss of profits, loss of data, business interruption or any other commercial damages or losses, arising out of or related to your use or inability to use this Software.

3. Limitation of Liability

- a. If a fault (bug) is discovered in this Software, preventing operation as described in the operation manual or specifications whether or not the customer uses this software as described in the manual, Anritsu shall at its own discretion, fix the bug, or exchange the software, or suggest a workaround, free-of-charge. However, notwithstanding the above, the following items shall be excluded from repair and warranty.
 - i) If this Software is deemed to be used for purposes not described in the operation manual or specifications.
 - ii) If this Software is used in conjunction with other non-Anritsu-approved software.
 - iii) Recovery of lost or damaged data.
 - iv) If this Software or the Equipment has been modified, repaired, or otherwise altered without Anritsu's prior approval.
 - v) For any other reasons out of Anritsu's direct control and responsibility, such as but not limited to, natural disasters, software virus infections, etc.
- b. Expenses incurred for transport, hotel, daily allowance, etc., for on-site repairs by Anritsu engineers necessitated by the above faults shall be borne by you.
- c. The warranty period for faults listed in article 3a above covered by this EULA shall be either 6 months from the date of purchase of this Software or 30 days after the date of repair, whichever is longer.

4. Export Restrictions

You may not use or otherwise export or re-export directly or indirectly this Software except as authorized by Japanese and United States law. In particular, this software may not be exported or re-exported (a) into any Japanese or US embargoed countries or (b) to anyone on the Japanese or US Treasury Department's list of Specially Designated Nationals or the US Department of Commerce Denied Persons List or Entity List. By using this Software, you warrant that you are not located in any such country or on any such list. You also agree that you will not use this Software for any purposes prohibited by Japanese and US law, including, without limitation, the development, design and manufacture or production of missiles or nuclear, chemical or biological weapons of mass destruction.

5. Termination

Anritsu shall deem this EULA terminated if you violate any conditions described herein. This EULA shall also be terminated if the conditions herein cannot be continued for any good reason, such as violation of copyrights, patents, or other laws and ordinances.

6. Reparations

If Anritsu suffers any loss, financial or otherwise, due to your violation of the terms of this EULA, Anritsu shall have the right to seek proportional damages from you.

7. Responsibility after Termination

Upon termination of this EULA in accordance with item 5, you shall cease all use of this Software immediately and shall as directed by Anritsu either destroy or return this Software and any backup copies, full or partial, to Anritsu.

8. Dispute Resolution

If matters of dispute or items not covered by this EULA arise, they shall be resolved by negotiations in good faith between you and Anritsu.

9. Court of Jurisdiction

This EULA shall be interpreted in accordance with Japanese law and any disputes that cannot be resolved by negotiation described in Article 8 shall be settled by the Japanese courts.

Before Using VISA*¹

For Those Who Use MP1800A and MP1900A

To use the MX183000A High-Speed Serial Data Test Software (hereafter MX183000A), you are required to install National Instruments™ (hereafter NI™) NI-VISA™*² on the PC controller. We recommend using NI-VISA™*² provided in the USB memory stick that contains MX183000A.

You are allowed to use NI-VISA™*² contained in the USB memory stick only for the purpose of using it for MX183000A. Use of NI-VISA™*² for any other product or purpose is prohibited. When uninstalling MX183000A from the PC controller, uninstall NI-VISA™ that was installed from the USB memory stick as well.

Glossary of Terms:

*1: VISA: Virtual Instrument Software Architecture
I/O software specification for remote control of measuring instruments using interfaces such as GPIB, Ethernet, USB, etc.

*2 :NI-VISA™
World de facto standard I/O software interface developed by NI and standardized by the VXI Plug&Play Alliance.

Trademarks:

- National Instruments™, NI™, NI-VISA™ and National Instruments Corporation are all trademarks of National Instruments Corporation

Before Using VISA*¹

For Those Who Use MT1810A

To use the MX183000A High-Speed Serial Data Test Software (hereafter MX183000A), you are required to install National Instruments™ (hereafter NI™) NI-VISA™*² on the PC controller.

You need to get the NI-VISA™ Installer yourself.

The USB memory stick for MX183000A does not contain NI-VISA™ because MT1810A does not include any NI™ hardware.

Glossary of Terms:

*1: VISA: Virtual Instrument Software Architecture
I/O software specification for remote control of measuring instruments using interfaces such as GPIB, Ethernet, USB, etc.

*2 :NI-VISA™
World de facto standard I/O software interface developed by NI and standardized by the VXI Plug&Play Alliance.

Trademarks:

- National Instruments™, NI™, NI-VISA™ and National Instruments Corporation are all trademarks of National Instruments Corporation

Protection Against Computer Virus Infections

Prior to the software installation

Before installing this software or any other software recommended or approved by Anritsu, run a virus scan on your computer, including removable media (e.g. USB memory stick and CF memory card) you want to connect to your computer.

When using this software and connecting with the measuring instrument

- Copying files and data

On your computer, do not save any copies other than the following:

- Files and data provided by Anritsu
- Files created by this software
- Files specified in this document

Before copying these files and/or data, run a virus scan, including removable media (e.g. USB memory stick and CF memory card).

- Connecting to network

Connect your computer to the network that provides adequate protection against computer viruses.

Cautions on Proper Operation of Software


This software may not operate normally if any of the following operations are performed on your computer:

- Simultaneously running any software other than that recommended or approved by Anritsu
- Closing the lid (Laptop computer)
- Turning on the screen saver function
- Turning on the battery-power saving function (Laptop computer)

For how to turn off the functions, refer to the operation manual that came with your computer.


About This Manual

A testing system comprised of the MP1800A Signal Quality Analyzer, MT1810A 4-Slot Chassis, module(s), and control software is called the Signal Quality Analyzer series. A set of operation manuals of the Signal Quality Analyzer series consists of separate documents about installation guide, the mainframe, remote control operation, module(s), control software, and extended applications as shown below.



A test system combining an MP1900A Signal Quality Analyzer-R, module(s), and control software is called a Signal Quality Analyzer-R Series. The operation manuals of the Signal Quality Analyzer-R Series consist of separate documents for the MP1900A, module(s), and control software as shown below.

Configuration of Signal Quality Analyzer-R Series Operation

 indicates this document.

MP1900A Signal Quality Analyzer-R Operation Manual

Describes the basic operations, panel details, and maintenance of the MP1900A, as well as the steps from module installation to the start of use.

Module Operation Manual

MU195020A 21G/32G bit/s SI PPG MU195040A 21G/32G bit/s SI ED
MU195050A Noise Generator Operation Manual

Describes the panel details, how to operate, performance test, maintenance, and troubleshooting of the module to be installed on the MP1900A.

MU196020A PAM4 PPG MU196040A PAM4 ED MU196040B PAM4 ED
Operation Manual

Describes the panel details, performance test, maintenance, and troubleshooting of the MU196020A, MU196040A, and MU196040B.

MU181000A 12.5GHz Synthesizer MU181000B 12.5GHz 4 port Synthesizer
Operation Manual

Describes the panel details, how to operate, performance test, maintenance, and troubleshooting of the MU181000A and MU181000B.

MU181500B Jitter Modulation Source Operation Manual

Describes the panel details, how to operate, performance test and maintenance of the MU181500B.


MU183020A 28G/32G bit/s PPG MU183021A 28G/32G bit/s 4ch PPG
Operation Manual

Describes the panel details, performance test, maintenance, and troubleshooting of the MU183020A and MU183021A.

MU183040A 28G/32G bit/s ED MU183041A 28G/32G bit/s 4ch ED
MU183040B 28G/32G bit/s High Sensitivity ED
MU183041B 28G/32G bit/s 4ch High Sensitivity ED Operation Manual

Describes the panel details, how to operate, performance test, maintenance, and troubleshooting of the MU183040A, MU183041A, MU183040B, and MU183041B.

Configuration of Signal Quality Analyzer-R Series Operation Manuals (Cont'd)

 indicates this document.

MX190000A Signal Quality Analyzer-R Control Software Operation Manual

Describes the operation of the software that controls the Signal Quality Analyzer-R Series.

Extended Application Operation Manual

Describes the operation of the extended application for the Signal Quality Analyzer-R Series.

MX183000A High-Speed Serial Data Test Software Operation Manual

Describes the setup and operating procedure of MX183000A.

Table of Contents

About This Manual.....	I
Chapter 1 Outline	1-1
1.1 Outline.....	1-2
1.2 Features.....	1-6
1.3 Model Names and Options	1-7
1.4 Uses.....	1-8
1.5 Glossary.....	1-9
Chapter 2 Before Use	2-1
2.1 Unpacking	2-2
2.2 Operating Environment.....	2-2
2.3 Installation/Uninstallation	2-3
2.4 License Key Activation.....	2-11
Chapter 3 Connecting Equipment	3-1
3.1 Target Equipment	3-2
3.2 Jitter Tolerance Test Connection Procedure	3-8
3.3 PCIe Link Sequence/Training Connection Procedure.....	3-11
3.4 USB Link Sequence/Training Connection Procedure.....	3-20
3.5 PAM4 Control Connection Procedure	3-27
3.6 DUT Error Counts Import Connection Procedure	3-31
Chapter 4 Operation	4-1
4.1 Start up and Exit	4-3
4.2 Setup Procedure and Editing Values.....	4-7
4.3 Measurement System Configuration	4-11
4.4 PCIe Link Sequence	4-21
4.5 USB Link Sequence.....	4-32
4.6 Jitter Tolerance Test	4-42
4.7 Jitter Tolerance Test Procedure	4-60
4.8 PCIe Link Training	4-68
4.9 PAM4 Control	4-103

4.10	USB Link Training	4-114
4.11	DUT Error Counts Import.....	4-121

Chapter 5 Remote Control..... 5-1

5.1	Setting Interface for Remote Control	5-3
5.2	Remote Control Procedure	5-4
5.3	Command Description Method	5-12
5.4	IEEE488.2 Common Commands	5-14
5.5	MX183000A Command List (Tree).....	5-15
5.6	Common Commands.....	5-23
5.7	Setting Measurement System	5-27
5.8	PCIe Link Sequence Setup Screen (With MX183000A-PL011 Installed)	5-43
5.9	PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)	5-84
5.10	USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)	5-170
5.11	USB Link Training Setup Screen (With MX183000A-PL022 Installed)	5-188
5.12	Jitter Tolerance Setup Screen	5-211
5.13	PAM4 Setup Screen	5-245
5.14	DUT Error Counts Import Setup Screen.....	5-270

Appendix A SpecificationsA-1

Appendix B Default SettingsB-1

Appendix C User Program SpecificationsC-1

1

2

3

4

5

Appendix

Chapter 1 Outline

This section outlines the details of the MX183000A High-Speed Serial Data Test Software.

1.1	Outline.....	1-2
1.2	Features.....	1-6
1.3	Model Names and Options	1-7
1.4	Uses.....	1-8
1.5	Glossary.....	1-9

1.1 Outline

The MX183000A High-Speed Serial Data Test Software (hereinafter referred to as “MX183000A”) controls the following devices and allows jitter tolerance to be measured in compliance with the relevant standards for the 10 Gbit/s and 20 Gbit/s bands, together with generation of PCIe/USB link sequences.

- MP1800A Signal Quality Analyzer (hereinafter referred to as “MP1800A”), MT1810A 4-slot Chassis (hereinafter referred to as “MT1810A”) or MP1900A Signal Quality Analyzer-R (hereinafter referred to as “MP1900A”)
- MU181000A 12.5 GHz Synthesizer or MU181000B 12.5 GHz 4-port Synthesizer
- MU181500B Jitter Modulation Source (hereinafter referred to as “MU181500B”)
- MU183020A 28G/32G bit/s PPG or MU183021A 28G/32G bit/s 4ch PPG (hereinafter referred to as “32G PPG”)
- MU183040A 28G/32G bit/s ED, MU183041A 28G/32G bit/s 4ch ED, MU183040B 28G/32G bit/s High Sensitivity ED, or MU183041B 28G/32G bit/s 4ch High Sensitivity ED (hereinafter referred to as “32G ED”)
- MU195020A 21G/32G bit/s SI PPG (hereinafter referred to as “32G SI PPG”)
- MU195040A 21G/32G bit/s SI ED (hereinafter referred to as “32G SI ED”)
- G0375A 32Gbaud PAM4 Converter (hereinafter referred to as “PAM4 Converter”)
- G0376A 32Gbaud PAM4 Decoder with CTLE (hereinafter referred to as “PAM4 Decoder”)
- MU196020A PAM4 PPG (hereinafter referred to as “PAM4 PPG”)
- MU196040A PAM4 ED (hereinafter referred to as “PAM4 ED”)
- MU196040B PAM4 ED (hereinafter referred to as “PAM4 ED”)

MX183000A controls MP1800A, MT1810A or MP1900A via Ethernet. Jitter Tolerance Measurement mode measures the bit error rate or bit error while varying the MU181500B jitter frequency and amplitude.

PCIe/USB Link Sequence mode generates data sequences for setting the target device to loop-back state using 32G PPG.

Also, PAM4 Control mode allows transmission/reception settings and real time BER measurement of PAM4 signal.




Figure 1.1-1 Setup and measurement items of MX183000A

MX183000A features the following four measurement functions.

PCIe Link Sequence

The PCIe Link Sequence function generates data sequences for setting the target device to loop-back state using 32G PPG.

PCIe Link Training

The PCIe Link Training function executes the link training with the target device for setting it to loop-back state using 32G SI PPG and 32G SI ED.

USB Link Sequence

The USB Link Sequence function generates data sequences for setting the target device to loop-back state using 32G PPG.

USB Link Training

The USB Link Training function executes the link training with the target device for setting it to loop-back state using 32G SI PPG and 32G SI ED.

Jitter Tolerance Test

The Jitter Tolerance Test sends the jitter modulated data to the target device, and measures the tolerance point indicated by the maximum jitter amplitude under the specified bit error rate. The high-rate jitter tolerance

point can also be used to estimate the low-rate jitter tolerance point such as E-20.

The Jitter Tolerance test displays the jitter modulation frequency and amplitude in graph and table form.




Figure 1.1-2 Jitter Tolerance Run Test Tab Screen




Figure 1.1-3 Jitter Tolerance Graph Screen

DUT Error Counts Import

The DUT Error Counts Import function acquires information about errors and alarms from the internal counter of device under test (hereafter, DUT) and displays the measurement results.

1.2 Features

MX183000A has the following features.

- Link sequence generation is available for setting the PCIe device to loop-back state.
- Link training is available for setting the PCIe device to loop-back state.
- Generating logs is available for showing LTSSM transition state of PCIe device under Link Training.
- Generating link sequence is available for setting the USB3.0/3.1 device to loop-back state.
- Link Training is available for setting the USB3.0/3.1 device to loop-back state.
- Generating logs is available for showing LTSSM transition state of USB3.0/3.1 device under Link Training.
- Jitter tolerance measurement involves testing by controlling the MU181500B and varying SJ while adding jitter such as RJ or BUJ at a fixed value.
- Jitter tolerance measurement provides three methods for varying jitter amplitude depending on the characteristics of Serdes, as shown below.
 - Binary search
 - Downward search from the upper limit value to the lower limit value
 - Upward search from the lower limit value to the upper limit value
- Estimation of low-rate jitter tolerance results
- Mask measurement according to various standards is available.
- MX183000A can control up to three MP1800A, MT1810A, or MP1900A.
- Measurement results can be output in the html or CSV format.
- MX183000A allows transmission/reception setting and BER measurement of PAM4 signal.
- MX183000A can acquire the error information from the internal counter of DUT and display the measurement results.


1.3 Model Names and Options

Table 1.3-1 shows the model names and options for MX183000A. Options can be added by entering a license key. Refer to 2.4 “License Key Activation” for details.

Table 1.3-1 MX183000A Model Names and Options

Model	Name	Remarks
MX183000A	High-Speed Serial Data Test Software	One of the following options must be included. All the options can be mounted at the same time.
MX183000A-PL001	Jitter Tolerance Test	
MX183000A-PL011	PCIe Link Sequence	
MX183000A-PL012	USB Link Sequence	
MX183000A-PL021	PCIe Link Training	
MX183000A-PL022	USB Link Training	
MX183000A-PL031	DUT Error Counts Import	

Note:
Option name format is as follows:



1.4 Uses

MX183000A is used for the following purposes:

- PCIe link sequence generation
- PCIe link training execution
- USB link sequence generation
- USB link training execution
- Serdes device jitter tolerance measurement in compliance with the relevant standards in the 2.4 to 32 Gbit/s band.
- Error and alarm measurement and jitter tolerance measurement of the device receiver that comply with various standards for 2.4 to 56 Gbaud band.

Table 1.4-1 shows the test items MX183000A supports for the relevant standards and DUTs.

Table 1.4-1 MX183000A Supported Standards and DUTs

Supported Standard		DUT	Link Sequence Generation	Jitter Tolerance Measurement
PCIe Sequence	1.x/2.0/3.x/4.0	Addin Card	✓	✓
		System Board		
PCIe Training		Addin Card	✓	✓
		System Board	✓	✓
USB Sequence	3.0/3.1	Device	✓	
		Host	✓	
USB Training		Device	✓	✓
		Host	✓	✓

1.5 Glossary

The following table contains the abbreviations used in this document and MX183000A.

Table 1.5-1 Abbreviation

Abbreviation	Full Term
BER	Bit Error Rate
BUJ	Bounded Uncorrelated Jitter
CBB	Compliance Base Board
CLB	Compliance Load Board
CP	Compliance Pattern
CSV	Comma Separated Value
DE	De-emphasis
DEMUX	De-multiplexer
DUT	Device Under Test
ED	Error Detector
EIEOS	Electrical Idle End Ordered Set
FTS	Fast Training Sequence
GPB	General Purpose Interface Bus
HPF	High Pass Filter
HTML	Hyper Text Markup Language
JTMP	Jitter Tolerance Measurement Pattern
JTOL	Jitter Tolerance
LBPM	LFPS-Based PWM Messaging
LFPS	Low Frequency Periodic Signaling
LPF	Low Pass Filter
LTSSM	Link Training and Status State Machine
MCP	Modified Compliance Pattern
MUX	Multiplexer
OS	Ordered Set
PAM	Pulse Amplitude Modulation
PCIe	PCI Express
PPG	Pulse Pattern Generator
PRBS	Pseudo-Random Bit Sequence
PS	Pre-shoot
RJ	Random Jitter
Serdes	Serializer/Deserializer
SSC	Spread Spectrum Clock
SI	System Integrity
SJ	Sinusoidal Jitter
SKP	Skip
SRIS	Separate Reference Clocks with Independent SSC
SRNS	Separate Reference Clocks with No SSC
TS	Training Sequence

Table 1.5-1 Abbreviation (Cont'd)

Abbreviation	Full Term
UI	Unit Interval
USB	Universal Serial Bus

Chapter 2 Before Use

This chapter describes preparation required before using MX183000A.

2.1	Unpacking	2-2
2.2	Operating Environment.....	2-2
2.3	Installation/Uninstallation	2-3
2.3.1	Installing	2-3
2.3.2	Uninstallation	2-10
2.4	License Key Activation.....	2-11
2.4.1	Purchasing license	2-11
2.4.2	Activating license.....	2-12
2.4.3	Transferring license	2-13
2.4.4	Precautions When Recovering MP1900A	2-15

2.1 Unpacking

At unpacking, refer to the standard configuration list shown in Table A-1 “Configuration”. Contact your Anritsu Service and Sales Office or an agent if any part is missing or damaged.

2.2 Operating Environment

As for the operating environment of a control personal computer (hereinafter “PC”), refer to Table A-2 “Operation Environment”.

MX183000A can be run on a control PC as well as on the MP1800A or MP1900A (hereinafter “SQA”). When you install MX183000A on SQA, use the mouse to operate the software.



CAUTION

When either one of the following operations starts during the startup process of MX183000A, it might not work well.

- Running another application at the same time
- Closing the lid of a laptop PC
- Using Screen Saver
- Battery saving operation in a laptop PC

Refer to the PC operation manual to disable each feature.

2.3 Installation/Uninstallation

MX183000A can be used in two installation modes: installation on SQA and installation on a control PC.


This section describes how to install MX183000A when using SQA. When using SQA, use the NI-VISA Installer in the USB memory stick that contains MX183000A (see page vi “Before Using VISA For Those Who Use MP1800A and MP1900A”).

When using MT1810A, you need to obtain the NI-VISA Installer yourself.


2.3.1 Installing

1. Install NI-VISA on the SQA or the control PC on which the MX183000A is to be installed. If NI-VISA is already installed, skip steps 2 to 4 and proceed to step 5.
2. To install NI-VISA on the SQA, insert the USB memory stick into the SQA and copy the installation file to the built-in HDD. To install NI-VISA on the control PC, insert the USB memory stick into the control PC.
3. End all active applications. End Main application, and click the **Close (x)** on the Selector screen.
4. Execute visa462full.exe to start installation.
The file is stored in the following folder in the USB memory stick.
\\Software\\visa462full.exe
Install as instructed on the screen.
5. Set up NI-VISA. Click **Measurement & Automation Explorer** on the **Start** menu.

6. Right-click **Network Devices** and click **Create New VISA TCP/IP Resource....**




7. Select **Manual Entry or Raw Socket**, and then click **Next**.



8. Enter the appropriate values for SQA* in Hostname or IP address and Port Number, and then click **Next**.

*: The default values for SQA are IP:192.168.2.100 and Port:5001.



Create New VISA TCP/IP Resource...

Measurement & Automation Explorer

NATIONAL INSTRUMENTS

Enter the TCP/IP address of your VISA network resource in the form of xxx.xxx.xxx.xxx, the hostname of the device, or a computer@some.domain


Hostname or IP address
127.0.0.1

Port Number
5001

Validate

< Back Next > Finish Cancel

9. Confirm that the IP address and Port Number values entered in step 8 are shown for Resource Name, and then click **Finish**.



Create New VISA TCP/IP Resource...

Measurement & Automation Explorer

NATIONAL INSTRUMENTS

You can specify an alias for this device. An alias is a logical name for a device that makes it easier to identify your instrument.

Use aliases in your code when opening sessions to devices without specifying their full VISA resource strings.

You may assign or change the alias at a later time through the alias editor or by clicking on the device to rename it.

Type in the alias you want to assign to this device or leave the alias field blank to not assign an alias to this device.

Resource Name: TCPIP0::127.0.0.1::5001::SOCKET

Alias:

< Back Next > Finish Cancel


10. Install MX183000A. Run the following file on the PC or SQA on which NI-VISA is installed.

\Installer\MX183000A_VER_x_xx_xx.exe


"x_xx_xx" here corresponds to the software version.

If the software is already installed, a message dialog saying "Reinstall all program features installed by the previous setup." will appear when you attempt to install by overwriting. To continue with the installation, click **Yes**. (Skip steps 11 to 15 and proceed to step 16.)


11. Click **Install** on the following screen.




12. The installer is activated. Click **Next**.



13. Select **I accept the terms in the license agreement**, and then click **Next**.



14. Enter User Name and Organization and then click **Next**.




15. Select a setup type and click **Next**.


If **Custom** is selected, you can select the location where you want to install* MX183000A.

If **Complete** is selected, proceed to step 16.


*: The default installation location is C:\Anritsu\MX183000A\.



16. Click **Change** to select the installation location. Then click **Next**.




17. Click **Install**.




18. Make sure **Add a program to startup** is selected and click the **Next** button.

Note:

When the installer is Ver. 2.00.00, the following window is not displayed. Also, the application is not added to the Start menu. For how to start the application, refer to 4.1 “Start up and Exit”.



19. When the installation completes successfully, the following window appears. Click **Finish** to end installation.




2.3.2 Uninstallation

This section describes the procedure for uninstalling MX183000A. Do the following procedure in SQA or control PC.

1. Select **Control Panel** in the **Start** menu to open the Control Panel.
2. Click **Programs and Features** in the Control Panel.
3. Select MX183000A in the list box and click **Uninstall** to start uninstallation.

When the following dialog box appears, click **Yes**.



2.4 License Key Activation

The paid options for this software (options PL001, PL011, PL012, PL021, and PL022) are activated using a license key.


Even if the license is not activated, all the options are available for 30-day trial period from the first installation date.

A license is specific data of each SQA or PC. The license file saved in a USB memory stick can be used only for a specific SQA or PC. To transfer the license file, refer to 2.4.3 “Transferring license”.


2.4.1 Purchasing license

To purchase a license, the CPU ID of the SQA or PC on which you use this software is required. Perform the following steps to obtain a CPU ID.

1. Start the MX183000A on the SQA or PC for which the license is to be validated. Select **License** → **License Details**.



2. Click **Copy to Clipboard** on the License window to obtain a CPU ID.




3. Please provide the CPU ID and serial number of your SQA or PC to our sales representative.

When the license file is provided by Anritsu, save it to the following folder.
C:\anritsu\MX183000A


2.4.2 Activating license

Perform the following steps to activate the license.

1. Start up the MX183000A and select **License** → **License Details**.
2. Click **Activate Licenses** on the License window.



3. When inputting a license file is prompted, load the license file provided by Anritsu. When the activation is completed, the license is valid.



2.4.3 Transferring license


How to transfer the MX183000A to another SQA or PC is explained below. The transfer destination and source are both PCs in the example here.

Notes:


A file made after the license transfer is necessary to activate the license, so store the file with care.

After transferring the file, the license on the source PC becomes invalid and its functions are no longer usable.


1. Start up the MX183000A on the destination PC and select **License** → **License Details**.




2. Click **Copy to Clipboard** on the License window to obtain a CPU ID.



3. Paste the obtained CPU ID on a text editor file, etc. and save. Move the file to the source PC.
4. Start up the MX183000A on the source PC and select **License** → **License Details**.
5. Click **Transfer License**.



6. When inputting a CPU ID is prompted on the **Transfer License** window, paste the CPU ID obtained at Step 3.



7. Click the **Transfer License** button. Store the license file in an arbitrary place on the PC. Give an arbitrary name to the license file.
8. Transfer the saved license file to the destination PC. For how to activate the license on the destination PC, refer to 2.4.2 "Activating license".

2.4.4 Precautions When Recovering MP1900A

Note:

This software license key becomes invalid if a system recovery is performed on the MP1900A where the software is installed. For details on the system recovery, refer to 8.3 “System Recovery Function” in the *MP1900A Signal Quality Analyzer-R Operation Manual*.

Be sure to transfer the license on the MP1900A to a PC or another MP1900A according to the following procedure before performing the system recovery. If you perform the system recovery without transferring the license, contact an Anritsu Service and Sales office. Contact information can be found on the last page of the printed version of this manual, and is available in a separate file on the PDF version.

You do not need to transfer the license when using MX183000A V3.07.00 or later. Perform the system recovery according to 8.3 “System Recovery Function” in *MP1900A Signal Quality Analyzer-R Operation Manual*.

<Procedure>

1. Prepare a PC or another MP1900A for the license to be transferred.
2. Transfer the license to the prepared PC or MP1900A according to the procedure given in 2.4.3 “Transferring license”.
3. Perform a system recovery according to the procedure given in 8.3 “System Recovery Function” in the *MP1900A Signal Quality Analyzer-R Operation Manual*.
4. Retransfer the license stored on the PC (or MP1900A) to the MP1900A where the system recovery has been completed
5. On the MP1900A where the system recovery has been completed, activate the license again. For details of the procedure, refer to 2.4.2 “Activating license”.

Chapter 3 Connecting Equipment

This chapter describes the types of equipment to be controlled by MX183000A and connecting procedures.

3.1	Target Equipment	3-2
3.2	Jitter Tolerance Test Connection Procedure	3-8
3.3	PCIe Link Sequence/Training Connection Procedure	3-11
3.3.1	Connection Using MP1800A	3-11
3.3.2	Connection Using MP1900A	3-14
3.4	USB Link Sequence/Training Connection Procedure	3-20
3.4.1	Connection Using MP1800A	3-20
3.4.2	Connection Using MP1900A	3-23
3.5	PAM4 Control Connection Procedure	3-27
3.5.1	Connection for transmitting and receiving linear PAM4 signal	3-27
3.5.2	Connection for transmitting and receiving non-linear PAM4 signal	3-29
3.6	DUT Error Counts Import Connection Procedure	3-31

3.1 Target Equipment

Shown below are the models of equipment to be controlled by MX183000A and the number of equipment required for each connection. Equipment marked as “-” in the Quality column are not used. The number in parentheses is the quantity required for the measurement, and these components are standard accessories for the equipment to be controlled.

Note:

MP1800A and MT1810A do not support Link Training.

Table 3.1-1 Equipment configuration for each measurement type (when MP1800A is used)

Equipment Type	Model	Options	Necessary Quantity for Each Connection Type		
			Jitter Tolerance Test	PCIe Link Sequence	USB Link Sequence
Signal Quality Analyzer	MP1800A	x02, x07*2, x32	1	1	1
Synthesizer	MU181000A/B*1		—	—	1
		x01	1	1	—
Jitter Source	MU181500B		1	1	1
32G PPG	MU183020A		1	—	—
		x30/x31	—	1	1
32G ED	MU183040A/B		1	—	—
	MU183040B	x22	1*3	1	—
		x23		—	—
4 Tap Emphasis	MP1825B*1	x02	—	1	1
Vector signal generator	MG3710A*1	x02, x29, x36, x41, x42, x66, x71, x72	—	2	—
PCIe Measurement Component Set	J1722A		—	1	—
USB Measurement Component Set	J1721A		—	—	1

*1: Cannot be controlled directly from this software.

*2: Not required if controlling from an external PC.

*3: Selects the option x22 or x23.

Table 3.1-1 Equipment configuration for each measurement type (when MP1800A is used) (Cont'd)

Equipment Type	Model	Options	Necessary Quantity for Each Connection Type		
			Jitter Tolerance Test	PCIe Link Sequence	USB Link Sequence
USB3.1 Receiver Test Adapter	G0373A		—	—	1
BNC-SMA connector cable	J1508A		(2)*4	(2)*4	(2)*4
Coaxial Cable set	J1615A		—	(1)*4	—
Coaxial cable 0.3m	J1624A		(2)*4	(2)*4	(2)*4
GND connection cable	J1627A		(1)*4	(1)*4	—

*4: These components are standard accessories for the MP1800A, MT1810A, MP1825B, MU181500B, and MU181000A.

Table 3.1-2 Equipment configuration for each measurement type (when MT1810A is used)

Equipment Type	Model	Options	Necessary Quantity for Each Connection Type		
			Jitter Tolerance Test	PCIe Link Sequence	USB Link Sequence
4Slot Chassis	MT1810A	x02, x32	2	2	1
Synthesizer	MU181000A/B* ¹		—	—	1
		x01	1	1	—
Jitter Source	MU181500B		1	1	1
32G PPG	MU183020A		1	—	—
		x30/x31	—	1	1
32G ED	MU183040A/B		1	—	—
	MU183040B	x22	1* ²	1	—
		x23		—	—
4TapEmphasis	MP1825B* ¹	x02	—	1	1
Vector signal generator	MG3710A* ¹	x02, x29, x36, x41, x42, x66, x71, x72	—	2	—
PCIe Measurement Component Set	J1722A		—	1* ³	—
USB Measurement Component Set	J1721A		—	—	1

*1: Cannot be controlled directly from this software.

*2: Selects the option x22 or x23.

*3: Refer to CAUTION described in Section 3.3 “PCIe Link Sequence/Training Connection Procedure” for handling the SMP connector.

Table 3.1-2 Equipment configuration for each measurement type (when MT1810A is used)
(Cont'd)

Equipment Type	Model	Options	Necessary Quantity for Each Connection Type		
			Jitter Tolerance Test	PCIe Link Sequence	USB Link Sequence
USB3.1 Receiver Test Adapter	G0373A		—	—	1
BNC-SMA connector cable	J1508A		(2)*4	(2)*4	(2)*4
Coaxial Cable set	J1615A		—	(1)*4	—
Coaxial cable 0.3m	J1624A		(2)*4	(2)*4	(2)*4
GND connection cable	J1627A		(1)*4	(1)*4	—

*4: These components are standard accessories for the MP1800A, M1810A, MP1825B, MU181500B, and MU181000A.

Table 3.1-3 Equipment configuration for each measurement type (when MP1900A is used)

Equipment Type	Model	Options	Necessary Quantity for Each Connection Type				
			Jitter Tolerance Test	PCIe Link Sequence	PCIe Link Training	USB Link Training	DUT Error Counts Import
Signal Quality Analyzer-R	MP1900A		1	1	1	1	1*6
Synthesizer	MU181000A/B*1		—	—	—	—	—
		x01	1	1	—	1	1*6
	MU181000B	x01, x02	—	—	1	—	—
Jitter Modulation Source	MU181500B		1	1	1	1	1*6
21G/32G bit/s SI PPG	MU195020A		1	—	—	—	1*6
		x11/x21, x30/x31	—	1	1	1	—
21G/32G bit/s SI ED	MU195040A	x22	1	1	1	1	—
Noise Generator	MU195050A		(1)*5	1	1	(1)*5	(1)*6
PAM4 PPG	MU196020A		1	—	—	—	1*6
PAM4 ED	MU196040A/B		1	—	—	—	—
PCIe Measurement Component Set	J1722A		—	1*3	—	—	—
BNC-SMA connector cable	J1508A		(2)*2	(2)*2	(2)*2	(2)*2	—
Coaxial skew match cable (0.8 m, K connector)	J1551A		—	—	4	2	—
Coaxial cable (Noise-SIPPG)	J1746A		—	(1)*2	(1)*2	(1)*2	(1)*6
Coaxial cable 0.3 m	J1624A		(2)*2	(2)*2	1 + (2)*2	2 + (2)*2	—
Coaxial cable 1 m	J1625A		—	—	3	—	—
Pick Off Tee	J1510A		—	—	4	(2)*4	—
Adaptor SMP(J)-SMA(J)	J1760A		—	—	6	—	—
PCIe Reference Clock Cable kit	J1761A		—	—	1	—	—
Precision DC Block	K261		—	—	2	—	—
GND connection cable	J1627A		(1)*2	(1)*2	(1)*2	(1)*2	—

*1: Cannot be controlled directly from this software.

*2: These components are standard accessories for the MP1900A, MU181500B, and MU181000A.

*3: Refer to CAUTION described in Section 3.3 “PCIe Link Sequence/Training Connection Procedure” for handling the SMP connector.

*4: Necessary for the USB Link Training connection system when using Pick Off Tee.

- *5: Necessary for the USB Link Training connection system when using Noise Generator.
- *6: The equipment configuration for DUT Error Counts Import indicates the transmitting devices for error or alarm measurement or Jitter Tolerance Test.

Table 3.1-4 J1722A PCIe Measurement Component Set Configuration

Model	Name	Quantity
J1398A	N-SMA ADAPTOR	4
41KC-3	Fixed Attenuator 3 dB	2
41KC-6	Fixed Attenuator 6 dB	2
41KC-20	Fixed Attenuator 20 dB	2
K241C	Power Splitter	2
J1510A	Pick Off Tee	2
J1551A	Coaxial skew match cable (0.8 m, K connector)	2
J1625A	Coaxial Cable 1 m (SMA connector)	6
J1715A	Coaxial skew match cable (0.1 m, SMP-J, SMA-J)	4
K261	DC Block	2

Table 3.1-5 J1721A USB Measurement Component Set Configuration

Model	Name	Quantity
J1510A	Pick Off Tee	2
J1551A	Coaxial skew match cable (0.8 m, K connector)	2
J1625A	Coaxial Cable 1 m (SMA connector)	3
J1624A	Coaxial Cable 0.3 m (SMA connector)	2

3.2 Jitter Tolerance Test Connection Procedure




Figure 3.2-1 Jitter Tolerance Test Connection Procedure






Figure 3.2-2 Jitter Tolerance Test Connection Procedure (Using Clock Recovery)

1. When MX183000A is installed on a control PC, connect the control PC to MP1800A with an Ethernet cable.
When MX183000A is installed on MP1800A, Ethernet cable connection is not required.
MP1800A requires the MP1800A-x02 LAN.
2. Set up as follows using the **Remote Control** tab on Setup Utility.
Activate Interface: Ethernet
Performance: Enhanced
3. Mount MU181000A/B and MU181500B in MP1800A.
4. Mount MU183020A in Slot 3 of MP1800A.
5. Mount MU183040A/B in Slot 4 of MP1800A.
6. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of MU181500B and the Ext. Clock Input connector of MU183020A using a coaxial cable.
9. If using Clock Recovery, proceed to Step 10. Use a coaxial cable to connect the Clock Output connector of the MU183020A and the Ext Clock Input connector of the MU183040A/B.
10. Connect the Data Output, $\overline{\text{Data}}$ Output connectors of MU183020A to the Data Input, $\overline{\text{Data}}$ Input connectors of a device under test with four coaxial cables.
11. Use coaxial cables to connect the Data Output and $\overline{\text{Data}}$ Output connectors of the DUT and the Data Input and $\overline{\text{Data}}$ Input connectors of the MU183040A/B.
12. Select MU181000A/B for Synthesizer Clock Source for the MU181500B.

 3.3 “Input Signal Settings” in the *MU181500B Jitter Modulation Source Operation Manual*

13. Select MU181500B in Clock Setting of the **Misc2** tab of MU183020A.

 5.6 “Misc2 Function” in the *MU183020A 28G/32G PPG MU183021A 28G/32G 4ch PPG Operation Manual*

3.3 PCIe Link Sequence/Training Connection Procedure

3.3.1 Connection Using MP1800A






Figure 3.3.1-1 PCIe Link Sequence Connection Using MP1800A

1. When MX183000A is installed on a control PC, connect the control PC to MP1800A with an Ethernet cable. Or connect the MP1800A to the MP1825B with a USB cable.
When MX183000A is installed on MP1800A, Ethernet cable connection is not required.
MP1800A requires the MP1800A-x02 LAN.
2. Set up as follows using the **Remote Control** tab on Setup Utility.
Performance: Enhanced
3. Mount MU181000A/B and MU181500B in MP1800A.
4. Mount MU183020A in Slot 3 of MP1800A.
5. Mount MU183040B in Slot 4 of MP1800A.
6. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock Input connector of the MU183020A using a coaxial cable.
9. Use coaxial cables to connect the Sub-rate Clock Output and XClock Output of the MU181500B to the DUT REFCLK and INJ connectors.
10. Use a 1.3 m coaxial cable (J1611A) to connect the Clock Output connector of the MU183020A and the Ext Clock Input connector of the MP1825B.
11. Use a 0.8 m coaxial cable (J1612A) to connect the Data Output connector of the MU183020A and the Data Input connector of the MP1825B.
12. Connect MG3710A to 41KC-3, 41KC-6, 41KC-20, K241C and J1510A as shown in Figure 3.3.1-1. The MG3710A output is the RF Output connector.
13. Set the MG3710A IP address, and connect to the PC.
14. Connect the J1510A to the MP1825B Data Output and $\overline{\text{Data}}$ Output connector.
15. Use a 0.8 m coaxial cable (J1551A) to connect the J1510A and the Compliance Base Board input (Rx In). (2 connections) Do not mount the Add-in Card at this stage.
16. Use a GND connector cable (J1627A) to connect the DUT GND and MP1825B GND jacks.


17. Select MU181000A/B for Clock Source for the MU181500B.

 3.3 “Input Signal Settings” in the *MU181500B Jitter Modulation Source Operation Manual*


18. Select MU181500B in Clock Setting of the **Misc2** tab of MU183020A.

 5.6 “Misc2 Function” in the *MU183020A 28G/32G PPG MU183021A 28G/32G 4ch PPG Operation Manual*


19. On the **Misc2** tab of MU183020A, select **Full Rate** in the Output Clock Rate box.

 5.6 “Misc2 Function” in the *MU183020A 28G/32G PPG MU183021A 28G/32G 4ch PPG Operation Manual*

20. Select the PPG connected for MP1825B Data Input.

 3.3 “Input Signal Settings” in the *MP1825B 4Tap Emphasis Operation Manual*

21. Select **Full Rate** for MP1825B Clock Input.

 3.3 “Input Signal Settings” in the *MP1825B 4Tap Emphasis Operation Manual*

22. Connect the Compliance Base Board output (Tx Out) to a real-time oscilloscope, and calibrate the Eye Pattern (amplitude, Jitter, and Emphasis settings).

23. Once Eye Pattern calibration is complete, connect the Compliance Base Board output (Tx Out) to the MU183040B Data Input and Data Input connector with a 0.8 m coaxial cable (J1551A).

24. Select Recovery Clock from Clock Setup Selection in the MU183040B **Input** tab.

 5.4 “Input Signal Settings” in the *MU183040A/MU183041A/MU183040B/MU183041B Operation Manual*



CAUTION

The SMP connector can withstand 100 insertion/removal cycles. Do not exceed this limit when you need to insert and remove the connector repeatedly. Exceeding the limit may cause performance deterioration by contact failure or connector damage.

3.3.2 Connection Using MP1900A

3.3.2.1 Connection to test Add-in card




Figure 3.3.2.1-1 PCIe Link Sequence/Training (Add-in Card) Connection Using MP1900A

1. When MX183000A is installed on Control PC, connect it to the Ethernet External Port of MP1900A with an Ethernet cable. When MX183000A is installed on MP1900A, Ethernet cable connection is not required.
2. Mount MU181000A/B in Slot 1 and 2, MU181500B in slot 3 and 4 of MP1900A.
3. Mount MU195040A in Slot 6 of MP1900A.
4. Mount MU195020A in Slot 7 of MP1900A.
5. Mount MU195050A into Slot 8 of MP1900A.
6. Connect the Clock Output connector of MU181000A/B and the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock Input connector of the MU195020A using a coaxial cable.
9. Use coaxial cables to connect the Sub-rate Clock Output and XClock Output of the MU181500B to the DUT REFCLK and INJ connectors.
10. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195020A to the Data Input and $\overline{\text{Data}}$ Input connectors of MU195050A with coaxial cables (J1746A) respectively.
11. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195050A to two input connectors (Rx In) of the Compliance Base Board with 0.8 m coaxial cables (J1551A). Do not install the Add-in Card yet.
12. Use a GND connector cable (J1627A) to connect the DUT GND and MP1900A GND jacks.
13. Start Standard Bert Application of MX190000A.



4.1 "Standard Bert Application" in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

14. Connect the Compliance Base Board output (Tx Out) to a real-time oscilloscope, and calibrate the Eye Pattern (amplitude, Jitter, and Emphasis settings).
15. Once Eye Pattern calibration is complete, connect the Compliance Base Board output (Tx Out) to the MU195040A Data Input and $\overline{\text{Data}}$ Input connector with a 0.8 m coaxial cable (J1551A).



CAUTION

The SMP connector can withstand 100 insertion/removal cycles. Do not exceed this limit when you need to insert and remove the connector repeatedly. Exceeding the limit may cause performance deterioration by contact failure or connector damage.

3.3.2.2 Connection to test System Board




Figure 3.3.2.2-1 PCIe Link Sequence/Training (System Board) Connection Using MP1900A

1. When MX183000A is installed on Control PC, connect it to the Ethernet External Port of MP1900A with an Ethernet cable. When MX183000A is installed on MP1900A, Ethernet cable connection is not required.

2. Mount MU181000A/B in Slot 1 and 2, MU181500B in slot 3 and 4 of MP1900A.
3. Mount MU195040A in Slot 6 of MP1900A.
4. Mount MU195020A in Slot 7 of MP1900A.
5. Mount MU195050A into Slot 8 of MP1900A.
6. Connect the Clock Output connector of MU181000A/B and the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock Input connector of the MU195020A using a coaxial cable.
9. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195020A to the Data Input and $\overline{\text{Data}}$ Input connectors of MU195050A with coaxial cables (J1746A) respectively.
10. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195050A to two input connectors (Rx In) of the Compliance Base Board with 0.8 m coaxial cables (J1551A).
11. At PCIe Link Training, connect the 100 MHz Ref Input connector of MU181000B and the Ref Clk connector on Compliance Load Board using the PCIe Reference Clock Cable kit (J1761A).
12. Use a GND connector cable (J1627A) to connect the System Board GND and MP1900A GND jacks.
13. Start Standard Bert Application of MX190000A.



4.1 “Standard Bert Application” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

14. Connect the Compliance Base Board output (Tx Out) to a real-time oscilloscope, and calibrate the Eye Pattern (amplitude, Jitter, and Emphasis settings).
15. Once Eye Pattern calibration is complete, connect the Compliance Base Board output (Tx Out) to the MU195040A Data Input and $\overline{\text{Data}}$ Input connector with a 0.8 m coaxial cable (J1551A).

Note:

The System Board (Root Complex) can be tested only in Separate Refclock.

Refer to the description of DUT in Table 4.8.2-1 “PCIe Link Training Setting Items”.



CAUTION

The SMP connector can withstand 100 insertion/removal cycles. Do not exceed this limit when you need to insert and remove the connector repeatedly. Exceeding the limit may cause performance deterioration by contact failure or connector damage.

3.4 USB Link Sequence/Training Connection Procedure

3.4.1 Connection Using MP1800A









Figure 3.4.1-1 USB Link Sequence Connection Using MP1800A

1. When MX183000A is installed on a control PC, connect the control PC to MP1800A with an Ethernet cable. Or connect the MP1800A to the MP1825B with a USB cable.
When MX183000A is installed on MP1800A, Ethernet cable connection is not required.
MP1800A requires the MP1800A-x02 LAN.
2. Set up as follows using the **Remote Control** tab on Setup Utility.
Activate Interface: Ethernet
Performance: Enhanced
3. Mount MU181000A/B and MU181500B in MP1800A.
4. Mount MU183020A in Slot 3 of MP1800A.
5. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
6. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock Input connector of the MU183020A using a coaxial cable.
7. Use a 1.3 m coaxial cable (J1611A) to connect the Clock Output connector of the MU183020A and the Ext Clock Input connector of the MP1825B.
8. Use a 0.8 m coaxial cable (J1612A) to connect the Data Output connector of the MU183020A and the Data Input connector of the MP1825B.
9. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of the MP1825B and the Pick Off Tee (J1510A) (2 connections).
10. Connect the J1510A and the LFPS TX Output connector of the USB3.1 Receiver Test Adapter with a 0.3 m coaxial cable (J1624A) as in Figure 3.4.1-1 (2 connections).
11. Connect the J1510A and Test Fixture with 0.8 m coaxial cable (J1612A) as in Figure 3.4.1-1 (2 connections).
12. Use a GND connector cable (J1627A) to connect the DUT GND and MP1825B GND jacks.
13. Use a cable supplied with the USB3.1 Receiver Test Adapter to connect the USB3.1 Receiver Test Adapter GND and MP1825B GND jacks.
14. Use a 1 m coaxial cable (J1625A) to connect the AUX Output connector of the MU183020A and the AUX Input connector of the USB3.1 Receiver Test Adapter.
15. Use a 1 m coaxial cable (J1625A) to connect the Gating Output connector of the MU183020A and the Gating Input connector of the USB3.1 Receiver Test Adapter.

16. Use a 1 m coaxial cable (J1625A) to connect the AUX Input connector of the MU183020A and the LFPS RX Output connector of the USB3.1 Receiver Test Adapter.
17. Use a 0.8 m coaxial cable (J1551A) to connect the LFPS RX Input connector of the USB3.1 Receiver Test Adapter and the USB3.1 Receiver Test Adapter (2 connections).
18. Select MU181000A/B for Clock Source for the MU181500B.
 3.3 “Input Signal Settings” in the *MU181500B Jitter Modulation Source Operation Manual*
19. Select MU181500B in Clock Setting of the **Misc2** tab of MU183020A.
 5.6 “Misc2 Function” in the *MU183020A 28G/32G PPG MU183021A 28G/32G 4ch PPG Operation Manual*
20. On the **Misc2** tab of MU183020A, select **Full Rate** in the Output Clock Rate box.
 5.6 “Misc2 Function” in the *MU183020A 28G/32G PPG MU183021A 28G/32G 4ch PPG Operation Manual*
21. Select the PPG connected for MP1825B Data Input.
 3.3 “Input Signal Settings” in the *MP1825B 4Tap Emphasis Operation Manual*
22. Select **Full Rate** for MP1825B Clock Input.
 3.3 “Input Signal Settings” in the *MP1825B 4Tap Emphasis Operation Manual*

3.4.2 Connection Using MP1900A

3.4.2.1 Connection using Pick Off Tee






Figure 3.4.2.1-1 USB Link Training Connection Using MP1900A (Pick Off Tee)

1. When MX183000A is installed on a control PC, connect the control PC to MP1900A with an Ethernet cable.
When MX183000A is installed on MP1900A, Ethernet cable connection is not required.
2. Mount MU181000A/B in Slot 1 and 2, MU181500B in Slot 3 and 4 of MP1900A.
3. Mount MU195040A in Slot 6 of MP1900A.
4. Mount MU195020A in Slot 7 of MP1900A.
5. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
6. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
7. Connect the Jittered Clock Output connector of MU181500B and the Ext. Clock Input connector of MU195020A using a coaxial cable.
8. Connect MU195020A Data Output and $\overline{\text{Data}}$ Output connectors and Pick Off Tee (J1510A).
9. Connect MU195020A Gating Out and $\overline{\text{Gating}}$ Output connectors to Pick Off Tee (J1510A) with the 0.3 m coaxial cable (J1624A).
10. Connect DUT GND to MP1900A GND jack with GND connection cable (J1627A).
11. Connect the output connectors of Pick Off Tees (J1510A) to the Test Fixture with 0.8 m coaxial cables (J1551A). (2 connections).
12. Connect the Test Fixture to MU195040A Data Input and $\overline{\text{Data}}$ Input connectors with 0.8 m coaxial cable (J1551A).
13. Launch MX190000A Standard Bert Application.

 4.1 “Standard Bert Application” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*


3.4.2.2 Connection using MU195050A



3
Connecting Equipment

Figure 3.4.2.2-1 USB Link Training Connection Using MP1900A (MU195050A)

1. When MX183000A is installed on a control PC, connect the control PC to MP1900A with an Ethernet cable.
When MX183000A is installed on MP1900A, Ethernet cable connection is not required.
2. Mount MU181000A/B in Slot 1 and 2, MU181500B in slot 3 and 4 of MP1900A.
3. Mount MU195040A in Slot 6 of MP1900A.
4. Mount MU195020A in Slot 7 of MP1900A.
5. Mount MU195050A in Slot 8 of MP1900A.
6. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of MU181500B and the Ext. Clock Input connector of MU195020A using a coaxial cable.
9. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195020A to the Data Input1 and $\overline{\text{Data}}$ Input1 connectors of MU195050A respectively.
10. Connect the External Input and $\overline{\text{External}}$ Input connectors of MU195050A to the Gating Out and $\overline{\text{Gating}}$ Output connectors respectively with 0.3m coaxial cables (J1624A).
11. Connect DUT GND to MP1900A GND jack with GND connection cable (J1627A).
12. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195050A to the test fixture with 0.8 m coaxial cables (J1551A) at two places.
13. Connect the Test Fixture to MU195040A Data Input and $\overline{\text{Data}}$ Input connectors with 0.8 m coaxial cable (J1551A).
14. Launch MX190000A Standard Bert Application.

 4.1 “Standard Bert Application” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

3.5 PAM4 Control Connection Procedure

3.5.1 Connection for transmitting and receiving linear PAM4 signal




Figure 3.5.1-1 Cable Connection for Linear PAM4 Signal

1. When MX183000A is installed on a control PC, connect the control PC to MP1900A with an Ethernet cable. Connect the Ethernet cable to the External port on the MP1900A rear panel. When MX183000A is installed on MP1900A, the Ethernet cable connection is not required.

2. Mount MU181000A/B in Slot 1 and 2, MU181500B in Slot 3 and 4, MU195040A in Slot 7, and MU195050A in Slot 8 of MP1900A.
3. Connect G0375A and G0376A to MP1900A with USB cables. To control MX183000A by an external PC, connect G0375A and G0376A to the control PC with USB cables.
4. Connect the Clock Output connector of MU181000A/B and the Ext Clock Input connector of MU181500B with a coaxial cable.
5. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock In connector of the MU195020A using a coaxial cable.
6. Connect the Data1 Output, $\overline{\text{Data1}}$ Output, Data2 Output, and $\overline{\text{Data2}}$ Output connectors of MU195020A to the Data Input1, $\overline{\text{Data}}$ Input1, Data Input2, and $\overline{\text{Data}}$ Input2 connectors of MU195050A respectively with coaxial adapters (J1717A).
7. Connect the Data Output1, $\overline{\text{Data}}$ Output1, Data Output2, $\overline{\text{Data}}$ Output2 connectors of MU195050A to the Data Input1, $\overline{\text{Data}}$ Input1, Data Input2, and $\overline{\text{Data}}$ Input2 connectors of G0375A respectively with coaxial cables (J1741A).
8. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of G0375A to the DUT with coaxial cables.
9. Connect the DUT signal to the CTLE Data Input and CTLE $\overline{\text{Data}}$ Input connectors of G0376A. If CTLE is not used, connect the DUT signal directly to the Decoder Data Input and Decoder $\overline{\text{Data}}$ Input connectors with coaxial cables. Then go to Step 11.
10. Connect the CTLE Data Output and CTLE $\overline{\text{Data}}$ Output connectors to the Decoder Data input and Decoder $\overline{\text{Data}}$ Input connectors with U Link cables.
11. Connect the Decoder Data Output1 and Decoder Data Output2 connectors of G0376A to the Data1 Input and Data2 Input connectors of MU195040A with coaxial cables (J1728A).
12. Connect the Clock Input connector of G0376A and the Clock Output connector of MU195020A with a coaxial cable.
13. Connect the DUT GND and the GND jack of G0375A or G0376A with a GND connection cable (J1627A).
14. Select MU181000A/B for Clock Source for the MU181500B.
15. In the clock setting on the **Misc2** tab of MU195020A, select MU181500B for Clock Source. Specify a bit rate for the measurement.

3.5.2 Connection for transmitting and receiving non-linear PAM4 signal





Figure 3.5.2-1 Cable Connection for Transmitting and Receiving Non-linear PAM4 Signal

1. When MX183000A is installed on a control PC, connect the control PC to MP1900A with an Ethernet cable. Connect the Ethernet cable to the External port. When MX183000A is installed on MP1900A, the Ethernet cable connection is not required.

2. Mount MU195020A in Slot 1 and 2, MU181500B and MU181000A/B into empty slots of MP1900A.
3. Connect G0375A and G0376A to MP1900A with a USB cable. To control MX183000A by an external PC, connect G0375A and G0376A to the control PC with USB cables.
4. Connect the Clock Output connector of MU181000A/B and the Ext Clock Input connector of MU181500B with a coaxial cable.
5. Connect the Jittered Clock Output connector of the MU181500B and the Ext. Clock In connector of the MU195020A using a coaxial cable. Use the cables of equal length for connecting two units of MU195020A.
6. Connect the Data1 Output, $\overline{\text{Data1}}$ Output connectors of MU195020A to the Data Input1, $\overline{\text{Data1}}$ Input1 connectors with coaxial cables (J1742A).
7. Connect J1735A Combiners to the Data Input2 and $\overline{\text{Data1}}$ Input2 connectors of G0375A respectively.
8. Connect the Data2 Output and $\overline{\text{Data2}}$ Output connectors of MU195020A in Slot 1, the Data1 Output and $\overline{\text{Data1}}$ Output connectors of MU195020A in Slot 2, and J1735As respectively with coaxial cables (J1741A).
9. Connect the Data Output and $\overline{\text{Data1}}$ Output connectors of G0375A to DUT with coaxial cables.
10. Connect the DUT signal to the Decoder Data Input and Decoder $\overline{\text{Data1}}$ Input connectors with coaxial cables.
11. Connect the Decoder Data Output1 and Decoder Data Output2 connectors of G0376A to the Data1 Input and Data2 Input connectors of MU195040A with coaxial cables (J1728A).
12. Connect the Clock Input connector of G0376A and the Clock Output connector of MU195020A with a coaxial cable.
13. Connect the DUT GND and the GND jack of G0375A or G0376A with a GND connection cable (J1627A).
14. Select MU181000A/B for Clock Source for the MU181500B.
15. In the clock setting on the **Misc2** tab of MU195020A, select MU181500B for Clock Source. Specify a bit rate for the measurement.
16. Select Combination Setting from the MX190000A menu and select Synchronization and 2ch Combination for Inter module combination.
17. Perform multi-channel calibration, following the on-screen instructions.

3.6 DUT Error Counts Import Connection Procedure



3

Connecting Equipment

Figure 3.6-1 DUT Error Counts Import Connection Using MP1900A (with SI PPG installed)

Note:

To communicate with DUT, configure the control PC or MP1900A in advance for Ethernet connection, USB driver and other settings.

1. When MX183000A is installed on a control PC, connect the control PC to MP1900A with an Ethernet cable.
When MX183000A is installed on MP1900A, Ethernet cable connection is not required.
2. Mount MU181000A/B in Slot 1 and 2, MU181500B in Slot 3 and 4 of MP1900A.
3. Mount MU195040A in Slot 6 of MP1900A.
4. Mount MU195020A in Slot 7 of MP1900A.
5. Mount MU195050A in Slot 8 of MP1900A.
6. Connect the Clock Output connector of MU181000A/B to the Ext Clock Input connector of MU181500B with a coaxial cable.
7. Use BNC-SMA cables (J1508A) to connect the Ext.I, Q connector of the MU181000A/B and the I, Q Output connector of the MU181500B. (2 connections)
8. Connect the Jittered Clock Output connector of MU181500B and the Ext. Clock Input connector of MU195020A using a coaxial cable.
9. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195020A to the Data Input1 and $\overline{\text{Data}}$ Input1 connectors of MU195050A respectively.
10. Connect the External Input and $\overline{\text{External}}$ Input connectors of MU195050A to the Gating Out and $\overline{\text{Gating}}$ Output connectors of MU195020A respectively with 0.3 m coaxial cables (J1624A).
11. Connect DUT GND to MP1900A GND jack with GND connection cable (J1627A).
12. Connect the Data Output and $\overline{\text{Data}}$ Output connectors of MU195050A to DUT with 0.8 m coaxial cables (J1551A).
13. Connect DUT to the control PC or MP1900A with an Ethernet cable or a USB cable.
14. Launch MX190000A Expert Bert Application.

 4.2 “Expert Bert Application” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

Chapter 4 Operation

This chapter describes the methods for measurement and the procedures for screen operation.

4.1	Start up and Exit	4-3
4.1.1	When using on MP1800A.....	4-3
4.1.2	When using on MP1900A.....	4-4
4.1.3	When using on an external PC.....	4-6
4.2	Setup Procedure and Editing Values.....	4-7
4.2.1	Setup procedure	4-7
4.2.2	Editing values	4-8
4.3	Measurement System Configuration	4-11
4.3.1	Selecting Application	4-11
4.3.2	Connecting Measurement Equipment.....	4-13
4.3.3	Entering Compliance Test Mode	4-18
4.3.4	RF Setting of MX180000A and MX190000A..	4-19
4.4	PCIe Link Sequence	4-21
4.4.1	PCIe Link Sequence Setup Screen.....	4-21
4.4.2	PCIe Link Sequence Setup	4-23
4.4.3	PCIe Link Sequence Start.....	4-28
4.4.4	Setting Up PCIe BER Measurement	4-29
4.4.5	Starting PCIe BER Measurement.....	4-31
4.5	USB Link Sequence.....	4-32
4.5.1	USB Link Sequence Setup Screen	4-32
4.5.2	USB Link Sequence Setup.....	4-34
4.5.3	USB Link Sequence Start.....	4-38
4.5.4	USB BER Measurement Setup	4-39
4.5.5	USB BER Measurement Start	4-41
4.6	Jitter Tolerance Test	4-42
4.6.1	Jitter Tolerance Test Setup Screen.....	4-42
4.6.2	Jitter Tolerance Measurement Sequence Setup	4-43
4.6.3	Jitter Tolerance Table Setup	4-49
4.6.4	Setting up the Mask data.....	4-52
4.6.5	Jitter Tolerance Measurement Start	4-52
4.6.6	Jitter Tolerance Test Result	4-53
4.6.7	Saving the graph and setting up the scale	4-57
4.6.8	File Operation and Printing.....	4-58
4.7	Jitter Tolerance Test Procedure	4-60
4.7.1	Measurement Sequence	4-60
4.7.2	Measurement time.....	4-63
4.7.3	Jitter Tolerance Estimate.....	4-64
4.8	PCIe Link Training	4-68
4.8.1	PCIe Link Training Setup Screen	4-68
4.8.2	PCIe Link Training Setup	4-69

4.8.3	Starting PCIe Link Training	4-84
4.8.4	Displaying PCIe Link Training Results	4-85
4.8.5	Displaying LTSSM Log of PCIe Link Training	4-87
4.8.6	Executing PCIe Link Training Link Equalization Test	4-89
4.8.7	Configuring BER Measurement Settings for PCIe Link Training	4-97
4.8.8	PCIe Link Training Matrix Scan	4-100
4.9	PAM4 Control	4-103
4.9.1	Selecting Equipment to Use	4-103
4.9.2	PAM4 Transmitter Setup Screen	4-105
4.9.3	Setting Ratio for PAM4 Transmission Waveform Amplitude	4-107
4.9.4	PAM4 Receiver Setup Screen	4-109
4.9.5	BER measurement using PAM4 Control	4-112
4.10	USB Link Training	4-114
4.10.1	USB Link Training Setup Screen	4-114
4.10.2	USB Link Training Setup	4-115
4.10.3	Starting USB Link Training	4-118
4.10.4	Displaying USB Link Training Results	4-119
4.10.5	Displaying LTSSM Log of USB Link Training	4-120
4.11	DUT Error Counts Import	4-121
4.11.1	DUT Control tab	4-121
4.11.2	Measurement tab	4-122
4.11.3	Operating MX190000A	4-124
4.11.4	Measuring Jitter Tolerance	4-126
4.11.5	Log Viewer function	4-128

4.1 Start up and Exit

This section explains the startup and exit procedures for cases where MX183000A is installed on SQA and cases where it is installed on an external PC.

4.1.1 When using on MP1800A

MX183000A is launched automatically when the MP1800A is started. The following procedures describe how to start up for the first time after installing or after closing the software.

Startup procedure

- (1) Click the **Auto Measurement** on the tool bar of the MX180000A Signal Quality Analyzer Control Software (hereafter, MX180000A). The Auto Measurement Select screen appears.



Figure 4.1.1-1 Auto Measurement button

- (2) In the Auto Measurement Select screen, click **High Speed Serial Data Test Software**. MX183000A starts and displays the Main screen.





Figure 4.1.1-2 Auto Measurement Select screen

When **High-Speed Serial Data Test Software** is not displayed on the above screen, add this software by Auto Measurement Setup.

 5.4.2 “Customizing automatic measurement functions” in the *MX180000A Signal Quality Analyzer Control Software Operation Manual*


Exit procedure

- (1) Open the **File** menu and then click **Exit**.
- (2) In the Main screen, click the **Close** button to exit MX183000A.
- (3) Turn off the power of all instruments.


4.1.2 When using on MP1900A

Startup procedure


- (1) Start Standard Bert of the MX190000A Signal Quality Analyzer-R Control Software (hereinafter “MX190000A”) and display the Application Selector window.



- (2) At Utility, click the **MX183000A** icon. The MX183000A starts and the Main window is displayed.



- (3) Change the application to be shown on the display using the MX190000A taskbar.



Exit procedure

- (1) Open the **File** menu and then click **Exit**.
- (2) In the Main screen, click the **Close** to exit MX183000A.
- (3) Turn off the power of all instruments.

4.1.3 When using on an external PC

Startup procedure

Start MX183000A by clicking **Start, All programs, MX183000A**, and then **High Speed Serial Data Test Software** in this order.

If you have created a shortcut on your desk top, double-click the shortcut.
Start MX183000A to display the Main screen.

Exit procedure

- (1) Open the **File** menu and then click **Exit**.
- (2) In the Main screen, click the **Close** to exit MX183000A.
- (3) Turn off the power of all instruments.

4.2 Setup Procedure and Editing Values

4.2.1 Setup procedure

Figure 4.2.1-1 shows the basic setup procedure.




Figure 4.2.1-1 Setup procedure

4.2.2 Editing values

The numeric values of MX183000A can be set only by using a mouse with center wheel.

This function is available in Version 2.03.00 or later of MX183000A.




Figure 4.2.2-1 How to Operate Mouse

[1] Right click

Right click on the mouse button allows you to go to Value Edit mode. In Value Edit mode, numeric values can be edited by rotating the mouse wheel.

The upper and lower limits pop out on the screen while editing.




Figure 4.2.2-2 Value Edit Mode

[2] Clicking center wheel

Clicking the center wheel allows you to go to Digit Place mode. In Digit Place mode, a desired digit place can be selected by rotating the wheel.

Clicking the wheel in Digit Place mode allows you to go to Value Edit mode. The upper and lower limits pop out on the screen while editing.




Figure 4.2.2-3 Digit Place Mode

[3] Rotating center wheel upward

- In Value Edit mode
The number under the cursor is increased.




Figure 4.2.2-4 Number Increase

- In Digit Place mode
The cursor moves to the left.




Figure 4.2.2-5 Cursor Moving to the Left

[4] Rotating center wheel downward

- In Value Edit mode

The number under the cursor is decreased.




Figure 4.2.2-6 Number Decrease

- In Digit Place mode

The cursor moves to the right.




Figure 4.2.2-7 Cursor Moving to the Right

4.3 Measurement System Configuration

4.3.1 Selecting Application

On launching the software, the Selector screen is displayed. The Selector screen allows you to select the application for measurement.




Figure 4.3.1-1 Selector Screen

Table 4.3.1-1 Selector Screen

Item	Description
Application selection area	Selects the application for measurement. The applications available for selection will vary depending on the options installed. <ul style="list-style-type: none">• PCIe Link Sequence Refer to 4.4 “PCIe Link Sequence”.• USB Link Sequence Refer to 4.5 “USB Link Sequence”.• Jitter Tolerance Test Refer to 4.6 “Jitter Tolerance Test”.• PCIe Link Training Refer to 4.8 “PCIe Link Training”.• PAM4 Control Refer to 4.9 “PAM4 Control”.• USB Link Training Refer to 4.10 “USB Link Training”.• DUT Error Counts Import Refer to 4.11 “DUT Error Counts Import”.
Start	Displays the measurement screen for the corresponding application.
Close button	Exits the software.

The menu includes the following items.

Table 4.3.1-2 Menu Items

Menu	Description
File	
Exit	Exits the software.
Setup	
Remote	Displays the remote setup for the software and external PC.
License	
License Details	Displays the screen for adding license keys for the software.
Help	
About	Displays the version information and options.

4.3.2 Connecting Measurement Equipment

When the application is started, the Equipment Setup screen is displayed. The Equipment Setup screen allows you to set the connections to equipment, select connected equipment, and select the type of measurement.

1. Click **Connection Guide**. The measurement equipment connection diagram is displayed. Connect the measurement equipment, referring to the connection diagram and the details in Chapter 3.
2. Click **Search Start**. The software searches for equipment, and displays the equipment currently connected in the connected equipment display area.
3. Click **Connect** to connect the required equipment.

If the equipment connected has been changed, repeat the equipment search.





Figure 4.3.2-1 Equipment Setup Screen (Before Starting Search)

Jitter Tolerance Test can be executed in 2ch combination only when Jitter Tolerance Test Application is selected. Perform the following steps.

1. Set the equipment to 2ch combination.

 3.3 “Multi Channel Function” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

2. Select 2ch combination in the Connected Equipment Area.
3. Click the **Connect** button.

When connected, this button displays Disconnect.





Figure 4.3.2-2 Equipment Setup Screen (After Searching)

Note:

Do not disconnect the Ethernet cable connecting the SQA or MT1810A while equipment searching is in progress. The software cannot recognize equipment correctly if the cable is disconnected.

When selecting **PAM4 Control** on the Selector screen (Figure 4.3.1-1), the G0375A/G0376A selector screen is displayed. Perform the following steps.

1. Set the equipment to 2ch combination.

 3.3 “Multi Channel Function” in the *MX190000A Signal Quality Analyzer-R Control Software Operation Manual*

2. Select 2ch combination in the Connected Equipment Area.
3. Click the Disconnect button.

When **PCIe Link Training** or **USB Link Training** is selected on the Selector screen (Figure 4.3.1-1), the **Calibration** button is displayed under the ED box after the connection is completed.

The calibration sets an optimum value to Clock Delay of SI ED. Perform the calibration to complete Link Training successfully.

When the equipment configuration is changed or the software version is updated, perform the calibration as follows.




Figure 4.3.2-3 Equipment Setup Screen (After Connect)

1. Click the **Calibration** button.
2. As displayed in GUI, connect the Data Output / XData Output connectors of PPG or Noise module to Data Input / XData Input connectors of the ED using coaxial cables.
3. Click **OK** in the confirmation dialog box.
4. The calibration will be completed within two minutes.




Figure 4.3.2-4 Equipment Setup Screen (After PAM4 Control Search)

Note:

Do not disconnect the Ethernet cable connecting the SQA or MT1810A while equipment searching is in progress. The software cannot recognize equipment correctly if the cable is disconnected.




Figure 4.3.2-5 Equipment Setup Screen (After USB Link Training Search)

Note:

Do not disconnect the Ethernet cable connecting the SQA or MT1810A while equipment searching is in progress. The software cannot recognize equipment correctly if the cable is disconnected.

4.3.3 Entering Compliance Test Mode

When MX183000A is connected to the MX180000A, the 28G/32G PPG enters Compliance Test Mode and the screen is displayed as Figure 4.3.3-1.

The 28G/32G PPG is operating in Compliance Test Mode, so the normal test pattern cannot be sent.

Notes:

- **Return to normal BERT mode** appears as below while operating (Refer to Section 4.3.4 “RF Setting of MX180000A and MX190000A”), but do not click this button. If clicked, click **Disconnect** and click **Connect** of MX183000A. (Refer to 4.3.2 “Connecting Measurement Equipment”).
- If **Return to normal BERT mode** is displayed even after disconnecting this software from the MX180000A, click **Return to normal BERT mode** to return the 28G/32G PPG to normal mode.




Figure 4.3.3-1 28G/32G PPG Window (after connecting from MX183000A)

4.3.4 RF Setting of MX180000A and MX190000A

When MX183000A is connected to MX180000A, **Operate MP1800A/MP1900A** appears in the upper right of the screen shown in Figure 4.3.2-2. Click **Operate MP1800A/MP1900A** to display the **Operating** dialog box of Figure 4.3.4-1 below.




Figure 4.3.4-1 Operating dialog box

While the **Operating** dialog box is displayed, the settings of the MU181500B, MP1825B and MU195020A that are installed on the SQA can be edited.

For setting items, refer to Table 4.3.4-1.

Note:

While the Operating dialog box is displayed, do not use the functions or parameters other than the items listed in Table 4.3.4-1. Otherwise, MX183000A may not be operated properly. If you have used something other than the items listed in Table 4.3.4-1, click **Disconnect** and click **Connect** of MX183000A. (Refer to 4.3.2 “Connecting Measurement Equipment”.)


Click **Return to MX183000A** after Operating is completed.

Table 4.3.4-1 Setting Items for Operating

Module	Setting Items
MU181500B Jitter Modulation Source	SJ/SJ2
	SSC
	RJ
	BUJ
MP1825B 4Tap Emphasis	Cursor or coefficient values
	Eye Amplitude value
MU195020A 21G/32Gbit/s SI PPG	Eye Amplitude value
MU195040A 21G/32Gbit/s SI ED	Measurement start and BER checking


For details of settings, refer to the following:

 3.4 “Setting Jitter” in the *MU181500B Jitter Modulation Source Operation Manual*

 7.10.3 “Jitter Setting Commands” in the *MX180000A Signal Quality Analyzer Control Software Remote Control Operation Manual*

 3.1.3 “MP1825B Control Screens” in the *MP1825B 4Tap Emphasis Operation Manual*

5.5.2 “Waveform Settings” in the *MP1825B 4Tap Emphasis Operation Manual*

 Chapter 5 “Operation Method” in the *MU195020A21G/32G bit/s SI PPG MU195040A 21G/32G bit/s SI ED MU195050A Noise Generator Operation Manual*

4.4 PCIe Link Sequence

4.4.1 PCIe Link Sequence Setup Screen

On the **Sequence** tab, you can view the following PCIe Link Sequence settings. The references for each setup area are shown in the figure.




Figure 4.4.1-1 PCIe Link Sequence Setup Screen

The screen menu includes the following items. For details of items other than files, refer to “Table 4.3.1-2 Menu Items”, as these are the same as for the Selector screen.

Table 4.4.1-1 Menu Items

Menu	Description
File	
Load	Loads measurement parameters from a file.
Save	Saves the measurement parameters to a file.
Initialize	Initializes the parameters.
Exit	Exits the software. Measurement results are not saved.

The abbreviations used in PCIe Link Sequence are listed below.

EIEOS: Electrical Idle Exit Ordered Set
 FTS: Fast Training Sequence
 LTSSM: Link Training and Status State Machine
 TS: Training sequences

The LTSSM State area displays an overview of the LTSSM State. Clicking a state displays the corresponding LTSSM Sub State on the Sequence Editor screen.




Figure 4.4.1-2 PCIe Link Sequence Setup Screen (2)

Table 4.4.1-2 Sequence Editor Setup Items

Menu	Description
All Parameter	Returns from the Sequence Editor screen to the All Parameter display.
Default	Resets values entered in Sequence Editor to their default values.

4.4.2 PCIe Link Sequence Setup

This section describes how to set the PCIe link training sequence parameters, and test pattern for measurement.




Figure 4.4.2-1 PCIe Link Sequence Setup Screen (Rev 4.0 Configuration)

Clicking **Option** displays the individual PCIe setup screen shown in Figure 4.4.2-2.




Figure 4.4.2-2 PCIe Link Sequence Option Window (Rev 3.0/3.1)

The setting items on the Option window are common with PCIe 4.0.

Table 4.4.2-1 PCIe Link Sequence Setup Items

Item	Description															
Specification	Selects the PCIe specification from Rev1.0/1.1(2.5 GT/s), 2.0(5.0 GT/s), 3.0/3.1(8.0 GT/s), and 4.0(16.0 GT/s). If MU181000A/B is installed, set the 32G PPG Operation Bitrate to Rev1.x:2.5 Gbit/s, Rev2.0:5.0 Gbit/s, Rev3.x:8.0 Gbit/s, and Rev4.0:16 Gbit/s respectively. Altering this item changes the link training sequence displayed in Sequence Editor.															
Loopback through	Sets the sequence type for looping back DUT. Altering this item changes the link training sequence displayed in Sequence Editor. The following selections are available depending on the Specification Rev. setting. <table><tr><th>Revision</th><th>Configuration</th><th>Recovery</th></tr><tr><td>1.0/1.1(2.5 GT/s)</td><td>✓</td><td></td></tr><tr><td>2.0(5.0 GT/s)</td><td>✓</td><td>✓</td></tr><tr><td>3.0/3.1(8.0 GT/s)</td><td>✓</td><td>✓</td></tr><tr><td>4.0(16.0 GT/s)</td><td>✓</td><td>✓</td></tr></table>	Revision	Configuration	Recovery	1.0/1.1(2.5 GT/s)	✓		2.0(5.0 GT/s)	✓	✓	3.0/3.1(8.0 GT/s)	✓	✓	4.0(16.0 GT/s)	✓	✓
Revision	Configuration	Recovery														
1.0/1.1(2.5 GT/s)	✓															
2.0(5.0 GT/s)	✓	✓														
3.0/3.1(8.0 GT/s)	✓	✓														
4.0(16.0 GT/s)	✓	✓														
Test Pattern	Selects the test pattern output repeatedly from Compliance or PRBS after completing the link training sequence transmission. Selecting Compliance displays the PCIe standard test pattern selection controller, and selecting PRBS displays the PRBS level setting controller. The pattern is set automatically in accordance with 32G PPG/ED to suit the Compliance/PRBS setting.															
PRBS	Sets the number of the PRBS pattern stages for PPG/ED. Because a pattern for synchronization is not inserted into a PRBS pattern, DUT in Loopback state may not recognize the pattern.															
MCP	Set the standard test pattern for PCIe. When the 32G SI PPG is installed and the specification is set to 3.0/3.1(8.0 GT/s) or 4.0(16.0 GT/s), Jitter Meas (Jitter Tolerance Measurement Pattern) is available. Also, Jitter Meas is a pattern for calibration and cannot be used for BER measurement.															
Insert Delay Symbol	Sets whether to insert Delay Symbol in MCP. Cannot be set if the Specification Rev. setting is 3.0/3.1 (8.0 GT/s) or 4.0 (16.0 GT/s).															
Option	Opens the dialog box (Figure 4.4.2-2), where you can edit specific PCIe link training sequence settings.															

Table 4.4.2-2 Loopback through Configuration Setup Items

Item	Description
Rev1.x/2.0/3.x/4.0 Loopback through “Configuration”	
Detect.Quiet	Sets the waiting time for Detect.Quiet.
Detect.Active	Sets the waiting time for Detect.Active.
Polling.Active	Sets the number of times patterns are sent for Polling.Active.
Polling.Configuration	Sets the number of times patterns are sent for Polling.Configuration.
Recovery.Equalization (Electrical Idle)* ¹	Sets the waiting time for Loopback.Entry(Electrical Idle).
Loopback.Entry	Sets the number of times patterns are sent for Loopback.Entry.
Loopback.Active	Sends a pattern specified for Test Pattern.
Rev2.0/3.x/4.0 Loopback through “Recovery”	
Detect	
Quiet	Sets the waiting time for Detect.Quiet.
Active	Sets the waiting time for Detect.Active.
Polling	
Active	Sets the number of times patterns are sent for Active.
Configuration	Sets the number of times patterns are sent for Configuration.
Configuration	
Linkwidth.Start	Sets the number of times patterns are sent for Linkwidth.Start.
Linkwidth.Accept	Sets the number of times patterns are sent for Linkwidth.Accept.
Lane.Wait	Sets the number of times patterns are sent for Lane.Wait.
Lane.Accept	Sets the number of times patterns are sent for Lane.Accept.
Complete	Sets the number of times patterns are sent for Complete.
Idle	Sets the waiting time for Idle.
Recovery	
RcvrLock	Sets the number of times patterns are sent for Rcvr.Lock.
Rcvr.Cfg(EQTS2)	Sets the number of times patterns are sent for RcvrCfg.
Speed* ²	Sets the waiting time for Speed.
Equalization.Phase1* ¹	Sets the number of times patterns are sent for Equalization.Phase1.
RcvrCfg(TS2)	Sets the number of times patterns are sent for RcvrCfg.
Idle	Sets the waiting time for Idle.
Loopback	
Entry* ²	Sets the number of times patterns are sent for Entry.
Active* ²	Sends a pattern specified for Test Pattern.

*1: Available for Rev 2.0 and Rev 3.x.

*2: Three types are available: 5G, 8G, and 16G.

Table 4.4.2-3 Option Setup Items

Item	Description
TS Parameter	
FTS	Sets the TS FTS Number.
Link Number	Sets the TS Link Number.
Lane Number	Sets the TS Lane Number.
Full Swing	Sets the TS Full Swing.
Low Frequency	Sets the TS Low Frequency.
Disable Scrambling	Sets whether to use scrambling for TS.
EIEOS	
Reset Interval	Sets the TS Reset EIEOS Interval.
16 G Format*	Sets whether to use the EIEOS format of Base Spec Rev 0.7 or later.
SKP	Symbol Length, Interval, and Double SKP can be set for 8b10b (2.5G, 5.0GT/s) and for 128b130b (8.0G, 16.0GT/s) separately.
Insert	Sets whether to insert SKP OS while sending TS.
Symbol Length	Specifies the SKP OS length.
Interval	Specifies the SKP OS interval.
Double SKP*	Sets whether to insert double SKP into the test pattern (MCP) to send in Loopback.Active state.
Send TS	
Polling.Active	Sets the type of TS sent for Polling Active State.
Loopback.Entry	Sets the type of TS sent for Loopback Entry State.
Tx Preset	
Initial Preset for 2.5 GT/s*	Sets the preset value at linking start (in 2.5 GT/s operation).
Loopback Preset Select*	Sets whether to manually set Emphasis Preset in the test pattern to send in Loopback.Active state. When set to Auto, the value specified for Downstream Preset(DE,PS[dB]) is used. When set to Manual, the value specified for Loopback Preset is used.
Loopback Preset*	Selects the Emphasis Preset value in the test pattern to send in Loopback.Active state. This is available when Manual is selected for Loopback Preset Select.
Auto Search	Selects whether to adjust ED data reception to the optimal state after sending the link sequence. When set to ON, it takes several tens of seconds to execute Auto Search after sending the link sequence.
CTLE Gain	Sets CTLE gain for PCIe 3.0 or PCIe 4.0 operation. This is available only when SI ED (with MU195040A-x11 or x21) is installed.

*: The function is available only when 32G SI PPG is installed.

Table 4.4.2-3 Option Setup Items (Cont'd)

Item	Description
Rev 2.0 Preset	
De-emphasis*	Sets De-emphasis that is specified in TS which PPG sends and is notified to DUT.
Rev 3.x/Rev 4.0 Preset Downstream*	Sets the parameters that Downstream Port (PPG) uses in TS that PPG sends. When Loopback Preset Select of Tx Preset is set to Auto, Emphasis set by this item is added to the signals that are sent in Loopback Active state.
Preset(DE, PS [dB])	Sets Transmitter Preset.
Preset Hint	Sets Receiver Preset Hint. Displayed only when Rev 3.x is selected.
Rev 3.x/Rev 4.0 Preset Upstream*	Sets the parameters that will be set in the TS which PPG sends and that PPG requests for DUT (Upstream Port).
Usepreset	Displays the parameters that should be used for Upstream Port. Only Preset is displayed currently.
Preset(DE, PS [dB])	Sets Transmitter Preset.
Preset Hint	Sets Receiver Preset Hint. Displayed only when Rev 3.x is selected.

4.4.3 PCIe Link Sequence Start

Press the PCIe Compliance Base Board reset switch before starting measurement. Then click **Sequence Start** to start the link training sequence.

The button name changes to **Stop** while the link training sequence is being sent. The button name changes to **Unlink** once the link training sequence is successfully sent and the PPG status changes from Electrical Idle to Loopback Active. A test pattern is sent from the PPG here.

Clicking **Unlink** while the test pattern is being sent aborts the test pattern transmission, and the PPG returns to Electrical Idle status.

Successful linking can be confirmed using the device debugging function or MX183000A screen. The Loopback Active display will change as follows depending on the ED status. When MX183000A is not connected ED, **Loopback Active.** is displayed.

Table 4.4.3-1 Link Status Confirmation

Loopback Active. display	ED status
Loopback Active. Clock Loss.	Clock Loss
Loopback Active. Sync Loss.	Sync Loss
Loopback Active. Error.	Error
Loopback Active. Error Free.	Error Free

If you wish to measure Jitter Tolerance after this, refer to 4.6 “Jitter Tolerance Test” for details of the **Run Test** tab, **Graph** tab, and **Report** tab.

If you wish to measure BER after this, click **BER Measurement**. For details of the BER Measurement, refer to 4.4.4 “Setting Up PCIe BER Measurement” and 4.4.5 “Starting PCIe BER Measurement”.

4.4.4 Setting Up PCIe BER Measurement

BER Measurement function is enabled in Loopback.Active state after link training sequence transmission is completed. Also, it is enabled when ED is installed.

When **Configure BER Measurement** is selected, the BER Measurement Setup Screen is displayed.




Figure 4.4.4-1 PCIe BER Measurement Setup Screen

Table 4.4.4-1 Pass/Fail Judgment Setting Items

Item	Description
EC Threshold	Sets a pass/fail threshold of the BER measurement.
Pass/Fail	It is judged as “Fail” if Total Error Count exceeds EC Threshold when the measurement of the time set by Gating Time has completed.

Table 4.4.4-2 Measurement Operation Setting Items

Item	Description
Cycle	Sets the measurement operation. Repeat: Repeats the measurement in the cycle specified at Gating Time. Single: Ends the measurement in one cycle.
Gating Time [s]	Sets the measurement cycle by seconds.
Measurement Progress Bar	Displays the measurement progress rate.

Table 4.4.4-3 BER Measurement Result Display Window

Item	Description
Switch To Manual BER Test	Displays the Manual BER Test dialog box (Figure 4.4.4-2) so that BER can be checked on the MX190000A screen.
Error Addition	Add single bit error to test pattern during BER measurement. This function is enabled when MU195020A is installed.
Total BER	Displays the error rate.
Total Error Count	Displays the error count.
Total Bits	Displays the amount of measurement data.
Current BER	Displays the error rate in 100 ms.
Sync Loss	Lights up in red in the sync loss status.
Clock Loss	Lights up in red when the clock is not reproduced from the data input in ED.

When **Switch To Manual BER Test** is clicked, the dialog box shown in Figure 4.4.4-2 is displayed. While this dialog box is displayed, the MU181500B, MP1825B, and MU195020A settings can be changed checking BER on the MU183040B or MU195040A. Refer to “Table 4.3.4-1 Setting Items for Operating” for the main setting items.




Figure 4.4.4-2 Manual BER Test Dialog Box

Table 4.4.4-4 RF Setting Items


Item	Description
Preset	Selects the Emphasis Preset value of Test Pattern to transmit in Loopback.Active. This value is enabled only when Manual is selected for Loopback Preset Select on the Option screen and SI PPG (with MU195020A-x11 or x21) is installed.
CTLE Gain [dB]	Sets CTLE gain for PCIe 3.0 or PCIe 4.0 operation. It is a common item with CTLE Gain on the option screen. It is enabled only when SI ED with MU195040A-x11 or x21 is installed.

4.4.5 Starting PCIe BER Measurement

Clicking **Start BER Measurement** starts measurement.

The measurement results are displayed in the BER measurement result display window, and Pass or Fail is displayed. Clicking **Stop BER Measurement** stops the measurement.

When DUT is transited to loop back state, the counts of **Total BER**, **Total Error Count**, and **Total Bits** start.



A screenshot of the BER Measurement Result Display Window. It has a dark blue background with white text. There are four rows, each with a label on the left and a value on the right. The labels are 'Total BER', 'Total Error Count', 'Total Bits', and 'Current BER'. The values are '0.0000E-10', '0', '3.0169E10', and '0.0000E-10' respectively.

Total BER	0.0000E-10
Total Error Count	0
Total Bits	3.0169E10
Current BER	0.0000E-10

Figure 4.4.5-1 BER Measurement Result Display Window
(When Link Establishment is Successful)

When DUT is not transited to loop back state or DUT fails to transmit test pattern normally, **Sync Loss** or **Clock Loss** lamp lights up in red.



Figure 4.4.5-2 BER Measurement Result Display Window
(When Link Establishment is Failed)

4.5 USB Link Sequence

4.5.1 USB Link Sequence Setup Screen

On the **Sequence** tab, you can view the following USB Link Sequence settings. The references for each setup area are shown in the figure.





Figure 4.5.1-1 USB Link Sequence Setup Screen

The screen menu is the same as in Table 4.4.1-1.

The abbreviations used in USB Link Sequence are listed below.

LBPM:	SuperSpeedPlus LFPS Based PWM Message
LBPS:	Introduction to LFPS Based PWM Signaling
LFPS:	Low Frequency Periodic Signaling
LTSSM:	Link Training and Status State Machine
PWM:	Pulse Width Modulation
SCD:	SuperSpeedPlus Capability Declaration
TS:	Training Sequences

The LTSSM State area displays an overview of the LTSSM State. Clicking a state displays the corresponding LTSSM Sub State on the Sequence Editor screen.



Sequence Editor Screen

Figure 4.5.1-2 USB Link Sequence Setup Screen (2)

Table 4.5.1-1 Sequence Editor Setup Items

Menu	Description
All Parameter	Returns from the Sequence Editor screen to the All Parameter display.
Default	Resets values entered in Sequence Editor to their default values.

4.5.2 USB Link Sequence Setup

This section describes how to set the USB link training sequence, and test pattern for measurement.




Figure 4.5.2-1 USB Sequence Setup Screen (Gen1(5.0 GT/s))

Clicking **TS Option** displays the individual USB Sequence setup screen shown in Figure 4.5.2-2.




Figure 4.5.2-2 TS Option Screen (Gen1)

Table 4.5.2-1 USB Link Sequence Setting Items

Item	Description
USB3.1 Specification	<p>Selects and sets the USB specification from Gen1(5.0 GT/s) and Gen2(10.0 GT/s).</p> <p>If MU181000A/B is installed, set the 32G PPG Operation Bitrate to Gen1:5.0 GT/s and Gen2:10 GT/s respectively.</p> <p>Altering this item changes the sequence displayed in Sequence Editor.</p>
Test Pattern	<p>Selects the test pattern output repeatedly from Compliance or USER after completing the link training sequence transmission. Selecting Compliance displays the USB standard test pattern selection controller. Selecting USER automatically sets a test pattern for 32G PPG on the MX180000A.</p> <p>If Compliance is set, the pattern is set automatically in accordance with 32G PPG.*</p> <p>Selectable value changes depending on the value set for USB 3.1 Specification.</p>
Transmit/Stop	<p>Starts sending a pattern selected at Test Pattern.</p> <p>The button display is changed to Stop while the pattern is sent.</p> <p>When Stop is clicked, sending the pattern is stopped.</p> <p>When Sequence Start is clicked, sending the pattern is stopped automatically. The button display is changed to Transmit.</p>
Add Single Bit Error	<p>Inserts a 1-bit error to the sending pattern.</p> <p>This function is enabled in one of the following conditions.</p> <ul style="list-style-type: none"> • Gen1(5.0 GT/s), Compliance, CP0 • Gen2(10.0 GT/s), Compliance, CP9
TS Option	<p>Enables the setting screen display and setting status for the USB Link Sequence in Figure 4.5.2-2 to be altered.</p>

*: Selecting CP5 or CP6 does not change de-emphasis setting that is actually output.

Table 4.5.2-2 Sequence Editor Setup Items

Item	Description
Gen1(5.0GT/s)	
Rx.Detect.Active(Idle)	Sets the Electrical Idle time for Rx.Detect.Active.
Polling.LFPS	Sets the LFPS time for transmission in Polling.LFPS state.
Polling.RxEQ	Sets the TSEQ times for transmission in Polling.RxEQ state.
Polling.Active(TS1)	Sets the number of TS1 cycles for transmission in Polling.Active state.
Polling.Configuration(TS2)	Sets the number of TS2 cycles for transmission in Polling.Configuration state.
Polling.Idle	Sets the Electrical Idle time for Polling.Idle.
Loopback.Active	Sends a pattern specified for Test Pattern.
Gen2(10.0GT/s)	
Rx.Detect.Active(Idle)	Sets the Electrical Idle time for Rx.Detect.Active.
Polling.LFPS(SCD1)	Sets the LFPS(SCD1) time for transmission in Polling.LFPS state.
Polling.LFPS(SCD2)	Sets the LFPS(SCD2) time for transmission in Polling.LFPS state.
Polling.PortMatch(PHY Capability LBPM)	Sets the LBPM time for transmission in Polling. PortMatch state.
Polling.PortConfig(PHY Ready LBPM)	Sets the LBPM time for transmission in Polling. PortConfig state.
Polling.RxEQ	Sets the TSEQ times for transmission in Polling.RxEQ state.
Polling.Active(TS1)	Sets the number of TS1 cycles for transmission in Polling.Active state.
Polling.Configuration(TS2)	Sets the number of TS2 cycles for transmission in Polling.Configuration state.
Polling.Idle	Sets the Electrical Idle time for Polling.Idle.
Loopback Active	Sends a pattern specified for Test Pattern.

Table 4.5.2-3 TS Option Setup Items

Item	Description
Link Configuration	
Loopback	Displays the TS Loopback Bit to be transmitted.
Disable Scrambling	Enables or disables scrambling.
SKP	
SKP Insert	Sets whether SKP OS insertion while sending TS.
Symbol Length	Sets the SKP OS symbol length.
SKP Interval	Sets the interval for inserting SKP OS.
Warm Reset	
tBurst	Displays the tBurst time (ms).
tPeriod	Displays the tPeriod time (ns).
Duty	Displays Duty (%).
LFPS	
tBurst	Displays the tBurst time (ms).
SuperSpeed tRepeat	Displays SuperSpeed tRepeat.
SuperSpeedPlus	
Logic0	Displays the SuperSpeedPlus Logic0 time (μs).
Logic1	Displays the SuperSpeedPlus Logic1 time (μs).
SCD1	Displays the SuperSpeedPlus SCD1 cycle (μs).
SCD2	Displays the SuperSpeedPlus SCD2 cycle (μs).
LBPM	
tLFPS-1	Displays the LFPS One Burst time (μs).
tLFPS-0	Displays the LBPS Zero Burst time (μs).
tPWM	Displays the LBPM Repeat time (μs).

4.5.3 USB Link Sequence Start




Figure 4.5.3-1 USB Link Sequence Transmission Procedure

When **Sequence Start** is clicked, PPG is in the wait status for receiving the LFPS signal and the button display is changed to **Stop**.

Connect the USB Test Fixture connector to DUT in this condition.

DUT detects the connection of the USB connector and outputs the LFPS signal.

PPG receives the LFPS signal output from DUT at AUX Input and starts the link training sequence.

When the link training sequence transmission is completed, the button display is changed to **Unlink** and the test pattern is sent from PPG.

When **Unlink** is clicked while the test pattern is sent, sending the test pattern is stopped and PPG is in the Electrical Idle status.

Refer to Section 4.5.5 “USB BER Measurement Start” for details of success or failure of the link establishment.

4.5.4 USB BER Measurement Setup

The BER measurement can be performed using the USB3.1 Receiver Test Adapter.

When **Configure BER Measurement** is selected, the BER measurement setting window is displayed.




Figure 4.5.4-1 USB BER Measurement Setting Window

Table 4.5.4-1 Pass/Fail Judgment Setting Item

Item	Description
EC Threshold	Sets an evaluation threshold of the BER measurement.
Pass/Fail	Pass: Passed, Fail: Failed When the number of bit errors exceeds the evaluation threshold, the BER measurement is judged as Fail.

Table 4.5.4-2 Measurement Operation Setting Item

Item	Description
Cycle	Sets the measurement operation. Repeat: Repeats the measurement in the period specified at Gating Time. Single: Ends the measurement in one period.
Gating Time [s]	Sets the measurement period in one second units.
Measurement progress bar	Displays the measurement progress.

Table 4.5.4-3 BER Measurement Result Display Window

Item	Description
Switch To Manual BER Test	Displays the BER Monitor dialog box (Figure 4.5.4-2).
Total BER	Displays the error rate.
Total Error Count	Displays the error count.
Total Bits	Displays the amount of measurement data.
Current BER	Displays the error rate in 100 ms.
Sync Loss	Lights in red in the sync loss status.
Detector IP Address	Input the IP address specified at G0373A USB3.1 Receiver Test Adapter. The initial value of the IP address specified at G0373A is "192.168.0.10".

When **Switch To Manual BER Test** is clicked, the BER Monitor dialog box shown in Figure 4.5.4-2 is displayed. The MU181500B and MP1825B settings can be changed while checking BER in this dialog box. Refer to "Table 4.3.4-1 Setting Items for Operating" for the main setting items.





Figure 4.5.4-2 BER Monitor Dialog Box

4.5.5 USB BER Measurement Start

The BER measurement is started by clicking **Start BER Measurement**. The measurement results are displayed in the BER measurement result display window, and Pass or Fail is displayed. When **Stop BER Measurement** is clicked, the measurement is stopped.

When the link establishment of DUT is successful, counting **Total BER**, **Total Error Count**, and **Total Bits** starts.



The image shows a software window with a dark blue background. It contains five rows of data, each with a label on the left and a value in a white box on the right. The labels are 'Total BER', 'Total Error Count', 'Total Bits', 'Current BER', and 'Sync Loss'. The values are '0.0000E-10', '0', '3.0169E10', '0.0000E-10', and a small black square icon respectively.

Total BER	0.0000E-10
Total Error Count	0
Total Bits	3.0169E10
Current BER	0.0000E-10
Sync Loss	<input type="checkbox"/>

Figure 4.5.5-1 BER Measurement Result Display Window
(When Link Establishment is Successful)

When the link establishment of DUT is failed, the **Sync Loss** indicator lights in red.



The image shows a software window with a dark blue background. It contains two rows of data. The first row has the label 'Current BER' and a white box containing a dashed line. The second row has the label 'Sync Loss' and a small red square icon.

Current BER	-----
Sync Loss	<input checked="" type="checkbox"/>

Figure 4.5.5-2 BER Measurement Result Display Window
(When Link Establishment is Failed)

4.6 Jitter Tolerance Test

4.6.1 Jitter Tolerance Test Setup Screen

On the **Run Test** tab, you can view the following Jitter Tolerance settings. The references for each setup area are shown in the figure.




Figure 4.6.1-1 Jitter Tolerance Setup Screen

Table 4.6.1-1 Measurement Sequence Setting Items

Item	Description
Measurement Sequence	Specifies the measurement sequence direction. From higher Freq.side: Measure s from the higher modulation frequency side. From lower Freq.side: Measures from the lower modulation frequency side.
BitRate	Displays the current bit rate.
Clock Selection	Selects Recovered Clock or External Clock for the clock.

Table 4.6.1-2 Measurement Status

Item	Description
Measurement progress bar	Displays the measurement progress.
Measurement Status	Displays the current measurement status.

4.6.2 Jitter Tolerance Measurement Sequence Setup

When measuring Jitter Tolerance, set parameters for the test pattern, stable time, executing/not executing auto search, Pass/Fail judgment condition, error judgment unit, Pass/Fail judgment error threshold, and measurement time.




Figure 4.6.2-1 Jitter Tolerance Setup Screen

Clicking **JTOL Settings** displays the individual Jitter Tolerance setup screen shown in Figure 4.6.2-2, and allows the settings to be altered.




Figure 4.6.2-2 JTOL Settings Screen

Table 4.6.2-1 JTOL Settings Items

Item	Description
Detection	
Unit	<p>Sets one of error rate and error count as a pass/fail criterion.</p> <p>Error Rate: Error rate</p> <p>Error Count: Error bit count (Default)</p> <p>Estimate: Error rate for jitter tolerance estimation</p> <p>Measures jitter tolerance using the error rate determined from the Direction Search setting such as 1E-6 as the target. The measurement results from this process are used to estimate the jitter tolerance for the value specified by BER for JTOL Estimation.</p> <p>Note:</p> <p>A BER for a rate lower than the intermediate measurement is estimated even using the Error Rate/Count Rate setting, but estimation may not be possible for certain intermediate results. Setting to Estimate allows BER to be estimated reliably. For details, refer to Section 4.7.3 “Jitter Tolerance Estimate”.</p> <p>In PAM4 PPG/ED PAM4 mode, select one of the following as a pass/fail criterion:</p> <p>Symbol: Symbol error rate</p> <p>Bit: Bit error rate only (Without correlating to symbol)</p> <p>MSB: MSB error rate</p> <p>LSB: LSB error rate</p>
Error Count/ Error Threshold	<p>Sets the threshold for judgment using the judgment method selected in Unit. The judgment will be Fail if the bit error value exceeds the threshold.</p> <p>When Unit is set to Error Rate: 1E-3 to E-12 1E-1 Step (Default: 1E-12)</p> <p>When Unit is set to Error Count: 0 to 10000000/Step 1 (default: 2)</p> <p>When Unit is set to Estimate: Cannot be changed.</p>
BER for JTOL Estimation	<p>The error rate used for Estimate can be changed. The results will be refreshed even if this value is changed after the Jitter Tolerance Test.</p>

Table 4.6.2-1 JTOL Settings Items (Cont'd)

Item	Description
Search Type	
Auto Search	<p>Selects whether Auto Search for 32G ED and 32G SI ED is executed before measurement.</p> <p>OFF: Auto Search is not performed before measurement. (default) When Meas. Type is PAM4, click Manual, and then in the PAM4 Threshold/Phase Settings dialog box (Figure 4.6.2-3), configure threshold (Upper/Middle/Lower) and phase settings for PAM4 signal eyes.</p> <p>FINE: Auto Search (FINE) is performed before measurement.</p> <p>COARSE: Auto Search (COARSE) is performed before measurement.</p> <p>This operation is not available in the following cases, as Auto Search cannot be executed.</p> <ul style="list-style-type: none"> • Auto Adjustment is executed by the DUT. • Auto Sync is set to Off.
Meas. Type	Select the type of signal (NRZ or PAM4) to be measured.
Selection of PAM4 Pattern	<p>When PAM4 is selected in the Meas. Type box, select the test pattern to be set for ED.</p> <p>For the patterns you can select, refer to “Appendix F” in the <i>MU183040B Operation Manual</i>.</p>
Direction Search	<p>Sets jitter modulation amplitude change direction and method. Refer to the description in 4.7.1 “Measurement Sequence”.</p> <ul style="list-style-type: none"> • Binary • Downwards Linear • Downwards Log • Upwards Linear • Upwards Log • Binary + Linear

Table 4.6.2-1 JTOL Settings Items (Cont'd)

Item	Description
Direction Search (Cont'd)	<p>Note:</p> <p>Only the following three selections are available when Estimate is selected.</p> <p>(1) Binary Measures BER with 1E-6 as the target for the measurement range. Calculates the estimate curve from the data obtained in the measurement process.</p> <p>(2) Downwards Linear Measures BER with 1E-7 as the target. Calculates the estimate curve in the same way as for (1).</p> <p>(3) Upwards Linear Measures BER with 1E-5 as the target. Calculates the estimate curve in the same way as for (1).</p> <p>Also, when PAM4 is selected for Meas. Type, the following selections are available.</p> <p>When Unit is Estimate: Upwards Linear only</p> <p>When Unit is Error Rate: Upwards Linear, Upwards Log</p>
Step	<p>Enabled when Downwards Linear or Upwards Linear is selected.</p> <p>Sets change ratio of jitter amplitude for each modulation frequency band below.</p> <p>Jitter Freq. ≤ 100 kHz 100 kHz < Jitter Freq. ≤ 1 MHz 1 MHz < Jitter Freq. ≤ 10 MHz 10 MHz < Jitter Freq.</p>
Ratio	<p>Enabled when Downwards Log or Upwards Log is selected.</p> <p>Sets change ratio of jitter amplitude for each modulation frequency band below.</p> <p>Jitter Freq. ≤ 100 kHz 100 kHz < Jitter Freq. ≤ 1 MHz 1 MHz < Jitter Freq. ≤ 10 MHz 10 MHz < Jitter Freq.</p>
SJ Amplitude setting	<p>Allows you to set the jitter modulation amplitude to be changed in steps when the frequency is changed during the measurement. The SJ Amplitude Setting Dialog Box (Figure 4.6.2-5) appears after clicking this button.</p>
Timer [s]	
Waiting	Sets the waiting time after changing the jitter modulation frequency until the next process starts. Refer to 4.7.2 "Measurement time".
Settling	Sets the waiting time after changing the jitter modulation amplitude until the BER measurement starts.
Gating	<p>Sets the measurement time until judgment ends.</p> <p>Fixed at 1 second when Estimate is selected for Direction Unit.</p>




Figure 4.6.2-3 PAM4 Threshold/Phase Settings Dialog Box

Table 4.6.2-2 PAM4 Threshold/Phase Settings Items

Item	Description
Manual Setting	
Data Input Condition	Displays the Input Condition settings of ED to be used for measurement. <ul style="list-style-type: none">• Single-End Data or XData• Differential 50Ohm• Differential 100Ohm
Threshold/Phase	Configure threshold and phase settings for Upper/Middle/Lower eyes of PAM4 signal.
Pretest ON/OFF	When selecting the Pretest checkbox: Verifies whether the measurement can be started using the threshold and phase value specified by Auto Search or manually before starting the AM4 Jitter Tolerance measurement. If verified to be Sync Loss, you will be notified that measurement does not start.




Figure 4.6.2-4 Definition of PAM4 Threshold Levels




Figure 4.6.2-5 SJ Amplitude Setting Dialog Box

Table 4.6.2-3 SJ Amplitude Setting Items

Item	Description
Change SJ amplitude in steps:	
SJ amplitude setting ON/OFF	<p>Selecting a check box applies the SJ amplitude settings that allow the jitter amplitude to be increased or decreased in steps to prevent from changing drastically when the SJ modulation frequency is changed in the jitter tolerance measurement.</p> <p>During the time to change SJ amplitude to 0 UI.:</p> <p>Applies the specified SJ amplitude settings when the jitter modulation amplitude returns to 0 UI after the jitter tolerance measurement at a certain modulation frequency.</p> <p>During the time to change SJ amplitude to the first value of the next frequency.:</p> <p>Applies the specified SJ amplitude settings when setting the jitter modulation amplitude for the next measurement after changing the modulation frequency.</p>
Number of steps	<p>Allows setting the number of steps of the jitter modulation amplitude setting for each of the following modulation frequency bands.</p> <p>Number of steps: 1 to 20</p> <p>Jitter Freq. ≤ 100 kHz</p> <p>100 kHz < Jitter Freq. ≤ 1 MHz</p> <p>1 MHz < Jitter Freq. ≤ 10 MHz</p> <p>10 MHz < Jitter Freq.</p>
Wait time of a step	<p>Allows setting the waiting time for each step.</p> <p>0.1 to 1.0 s / 0.1 s step</p>

4.6.3 Jitter Tolerance Table Setup

The Jitter Tolerance Table setting area is used to set the SJ modulation frequency for measuring jitter tolerance.

No.	Jitter Freq. [Hz]	Mask [UI]	Upper Limit [UI]	Lower Limit [UI]
<input checked="" type="checkbox"/> 1	100,000,000	0.100	0.500	0.010
<input checked="" type="checkbox"/> 2	10,000,000	0.100	1.000	0.010
<input checked="" type="checkbox"/> 3	1,000,000	1.000	10.000	0.100
<input checked="" type="checkbox"/> 4	300,000	1.000	10.000	0.100

Jitter Freq.[Hz]10Add

Mask [UI]1.000Delete

Upper Limit [UI]2.000All Clear

Lower Limit [UI]1.000Set All Limit

Upper Ratio2.000

Lower Ratio1.000

Figure 4.6.3-1 Jitter Tolerance Table Setting Area

Used →

Not Used →

<input checked="" type="checkbox"/>	1	100,000,000
<input type="checkbox"/>	2	10,000,000
<input checked="" type="checkbox"/>	3	1,000,000
<input type="checkbox"/>	4	300,000

The column on the left is for the check boxes, as shown in the figure above. The frequencies selected will be used for measurement.

Table 4.6.3-1 Jitter Tolerance Table Setting Items

Item	Description																																													
Jitter Freq. [Hz]	<div>Sets the jitter modulation frequency. The setting range is equal to the setting range of the modulation frequency of MU181500B.</div> <table><tr><th>Range [Hz]</th><th>Resolution [Hz]</th></tr><tr><td>10 to 10 000</td><td>1</td></tr><tr><td>10 010 to 100 000</td><td>10</td></tr><tr><td>100 100 to 1 000 000</td><td>100</td></tr><tr><td>1 001 000 to 10 000 000</td><td>1 000</td></tr><tr><td>10 010 000 to 100 000 000</td><td>10 000</td></tr><tr><td>100 100 000 to 250 000 000</td><td>100 000</td></tr></table>	Range [Hz]	Resolution [Hz]	10 to 10 000	1	10 010 to 100 000	10	100 100 to 1 000 000	100	1 001 000 to 10 000 000	1 000	10 010 000 to 100 000 000	10 000	100 100 000 to 250 000 000	100 000																															
Range [Hz]	Resolution [Hz]																																													
10 to 10 000	1																																													
10 010 to 100 000	10																																													
100 100 to 1 000 000	100																																													
1 001 000 to 10 000 000	1 000																																													
10 010 000 to 100 000 000	10 000																																													
100 100 000 to 250 000 000	100 000																																													
Mask [UI]	<div>Sets the mask for the modulation frequency. The setting range is the setting range for the MU181500B amplitude. The available ranges and resolutions will vary depending on the 32G PPG Bit Rate and Clock Setting. For Bit Rate: 30.000004 to 32.1 Gbit/s</div> <table><tr><th>Frequency [Hz]</th><th>Range [Ulp-p]</th><th>Resolution [Ulp-p]</th></tr><tr><td>10 to 100 000</td><td>0 to 1000</td><td>0.004</td></tr><tr><td>100 100 to 1 000 000</td><td>0 to 100</td><td>0.004</td></tr><tr><td>1 001 000 to 10 000 000</td><td>0 to 8</td><td>0.004</td></tr><tr><td>10 010 000 to 250 000 000</td><td>0 to 0.5</td><td>0.004</td></tr></table> <div>For Bit Rate: 15.000002 to 30 Gbit/s, Clock Setting: Full Rate or Bit Rate: 2.4 to 30 Gbit/s, Clock Setting: Half Rate</div> <table><tr><th>Frequency [Hz]</th><th>Range [Ulp-p]</th><th>Resolution [Ulp-p]</th></tr><tr><td>10 to 100 000</td><td>0 to 2000</td><td>0.002</td></tr><tr><td>100 100 to 1 000 000</td><td>0 to 200</td><td>0.002</td></tr><tr><td>1 001 000 to 10 000 000</td><td>0 to 16</td><td>0.002</td></tr><tr><td>10 010 000 to 250 000 000</td><td>0 to 1</td><td>0.002</td></tr></table> <div>For Bit Rate: 4.000002 to 15 Gbit/s, Clock Setting: Full Rate</div> <table><tr><th>Frequency [Hz]</th><th>Range [Ulp-p]</th><th>Resolution [Ulp-p]</th></tr><tr><td>10 to 100 000</td><td>0 to 1000</td><td>0.001</td></tr><tr><td>100 100 to 1 000 000</td><td>0 to 100</td><td>0.001</td></tr><tr><td>1 001 000 to 10 000 000</td><td>0 to 8</td><td>0.001</td></tr><tr><td>10 010 000 to 250 000 000</td><td>0 to 0.5</td><td>0.001</td></tr></table>	Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]	10 to 100 000	0 to 1000	0.004	100 100 to 1 000 000	0 to 100	0.004	1 001 000 to 10 000 000	0 to 8	0.004	10 010 000 to 250 000 000	0 to 0.5	0.004	Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]	10 to 100 000	0 to 2000	0.002	100 100 to 1 000 000	0 to 200	0.002	1 001 000 to 10 000 000	0 to 16	0.002	10 010 000 to 250 000 000	0 to 1	0.002	Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]	10 to 100 000	0 to 1000	0.001	100 100 to 1 000 000	0 to 100	0.001	1 001 000 to 10 000 000	0 to 8	0.001	10 010 000 to 250 000 000	0 to 0.5	0.001
Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]																																												
10 to 100 000	0 to 1000	0.004																																												
100 100 to 1 000 000	0 to 100	0.004																																												
1 001 000 to 10 000 000	0 to 8	0.004																																												
10 010 000 to 250 000 000	0 to 0.5	0.004																																												
Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]																																												
10 to 100 000	0 to 2000	0.002																																												
100 100 to 1 000 000	0 to 200	0.002																																												
1 001 000 to 10 000 000	0 to 16	0.002																																												
10 010 000 to 250 000 000	0 to 1	0.002																																												
Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]																																												
10 to 100 000	0 to 1000	0.001																																												
100 100 to 1 000 000	0 to 100	0.001																																												
1 001 000 to 10 000 000	0 to 8	0.001																																												
10 010 000 to 250 000 000	0 to 0.5	0.001																																												

Table 4.6.3-1 Jitter Tolerance Table Setting Items (Cont'd)

Item	Description		
Max Limit [UI] (Cont'd)	For Bit Rate: 2.4 to 4 Gbit/s, Clock Setting: Full Rate		
	Frequency [Hz]	Range [Ulp-p]	Resolution [Ulp-p]
	10 to 100 000	0 to 500	0.001
	100 100 to 1 000 000	0 to 100	0.001
	1 001 000 to 10 000 000	0 to 8	0.001
	10 010 000 to 250 000 000	0 to 0.5	0.001
Upper Limit [UI]	Sets the upper limit. Be sure to enter a value not less than the value set for Mask. The setting range is the same as the setting range above.		
Lower Limit [UI]	Sets the lower limit. Be sure to enter a value not exceeding the value set for Mask. The setting range is the same as the setting range above.		
Add	Adds the value entered above to the Jitter Tolerance Table.		
Delete	Deletes selected jitter modulation frequency data.		
All Clear	Deletes all jitter modulation frequency data.		
Upper Ratio	Resets the Upper Limit value as a ratio of the value set for Mask. Click Set All Limit to update the changes.		
Lower Ratio	Resets the Lower Limit value as a ratio of the value set for Mask. Click Set All Limit to update the changes.		
Set All Limit	Resets all of the Upper Limit [UI] and Lower Limit [UI] values for the frequencies selected in the Jitter Tolerance Table.		

4.6.4 Setting up the Mask data

Mask data is the amplitude value with which the Pass/Fail judgment is made on the Jitter Tolerance measurement value. If the jitter amplitude measurement value is smaller than the value of the mask data, the judgment result will be Fail.




Figure 4.6.4-1 Mask Data Table setup area

Table 4.6.4-1 Mask Data Table setup items

Item	Description
Save	Saves the table data edited by a user to a user data file (extension: umsk).
Open	Opens the dialog box, where you can select a mask file.

4.6.5 Jitter Tolerance Measurement Start

Click **Run Test** to start measurement.

The measurement results are displayed in the Jitter Tolerance Table, and the results are displayed as a graph on the **Graph** tab.

The button name changes to **Stop Test** while measurement is in progress.

When measurement is complete, the button name returns to **Run Test**.

Clicking **Stop Test** aborts measurement.

4.6.6 Jitter Tolerance Test Result




Figure 4.6.6-1 Jitter Tolerance Table Screen





Figure 4.6.6-2 Jitter Tolerance Table Screen (For PAM4 Measurement)


Table 4.6.6-1 Jitter Tolerance Table

Item	Description
Meas. [UI]	Displays measured results. When Meas. Type is PAM4 , the following are displayed: <ul style="list-style-type: none"> Upper/Middle/Lower Eye measurement results Total of three eye measurement results
Meas.Judge	Pass: Pass, Fail: Fail The pass/fail judgment is determined as fail if the jitter tolerance point is below the Mask set. If the modulation frequency is outside the frequency range set for the Mask Data Table, the specification for Mask Data Table modulation frequency closest to that modulation frequency is used as the pass/fail judgment datum. When Meas. Type is PAM4 , pass/fail evaluation of the following is displayed: <ul style="list-style-type: none"> Upper/Middle/Lower Eye measurement Total of three eye measurement
Estimate [UI]	Displays the estimate for the error rate specified for BER for JTOL Estimation.
Adjusted R-Squared	Displays R ² (free-adjusted coefficient of determination).
Estimate.Judge	Judges the estimate in the same way as Meas.Judge.
FL	The following message is displayed if the measurement result matches the Upper Limit of fails due to the Lower Limit. Upper Limit \geq Measurement result: OVF Lower Limit $<$ Measurement result: UNF
Detail	The detailed measurement results table for the measurement points selected in Figure 4.6.6-1 is shown in a separate window. Figure 4.6.6-3 shows a typical window. When Meas. Type is PAM4 , Upper/Middle/Lower eye measurement results are displayed. Figure 4.6.6-4 shows the image of how the detailed measurement results are displayed. In PAM4 PPG/ED PAM4 mode, the following measurement results are displayed: Symbol, Bit, MSB, LSB



No.	Jitter Freq. [Hz]	Mask [UI]	Upper Limit [UI]	Lower Limit [UI]	Meas. [UI]	Upper Eye	Middle Eye
1	100,000,000	0.100	0.200	0.100	----	----	----
2	10,000,000	0.100	0.200	0.100	----	----	----
3	1,000,000	1.000	2.000	1.000	----	----	----
4	30,000	1.000	2.000	1.000	----	----	----


Figure 4.6.6-3 Jitter Tolerance Table Detail



The screenshot shows a window titled "JTOL Table Detail" with a table containing jitter tolerance test results. The table has columns for Jitter (J), Lower Limit, Measured value (Meas.), Upper Eye, Middle Eye, Lower Eye, Total Eye, and a Pass/Fail judgment (Meas. Judge). The first row shows a jitter of 0.00 and a lower limit of 0.100. The measured value is 0.100, and the judgment is PASS. The second row shows a jitter of 0.280, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The third row shows a jitter of 0.424, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fourth row shows a jitter of 0.538, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fifth row shows a jitter of 0.630, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The sixth row shows a jitter of 0.704, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The seventh row shows a jitter of 0.762, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The eighth row shows a jitter of 0.808, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The ninth row shows a jitter of 0.846, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The tenth row shows a jitter of 0.876, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The eleventh row shows a jitter of 0.900, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. A "Close" button is located at the bottom right of the window.

J	Lower Limit	Meas.	Upper Eye	Middle Eye	Lower Eye	Total Eye	Meas. Judge
0.00	0.100	0.100	0	0	0	0	
		0.280	0	0	0	0	PASS
		0.424	0	0	1.5624E-10	7.8120E-11	
		0.538	0	0			
		0.630	0	0			
		0.704	7.8127E-11	0			
		0.762		0			
		0.808		0			
		0.846		0			
		0.876		0			
		0.900		0			

Figure 4.6.6-4 Jitter Tolerance Table Detail (For PAM4 Measurement)



The screenshot shows a window titled "JTOL Table Detail" with a table containing jitter tolerance test results for PAM4 PPG/ED mode. The table has columns for Jitter (J), Lower Limit, Measured value (Meas.), Symbol, Bit, MSB, LSB, and a Pass/Fail judgment (Meas. Judge). The first row shows a jitter of 0.158, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The second row shows a jitter of 0.166, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The third row shows a jitter of 0.172, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fourth row shows a jitter of 0.176, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fifth row shows a jitter of 0.180, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The sixth row shows a jitter of 0.184, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The seventh row shows a jitter of 0.186, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The eighth row shows a jitter of 0.188, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The ninth row shows a jitter of 0.190, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The tenth row shows a jitter of 0.192, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The eleventh row shows a jitter of 0.194, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The twelfth row shows a jitter of 0.196, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The thirteenth row shows a jitter of 0.198, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fourteenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The fifteenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The sixteenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The seventeenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The eighteenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The nineteenth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. The twentieth row shows a jitter of 0.200, a lower limit of 0.100, a measured value of 0.100, and a judgment of PASS. A "Close" button is located at the bottom right of the window.

J	Lower Limit	Meas.	Symbol	Bit	MSB	LSB	Meas. Judge
0.158	0.100	0.100	0	0	0	0	
0.166	0.100	0.100	0	0	0	0	
0.172	0.100	0.100	0	0	0	0	
0.176	0.100	0.100	0	0	0	0	
0.180	0.100	0.100	0	0	0	0	
0.184	0.100	0.100	0	0	0	0	
0.186	0.100	0.100	0	0	0	0	
0.188	0.100	0.100	0	0	0	0	
0.190	0.100	0.100	0	0	0	0	
0.192	0.100	0.100	0	0	0	0	
0.194	0.100	0.100	0	0	0	0	
0.196	0.100	0.100	0	0	0	0	
0.198	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	PASS
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	
0.200	0.100	0.100	0	0	0	0	

Figure 4.6.6-5 Jitter Tolerance Table Detail (In PAM4 PPG/ED Mode)




Figure 4.6.6-6 Jitter Tolerance Graph Tab


The estimate curve specified for BER for JTOL Estimation is displayed on the graph on the **Graph** tab. The estimate curve can be displayed or hidden by selecting or clearing the **Display** check box.

When **Meas. Type** is **PAM4**, the Upper/Middle/Lower Eye measurement results and total of three eye measurement results are plotted. They can be displayed or hidden by selecting or cleaning the check boxes.

4.6.7 Saving the graph and setting up the scale

Right-click in the measurement result graph display area on the Result screen, a submenu will appear.

You can copy and save the graph, or change the graph display from the submenu.



4
Operation

Figure 4.6.7-1 Submenu in the measurement result graph display area

Table 4.6.7-1 Submenu in the measurement result graph display

Item	Description
Copy	Copies the graph display area to the clip board.
Save Image As...	Saves the graph display area as a file in the specified format.
Page Setup...	Opens the graph printing settings.
Print	Prints out the graph.
Show Point Values	Displays the coordinates at the mouse cursor position.
Un-Zoom	Zooms out the graph.
Set Scale to Default	Displays the entire graph.

4.6.8 File Operation and Printing

On the **Report** tab, you can save measurement result data.




Figure 4.6.8-1 Report Tab Screen

1. Click the **Report** tab.
2. Click **Make HTML** to print/save the data in the HTML format.
The print image will appear.
3. Click **Make CSV** to print/save the data in the CSV format.
The print image will appear.
4. Click **Save** to save as a file in the format specified in steps 2 and 3.




Figure 4.6.8-2 Result Screen-Report (Make HTML)

When you saved the data, the following files are created:

(1) HTML data

- Specified file name.htm
- conf.css
- IMG folder: A png file of the waveform and the graph will be created.

The name of the file will be created in the specified file name xx.png. xx will be replaced by a number.

If you double-click the htm file, you can display the saved result on a Web browser such as the Internet Explorer.

Required file size to save HTML may sometimes be up to about 20MB. Verify the amount of free space on the hard disk before executing Save.

(2) CSV data

- Specified file name.csv

4.7 Jitter Tolerance Test Procedure

4.7.1 Measurement Sequence

Jitter Tolerance measures the tolerance of jitter per each listed jitter frequency.

Jitter tolerance is the maximum jitter amplitude at which the number of errors or the error rate becomes equal to or below the Pass/Fail Threshold. The following types of measurement methods are available:

- Binary

The binary search method is used to search for the target jitter amplitude.

The binary search method decreases its searching range of jitter amplitude by half for every measurement execution. If the error measurement value is equal to or below the value of Threshold, the jitter amplitude is increased; if it exceeds the value of Threshold, the jitter amplitude is decreased. The search ends when the amount of searching range becomes equal to or below the value of the permitted resolution setting. In the Figure 4.7.1-1, the jitter amplitude of the fourth measurement represents the final measurement result.




Figure 4.7.1-1 Procedure for the Binary Search measurement method

- Downwards

The jitter amplitude is decreased from the Start Value until the error measurement value becomes equal to or below the value of Threshold.

In the case of Downwards Linear, the jitter amplitude is decreased by the value set in Step.

In the case of Downwards Log, the jitter amplitude is decreased by the magnification set in Ratio.

In cases that the error measurement value still exceeds the Threshold even when the jitter amplitude becomes equal to or below Lower Value, the next step jitter amplitude will be taken as the final measurement value.




Figure 4.7.1-2 Procedure for Downwards Linear measurement




Figure 4.7.1-3 Procedure for Downwards Log measurement

- Upwards

The jitter amplitude is increased from the Start Value until the error measurement value exceeds the value of Threshold.

In the case of Upwards Linear, the jitter amplitude is increased by the value set in Step.

In the case of Upwards Log, the jitter amplitude is increased by the magnification set in Ratio.

In cases that the error measurement value still does not exceed the Threshold even when the jitter amplitude becomes equal to or above Upper Value, the next step jitter amplitude will be taken as the final measurement value.




Figure 4.7.1-4 Procedure for Upwards Linear measurement




Figure 4.7.1-5 Procedure for Upwards Log measurement

- Binary + Linear

After searching the jitter amplitude from the lower value by the binary search method, the Upwards Linear measurement is executed.

From the point searched by the binary search method, the jitter amplitude is increased at a step of the value, which is a half of the value set for Step Resolution, until the error measurement value exceeds the Threshold value.




Figure 4.7.1-6 Procedure for Binary + Linear measurement

4.7.2 Measurement time

Repeat the process for measuring the bit error rate by changing the jitter frequency and jitter amplitude.

MX183000A sets up the jitter frequency, the waiting time after changing the jitter amplitude, and the bit error rate measurement time under the following names:

Waiting: Waiting time after changing the jitter frequency
 Settling: Waiting time after changing the jitter amplitude
 Gating: Bit error rate measurement time

The time relationship in the Jitter Tolerance measurement is as shown in the figure below:




Figure 4.7.2-1 Setup time relationship

Moreover, if the **Change SJ amplitude in steps** function is enabled, MX183000A repeats processing of the measurement for the bit error rate, with changing the jitter amplitude in steps when changing the jitter frequency.

MX183000A allows you to configure the following settings:

Waiting: Waiting time after changing the jitter frequency (described above)
 Wait time of a step: Waiting time for each step

The following figure shows the relationship of “Waiting” and “Wait time of a step” when changing the jitter frequency.




Figure 4.7.2-2 Setup time relationship

4.7.3 Jitter Tolerance Estimate

The MX183000A allows BER to be estimated for high rates such as 1E-6 and for low rates such as 1E-20.

For example, the BER for E-20 cannot be measured practically, as the error rate produces errors of 1 bit in 10¹⁰ seconds (>317 years) even with a 10 Gbit/s signal.

The distribution parameters σ and μ can be determined by measuring the correlation with jitter modulation amplitude (SJ) for bitter error rate over a particular range as shown in Figure 4.7.3-1. Jitter modulation amplitude estimate curves for jitter modulation frequencies can be calculated for any particular error rate using the equation in the distribution Figure 4.7.3-1.




Figure 4.7.3-1 Noise Distribution Estimate and BER Estimate Calculation

The MX183000A allows an estimate curve to be plotted if three or more measurement results have an error rate between 1.0E-6 and 1.0E-9 while measuring Jitter Tolerance.

Intermediate results as shown in Figure 4.7.3-2 can be obtained for settings as shown in Table 4.6.2-1.

Unit: Estimate
Direction Search: Upwards Linear

Meas. [UI]	Error Rate
0.800	1.5050E-08
0.810	3.7400E-08
0.820	7.9250E-08
0.830	1.7350E-07
0.840	3.7240E-07
0.850	7.5995E-07
0.860	1.8573E-06

Figure 4.7.3-2 Example Intermediate Measurement Results for Upwards Linear (Unit Setting: Estimate)

As there are at least three measurement results with an error rate between $1.0\text{E}-6$ and $1.0\text{E}-9$, the approximation line shown in Figure 4.7.3-1 can be drawn, allowing estimation of BER for low rates such as E-20.

If Unit is Estimate, even if there are less than three measurement results with an error rate between $1.0\text{E}-6$ and $1.0\text{E}-9$, measurement is continued until there are three measurement results with an error rate between $1.0\text{E}-6$ and $1.0\text{E}-9$ by measuring with additional SJ values.

If you wish to determine jitter tolerance estimate results accurately for low rates, set Unit to Estimate.

Note:

Three or more measurement results between $1.0\text{E}-6$ and $1.0\text{E}-9$ cannot be obtained if the jitter amplitude reaches the Upper Limit, and the Error Rate at this point is $1.0\text{E}-9$ or less. For this reason, jitter tolerance cannot be estimated for low rates.

Estimate curves can be drawn for intermediate measurement results even when Unit is set to Error Rate or Error Count.

Intermediate results as shown in Figure 4.7.3-3 can be obtained for settings as shown in Table 4.6.2-1.

Unit: Error Rate

Error Threshold: 1.0E-7

Direction Search: Binary

Meas. [UI]	Error Rate
1.000	1.6560E-03
0.504	0
0.752	1.5000E-10
0.876	5.4154E-06
0.814	5.2750E-08
0.844	5.3230E-07
0.828	1.5685E-07
0.820	8.4250E-08
0.824	1.0950E-07
0.822	8.5300E-08

Figure 4.7.3-3 Example Intermediate Measurement Results for Binary, Error Threshold 1.0E-7

In this case, as there are at least three measurement results with an error rate between 1.0E-6 and 1.0E-9, the approximation line shown in Figure 4.7.3-1 can be drawn, even without setting Unit to Estimate. BER can therefore be estimated for low rates such as E-20.

Intermediate results as shown in Figure 4.7.3-4 can be obtained for settings as shown in Table 4.6.2-1.

Unit: Error Rate
Error Threshold: 1.0E-10
Direction Search: Binary

Meas. [UI]	Error Rate
1.000	1
0.504	0
0.752	5.0000E-11
0.876	1.8923E-06
0.814	2.0900E-08
0.782	8.0000E-10
0.766	5.0000E-10
0.758	5.0000E-11
0.762	1.5000E-10
0.760	2.0000E-10

Figure 4.7.3-4 Example Intermediate Measurement Results for Binary, Error Threshold 1.0E-10

In this case, as there are only two measurement results with an error rate between 1.0E-6 and 1.0E-9, the approximation line shown in Figure 4.7.3-1 cannot be drawn, and BER cannot be estimated for low rates such as E-20.

If Unit is set to Estimate, measurement can be continued until three measurements are obtained between 1.0E-6 and 1.0E-9 by adding SJ values, but additional measurement is not performed when Unit is set other than to Estimate.

If you wish to determine jitter tolerance estimate results accurately for low rates, set Unit to Estimate.

4.8 PCIe Link Training

4.8.1 PCIe Link Training Setup Screen

On the **Link Training** tab, you can view the following PCIe Link Training settings. The references for each setup area are shown in the figure.




Figure 4.8.1-1 PCIe Link Training Setup Screen

For details of menus and abbreviations on the above screen, refer to 4.4.1 “PCIe Link Sequence Setup Screen,” since they are common in these screens.

4.8.2 PCIe Link Training Setup

This section explains how to set the link training parameters and test patterns for PCIe measurement.




Figure 4.8.2-1 PCIe Link Training Setup Screen

Click **Option** shown in Figure 4.8.2-1 to display the PCIe Setup Screen shown in Figure 4.8.2-2.




Figure 4.8.2-2 PCIe Link Training Option Setup Screen (PCIe 3.0/3.1)

The setting items on the Option Setup window are common with PCIe 4.0.

Click **Timeout** shown in Figure 4.8.2-1 to display the LTSSM Timeout setup screen shown in Figure 4.8.2-3.




Figure 4.8.2-3 PCIe Link Training Timeout Window

Table 4.8.2-1 shows the setting items of Figure 4.8.2-1.

Table 4.8.2-1 PCIe Link Training Setup Items

Item	Description															
Specification	Select PCIe specification from PCIe 1.0/1.1(2.5 GT/s), 2.0(5.0 GT/s), 3.0/3.1(8.0 GT/s), and 4.0(16.0 GT/s). When the MU181000A/B is installed, set PPG operation bitrate to PCIe 1.x:2.5 Gbit/s, PCIe 2.0:5.0 Gbit/s, PCIe 3.0/3.1:8.0 Gbit/s, and PCIe 4.0:16 Gbit/s.															
DUT	Selects type of device under test (DUT). When set to Root Complex, DUT operates only with Separate Refclock. Select Option > TS Parameter and enable SRIS.															
LTSSM Log	Open the screen that displays log captured during training. For details, refer to 4.8.4 “Displaying PCIe Link Training Results”.															
Loopback through	Selects the state to go through until DUT transition to the Loopback state is completed. To perform Link Training in loopback between PPG and ED, set this item to “Configuration”. The following can be selected depending on Specification Rev. <table><tr><th>Revision</th><th>Configuration</th><th>Recovery</th></tr><tr><td>1.0/1.1(2.5 GT/s)</td><td>✓</td><td></td></tr><tr><td>2.0(5.0 GT/s)</td><td>✓</td><td>✓</td></tr><tr><td>3.0/3.1(8.0 GT/s)</td><td>✓</td><td>✓</td></tr><tr><td>4.0(16.0 GT/s)</td><td>✓</td><td>✓</td></tr></table>	Revision	Configuration	Recovery	1.0/1.1(2.5 GT/s)	✓		2.0(5.0 GT/s)	✓	✓	3.0/3.1(8.0 GT/s)	✓	✓	4.0(16.0 GT/s)	✓	✓
Revision	Configuration	Recovery														
1.0/1.1(2.5 GT/s)	✓															
2.0(5.0 GT/s)	✓	✓														
3.0/3.1(8.0 GT/s)	✓	✓														
4.0(16.0 GT/s)	✓	✓														
Test Pattern	Selects the test pattern output repeatedly from Compliance or PRBS after completing the link training sequence transmission. When Compliance is selected, selection controller of PCIe standard test pattern is displayed. When PRBS is selected, PRBS pattern stage setup controller is displayed.															
PRBS	Sets the number of the PRBS pattern stages for PPG/ED. Because PRBS pattern does not follow 8b10b or 128b130b encoding rules, a SKP pattern or a pattern for synchronization is not inserted into a PRBS pattern. Thus, the DUT in Loopback state may not recognize the pattern. To measure BER in a PRBS pattern, disable SKP Insert/Filter of the SKP items on the Option screen.															
MCP	Sets the standard test pattern of PCIe. When the 32G SI PPG is installed and the specification is set to 3.0/3.1(8.0 GT/s) or 4.0(16.0 GT/s), Jitter Meas (Jitter Tolerance Measurement Pattern) is available. Also, Jitter Meas is a pattern for calibration and cannot be used for BER measurement.															
Timeout	The window of Figure 4.8.2-3 is displayed, and timeout can be set for LTSSM that transits during link training.															
Option	The window of Figure 4.8.2-2 is displayed and proper setting of PCIe link training can be performed.															

Table 4.8.2-2 shows the setting items of Figure 4.8.2-2.

Table 4.8.2-2 Option Setup Items

Item	Description
State Machine tab	
TS Parameter	
FTS	Sets the TS FTS Number. FTS is used for locking bit and symbol when transferring from L0 to L0.
Link Number	Sets the TS Link Number.
Lane Number	Sets the TS Lane Number.
Full Swing	Displays the Full Swing value for TS.
Low Frequency	Displays the Low Frequency value for TS.
Disable Scrambling	Sets whether to use scrambling for TS.
EIEOS	
Reset Interval	Enables or disables Reset EIEOS Interval that is used in TS Recovery.Equalization State. Disable it in general cases. To use a longer PRBS pattern, enable Reset EIEOS Interval and obtain Block Alignment.
16 G Format	Sets whether to use EIEOS format of Base Spec Rev 0.7 or later. If this value is different from what DUT expects, the measuring instrument cannot transmit/receive data properly to/from DUT, because EIEOS is used for data block alignment.
Send TS	
Polling.Active	Sets the type of TS sent for Polling Active State.
Loopback.Entry	Sets the type of TS sent for Loopback Entry State.
Timeout to	When the measuring instrument is timed out in Loopback Entry State, set a LTSSM state for next transition. When Loopback.Active is set and timed out in Loopback.Entry State, the measuring instrument is forced to be in Loopback.Active State, regardless of the DUT state.
Insert Delay Symbol	Sets whether to insert Delay Symbol in MCP. It cannot be set when Specification is set to 3.0/3.1 (8.0 GT/s) or 4.0 (16.0 GT/s).
Extended Sync Patterns	Sets Normal or Extended. When set to Extended, “at least 1024 TS1 Ordered Sets are transmitted” is added to the transition conditions from Recovery.RcvrLock to Recovery.RcvrCfg.
PPG Electrical Idle Time	Sets the period of time the signal from the PPG’s Output connector is Electrical Idle before the MP1900A changes the bit rate. <1ms: Sets the Electrical Idle time to less than 1 ms. This is the Electrical Idle time specified in the PCIe Base Specification. ≥1ms: Sets the Electrical Idle time to 1 ms or more. During the period of time specified by Speed Change , the signal from the PPG’s Output connector is Electrical Idle. With this setting, you can measure the tolerance of the DUT receiver to the Electrical Idle time.

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
State Machine tab (Cont'd)	
Speed Change	<p>Sets the time for changing the bit rate by the MP1900A. It is used to check the operation of the DUT Timeout time.</p> <p>Fast: Typ. 2.0 ms</p> <p>This is used to measure a special DUT whose Timeout time in the LTSSM state for changing the bit rate is faster than the value specified in the PCIe base specifications. When this setting is selected, set SSC of the MP1900A to OFF.</p> <p>Middle: Typ. 6.5 ms</p> <p>This is the recommended setting value.</p> <p>Low: Typ. 11 ms</p> <p>This is used to check the operation of the DUT Timeout time.</p>
CBB Controller	<p>Controls the power supply to DUT connected to CBB 4.0 (Compliance Base Board) through CBB 4.0 control pins.</p> <p>This function allows you to omit manually resetting the power supply. Using this function in combination with remote commands enables the operation tests of DUT to be fully automated.</p> <p>For preparations before using this function, refer to 4.8.2.2 “About CBB Controller”.</p>
Auto Reset	<p>Allows you to select a signal type to be sent to the CBB control pins when clicking Link Start, from the following.</p> <p>Auto Power Reset: Sends a signal to reset the power supply to DUT to the CBB control pins.</p> <p>Auto Power Cycle: Sends a signal to power on or off DUT to the CBB control pins.</p> <p>No: Sends no signal to any CBB control pins after clicking Link Start.</p>
Power Reset	<p>Clicking the button sends a Power Reset signal to CBB during the specified time (seconds).</p> <p>The time specified here is also applied to the power reset time after clicking Link Start, when Auto Power Reset is selected for Auto Reset.</p>
Power Cycle	<p>Clicking the button sends a Power OFF signal to CBB during the specified time (seconds).</p> <p>The time specified here is also applied to the power off time after clicking Link Start, when Auto Power Cycle is selected for Auto Reset.</p>
Comp. Trigger	<p>Clicking the button sends a Compliance Trigger signal to CBB during the specified time (seconds).</p>
Waiting Time	<p>Allows setting the waiting time after DUT is powered on again after resetting the power supply or turning the power off by clicking Link Start. Use this function for DUT that needs a time to be stable after turning the power on.</p>




Figure 4.8.2-4 Control Flow for Link Start
(When Auto Power Reset Is Selected for Auto Reset)

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
SKP tab	Invalid when Test Pattern is set to PRBS . Symbol Length, Interval, and Double SKP can be set for 8b10b (2.5G, 5.0GT/s) and 128b130b (8.0G, 16.0GT/s) separately.
SRIS	Sets whether to operate in Separate Refclock with Independent SSC. Disable this parameter when performing link training with DUT in Common RefClock Architecture. Enable it when performing it in Separate RefClock Architecture. In general, a compliance test is performed in Common RefClock Architecture. When switching this parameter, SKP-related items are set to their recommended values respectively. The MU181000B-x02 of the MU181000B Synthesizer is required when Common Ref Clock and DUT are operated by the system (Synchronize MP1900A with Ref Clock of DUT system).
Insert	Sets whether to insert SKP OS while sending TS. It is used for compensating the bit rate difference between the measuring instrument and DUT. Disable this parameter when Test Pattern is PRBS.
Symbol Length	Specifies the SKP OS length. When the speed difference between the measuring instrument and DUT is big, for example, when operating in Separate Ref Clock, set this value bigger.
Interval	Specifies the SKP OS interval. When the speed difference between the measuring instrument and DUT is big, for example, when operating in Separate Ref Clock, set the value smaller.
Double SKP	Sets whether to insert double SKP into the test pattern (MCP) to send in Loopback Active state.
Filter	Sets whether to remove the received SKP OS. Disable this parameter when Test Pattern is PRBS.

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
PPG/ED tab	
CTLE Gain	Sets CTLE gain for PCIe 3.0 or PCIe 4.0 operation. Set CTLE gain to 0 dB for measuring systems with low insertion loss.
Tx Preset	
Tx Equalization for 2.5 GT/s	Sets the preset value at link start (in 2.5 GT/s operation).
Tx Equalization for Loopback.Active State (Auto/Manual)	<p>Selects how to set Equalization of the test pattern to send in Loopback Active state.</p> <p>Auto: Uses the Equalization figured out by Link Training (Recovery.Equalization state). The Equalization value is displayed at the location shown in “Figure 4.8.4-1 PCIe Link Training Results”.</p> <p>When Use Preset is Preset: PPG Final Preset When Use Preset is Cursor: PPG Final Cursor</p> <p>Manual: The value specified by Loopback Preset is used.</p>
Tx Equalization for Loopback.Active State	<p>Selects Equalization for Test Pattern to be sent in Loopback.Active state, from Preset, Cursor and User. This value can be selected when Manual is selected for Loopback Preset Select.</p> <p>For details of this function, refer to 4.8.7 “Configuring BER Measurement Settings for PCIe Link Training”.</p>
Trigger tab	
Trigger	Selects a trigger type.
Link Speed	Outputs trigger signal (pulse) when the measuring instrument transits to the link speed specified by this item and to the conditions specified by State or Change Preset during link training.
State	<p>Outputs trigger signal (pulse) from PPG Aux Out when the measuring instrument transits to the LTSSM State that was specified by this item during link training. This parameter is enabled when LTSSM is selected for Trigger.</p> <p>Because the pulse signal output from Aux Out changes from 0 to –1 during the transition to the specified state, set the Scope trigger to Fall Edge. When transits from the specified state to the next state, the pulse signal changes from –1 to 0. Set the Scope trigger to Rise Edge. When using the negative side of the Aux Out connector, the operation is reversed.</p>
Change Preset	<p>Outputs trigger signal (pulse) from Aux output when the measuring instrument exchanges the Change Preset signals in Link Equalization (Phase 2 or 3). It is used for measuring the time from transmission or reception of Change Preset until the Preset value is actually changed in Tx LEQ Response Test.</p> <p>It is enabled when Link EQ is selected by Trigger.</p>

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
Link EQ tab	These parameters are used after the Preset value is changed in Recovery.Equalization. They are used when Loopback through is set to Recovery on the PCIe Link Training Setup screen (Figure 4.8.1-1).
Recovery Phase2, 3	Sets whether to execute (Try) or skip (Bypass) Recovery.Equalization. When “skip” is selected, Phase2 through 4 of Recovery.Equalization are skipped.
Algorithm	Selects a method where the measuring instrument requests DUT to change Preset in Recovery.Equalization State. When Increment is selected, the measuring instrument requests DUT to increase Preset one by one. When Change Preset is selected, the measuring instrument requests DUT to change Preset directly to the value specified for Change Preset.
Repeat	Specifies a count where the measuring instrument requests DUT to change Preset in Recovery.Equalization State.
PCIe 2.0 Preset	
De-emphasis	Sets De-emphasis that is specified in TS that PPG sends and is notified to DUT. It is displayed when PCIe2.0 is selected for Specification.

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
Link EQ tab (Cont'd)	
PCIe 3.0/3.1, PCIe 4.0	
Use Preset	<p>Equalizer for DUT can be selected from Preset, Cursor, and Saved Cursor.</p> <p>Preset is used in general and Preset and Saved Cursor are used for Tx LEQ Response Test. When tested by Preset, obtain the cursor value from DUT corresponding to the specified Preset value through link equalization and saves it in Saved Cursor. Saved Cursor is used for Tx LEQ Response Test. For how to use the function, refer to 4.8.2.1 "Usepreset Saved Cursor" or 4.8.6.3 "Transmitter Link Equalization Response (Tx LEQ Response)".</p> <p>Cursor can be used for Tx LEQ Response Test by notifying DUT of the Cursor value corresponding to the Preset value hardcoded to MP1900A.</p>
Downstream*	
DUT is AIC: Starting Preset DUT is Host: Preset Hint (Tx)	<p>Starting Preset: Sets Preset of the measuring instrument at Recovery.EQ start. The measuring instrument is set to the requested Preset when receiving a Preset change request from DUT (AIC) in Recovery.EQ.Phase2.</p> <p>Preset Hint (Tx): Sets a desired Preset for transmitting DUT (System) at Recovery.EQ start. By setting Link EQ to "Try" and selecting a value for Algorithm, the operation of Recovery.EQ.Phase2 is as below.</p> <p>Increment: Tries to change the Preset value for the number of times specified for Recovery.EQ. For example, when Preset Hint is set to Preset7 and Repeat is set to 1 only Preset7 is tried. When it is set to Preset7 and Repeat is set to 3, Preset7, 8, and 9 are tried.</p> <p>Change Preset: Changes the Preset value from the value specified for Preset Hint to the value specified by Change Preset in Recovery.EQ. It is used for Rx LEQ Test.</p>
Preset Hint (Rx)	<p>Sets Receiver Preset Hint (Rx).</p> <p>Displayed only when Rev 3.x is selected.</p>
Recovery.EQ.Phase2	Enabled when DUT is Root Complex (System) and Algorithm is set to Change Preset .
Change Preset	Sets the Preset value which the measurement instrument requests DUT (System) to change from Preset Hint (Tx) value in Recovery.EQ.Phase2.

*: These values are displayed in PCIe 3.0/3.1 or PCIe 4.0.

Table 4.8.2-2 Option Setup Items (Cont'd)

Item	Description
Link EQ tab (Cont'd)	
PCIe 3.0/3.1, PCIe 4.0 (Cont'd)	
Upstream	
DUT is AIC: Preset Hint (Tx) DUT is Host: Starting Preset	Starting Preset: Sets Preset of the measuring instrument at Recovery.EQ start. Preset Hint (Tx): Sets a desired Preset for transmitting DUT (AIC) at Recovery.EQ start. By setting Link EQ to "Try" and selecting a value for Algorithm, the operation of Recovery.EQ.Phase3 is as below. Increment: Tries to change the Preset value for the number of times specified for Repeat in Recovery.EQ. For example, when Preset Hint is set to Preset7 and Repeat is set to 1, only Preset7 is tried. When it is set as Preset7 and Repeat is set to 3, Preset7, 8, and 9 are tried. Change Preset: Changes the Preset value from the value specified here to the value specified by Change Preset in Recovery.EQ. It is used for Rx LEQ Test.
Preset Hint (Rx)	Sets Receiver Preset Hint (Rx). Displayed only when Rev 3.x is selected.
Recovery.EQ.Phase3	Enabled when DUT is Endpoint (AIC) and Algorithm is set to Change Preset.
Change Preset	Sets the Preset value which the measurement instrument requests DUT (AIC) to change from Preset Hint (Tx) value in Recovery.EQ.Phase3.


Table 4.8.2-3 shows the setting items of Figure 4.8.2-3.

Table 4.8.2-3 Timeout Setup Items

Item	Description
Detect	Sets the timeout (ms) for each state.
Quiet	
Polling	
Config	
Active	
Configuration	
Linkwidth.Start	
Lanenum.Wait	
Linkwidth.Accept	
Complete	
Idle	
Recovery	
RcvrLock	
RcvrCfg	
Speed	
Idle	
Equalizaion.Phase1-3	
Equalizaion.Phase0-3 (DUT is in Root Complex)	
Loopback	
Entry (to Active)	
Entry (to Exit)	
Hotreset	
Disable	
Initialize	Resets the Timeout setting items to defaults.
Close	Closes the Timeout setup screen.

4.8.2.1 Saved Cursor

This function is to execute Transmitter Link Equalization Response Test. MP1900A keeps the cursor value corresponding to the Preset value notified from DUT during link training, and uses it to specify the Equalizer setting for DUT by cursor value. These functions are valid only in PCIe 3.0 or 4.0.

To display the Saved Cursor dialog box, click  on the **Link EQ** tab of the LEQ test or Option screen.




Figure 4.8.2.1-1 Saved Cursor Dialog Box

Saved Cursor is updated when one of the following conditions is met.

- 1 Loopback Through is set to **Recovery** on the PCIe Link Training Setup Screen (Figure 4.8.2-1).
- 2 UsePreset is set to **Preset** on the **Link EQ** tab of the Option dialog box. Also, Link EQ (Recovery Phase2, 3) is set to **Try** (See Figure 4.8.2.1-2).
- 3 When the above conditions 1 and 2 are met together, **Link Start** is clicked on the PCIe Link Training Setup Screen (Figure 4.8.2-1) and the cursor value is transmitted/received normally in Phase2 or 3 of Recovery.Equalization State.

For example, if Link Training is performed with the following settings, the Saved Cursor value of Preset0 specified at Change Preset of PCIe 4.0 is updated.




Figure 4.8.2.1-2 Preset Setting Example

When Algorithm is set to **Increment** and Repeat is set to **12** as in the figure below, The cursor values corresponding to all preset values can be updated collectively by one link training.




Figure 4.8.2.1-3 Algorithm Setting Example

When the values notified by DUT are saved, the checkboxes are selected as in the figure below.

Saved Cursor	PCIe 4.0		
	C-1	C0	C+1
<input checked="" type="checkbox"/> P0	0	18	6
<input checked="" type="checkbox"/> P1	0	20	4

Figure 4.8.2.1-4 Saved Cursor Checkboxes

The cursor values sent to/received from DUT can be checked in the LTSSM log.

State	Speed	GT/Detect	PreError	Count	Use	Preset	Preset	Pre-cursor	Cursor	Post-cursc
2 RECOVERY_EQUALIZATION_PHASE1	8	----	-----	-----	-----	-----	-----	-----	-----	-----
6 RECOVERY_EQUALIZATION_PHASE1	8	----	-----	172	-----	-----	-----	-----	-----	-----
0 RECOVERY_EQUALIZATION_PHASE2	8	0	0	0	1	7	0	24	0	0
0 RECOVERY_EQUALIZATION_PHASE2	8	1	0	0	1	7	0	24	0	0
4 RECOVERY_EQUALIZATION_PHASE3	8	0	0	0	1	6	7	56	0	0
0 RECOVERY_EQUALIZATION_PHASE3	8	1	0	0	0	6	7	56	0	0
0 RECOVERY_EQUALIZATION_PHASE3	8	1	0	0	1	7	7	45	11	11

Figure 4.8.2.1-5 LTSSM Log

How to use acquired values
Change Use Preset to **Saved Cursor** as in the following figure and start link training when the values notified by DUT are saved. This commands DUT to change the equalizer by the cursor values corresponding to the set Preset Hint and Change Preset values.




Figure 4.8.2.1-6 Link EQ Tab

To perform a test according to the compliance test, refer to 4.8.6.3 “Transmitter Link Equalization Response (Tx LEQ Response)”.

4.8.2.2 About CBB Controller

This function allows you to automatically run the operation tests of DUT by controlling the power supplies connected to CBB 4.0 through CBB 4.0 control pins without resetting the power supplies manually. Using this function in combination with remote commands enables the operation tests of DUT to be fully automated. Z2025A must be installed to use this function.

This function is assumed to control DUT through CBB 4.0 and is valid for DUT that can be implemented in CBB 4.0

This function is available only for PCIe Link Training (PL-021).

For how to activate this function, refer to the Installation Guide that came with Z2025A.

4.8.3 Starting PCIe Link Training

1. Press the PCIe Compliance Base Board reset switch before starting measurement.
2. Click **Link Start**. Link training with DUT starts.
Link Start changes to **Stop** during link training. It changes to **Unlink** when the link training is completed and the PPG status changes from Electrical Idle to Loopback Active. At that time, PPG sends a test pattern.
3. Clicking **Unlink** while the test pattern is being sent aborts the test pattern transmission, and the PPG returns to Electrical Idle status.
For how to display link success/failure or LTSSM transition log, refer to 4.8.4 “Displaying PCIe Link Training Results” and 4.8.5 “Displaying LTSSM Log of PCIe Link Training”.
4. If you wish to measure Jitter Tolerance after this, refer to 4.6 “Jitter Tolerance Test” for details of the **Run Test** tab, **Graph** tab, and **Report** tab.
5. If you wish to measure BER after this, click **BER Measurement**. For details of the BER Measurement, refer to 4.4.4 “Setting Up PCIe BER Measurement” and 4.4.5 “Starting PCIe BER Measurement”.

4.8.4 Displaying PCIe Link Training Results

After performing link training as explained in 4.8.3, the results can be displayed.




Figure 4.8.4-1 PCIe Link Training Results

Table 4.8.4-1 PCIe Link Training Result Items

Item	Description
Common Parameter	
LTSSM State	Displays LTSSM State of measuring instrument.
Linkup Speed	Displays Link Speed (2.5, 5.0, 8.0, or 16.0 GT/s).
SKP 128b/130b	
SKP Count (Rx, Tx)	Displays the SKP OS number counted during link training. Rx and Tx have separate counts
DC Balance (Rx, Tx)	Displays the polar state of DC Balance counted during link training. When the polar character of data string is unbalanced, it is counted as plus or minus. Rx and Tx have separate counts
Sync Header Error	Displays the Sync Header Error number counted during link training.
Parity Error	Displays the Parity Error number counted during link training.
Block Lock	Displays the Block Lock number counted during link training.
SKP 8b/10b	
SKP Count (Rx, Tx)	Displays the SKP OS number counted during link training. Rx and Tx have separate counts
Symbol Error	Displays the Symbol Error number counted during link training.
Current RD Error	Displays the Running Disparity number during link training.
Symbol Lock	Displays the Symbol Lock state.

Table 4.8.4-1 PCIe Link Training Result Items (Cont'd)

Item	Description
Link Equalization	Displays the Link Equalization state. Displayed when the specification is set to 3.0/3.1 or 4.0. Also, each specification has its own value.
Phase0	Displays the Link Equalization result of each phase. Phase0 is displayed when Root Complex is selected for DUT. All phases are Incomplete when one of the following conditions is met. <ul style="list-style-type: none"> • Loopback Through is set to Configuration. • Recovery and Link EQ (Recovery Phase2, 3) are set to Skip. (in case of Tx EQ Initial Test) • Transition to another phase failed due to an error.
Phase1	
Phase2	
Phase3	
ALL	
Received	
Use Preset	Displays the method (Preset or Cursor) of EQ to be used by PPG notified from the DUT.
PPG Final Preset	Displays the Preset used by PPG notified from the DUT. It is displayed only when Specification 3.0/3.1 or 4.0 is selected. When Use Preset is Preset, this value is valid.
PPG Final Cursor	Displays the Cursor sent from PPG notified from the DUT. It is displayed only when Specification 3.0/3.1 or 4.0 is selected. When Use Preset is Cursor, this value is valid.
Full Swing	Displays the Full Swing notified from the DUT.
Low Frequency	Displays the Low Frequency notified from the DUT.
Link Number	Displays the Link Number notified from the DUT.
Lane Number	Displays the Lane Number notified from the DUT.
Request Equalization	Displays the Request Equalization notified from the DUT. It is displayed when the DUT is Root Complex.
PCIe 4.0 Control SKP	
Count (Rx/Tx)	Displays the count value of Control SKP OS.
Margin Type (Rx/Tx)	Displays Margin Type in Control SKP OS.
Usage Model (Rx/Tx)	Displays Usage Model in Control SKP OS.
Payload (Rx/Tx)	Displays Margin Payload in Control SKP OS.
Receiver Number (Rx/Tx)	Displays Receiver Number in Control SKP OS.
CRC	Displays Margin CRC Error count in Control SKP OS.
Parity	Displays Margin Parity Error count in Control SKP OS.

4.8.5 Displaying LTSSM Log of PCIe Link Training

After performing link training as explained in 4.8.3, click **LTSSM Log** to display log.

The Log Data is recorded when one of the following condition is met.

- When LTSSM State is switched
- When changing Preset is requested at Recovery.Equalization State

Time [ns]	ΔTime [ns]	State	Speed[GT/s]	Detect Preset	Error Count	Use Pre...	Preset	Pre-cur...	Cursor	Post-cursor	Detail
1244122144	1936	RECOVERY_IDLE	8.0	—	—	—	—	—	—	—	00 35 00 00 00 89 00 00 00
1244124080	24	LO	8.0	—	—	—	—	—	—	—	00 41 00 00 00 89 00 00 00
1244124104	2512	RECOVERY_RCVL_LOCK	8.0	—	—	—	—	—	—	—	00 31 00 00 00 89 00 00 00
1244126616	2504	RECOVERY_RCVL_CFG_EQTS2	8.0	—	—	—	—	—	—	—	00 34 00 00 00 89 00 00 00
1244129120	8518400	RECOVERY_SPEED	8.0	—	—	—	—	—	—	—	00 32 00 00 00 89 00 00 00
1252647520	481600	RECOVERY_SPEED	16.0	—	—	—	—	—	—	—	00 32 00 05 35 00 86 00 00 00
1253129120	8	RECOVERY_RCVL_LOCK	16.0	—	—	—	—	—	—	—	00 31 00 00 00 01 86 00 00 00
1253129128	535352	RECOVERY_EQUALIZATION_PHASE1	16.0	—	—	—	—	—	—	—	00 39 00 00 00 02 86 00 00 00
1253664480	6002296	RECOVERY_EQUALIZATION_PHASE2	16.0	0	0	0	6	0	0	0	00 3A
1259666776	23009232	RECOVERY_EQUALIZATION_PHASE2	16.0	0	0	0	6	0	0	0	00 3A
1282676008	1999976	RECOVERY_EQUALIZATION_PHASE3	16.0	1	0	1	6	0	0	0	00 3B
1284675984	2000000	RECOVERY_EQUALIZATION_PHASE3	16.0	1	0	1	6	0	0	0	00 3B
1286675984	2000000	RECOVERY_EQUALIZATION_PHASE3	16.0	1	0	1	7	0	0	0	00 3B
1286675984	24	RECOVERY_EQUALIZATION_PHASE3	16.0	1	0	1	8	0	0	0	00 3B
1286676008	1504	RECOVERY_RCVL_LOCK	16.0	—	—	—	—	—	—	—	00 31 00 00 00 89 00 00 00
1286677512	552	RECOVERY_RCVL_CFG_TS2	16.0	—	—	—	—	—	—	—	00 33 00 00 00 89 00 00 00
1286678064	1536	LOOPBACK_ENTRY_MASTER_TS1	16.0	—	—	—	—	—	—	—	00 61 00 00 00 89 00 00 00
1286679600	—	LOOPBACK_ACTIVE_MASTER	16.0	—	—	—	—	—	—	—	00 64 00 00 00 89 00 00 00

Figure 4.8.5-1 LTSSM Log Viewer

Table 4.8.5-1 LTSSM Log viewer

Item	Description
Time [ns]	Displays the time the log data was acquired. The start of acquisition is zero.
ΔTime [ns]	Displays the time interval between when the log data was acquired and when next log data was acquired.
State	Displays LTSSM State.
Speed[GT/s]	Displays Link Speed [GT/s].
Detect Preset*	Displays whether the Preset information in the LTSSM log is the value sent from the MP1900A or sent from the DUT. When the value related to Preset is sent from the MP1900A, Detect Preset is 0. When the value related to Preset is sent from the DUT, Detect Preset is 1.
Error Count*	Displays error count of the following cases. <ul style="list-style-type: none"> Block synchronization is Unaligned. Parity error is detected by received TS1 OS.
Use Preset*	Displays the Use Preset value selected at Recovery.EQ State. 1 means Preset, and 0 means Cursor.
Preset*	Displays the Preset value selected at Recovery.EQ State. When Detect Preset is 0, the Preset value sent from the MP1900A to the DUT is displayed. When Detect Preset is 1, the Preset value sent from the DUT to the MP1900A is displayed.

Table 4.8.5-1 LTSSM Log viewer (Cont'd)

Item	Description
Postcursor*	Displays the Precursor value selected at Recovery EQ State.
Cursor*	When Detect Preset is 0, the Precursor/Cursor/Postcursor value notified from the MP1900A to the DUT is displayed.
Postcursor*	When Detect Preset is 1, the Precursor/Cursor/Postcursor value notified from the DUT to the MP1900A is displayed.
FS	Displays the FS and LF values notified from the DUT at Recovery.EQ State.
LF	
Export CSV	Saves logs in the csv format. This is enabled when the log decoding is completed.
Detail	Displays the management code.
Progress bar	Displays log decoding progress. It disappears when the decoding is completed.
Stop	Aborts log decoding.
Close	Closes Log Viewer.

∗: The value is displayed when the following conditions are met:
 Loopback through is set to Recovery, and DUT goes through
 Recovery.Equalization Phase3 (at End Point test) or Phase2 (at Root
 Complex test) of LTSSM State.
 Specification Rev is set to 3.0/3.1 or 4.0.

4.8.6 Executing PCIe Link Training Link Equalization Test

This is a test function to perform the following Link Equalization Tests defined in *PCI Express® Architecture PHY Test Specification Revision 3.0, Ver. 1.0* published by PCI-SIG.

- 2.3. Add-in Card Transmitter Initial TX EQ test
- 2.4. Add-in Card Transmitter Link Equalization Response Test
- 2.7. System Board Transmitter Link Equalization Response Test
- 2.10. Add-in Card Receiver Link Equalization Test
- 2.11. System Receiver Link Equalization Test

Take the following steps to perform Link Equalization Test (LEQ Test). Click the Setting checkbox next to LEQ Test on the Link Training tab to display the Setup screen.

The values set by this function are automatically applied to the parameters of this application. The general flow to use this function is as below.

- Initialize this application.
- Select a desired Specification (ex. PCIe 4.0).
- Select a desired LEQ Test and click **Apply**.
- Click **Link Start**.

4.8.6.1 Receiver Link Equalization Test (Rx LEQ)

This is a test function to perform the following tests.

- 2.10. Add-in Card Receiver Link Equalization Test
- 2.11. System Receiver Link Equalization Test

It checks that DUT is changed to the Preset value specified by the measuring instrument (Change Preset) and that the measurement result is error-free in Recovery.Equalization.Phase2 or 3.




Figure 4.8.6.1-1 Rx LEQ Tab

1. Connect the devices as the following figure.




Figure 4.8.6.1-2 DUT is Endpoint (AIC)




Figure 4.8.6.1-3 DUT is Root Complex (System)

2. Execute File > Initialize.
3. Click the **Rx LEQ** tab.
4. Set the parameters in Table 4.8.6.1-1 and click **Apply**.

Table 4.8.6.1-1 LEQ Parameters

Item	Description
Link EQ	Specify how to change Tx EQ for the DUT. Specify as follows: RxLEQ: Select Preset . Initial Tx LEQ: Can be selected only when DUT is set to AIC. Tx LEQ Response: Select Preset and click Saved Cursor .
Starting Preset	Set the Preset value that the measuring instrument uses in Recovery.Equalization.
Preset Hint Tx	Set the Preset value that the DUT uses in Recovery.Equalization.
Change Preset	Set the Preset value that the DUT changes in Recovery.Equalization.

5. Perform Link Training following 4.8.3 “Starting PCIe Link Training”.
6. It is completed when LTSSM State is Loopback.Active and the BER measurement result is “Pass”. If the result is “Fail”, change the Loopback Preset to **Manual** on the Option dialog box, and find out the Preset value to make Error Free.

- How to check Preset

When DUT is AIC, check that the Preset value is changed from Preset Hint to Change Preset in Recovery.Equalization.Phase3.

When DUT is System, check that the Preset value is changed from Preset Hint to Change Preset in Recovery.Equalization.Phase2.

Figure 4.8.6.1-4 shows an example of LTSSM Log when AIC was tested. Recovery.Equalization.Phase2 shows the Preset value that the measuring instrument is transmitting and

Recovery.Equalization.Phase3 shows the status where DUT changes from Preset Hint Tx (P6 in the figure) to Change Preset (P8).

State	Speed[GT/s]	Detect Preset	Error Count	Use Preset	Preset
0 RECOVERY_SPEED	2.5	----	----	----	----
2 RECOVERY_SPEED	8	----	----	----	----
3 RECOVERY_RCVR_LOCK	8	----	----	----	----
3 RECOVERY_EQUALIZATION_PHASE1	8	----	44959	----	----
2 RECOVERY_EQUALIZATION_PHASE2	8	1	0	0	4
0 RECOVERY_EQUALIZATION_PHASE2	8	0	0	0	4
0 RECOVERY_EQUALIZATION_PHASE3	8	1	0	1	6
0 RECOVERY_EQUALIZATION_PHASE3	8	1	0	1	8
2 RECOVERY_RCVR_LOCK	8	----	----	----	----
0 RECOVERY_RCVR_CFG_TS2	8	----	----	----	----
3 RECOVERY_IDLE	8	----	----	----	----
4 LO	8	----	----	----	----

Figure 4.8.6.1-4 Example of LTSSM Log after Rx LEQ Test for AIC
(Preset Hint Tx: P6, Change Preset: P8)

4.8.6.2 Transmitter Initial Tx EQ Test (Initial TX LEQ)

This is a test function to perform the following test.

2.3. Add-in Card Transmitter Initial TX EQ test

It skips (Bypass) Recovery.Equalization.Phase2 and 3 and checks that DUT is changed to the Preset value (Preset Hint Tx) specified by the measuring instrument using the oscilloscope.

This test is designed for AIC only, and not for the system.




Figure 4.8.6.2-1 Initial TX LEQ Tab

1. Connect the devices as the following figure.




Figure 4.8.6.2-2 Device Connection for Endpoint (AIC) and Target Initial TX LEQ Test

2. Execute File > Initialize.
 3. Click the **Initial TX LEQ** tab.
 4. Set parameters in Table 4.8.6.1-1 (Change Preset is unnecessary for this test) and click **Apply**.
 5. Perform Link Training following 4.8.3 “Starting PCIe Link Training”.
 6. Check that LTSSM State is Loopback.Active and the BER measurement result is Error Free.
 7. Save the output signal at real-time oscilloscope*1 (Timedivision 10 us) under the above conditions.
 8. Perform Steps 3 through 5 for **P0** to **P9** of DUT Initial Preset.
 9. Using SIGTEST*udge the result of every Preset waveform saved by real-time oscilloscope.
- *1: Use the scope that meets the following performance or above. Also, this value can be changed depending on the PCIe specification trend.
- Gen3: 4ch, Bandwidth: 13 GHz, Sampling rate: 40GS/s
- Gen4: 4ch, Bandwidth: 25 GHz, Sampling rate: 80GS/s
- *2: SIGTEST is available on the PCI-SIG website. For how to use SIGTEST, refer to the SIGTEST manual.

4.8.6.3 Transmitter Link Equalization Response (Tx LEQ Response)

This is a test function to perform the following tests.

2.4. Add-in Card Transmitter Link Equalization Response Test

2.7. System Board Transmitter Link Equalization Response Test

These tests are to measure the response time from a preset change request from the measuring instrument to DUT until DUT's actual change to the specified value (Change Preset) and to measure the changed waveform amplitude to check if they meet the specifications. They are measured in Recovery.Equalization.Phase2 and 3 using the oscilloscope.

Tx LEQ Response is performed with Link EQ set to **Preset** and **Saved Cursor**. When starting a test with Link EQ set to **Preset** only, the cursor values corresponding to Preset are notified from DUT, and they are saved in MP1900A. Thus, perform the test with Link EQ set to Preset only first and then perform it with the settings of **Saved Cursor**.




Figure 4.8.6.3-1 Tx LEQ Response Tab

1. Connect the devices as the following figure.




Figure 4.8.6.3-2 DUT is Endpoint (AIC)




Figure 4.8.6.3-3 DUT is Root Complex (Host)

2. Execute File > Initialize.
3. Click the **Tx LEQ Response** tab and set LinkEQ to **Preset**.
4. Set DUT Target Preset to **P0** and click **Apply**.
5. Set the measurement start (trigger waiting) on real-time oscilloscope (Time division 100 ns).
6. Perform Link Training following 4.8.3 “Starting PCIe Link Training”.
7. Check that LTSSM State is Loopback.Active and the waveform is captured by real-time oscilloscope*.
8. Check the time from the trigger start until DUT Preset change by the Marker function. It is “Pass” if the time is 500 ns or under.
9. Capture waveforms by scope in the same manner as described in 4.8.6.2 “Transmitter Initial Tx EQ Test (Initial TX LEQ)”.

10. Change DUT Target Preset (Step 4) to **P1** to **P9** by turns and perform Steps 4 through 9 respectively. When this test is completed, the cursor value corresponding to the Preset value notified from DUT is saved inside the MP1900A.
 11. Set Link EQ to **Saved Cursor** (Step 3) and repeat Steps 4 through 10.
- *: Use the scope that meets the following performance or above. Also, this value can be changed depending on the PCIe specification trend.
- Gen3: 4ch, Bandwidth: 13 GHz, Sampling rate: 40GS/s
- Gen4: 4ch, Bandwidth: 25 GHz, Sampling rate: 80GS/s

4.8.7 Configuring BER Measurement Settings for PCIe Link Training

The BER Measurement function is enabled when all of the following conditions are met:

- Link Training is complete.
- PPG is in Loopback.Active state.
- ED is installed.

Select the **Configure** check box, and you will see the BER Measurement Setup screen.

For how to start the BER measurement, refer to 4.4.5, “Starting PCIe BER Measurement”.





Figure 4.8.7-1 PCIe BER Measurement Setup Screen

This setup screen has the same functions as 4.4.4, “Setting Up PCIe BER Measurement”. Refer to Table 4.4.4-1 to Table 4.4.4-3. Click on  at the upper right of the screen to show the area for configuring PPG Equalization settings.

PCle 4.0

CTLE Gain [dB] 0

EC Threshold 1

Pass/Fail

Cycle Single

Gating Time 1 [s]

Switch To Manual BER Test

Total BER

Total Error Count

Total Bits

Current BER

Sync Loss

Clock Loss

Preset

Auto

BER Measurement

P7 : -6.0, 3.5

Figure 4.8.7-2 Equalization Setup Screen (Preset)

PCle 4.0

CTLE Gain [dB] 0

EC Threshold 1

Pass/Fail

Cycle Single

Gating Time 1 [s]

Switch To Manual BER Test

Total BER

Total Error Count

Total Bits

Current BER

Sync Loss

Clock Loss

Cursor

Manual

BER Measurement

Coefficient

C-1 0 0.0000 PS 0.0 dB

C0 16 0.6667 DE -9.5 dB

C+1 8 0.3333 Boost 9.5 dB

	C+1	0/24	1/24	2/24	3/24	4/24	5/24	6/24	7/24	8/24
C-1		0.0000	0.0417	0.0833	0.1250	0.1667	0.2083	0.2500	0.2917	0.3333
0/24	0.0000	0.0, 0.0	0.0, -0.8	0.0, -1.6	0.0, -2.5	0.0, -3.5	0.0, -4.7	0.0, -6.0	0.0, -7.6	0.0, -9.5
1/24	0.0417	0.8, 0.0	0.8, -0.8	0.9, -1.7	1.0, -2.8	1.2, -3.9	1.3, -5.3	1.6, -6.8	1.9, -8.8	
2/24	0.0833	1.6, 0.0	1.7, -0.9	1.9, -1.9	2.2, -3.1	2.5, -4.4	2.9, -6.0	3.5, -8.0		
3/24	0.1250	2.5, 0.0	2.8, -1.0	3.1, -2.2	3.5, -3.5	4.1, -5.1	4.9, -7.0			
4/24	0.1667	3.5, 0.0	3.9, -1.2	4.4, -2.5	5.1, -4.1	6.0, -6.0				
5/24	0.2083	4.7, 0.0	5.3, -1.3	6.0, -2.9	7.0, -4.9					
6/24	0.2500	6.0, 0.0	6.8, -1.6	8.0, -3.5						

Figure 4.8.7-3 Equalization Setup Screen (Cursor)

PCle 4.0

CTLE Gain [dB] 0

EC Threshold 1

Pass/Fail

Cycle Single

Gating Time 1 [s]

Switch To Manual BER Test

Total BER

Total Error Count

Total Bits

Current BER

Sync Loss

Clock Loss

User

Manual


BER Measurement

PS 0.0 dB

DE 0.0 dB

Figure 4.8.7-4 Equalization Setup Screen (User)

Table 4.8.7-1 Equalization Setting Items

Item	Description																																																																																																																			
	Shows and hides the area where you can configure settings for PPG Equalization.																																																																																																																			
Auto / Manual	<p>Selects the PPG Equalization setup mode. To switch to Auto, click Apply shown in “Figure 4.8.6.1-1 Rx LEQ Tab”, “Figure 4.8.6.2-1 Initial TX LEQ Tab”, or “Figure 4.8.6.3-1 Tx LEQ Response Tab”.</p> <p>Auto: Automatically sets the value requested from the DUT in Recovery.Equalization Phase2/3 state, for the PPG.</p> <p>Manual: Sets the PPG Equalization via the MX183000A GUI. Select this mode for searching for the Equalization optimal for the DUT's receiver after Loopback.Active.</p>																																																																																																																			
Equalization type	<p>Selects the PPG Equalization setup mode.</p> <p>When Auto is selected at Auto / Manual, this is set automatically and cannot be changed.</p>																																																																																																																			
Preset (Figure 4.8.7-2)	Sets the level of Equalization signal output from the PPG by selecting from the drop-down menu under Preset . Range: Preset 0 to 10																																																																																																																			
Cursor (Figure 4.8.7-3)	<p>Sets the level of Equalization signal output from the PPG by selecting a cursor (white cell, calculated with Full Swing set to 24) in the table.</p> <p>When a cell is clicked, its background color turns blue and the Coefficient values are changed.</p> <table border="1"><thead><tr><th></th><th>C+1</th><th>0/24</th><th>1/24</th><th>2/24</th><th>3/24</th><th>4/24</th><th>5/24</th><th>6/24</th><th>7/24</th><th>8/24</th></tr></thead><tbody><tr><th>C-1</th><td></td><td>0.0000</td><td>0.0417</td><td>0.0833</td><td>0.1250</td><td>0.1667</td><td>0.2083</td><td>0.2500</td><td>0.2917</td><td>0.3333</td></tr><tr><th>0/24</th><td>0.0000</td><td>0.0, 0.0</td><td>0.0, -0.8</td><td>0.0, -1.6</td><td>0.0, -2.5</td><td>0.0, -3.5</td><td>0.0, -4.7</td><td>0.0, -6.0</td><td>0.0, -7.6</td><td>0.0, -9.5</td></tr><tr><th>1/24</th><td>0.0417</td><td>0.8, 0.0</td><td>0.8, -0.8</td><td>0.9, -1.7</td><td>1.0, -2.8</td><td>1.2, -3.9</td><td>1.3, -5.3</td><td>1.6, -6.8</td><td>1.9, -8.8</td><td></td></tr><tr><th>2/24</th><td>0.0833</td><td>1.6, 0.0</td><td>1.7, -0.9</td><td>1.9, -1.9</td><td>2.2, -3.1</td><td>2.5, -4.4</td><td>2.9, -6.0</td><td>3.5, -8.0</td><td></td><td></td></tr><tr><th>3/24</th><td>0.1250</td><td>2.5, 0.0</td><td>2.8, -1.0</td><td>3.1, -2.2</td><td>3.5, -3.5</td><td>4.1, -5.1</td><td>4.9, -7.0</td><td></td><td></td><td></td></tr><tr><th>4/24</th><td>0.1667</td><td>3.5, 0.0</td><td>3.9, -1.2</td><td>4.4, -2.5</td><td>5.1, -4.1</td><td>6.0, -6.0</td><td></td><td></td><td></td><td></td></tr><tr><th>5/24</th><td>0.2083</td><td>4.7, 0.0</td><td>5.3, -1.3</td><td>6.0, -2.9</td><td>7.0, -4.9</td><td></td><td></td><td></td><td></td><td></td></tr><tr><th>6/24</th><td>0.2500</td><td>6.0, 0.0</td><td>6.8, -1.6</td><td>8.0, -3.5</td><td></td><td></td><td></td><td></td><td></td><td></td></tr></tbody></table> <p>Also, in the numerical value boxes below, C-1 can be set in the range of 0 to 6 and C+1 in the range of 0 to 8. C0 cannot be set because it is calculated automatically from C-1 and C+1.</p> <p>Depending on the selected cursor, the Coefficient, PS, DE and Boost values vary.</p> <table><thead><tr><th colspan="4">Coefficient</th></tr></thead><tbody><tr><td>C-1</td><td><input type="text" value="0"/></td><td><input type="text" value="0.0000"/></td><td>PS <input type="text" value="0.0"/> dB</td></tr><tr><td>C0</td><td><input type="text" value="16"/></td><td><input type="text" value="0.6667"/></td><td>DE <input type="text" value="-9.5"/> dB</td></tr><tr><td>C+1</td><td><input type="text" value="8"/></td><td><input type="text" value="0.3333"/></td><td>Boost <input type="text" value="9.5"/> dB</td></tr></tbody></table>		C+1	0/24	1/24	2/24	3/24	4/24	5/24	6/24	7/24	8/24	C-1		0.0000	0.0417	0.0833	0.1250	0.1667	0.2083	0.2500	0.2917	0.3333	0/24	0.0000	0.0, 0.0	0.0, -0.8	0.0, -1.6	0.0, -2.5	0.0, -3.5	0.0, -4.7	0.0, -6.0	0.0, -7.6	0.0, -9.5	1/24	0.0417	0.8, 0.0	0.8, -0.8	0.9, -1.7	1.0, -2.8	1.2, -3.9	1.3, -5.3	1.6, -6.8	1.9, -8.8		2/24	0.0833	1.6, 0.0	1.7, -0.9	1.9, -1.9	2.2, -3.1	2.5, -4.4	2.9, -6.0	3.5, -8.0			3/24	0.1250	2.5, 0.0	2.8, -1.0	3.1, -2.2	3.5, -3.5	4.1, -5.1	4.9, -7.0				4/24	0.1667	3.5, 0.0	3.9, -1.2	4.4, -2.5	5.1, -4.1	6.0, -6.0					5/24	0.2083	4.7, 0.0	5.3, -1.3	6.0, -2.9	7.0, -4.9						6/24	0.2500	6.0, 0.0	6.8, -1.6	8.0, -3.5							Coefficient				C-1	<input type="text" value="0"/>	<input type="text" value="0.0000"/>	PS <input type="text" value="0.0"/> dB	C0	<input type="text" value="16"/>	<input type="text" value="0.6667"/>	DE <input type="text" value="-9.5"/> dB	C+1	<input type="text" value="8"/>	<input type="text" value="0.3333"/>	Boost <input type="text" value="9.5"/> dB
	C+1	0/24	1/24	2/24	3/24	4/24	5/24	6/24	7/24	8/24																																																																																																										
C-1		0.0000	0.0417	0.0833	0.1250	0.1667	0.2083	0.2500	0.2917	0.3333																																																																																																										
0/24	0.0000	0.0, 0.0	0.0, -0.8	0.0, -1.6	0.0, -2.5	0.0, -3.5	0.0, -4.7	0.0, -6.0	0.0, -7.6	0.0, -9.5																																																																																																										
1/24	0.0417	0.8, 0.0	0.8, -0.8	0.9, -1.7	1.0, -2.8	1.2, -3.9	1.3, -5.3	1.6, -6.8	1.9, -8.8																																																																																																											
2/24	0.0833	1.6, 0.0	1.7, -0.9	1.9, -1.9	2.2, -3.1	2.5, -4.4	2.9, -6.0	3.5, -8.0																																																																																																												
3/24	0.1250	2.5, 0.0	2.8, -1.0	3.1, -2.2	3.5, -3.5	4.1, -5.1	4.9, -7.0																																																																																																													
4/24	0.1667	3.5, 0.0	3.9, -1.2	4.4, -2.5	5.1, -4.1	6.0, -6.0																																																																																																														
5/24	0.2083	4.7, 0.0	5.3, -1.3	6.0, -2.9	7.0, -4.9																																																																																																															
6/24	0.2500	6.0, 0.0	6.8, -1.6	8.0, -3.5																																																																																																																
Coefficient																																																																																																																				
C-1	<input type="text" value="0"/>	<input type="text" value="0.0000"/>	PS <input type="text" value="0.0"/> dB																																																																																																																	
C0	<input type="text" value="16"/>	<input type="text" value="0.6667"/>	DE <input type="text" value="-9.5"/> dB																																																																																																																	
C+1	<input type="text" value="8"/>	<input type="text" value="0.3333"/>	Boost <input type="text" value="9.5"/> dB																																																																																																																	
User (Figure 4.8.7-4)	<p>Sets Tx Equalization level of the PPG while finely adjusting in the following ranges:</p> <p>PS: 0 to 20 dB, 0.1 dB step</p> <p>DE: -20 to 0 dB, 0.1 dB step</p> <p>You will receive a warning if the emphasis peak voltage is out of the range due to these settings.</p> <div><div>UserManualBER Measurement</div><div>PS20.0 dB0.1 Vpp Limit Under</div><div>DE0.0 dB</div></div>																																																																																																																			

4.8.8 PCIe Link Training Matrix Scan

Matrix Scan automatically performs the BER measurement of the cursor value in Loopback.Active state after it completes link training.

Click the **Matrix Scan** on the PCIe Link Training Setup Screen (Figure 4.8.1-1) to display the setup screen.




Figure 4.8.8-1 Matrix Scan Setup Screen

Table 4.8.8-1 Matrix Scan Setting Items

Item	Description
Start	<p>Starts the Matrix Scan measurement.</p> <p>When one of the following conditions is met, the dialog box appears to prompt you to reset DUT. In that case, reset DUT and click OK in the dialog box.</p> <ul style="list-style-type: none"> • CBB Controller is invalid. (Z2025A is not connected) • CBB Controller is set to No. <p>Link training starts in ascending order from the smallest Starting Preset selected by PPG Starting Preset. If DUT enters Loopback.Active state as a result of the link training, Matrix Scan starts subsequently.</p> <p>When Matrix Scan of one Preset has completed, link training starts at the next Starting Preset and Matrix Scan follows.</p> <p>When you interrupt the scan and click the Start again, you can select whether to clear the measurement results before resuming the measurement.</p>
BER Meas. time [sec]	<p>Sets the BER measurement time for each condition.</p> <p>Setting Range: 1 to 300 sec 1 sec/step</p>
Relax time [sec]	<p>Sets the time from SI PPG cursor setting to BER measurement start.</p> <p>Setting Range: 0 to 60 sec 1 sec/step</p>
Loopback Through	<p>Sets the LTSSM route to pass through until DUT enters Loopback Active state.</p>
PPG Starting Preset	<p>Selects PPG Starting Preset for performing link training before Matrix Scan starts.</p> <p>All ON: Sets all Presets to ON.</p> <p>All OFF: Sets all Presets to OFF.</p> <p>P0 to P10: Starts link training after setting the selected Preset as SI PPG Starting Preset. The Matrix Scan results for Starting Presets are displayed in the result area.</p> <p>If you start the measurement without selecting any Preset, P7 is selected automatically.</p>
CBB Controller	<p>Controls the power supply to DUT connected to CBB 4.0 (Compliance Base Board) through CBB 4.0 control pins. This function allows you to omit manually resetting the power supply. Refer to the description of CBB Controller in Table 4.8.2-2 “Option Setup Items”.</p>
Search Direction	<p>Sets the order of cells in which Matrix Scan is performed.</p> <p>Horizontal: Performs measurement horizontally in the C–1, C+1 order as [0,0], [0,1], [0,2]…[0,8], [1,0], [1,1], [1,2]… .</p> <p>Vertical: Performs measurement vertically in the C–1, C+1 order as [0,0], [1,0], [2,0]…[6,0], [0,1], [1,1], [2,1]… .</p> <p>Boost: Performs measurement making the same boost values; in the C–1, C+1 order as [0,0], [0,1], [1,0], [0,2], [1,1], [2,0], [0,3], [1,2], [2,1], [3,0]… .</p>

Table 4.8.8-1 Matrix Scan Setting Items (Cont'd)

Item	Description
Full Scan	Selecting the checkbox starts Matrix Scan from the cell whose C-1, C+1 is zero (top-left cell). Clearing the checkbox starts Matrix Scan from the cell selected by Matrix in the Matrix Scan area.
FS (Full Swing)	Select 24, 48, or 63. Different from Full Swing on the Option screen, the value is used for creating a cursor matrix table in Loopback.Active state after link training is completed. The bigger the Full Swing value becomes, the bigger the matrix table becomes. This allows specifying the cursor value in more detailed steps.
LF (Low Frequency)	The value is set automatically according to FS. 8, 16, and 21 are set when FS is 24, 48, and 63 respectively.
Arrow Keys	Selects a cell on the matrix.
Report	When the measurement is completed, a report file can be saved in csv or html format. If you want to save a table with colors, use html format.
Close	Closes the Matrix Scan Setup Screen.

Table 4.8.8-2 Matrix Scan Display Area

Item	Description
Matrix (Details)	Displays the scan result of Starting Preset selected by Display. PS: Displays Pre Shoot value figured out from the cursor value of the selected cell. DE: Displays De Emphasis value figured out from the cursor value of the selected cell. Boost: Displays Boost value figured out from the cursor value of the selected cell. EC: Displays the Error Count measurement result of the selected cell. BER: Displays the BER measurement result of the selected cell.
Matrix (Overview)	The result of the entire matrix can be checked by colors. Clicking the specific cell changes the color of the corresponding cell on Matrix (Overview).
Legend	Displays the correspondence between Matrix cell colors and BER values.
Status Area	Displays the measurement details with statuses.
Elapsed Time	Displays the elapsed time from the start of measurement.
Remaining Time	Displays the assumed remaining time until the measurement ends.

4.9 PAM4 Control

4.9.1 Selecting Equipment to Use

This section explains selection of equipment to use for PAM4 Control. For details of MP1800A/MP1900A search, refer to 4.3.2 “Connecting Measurement Equipment”.




Figure 4.9.1-1 Equipment Setup Screen (when G0375A is selected)




Figure 4.9.1-2 Equipment Setup Screen (when G0375A + Combiner is selected)

Table 4.9.1-1 Equipment Setup Items

Item	Description
Converter	Selects a PAM4 Converter. Select equipment that is actually connected. G0375A: For generating linear PAM4 signal. G0375A+J1735A Combiner: For generating non-linear PAM4 signal.
G0375A Number Selector	Select a number of PAM4 converters to use. Up to 4 units can be controlled. A 32G PPG or SI PPG is required for each G0375A to be controlled.
Jitter	Selects whether to use MU181500B. When MU181500B is selected and MX183000A PL001 Jitter Tolerance Test is installed, the Jitter Tolerance measurement of PAM4 signal is available.
Input1&2 Input1&Combiner1	Selects PPG for Data1 (MSB) and Data2 (LSB). The selections are MU195020A, MU183020A, and MU183021A.
Combiner2	Selects PPG for Data3 to generate non-linear PAM4 signal. The selections are MU195020A, MU183020A, and MU183021A. It is enabled only when G0375A+Combiner is selected for Converter.
Use Noise Generator	Selects whether to use MU195050A. It is available only when G0375A is selected for Converter and MU195020A is used as PPG.
ED	Selects ED for Data1 (MSB) and Data2 (LSB). The selections are MU195040A, MU183040B, and MU183041B.
Extenal Att	Sets a value for the external attenuator connected between PPG and the converter. The following is recommended attenuator values* for PPGs. Select a value corresponding to the actually connected attenuator. MU195020A: 0 dB (linear/non-linear) MU18302xA (Option x12/x22): 0 dB (linear/non-linear) MU18302xA (Option x13/x23): 6 dB (linear), 0 dB (non-linear) However, when PPG:MU195020A and Noise: MU195050A are selected, the MU195050A's internal loss of 3.3 dB is added to the external attenuator value.
G0376A	Selects a G0376A Decoder.

*: The recommended attenuator value between PPG and the converter maximizes the amplitude variable range of G0375A PAM4 signal.
When the selected value for the External Att and the actually connected attenuator do not match, the screen settings and output signals will not match.

Operation

Operation



Operation

Table 4.9.2-1 PAM4 Transmitter Setup Items

Item	Description
Screen Display Selector	Changes the screen display. TX1 to 4: Displays the transmission setting. RX: Displays the reception setting.
PAM4/NRZ	Switches the transmission signal between PAM4 and NRZ. Default: PAM4
Variable Eye* ¹	Selects Eye to enlarge. Enlarge Upper Eye: Enlarges the upper part of Non-Linear Eye. Variable Middle Eye: Enlarges the Middle Eye. Enlarge Lower Eye: Enlarges the lower part of Non-Linear Eye. Default: Enlarge Upper Eye
Output	Outputs the set waveform. Default: OFF
Emphasis Setting	When MU195020A (with MU195020A-x21) is used as PPG, the Emphasis Setting is available for Middle Eye (MSB), Upper/Lower Eye (LSB), and Non-Linear Eye. To display the Emphasis Setting screen of Data1 (Middle Eye), Data2 (Upper/Lower Eye), or Data3 (Non Linear Eye) of MU195020A, click the corresponding button.
Tracking	Sets tracking for the Emphasis Setting of PPG Data1 and 2. When set to On, Data1 and 2 have common values in the Emphasis Setting. Default: OFF
Data Delay	Sets Delay of PAM4 waveform. –64000 to +64000 mUI 2 mUI step Default: 0 mUI
Eye Skew	Turns On/Off the output of PPG Data1 (MSB), Data2 (LSB), or Data3 (non-linear) to input to the converter and the Skew adjustment between channels. Data1-Middle EYE: Data1 output and skew setting. Data2-Upper&Lower EYE: Data2 output and skew setting. Data3-Non Linear EYE: Data3 output and skew setting.
Baudrate	Displays Baudrate of PAM4 signal.
Pattern* ²	Sets TX pattern and RX pattern.
Pattern Tracking	Applies the TX pattern of the selected PPG to all PPGs.
Default	Restore the Transmitter setting to default.
Screen Size Selector	Switches the screen size. Full: Displays two interfaces. Half: Displays one interface.

*1: When G0375A is selected for Converter on the Equipment Setup screen, only Variable Middle Eye can be set.

*2: When G0376A is not selected for Decoder on the Equipment Setup screen, the RX pattern is not set.

4.9.3 Setting Ratio for PAM4 Transmission Waveform Amplitude

This section explains how to set the ratios for the total amplitude and each eye of PAM4 signal to transmit.




Figure 4.9.3-1 PAM4 Transmitter Dialog Box

Table 4.9.3-1 PAM4 Transmitter Setup Items in the Dialog Box

Item	Description
Total Amplitude [mV]	Sets PAM4 total amplitude. The setting range depends on the PPG, Ext. ATT, Converter, presence of noise, and Variable Eye Setting. Table 4.9.3-2 shows the Total Amplitude setting range according to the conditions.
2 Level [mV]*	Sets 2 Level amplitude as PAM4 Symbol. When Total Amplitude is changed, 2 Level adjusts itself so that the Eye ratio stays the same. If the same value cannot be set, it is rounded to the closest possible value. The setting range depends on the PPG, Ext. ATT, Converter, presence of noise, and Variable Eye Setting.
1 Level [mV]*	Sets 1 Level amplitude as PAM4 Symbol. When Total Amplitude is changed, 1 Level adjusts itself so that the Eye ratio stays the same. If the same value cannot be set, it is rounded to the closest possible value. The setting range depends on the PPG, Ext. ATT, Converter, presence of noise, and Variable Eye Setting.
Eye Amplitude[mV], [%] (calculated value)	Displays the calculated value of 0 Level and 3 Level in [mV]. Also, displays the Amplitude monitor value of Upper/Middle/Lower Eye in [mV] [%]. Table 4.9.3-3 shows the Eye ranges [%].

∗: When Variable Middle Eye is set, editing 2 Level amplitude changes 1 Level amplitude simultaneously so that Upper Eye and Lower Eye will have the same amplitude.

Table 4.9.3-2 G0375A Total Amplitude Setting Range

Converter	PPG	Ext. ATT (dB)	Total Amplitude (mV)	Recommended Ext.ATT
G0375A	MU18302xA (option x12/x22)	0	1500 to 2200	—
		6	754 to 1502	✓
	MU18302xA (option x13/x23)	0	1500 to 2200	—
		6	754 to 2200	✓
	MU195020A	0	300 to 1950	—
		6	154 to 976	✓
G0375A + J1735A Combiner (Enlarge Upper/Lower Eye)	MU18302xA (option x12/x22)	0	910 to 2200	✓
		6	458 to 1142	—
	MU18302xA (option x13/x23)	0	910 to 2200	✓
		6	458 to 2000	—
	MU195020A	0	182 to 1482	✓
		6	94 to 742	—
G0375A + J1735A Combiner (Variable Middle Eye)	MU18302xA (option x12/x22)	0	750 to 1506	✓
		6	378 to 752	—
	MU18302xA (option x13/x23)	0	750 to 2200	✓
		6	378 to 1320	—
	MU195020A	0	150 to 978	✓
		6	78 to 488	—
G0375A+Noise	MU195020A	3.3*	106 to 1332	✓

*: When using G0375A+MU195020A+Noise, the recommended Ext ATT is the Noise module attenuation (3.3 dB).

Table 4.9.3-3 Upper/Middle/Lower Eye Ranges

Variable Eye Setting	Upper Eye Range	Middle Eye Range	Lower Eye Range
Enlarge Upper Eye	35 to 50%	20 to 35%	20 to 30%
Variable Middle Eye	20 to 40%	20 to 60%	20 to 40%
Enlarge Lower Eye	20 to 30%	20 to 35%	35 to 50%

Operation

Operation



Operation

Table 4.9.4-1 PAM4 Receiver Setup Items

Item	Description
Decoder Setting	Setting for G0376A Decoder.
Data* ¹	CTLE gain setting for Data. –12.0 to 0.0 dB, 0.1 dB step Default: 0.0 dB
XData* ¹	CTLE gain setting for XData. –12.0 to 0.0 dB, 0.1 dB step Default: 0.0 dB
Tracking	Tracking setting for CTLE Data and XData Input. When set to On, the gain values of Data and XData will be the same. Default: ON
Input Mode	Selects the input mode for Decoder Input. Differential, Single Ended Default: Differential
DFF	Turns On/Off the DFF inside the decoder. When the DFF is On, input the PPG Fullrate clock signal to the Clock Input connector. Default: ON
Auto Search Setting	Setting for searching the optimal parameters for reception.
Search State	Displays what is being processed in Auto Search.
CTLE Auto Search	Sets whether to search CTLE in Auto Search. Default: OFF
Short Time Search	Sets whether to perform the optimal Vref search with shortened sequence in Auto Search. Default: ON
Start PAM Auto Search* ²	Clicking the button starts Auto Search for the optimal Vref value of PAM4 signal. When DFF is On, the DFF Delay search is performed. When the CTLE search is selected, the CTLE optimal search is also performed.
Vref Setting	Vref setting for PAM4 signal.
Middle/Upper/Lower Vref Setting.	Vref is set for Middle, Upper, and Lower individually. Upper: –0.400 to 0.400 V, 0.001 V step Default: 0.100 V Middle: –0.400 to 0.400 V, 0.001 V step Default: 0.000 V Lower: –0.400 to 0.400 V, 0.001 V step Default: –0.100 V Note that the setting for Lower is invalid when Tracking is ON. POS value can be edited, but NEG value is read-only.
Upper/Lower Vref Tracking	Tracking setting for Upper and Lower Vref. When it is On, the Upper and Lower values work in positive and negative symmetrically. Example) Upper: +0.050 mV, Lower: –0.050 mV Default: ON

*1: When CTLE Gain is 0 dB, it is recommended to input the signal directly to the G0376A Decoder without using CTLE Input/Output.

*2: PAM4 Auto Search is available only if PAM4 signal is equivalent to AC, meaning Middle Vref is around 0.000 V.

Table 4.9.4-1 PAM4 Receiver Setup Items (Cont'd)

Item	Description
Others	Displays other parameters.
Pair PPG	Set the same pattern as the selected TX for RX.
BER Result	Clicking the button minimizes the MX183000A screen and displays the result screen of ED that is used for the BER measurement.
Baud Rate	Displays the Baud rate of PAM4 signal.
G0376A SN	Displays a serial number of the connected G0376A.

4.9.5 BER measurement using PAM4 Control

This section explains the procedure to connect and set up devices as the module configuration described in 3.5.1 “Connection for transmitting and receiving linear PAM4 signal” as an example.

1. Start MX183000A and select **PAM4 Control** on the Figure 4.3.1-1 Selector Screen. Then select equipment to use on the Equipment Setup Screen (Before Starting Search) (Figure 4.3.2-1).

Jitter:	MU181500B
Noise:	MU195050A
PPG:	MU195020A
Converter:	G0375A
Ext. ATT:	0 dB
ED:	MU195040A
Decoder:	G0376A

Select the equipment above and click **Connect**.

2. Select a test pattern to use for the measurement. Select **GrayPRBS13Q-IEEE200G_400G [Draft2]** in this case.
3. Refer to 4.9.2 “PAM4 Transmitter Setup Screen” and 4.9.3 “Setting Ratio for PAM4 Transmission Waveform Amplitude”, and set PAM4 signal amplitude. If clicking **Emphasis Setting** and editing the MU195020A setting, or if going back to the MU195020A screen after clicking **Operate MP1800A/MP1900A** and editing other module setting, click **Return to MX183000A** on the Operating dialog box. When the PAM4 waveform setting is completed, set **Output** to **ON**. Additionally, before **Output** is set to **ON**, it is recommended to check the amplitude by oscilloscope to make sure it is good for DUT input.
4. After inputting the DUT output to CTLE Input of G0376A, refer to 4.9.4 “PAM4 Receiver Setup Screen” and set CTLE and Decoder. Clicking **Start PAM Auto Search** starts the optimal Vref search of each Eye.
5. The status of BER measurement can be checked on the MU195040A screen by clicking **Operate MP1800A/MP1900A**. After starting the measurement, the 2ch combination results that MU195040A displays are the total BER measurement results of PAM4 signal. The BER measurement result of Data1 is for MSB and Data2 is for LSB. Displaying All Channel screen of MU195040A is convenient to check the results of Data1 and Data2.

6. If set to RX, only Receiver Setup Screen is displayed on the MU195040A. It is convenient to adjust the Vref of each eye in detail seeing the BER measurement results of ED.




Figure 4.9.5-1 PAM4 RX Setup Screen and SI ED Result Screen

4.10 USB Link Training

4.10.1 USB Link Training Setup Screen

On the **Link Training** tab, you can view the following USB Link Training settings. The references for each setup area are shown in the figure.




Figure 4.10.1-1 USB Link Training Setup Screen

For details of menus and abbreviations on the above screen, refer to 4.5.1 “USB Link Sequence Setup Screen”, since they are common in these screens.

4.10.2 USB Link Training Setup

This section explains how to set the link training parameters and test patterns for USB measurement.




Figure 4.10.2-1 USB Link Training Setup Screen

Click **Option** (see Figure 4.10.2-1) to display the USB Link Training Option dialog box (Figure 4.10.2-2).




Figure 4.10.2-2 USB Link Training Option Dialog Box

Table 4.10.2-1 USB Link Training Setup Items

Item	Description
Specification	Select and set the USB specification from Gen1 (5.0 GT/s) and Gen2 (10.0 GT/s). When installing MU181000A/B, set Operation Bitrate of 32G PPG to Gen1: 5.0 GT/s, Gen2: 10.0 GT/s respectively.
Not Wait for The LFPS Signal	When this item is checked, link training will start immediately after clicking Start Link Training . If Start Link Training is clicked without checking this item, the application waits to receive the LFPS signal from the DUT.
LTSSM Log	Open the screen that displays log captured during training. For details, refer to 4.10.4 “Displaying USB Link Training Results”.
Send Ping LFPS	When this button is clicked, Ping LFPS signal is output.
Test Pattern	After completing the transmission of the link training sequence, select the test pattern that is repeatedly output at the end from Compliance/USER. When Compliance is selected, USB standard test pattern selection controller is displayed. When USER is selected, the test pattern sent to 32G SI PPG with MX190000A is set. When Compliance is set, a pattern corresponding to the condition for 32G SI PPG is set. Selectable value changes depending on the value set for Specification.

Table 4.10.2-2 shows the setting items in Figure 4.10.2-2.

Table 4.10.2-2 Option Setting Items

Item	Description
SKP	
Insert	Sets whether to insert SKP OS while transmitting TS.
Filter	Sets whether to remove SKP OS at the BER measurement.
Symbol Length	Specifies the SKP OS length.
Interval	Specifies the SKP OS interval.
Double SKP	Sets whether to insert double SKP into the test pattern (CP/MCP) to send at Loopback Active.
LTSSM	
Polling.LFPS Transition Delay	When Enable is selected: You can set a time after BERT receives LFPS from DUT and before it transits to the Polling.LFPS state. The time can be set in ms units. When Disable is selected: LFPS from DUT is received by BERT and simultaneously it transits to the Polling.LFPS state.
PPG AUX Output Trigger	
Trigger	Selects a trigger type.
Link Speed	Outputs trigger signal (pulse) when the measuring instrument transits to the link speed specified by this item and to the conditions specified by State or Change Preset during link training.
State	Outputs trigger signal (pulse) from PPG Aux Out when the measuring instrument transits to the LTSSM State that was specified by this item during link training. This parameter is enabled when LTSSM is selected for Trigger. Because the pulse signal output from Aux Out changes from 0 to –1 during the transition to the specified state, set the Scope trigger to Fall Edge. When transits from the specified state to the next state, the pulse signal changes from –1 to 0. Set the Scope trigger to Rise Edge. When using the negative side of the Aux Out connector, the operation is reversed.
Emphasis	
Enable Preset	Sets the Emphasis Preset value enabled for 5.0 GT/s or 10.0 GT/s signal that is under Link Training.

4.10.3 Starting USB Link Training

1. Click **Start Link Training**. Then, the PPG will wait for receiving LFPS signal and the button changes to **Stop**.
2. In this state, when the USB Test Fixture connector is connected to the DUT, the DUT detects the USB connection and outputs the LFPS signal. PPG receives the LFPS signal by the DUT with AUX Input and link training begins.

Start Link Training changes to **Stop** during link training. It changes to **Unlink** when the link training is completed and the **DUT** status changes from Electrical Idle to Loopback Active. At that time, PPG sends a test pattern.

3. Clicking **Unlink** while the test pattern is being sent aborts the test pattern transmission, and the PPG returns to Electrical Idle status. For how to display link success/failure or LTSSM transition log, refer to 4.10.4 “Displaying USB Link Training Results” and 4.10.5 “Displaying LTSSM Log of USB Link Training”.
4. If you wish to measure Jitter Tolerance after this, refer to 4.6 “Jitter Tolerance Test” for details of the **Run Test** tab, **Graph** tab, and **Report** tab.
5. If you wish to measure BER after this, click **Start BER Measurement**. For details of the BER Measurement, refer to 4.4.4 “Setting Up PCIe BER Measurement” and 4.4.5 “Starting PCIe BER Measurement”.

4.10.4 Displaying USB Link Training Results

After performing link training as explained in 4.10.3, the results can be displayed.




Figure 4.10.4-1 USB Link Training Results

Table 4.10.4-1 USB Link Training Result Items

Item	Description
Common Parameter	
LTSSM State	Displays LTSSM State of measuring instrument.
Linkup Speed	Displays Link Speed (5.0 or 10.0 GT/s).
SKP	
SKP Count (Rx, Tx)	Displays the SKP OS number counted during link training. Rx and Tx have separate counts

4.10.5 Displaying LTSSM Log of USB Link Training

After performing link training as explained in 4.10.3, click **LTSSM Log** to display log.

Log data of each row is recorded when the LTSSM state is changed.




Figure 4.10.5-1 LTSSM Log Viewer

Table 4.10.5-1 LTSSM Log viewer

Item	Description
Time [ns]	Displays the time the log data was acquired. The start of acquisition is zero.
ΔTime [ns]	Displays the time interval between when the log data was acquired and when next log data was acquired.
State	Displays LTSSM State.
Speed[GT/s]	Displays Link Speed [GT/s].
Error Count	Displays the Error Count of TS.
Detail	Displays the management code.
Progress bar	Displays log decoding progress. It disappears when the decoding is completed.
Stop	Aborts log decoding.
Close	Closes Log Viewer.

4.11 DUT Error Counts Import

4.11.1 DUT Control tab

This section explains how to select user programs for controlling DUT.




Figure 4.11.1-1 DUT Control tab

Table 4.11.1-1 DUT Control tab

Item	Description
Initialization Program	Allows you to select a program file for initializing DUT. A path to program and a path to start-up argument can be specified.
Run button	Starts the Initialization program.
Measurement Program	Allows you to select a program file for performing measurement for DUT. A path to program and a path to start-up argument can be specified.
Run button	Starts the Measurement program. Clicking this button displays the Measurement tab.
Finalization Program	Allows you to select a program file for finalizing DUT. A path to program and a path to start-up argument can be specified.
Run button	Starts the selected Finalization program.
Log Viewer button	Displays the window to view log for each program.
DUT Control and Measurement Parameter Setting	Saves/loads/initializes parameters on the DUT Control and Measurement tabs.
Load	Loads the saved parameter file to the DUT Control tab and Measurement tab.
Save	Saves parameters on the DUT Control tab and Measurement tab in a file.
Initialize	Initializes parameters on the DUT Control tab and Measurement tab.

4.11.2 Measurement tab

This section explains the start of measurement and the display of measurement results.





Figure 4.11.2-1 Measurement tab

Table 4.11.2-1 Elements on Measurement Tab

Item	Description
Result display area	Displays the results of error rate, error count, and alarm. ER1 to 8: display error rates . 0, 0.0001E-18 to 1.0000E00 EC1 to 8: display the number of error counts. 0 to 18,446,744,073,709,551,615 AL1 to 4: display whether alarms are given or not. 1 or 0 is displayed. If NA is acquired as value, “-----” (seven hyphen characters) is displayed.

Table 4.11.2-1 Elements on Measurement Tab (Cont'd)

Item	Description
Result display area (Cont'd)	<p>Conditions for Jitter Tolerance measurement are the parameters defined by ER1, EC1, and AL1 to 4 in the Measure program. Also, by definitions, background colors of the results can be specified. For details on the definition method, refer to Appendix C "User Program Definitions".</p> 
Cycle	<p>Changes measurement cycle.</p> <p>Single: 1-cycle measurement (running the Measurement program once)</p> <p>Repeat: Repeated measurement (running the Measurement program repeatedly)</p>
Run/Stop button	<p>Starts or stops the measurement.</p> <p>Run: Starts the measurement. Runs the Measurement program.</p> <p>Stop: Stops the measurement after the Measurement program being run ends.</p>
Abort button	<p>Aborts the measurement.</p> <p>Unlike the Stop button, this button stops the measurement even if the Measurement program is being run.</p>
Debug Mode check box	<p>When selecting the check box, the Measurement program continues to run with ignoring syntax errors.</p>
Log Viewer button	<p>Displays the Log dialog box.</p> <p>The Log dialog box shows the following. For more details, refer to 4.11.5 "Log Viewer function".</p> <ul style="list-style-type: none"> • Messages at the start and end of the user program • Strings output from the user program • Syntax errors in the user program detected by MX183000A

4.11.3 Operating MX190000A

This section explains how to operate MX190000A when using the DUT Error Counts Import function.

You can change settings through the MX190000A screen even if the DUT Error Counts Import function acquires the measurement results from DUT.

Figure 4.11.3-1 shows an example of the screen displayed when the BER measurement is performed using MU196020A PAM4 PPG as a pattern generator.




Figure 4.11.3-1 DUT Error Counts Import and MX190000A Screens

However, for Jitter Tolerance measurement described in 4.11.4 “Measuring Jitter Tolerance”, you must click **Disconnect** of MX183000A before operating MX190000A.

Figure 4.11.3-2 shows an example of the screen displayed when the Jitter Tolerance measurement is performed using MU196020A PAM4 PPG as a pattern generator.




Figure 4.11.3-2 Jitter Tolerance and MX190000A Screens

4.11.4 Measuring Jitter Tolerance

This section explains procedures to acquire measurement results from the DUT counter using DUT Error Counts Import function and to measure jitter tolerance. A Jitter module, a PPG module, and the MX183000A-PL001 Jitter Tolerance Test are required for the measurement. For details on the modules required for the measurement, refer to 3.1 “Target Equipment”.

1. On the **Equipment Setup** tab, select the jitter module and the PPG module to be used to measure jitter tolerance, and then click **Connect**.




Figure 4.11.4-1 Equipment Setup tab

2. On the **Run Test** tab, set parameters for Jitter Tolerance measurement. For each parameter, refer to 4.6 “Jitter Tolerance Test”. However, when using the DUT Error Counts Import function, some functions such as Clock Selection, Auto Search, and Gating Time don’t appear.

The parameters defined in ER1, EC1, and AL1 to 4 in the Measurement program are available for Detection that allows defining condition for Jitter Tolerance measurement. Correspondence between Detection setting parameters and measurement items is as follows:

ER1:	Error Rate
EC1:	Error Count
AL1 to AL4:	Alarms that are termination conditions for Jitter Tolerance Test

For details on the Measurement program, refer to Appendix C “User Program Specifications”.




Figure 4.11.4-2 Run Test Screen




Figure 4.11.4-3 JTOL Setting Setup Screen

- Click **Run Test** to start Jitter Tolerance measurement and display the measurement results. Also, the **Graph** tab and the **Report** tab are available. For details on the displayed measurement results, refer to 4.6 “Jitter Tolerance Test”.

4.11.5 Log Viewer function

This section explains the Log Viewer function. On the **DUT Control** tab or the **Measurement** tab, click **Log Viewer**, and the Log Viewer function will start. The Log Viewer function can hold event log up to 3000 lines. If the number of lines reaches the limit, the older one will be deleted. For details on formats of event log and examples of messages, refer to C.5.6 “Examples of Syntax Errors”.




Figure 4.11.5-1 Log Viewer

Chapter 5 Remote Control

This chapter describes the remote control method and remote commands of MX183000A.

5.1	Setting Interface for Remote Control	5-3
5.2	Remote Control Procedure	5-4
5.3	Command Description Method	5-12
5.4	IEEE488.2 Common Commands.....	5-14
5.5	MX183000A Command List (Tree).....	5-15
5.6	Common Commands	5-23
5.7	Setting Measurement System.....	5-27
5.8	PCIe Link Sequence Setup Screen (With MX183000A-PL011 Installed)	5-43
5.8.1	Link Sequence Screen	5-43
5.8.2	BER Measurement Screen.....	5-60
5.8.3	Option Screen.....	5-65
5.9	PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)	5-84
5.9.1	Link Training Screen.....	5-84
5.9.2	BER Measurement Screen.....	5-93
5.9.3	Timeout Screen	5-100
5.9.4	Option Screen.....	5-114
5.9.5	Link Equalization Test Setup Screen	5-152
5.9.6	Saved Cursor Dialog Box	5-158
5.9.7	Matrix Scan.....	5-160
5.10	USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)	5-170
5.11	USB Link Training Setup Screen (With MX183000A-PL022 Installed)	5-188
5.11.1	Link Training Screen.....	5-188
5.11.2	BER Measurement Screen.....	5-195
5.11.3	Option Screen.....	5-200
5.12	Jitter Tolerance Setup Screen	5-211
5.12.1	Run Test Screen.....	5-211
5.12.2	Graph Screen	5-241
5.12.3	Result Screen	5-243
5.13	PAM4 Setup Screen	5-245
5.13.1	TX1 Setup.....	5-245
5.13.2	TX2 Setup.....	5-255
5.13.3	TX3 Setup.....	5-256
5.13.4	TX4 Setup.....	5-257
5.13.5	RX Setup	5-258
5.13.6	Common Setting.....	5-267
5.14	DUT Error Counts Import Setup Screen	5-270
5.14.1	DUT Control tab.....	5-270

5.14.2 Measurement tab.....	5-277
-----------------------------	-------

5.1 Setting Interface for Remote Control

This section describes the remote interface setting method for MX183000A.

1. Click **Menu** → **Setup** → **Remote** on the MX183000A Main screen.




Figure 5.1-1 Remote Setting Screen

2. Select either **Ethernet** or **GPIB**.
3. When **Ethernet** of Remote Interface is selected
 TCP Port can be set. Set a number that does not duplicate the TCP Port setting for the SQA or control PC on which the software is installed.
 TCP Port setting initial value: 5000
 TCP Port setting range: 1024 to 5001
 The IP address cannot be changed on the Remote Setting screen. Change the IP address on the Setup Utility of the MP1800A, the Remote Control of the MP1900A, or the Network Setting of the control PC.
4. If **GPIB** is selected
 Set the GPIB address within 1 to 30. The initial value is 3.

5.2 Remote Control Procedure

It describes how to control the MP1800A from a remote-control PC via an Ethernet or GPIB.

Set the MP1800A Setup Utility as follows for both Ethernet and GPIB.

Activate Interface: Ethernet

Performance: Enhanced




Figure 5.2-1 MP1800A Setup Utility Settings

The default values are as below for the MP1900A.

Port Number:	5001
IP Address:	192.168.2.100
Subnet Mask:	255.255.255.0

To change the values, perform the setting on the following windows.

Port Number

Remote Control window of MX190000A System Configuration

IP Address and Subnet Mask

Network and Sharing Center window of Windows




Figure 5.2-2 MP1900A Remote Control Settings

When controlling the MP1800A via Ethernet

There are two following methods when MX183000A is remotely controlled via Ethernet:

- Controlling MX183000A installed in the PC for the remote control
- Controlling MX183000A installed in the MP1800A




Figure 5.2-3 Remote Control System Configuration (Ethernet Control 1)




Figure 5.2-4 Remote Control System Configuration (Ethernet Control 2)

In the system configuration as shown in Figure 5.2-3, the IP address for transmitting MX183000A to the remote control software is “127.0.0.1” and the port number is “5000”.

In the system configuration as shown in Figure 5.2-4, the IP address for transmitting MX183000A to the remote control software is “192.168.2.100” and the port number is “5000”.

When controlling the MP1800A via GPIB

MX183000A can be controlled remotely via GPIB as follows.

- Controlling MX183000A installed in the MP1800A

Note that the MP1800A cannot be controlled via GPIB from MX183000A on the control PC.




Figure 5.2-5 Remote Control System Configuration (GPIB Control)

In the system configuration in Figure 5.2-5, the GPIB address for communication between the remote control software and MX183000A is "3".

Note:

MX183000A cannot be controlled via GPIB when it is installed on MP1900A.

This is an example of the procedure for performing a jitter tolerance test.

1. Connect the MP1800A and the control PC with Ethernet or GPIB.
2. Start MX183000A, and wait until the Selector screen appears.
3. Click **Menu** → **Setup** → **Remote (R)**.
4. Set the remote interface port number for MX183000A to 5000 or the GPIB address to 3. Refer to 5.1 “Setting Interface for Remote Control”.
5. Start the Jitter Tolerance test application.
:SYSTem:MEASure:SElect TOL
6. Send the following commands to search the MP1800A in the controller.
:SYSTem:EQUIPMENT:SEARCh:SETTing
TCPIP0::127.0.0.1::5001::SOCKET,1
:SYSTem:EQUIPMENT:SEARCh:ENABle 1,1
:SYSTem:EQUIPMENT:SEARCh:ENABle 0,2
:SYSTem:EQUIPMENT:SEARCh:ENABle 0,3
:SYSTem:EQUIPMENT:SEARCh:STARt
7. Check the unit numbers of detected equipment.
:SYSTem:EQUIPMENT:SETTing? JITTer
:SYSTem:EQUIPMENT:SETTing? PPG
:SYSTem:EQUIPMENT:SETTing? ED
8. Set the unit number for the equipment detected.
:SYSTem:EQUIPMENT:SETTing JITTer,1,1,2
:SYSTem:EQUIPMENT:SETTing PPG,1,1,3
:SYSTem:EQUIPMENT:SETTing ED,1,1,4
9. Connect to the controller.
:SYSTem:EQUIPMENT:CONNect
10. Start the Tolerance measurement.
:DISPlay:MEASure:CHANge RUNTest
:SENSe:MEASure:JITTer:STARt
11. During Tolerance measurement, the only remote control operations possible are measurement stop and obtain measurement status.
:SENSe:MEASure:JITTer:STATe?
:SENSe:MEASure:JITTer:STOP
12. Acquire the measurement result after the Tolerance measurement is finished.
:CALCulate:RESult:DATA? ALL

13. Save the report in HTML/CSV format.
:SYSTem:MMEMory:RESult:STORe
"D:\test_folder\test",HTML
:SYSTem:MMEMory:RESult:STORe
"D:\test_folder\test",CSV
14. Close the application.
:SENSe:MEASure:JITTer:STOP
:SYSTem:MEASure:SElect NONE

This is an example of the procedure for jitter tolerance testing using a PCIe device.

1. Start the PCIe Link Sequence application.
:SYSTem:MEASure:SElect PCI
2. Connect using steps 6 to 9 in the jitter tolerance test example procedure.
3. Set the test target specification to Revision 3.
:DISPlay:MEASure:CHANGe SEquence
:LTRaining:SEquence:SPECification REV3
4. Set the test pattern to Modified Compliance Pattern.
:SOURce:PATtern:TYPE COMPLIance
:LTRaining:SEquence:TEST:PATtern MCP
5. Send a sequence to loopback the DUT.
:LTRaining:SEquence:START
6. During sequence transmission, the only remote control operations possible are measurement stop and obtain measurement status.
:LTRaining:SEquence:STATe?
:LTRaining:SEquence:STOP
7. When the MX183000A-PL001 is installed, perform the jitter tolerance test on the DUT in loopback status using steps 10 to 13 in the jitter tolerance test example procedure.
8. Close the application.
:SENSe:MEASure:JITTer:STOP
:LTRaining:SEquence:STOP
:SYSTem:MEASure:SElect NONE

This is an example of the procedure for sending a Link Sequence using a USB device.

1. Start the USB Link Sequence application.
:SYSTem:MEASure:SElect USB
2. Connect using steps 6 to 9 in the jitter tolerance test example procedure.
3. Set the test target specification to GEN 1.
:DISPlay:MEASure:CHANge SEquence
:LTRaining:SEquence:SPECification GEN1
4. Set the test pattern to Compliance Pattern CP0.
:SOURce:PATtern:TYPE COMPLiance
:LTRaining:SEquence:TEST:PATtern 0
5. Send a sequence to loopback the DUT. *
:LTRaining:SEquence:START

*: When this command is sent, the DUT should be connected to the USB test fixture.
6. During sequence transmission, the only remote control operations possible are measurement stop and obtain measurement status.
:LTRaining:SEquence:STATe?
:LTRaining:SEquence:STOP
7. Close the application.
:LTRaining:SEquence:STOP
:SYSTem:MEASure:SElect NONE

5.3 Command Description Method

This chapter explains the notations used in the message syntax.

Table 5.3-1 Notation used in Command Syntax

Symbol	Usage
<>	Parameters enclosed in < > are character strings input to the program.
[]	Messages or parameters enclosed in square brackets can be omitted.
	Choose one from multiple choices. A B C D means choose from A, B, C, and D.
{}	Groups choice in braces. A B({C D}) means choose one of A, B(C), and B(D).
<CHARACTER PROGRAM DATA> <CHARACTER RESPONSE DATA> <DECIMAL NUMERIC PROGRAM DATA>	Short alphabet or alphanumeric
<NR1 NUMERIC RESPONSE DATA>	Decimal numeric value Example: -1.00, 256000, 1.3E-1
<NR2 NUMERIC RESPONSE DATA>	Decimal integer value Example: -100, 12500000
<STRING PROGRAM DATA> <STRING RESPONSE DATA> <BOOLEAN PROGRAM DATA>	Decimal fraction Example: -0.02, 2.35 Alphanumeric data Double or single quotes are required before and after the data. Data indicating logical true or false

The following shows the description example of command.

- Example of program command

Program command	Parameter type name	Parameter type
:DISPlay:MEASure:CHANge <type>		
Parameter	<type>=<CHARACTER PROGRAM DATA>	
	SETTing	Setting screen
	RESult	Result screen
	REPort	Report screen
Function	Switches the display screen for Tolerance/Sweep measurement. Result cannot be specified for measurement not executed.	
Example	Displays the Result screen for Tolerance measurement. > :DISPlay:MEASure:CHANge RES	
Parameter contents		Command example

- Example of query command

Program command	Parameter type name	Parameter type
:SENSe:MEASure:SYSCond:SJSelect?		
Response	<div><type> <CHARACTER RESPONSE DATA></div> <div>OFF,SJ,SJ2</div>	
Function	Queries the sine wave jitter setting fixed and added for Tolerance/Sweep measurement.	
Example	<div>> :SENSe:MEASure:SYSCond:SJSelect?</div> <div>< SJ2</div>	
Command example, response example		

The < and > in the example indicate the response and the program message respectively.

Notes:

- Any commands for MX183000A are sequential commands.
- If commands have restrictions, other settings may be affected. For the setting items to be affected and conditions to be restricted, refer to the *MX180000A Signal Quality Analyzer Control Software Operation Manual* and operation manual for each module.
- When the parameters of program command and query command are same, the parameter of query command may be omitted.

5.4 IEEE488.2 Common Commands

MX183000A supports the following IEEE188.2 common commands.

Table 5.4-1 IEEE488.2 Common Commands List

Mnemonic	Command's full spell
*CLS	Clear Status Command
*IDN?	Identification Query

***CLS Clear Status Command**

Parameter	None
Function	Clears any event register and queue excluding output queues and their MAV summary messages for MX183000A.
Example	> *CLS

***IDN? Identification Query**

Parameter	None
Response	<Manufacturer>, <Model>, <Serial No.> <Manufacturer>, <Model>=<CHARACTER RESPONSE DATA> ANRITSU MX183000A <Serial No.>=<NR1 NUMERIC RESPONSE DATA> 0000000000 The serial No. of MX183000A is always "0000000000". Main frame Serial number
Function	Reports manufacture name, model, etc.
Example	> :MFRame:ID 0 > *IDN? < ANRITSU,MX183000A,0000000000

5.5 MX183000A Command List (Tree)

The command list of MX183000A is displayed in tree.

The compatibilities of the MX181500A remote commands are listed below.

✓: Compatible

‡: Partially compatible

—: Not compatible (new MX183000A function)

Table 5.5-1 MX183000A Command Tree

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:CALCulate	:DATA	:EALarm			Q	—
	:RESult	:DATA			Q	✓
		:DETail			Q	—
		:EMONitor			Q	—
		:MAXPass			Q	—
		:MINFail			Q	—
		:STATus			Q	✓
:DISPlay	:MEASure	:CHANge			C	✓
	:RESult	:BER			C/Q	—
		:ESTimate			C/Q	—
			:ERATe		C/Q	—
	:SETTing	:LEQ			C/Q	—
		:LEFT			C/Q	—
		:RIGHT			C/Q	—
	:SIZE				C/Q	—
:INPut	:CLOCK	:SELection			C/Q	—*1
	:CTLE	:SETTing			C/Q	—
		:TRACKing			C/Q	—
	:DATA	:EQUalizer	:AMPLitude		C/Q	—
		:INTerface			C/Q	—
	:DFF	:SETTing			C/Q	—
:LTRaining	:POLling	:LFPS	:DELay		C/Q	—
				:ENAB	C/Q	—
	:SEQuence	:AUTO	:AWAit	:TIME	C/Q	—
			:CTRigger		C	—
				:TIME	C/Q	—
			:PCYCLE		C	—
				:TIME	C/Q	—

*1: This command is compatible with the MU183040A and MU183041A remote commands.

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:LTRaining	:SEQuence	:AUtO	:PRESet		C	—
				:TIME	C/Q	—
			:RESet		C/Q	—
		:BMATrix	:BER	:RTIME	C/Q	—
				:TIME	C/Q	—
			:DISPlay		C/Q	—
			:ELAPsed		Q	—
			:EXPort		Q	—
			:FSWing		C/Q	—
			:LFRequency		Q	—
			:MRESume		C	—
			:PDISplay		C/Q	—
			:PRESet		C	—
			:PROGress		Q	—
			:PSEL		C/Q	—
			:REMaining		Q	—
			:RESult		Q	—
			:SCAN		C/Q	—
			:SDIRection		C/Q	—
			:STARt		C	—
			:STATe		Q	—
			:STOP		C	—
			:TSEL		C/Q	—

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:LTRaining	:SEQuence	:CSpeed			C/Q	—
		:DESIGN	:GEN1		C/Q	—
			:GEN2		C/Q	—
			:REV1	:CONFiguration	C/Q	—
			:REV2	:CONFiguration	C/Q	—
				:RECOvery	C/Q	—
			:REV3	:CONFiguration	C/Q	—
				:RECOvery	C/Q	—
				:UPReset	C/Q	—
			:REV4	:CONFiguration	C/Q	—
				:RECOvery	C/Q	—
				:UPReset	C/Q	—
		:DSCRamble			C/Q	—
		:DSYMBOL			C/Q	—
		:DUT			C/Q	—
		:EIEos	:FORMat		C/Q	—
			:INTerval		C/Q	—
		:EITime			C/Q	—
		:ENABle	:PRESet		C/Q	—
		:FSWing			C/Q	—
		:FTS			C/Q	—
		:INITialize			C	—
		:LANenum			C/Q	—
		:LENTry	:TS		C/Q	—
		:LEQTest	:REV3		C/Q	—
		:LEQTest	:REV4		C/Q	—
		:LFRequency			C/Q	—
		:LINKnum			C/Q	—
		:LTHRough			C	—
		:LTSSm	:LOG	:EXPort	C	—
				:GATing	Q	—
				:STARt	C	—
				:STATe	Q	—
				:STOP	C	—

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:LTRaining	:SEQuence	:PACTive	:TS		C/Q	—
		:RESult			Q	—
			:CSKP		Q	—
		:REV2	:DEMPhasis		C/Q	—
		:REV3	:DSTReam	:HPRESet	C/Q	—
				:PRESet	C/Q	—
			:USTReam	:HPRESet	C/Q	—
				:PRESet	C/Q	—
			:UPReset		C/Q	—
			:RECOvery	:ALGorithm	C/Q	—
		:REV4	:DSTReam	:PRESet	C/Q	—
			:USTReam	:PRESet	C/Q	—
			:UPReset		C/Q	—
			:RECOvery	:ALGorithm	C/Q	—
		:SCURsor	:REV3		Q	—
			:REV4		Q	—
		:SKP			C/Q	—
			:REMOve		C/Q	—
			:DOUBle	:8B10B	C/Q	—
				:128B130B	C/Q	—
			:SLENgth	:8B10B	C/Q	—
				:128B130B	C/Q	—
				:128B132B	C/Q	—
			:INTerval	:8B10B	C/Q	—
				:128B130B	C/Q	—
				:128B132B	C/Q	—
		:SPECification			C/Q	—
		:SRIS			C/Q	—
		:STARt			C	—
		:STATe			Q	—
		:STOP			C	—
		:TEST	:PATtern		C/Q	—
				:EADDition	C	—
				:STOP	C	—
				:TRANsmitt	C	—

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:LTRaining	:SEQuence	:TOUT	:CONFIguration	:COMPLete	C/Q	—
				:IDLE	C/Q	—
				:LACCept	C/Q	—
				:LSTArt	C/Q	—
				:LWAit	C/Q	—
			:DISable		C/Q	—
			:DQUiet		C/Q	—
			:HOTReset		C/Q	—
			:INITialize		C	—
			:LBENtry	:ACTive	C/Q	—
				:EXIT	C/Q	—
				:SElect	C/Q	—
			:POLLing	:ACTive	C/Q	—
				:CONFIguration	C/Q	—
			:RECOvery	:EEQP1	C/Q	—
				:EEQP2	C/Q	—
				:EEQP3	C/Q	—
				:IDLE	C/Q	—
				:RCFG	C/Q	—
				:REQP0	C/Q	—
				:REQP1	C/Q	—
				:REQP2	C/Q	—
				:REQP3	C/Q	—
				:RLOCK	C/Q	—
				:SPEEd	C/Q	—
		:TRIGger	:CPReset		C/Q	—
			:SElect		C/Q	—
			:SPEEd		C/Q	—
			:STATe		C/Q	—
		:TXCursor			C/Q	—
		:TXPReset	:DEMPhasis		C/Q	—
			:IPReset		C/Q	—
			:LPReset		C/Q	—
				:PRESet	C/Q	—
			:PSHoot		C/Q	—
			:SElect		C/Q	—

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:OUTPut	:DATA	:AMPLitude	*2		C/Q	—
			:RANGe	*2	Q	—
		:BAUDrate			Q	—
		:DEFault	*2		C	—
		:DELay	*2		C/Q	—
		:EAMPLitude	*2		Q	—
		:INTERface	*2		C/Q	—
		:LEVEL	*2		C/Q	—
		:OUTPut	*2		C/Q	—
		:SElect	*2		C/Q	—
		:SKEW	*2		C/Q	—
		:TRACking	*2		C/Q	—
		:TYPE	*2		C/Q	—
:SENSE	:ASEarch	:CTLE			C/Q	—
		:DFF			C/Q	—
		:MODE			C/Q	—
		:SELPpg			C/Q	—
		:STARt			C	—
		:STATe			Q	—
		:STOP			C	—
	:DECoder	:SERial			Q	—
	:JITTer	:TABLe	:ADD		C	—
			:ADELete		C	—
			:DELete		C	—
			:FREQuency		Q	—
			:INDEX		Q	—
	:MEASure	:BER	:ABORt		C	—
			:ECTHreshold		C/Q	—
			:IPAdDress		C/Q	—
			:MODE		C/Q	—
			:STARt		C	—
			:STATe		Q	—
			:STOP		C	—
			:TIME		C/Q	—

*2: :PPG1, :PPG2, :PPG3, or :PPG4 can be specified. If omitted, :PPG1 is specified.

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:SENSe	:MEASure	:BERCond	:ASEarch		C/Q	✓
			:GTIMe		C/Q	†
			:MANual	:DATA	C/Q	—
				:DELay	C/Q	—
				:INTerface	Q	—
				:XDATA	C/Q	—
			:MTYPE		C/Q	—
			:PATtern		C/Q	—
			:RATiosetting		C/Q	†
			:RESolution		C/Q	✓
			:SEARch		C/Q	✓
			:SEQuence		C/Q	✓
			:SJ	:SSTep	C/Q	—
			:SSETing		C/Q	✓
			:STIMe		C/Q	✓
			:THReshold		C/Q	✓
			:UNIT		C/Q	✓
			:WTIME		C/Q	✓
		:JITTer	:STARt		C	✓
			:STATe		Q	✓
			:STOP		C	✓
		:SYSCond	:BITRate		Q	✓
		:TABLedata	:OPEN		C	✓
			:SElect		Q	✓
			:SAVe		C	—
:SOURce	:PATtern	:EADdition	SINGLE		C	—
		:PRBS	:LENGth		C/Q	—*3
		:TYPE			C/Q	—*2
			:TRACking		C/Q	—
:SYSTem	:ERRor				Q	✓
	:EQUIPMENT	:ADJust			C/Q	—
		:CONNect			C	—
		:DCONnect			C	—

Table 5.5-1 MX183000A Command Tree (Cont'd)

Command Header 1	Command Header 2	Command Header 3	Command Header 4	Command Header 5	Command /Query	MX181500A Compatibility
:SYSTem	:EQUIPMENT	:DUT	:FINAlize		C	—
				:ABORt	C	—
				:CONdition	Q	—
				:STARt	C	—
				:STATe	Q	—
			:INITialize		C	—
				:ABORt	C	—
				:CONdition	Q	—
				:STARt	C	—
				:STATe	Q	—
			:MEASure		C	—
			:SETTing	:INITialize	C	—
				:RECall	C	—
				:STORe	C	—
		:ECOMbination			C/Q	—
		:EXTatt			C/Q	—
		:LFPS			C/Q	—
		:SEARCh	:ENABle		C/Q	✓
			:SETTing		C/Q	✓
			:STARt		C	✓
		:SELConverter			C/Q	—
			:NUMBer		C/Q	—
		:SELDecoder			C/Q	—
		:SETTing			C/Q	✓
			:MODule		Q	✓
		:USBConnection			C/Q	—
		:USENoise			C/Q	—
	:MEASure	:EXIT			C	—
		:INITialize			C	✓
		:SELeCt			C/Q	✓
			:STATe		Q	—
	:MMEMory	:RESult	:STORe		C	✓
		:SETTing	:RECall		C	✓
			:STORe		C	✓
	:TERMination				C/Q	✓

*3: This command is compatible with the MU183020A and MU183021A remote commands.

5.6 Common Commands

This section explains the commands for the common setting and function of MX183000A.




Figure 5.6-1 Selector Screen

Table 5.6-1 Common Commands

Setting Item	Command
Queries error message	:SYSTem:ERRor?
Sets terminator	:SYSTem:TERMination
	:SYSTem:TERMination?
Start application setting	:SYSTem:MEASure:SElect
	:SYSTem:MEASure:SElect?
Displayed tab switching	:DISPlay:MEASure:CHANge

:SYSTem:ERRor?

Parameter	None
Response	<p><error/event_number>,"<error/event_description>"</p> <p><error/event_number>=<NR1 NUMERIC RESPONSE DATA></p> <p>–32768 to 32767</p> <p>The value of zero indicates no error or no event occurrence.</p> <p>Others return standard errors reserved by SCPI or equipment-specific errors.</p> <p><error/event_description>=<STRING RESPONSE DATA></p> <p>Error messages corresponding to each <error/event_number>. The maximum length of this character string is 255 characters.</p>
Function	Queries error messages that exist in errors or event queues.
Example	<p>> :SYSTem:ERRor?</p> <p>< 0, "No error"</p>

:SYSTem:TERMination <numeric>

Parameter	<p><numeric>=<DECIMAL NUMERIC PROGRAM DATA></p> <p>0 LF + EOI</p> <p>1 CR + LF + EOI</p>
Function	Sets terminator type of response data.
Example	<p>To set terminator type to LF + EOI:</p> <p>> :SYSTem:TERMination 0</p>

:SYSTem:TERMination?

Response	<p><numeric>=<NR1 NUMERIC RESPONSE DATA></p> <p>0 LF + EOI</p> <p>1 CR + LF + EOI</p>
Function	Queries terminator of response data
Example	<p>> :SYSTem:TERMination?</p> <p>< 0</p>

:SYSTem:MEASure:SElect <item>

Parameter	<item>=<CHARACTER PROGRAM DATA>	
	NONE	Selector
	TOL	Jitter Tolerance Test
	PCIS	PCIe Link Sequence
	PCIT	PCIe Link Training
	USBS	USB Link Sequence
	USBT	USB Link Training
	PAM	PAM4 Control
Function	Selects the application to be started.	
Example	To select and start PCIe Link Sequence:	
	> :SYSTem:MEASure:SElect PCIS	

:SYSTem:MEASure:SElect?

Response	<item>=<CHARACTER RESPONSE DATA>	
	NONE, TOL, PCIS, PCIT, USBS, USBT, PAM	
Function	Queries the application running.	
Example	> :SYSTem:MEASure:SElect?	
	< PCIS	

:SYSTem:MEASure:SElect:STATe?

Response	<item>=<NR1 NUMERIC RESPONSE DATA>	
	0	Not ready
	1	Ready
Function	Queries whether MX183000A is ready for :SYST:MEAS:SEL. If the response to this command is 0, the :SYST:MEAS:SEL command results in the error -221 "Setting conflict".	
Example	> :SYSTem:MEASure:SElect:STATe?	
	< 1	

:DISPlay:MEASure:CHANge <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> EQUIPMENT Equipment Setup tab SEQUENCE Sequence tab TRAINING Link Training tab RUNTEST Run Test tab GRAPH Graph tab REPORT Report tab PAM PAM4 Control tab
Function	Switches between application display screens. This command can be used after the application has been started using the :SYSTEM:MEASure:SElect command and connected to the SQA using :SYSTEM:EQUIPMENT:CONNECT. Some screens may not be available depending on the particular MX183000A license.
Example	To display the Tolerance Measurement Report tab: > :DISPlay:MEASure:CHANge REPORT

5.7 Setting Measurement System




Figure 5.7-1 Equipment Setup Screen




Figure 5.7-2 Equipment Setup Screen After Search Completion




Figure 5.7-3 Equipment Setup Screen After Connect Completion

Note:

"::SYSTem:EQUIPMENT:CONNEct" must be used to connect to the SQA except when using the following commands.

```

::SYSTem:MEASure:SELEct
::SYSTem:MEASure:EXIT
::SYSTem:EQUIPMENT:SEARch:SETTing
::SYSTem:EQUIPMENT:SEARch:STARt
::SYSTem:EQUIPMENT:SEARch:ENABle
::SYSTem:EQUIPMENT:SEARch:SETTing
::SYSTem:EQUIPMENT:SETTing:MODule
::SYSTem:EQUIPMENT:CONNEct
    
```




Figure 5.7-4 Equipment Setup Screen After Search (PAM4 Control)




Figure 5.7-5 Equipment Setup Screen after Search Completion (USB Link Training)

Table 5.7-1 Setting Commands of Main Window

No.	Setting Item	Command
[1]	Exit	:SYSTem:MEASure:EXIT
	Initialize	:SYSTem:MEASure:INITialize
	Save	:SYSTem:MMEMory:SETTing:STORe
	Load	:SYSTem:MMEMory:SETTing:RECall
[2]	SQA	:SYSTem:EQUipment:SEARch:SETTing
		:SYSTem:EQUipment:SEARch:SETTing?
[3]	Search Enable	:SYSTem:EQUipment:SEARch:ENABle
		:SYSTem:EQUipment:SEARch:ENABle?
[4]	Search Start	:SYSTem:EQUipment:SEARch:STARt
[5]	Connect	:SYSTem:EQUipment:CONNect
	Disconnect	:SYSTem:EQUipment:DCONnect
[6]	Equipment	:SYSTem:EQUipment:SETTing
		:SYSTem:EQUipment:SETTing?
		:SYSTem:EQUipment:SETTing:MODule?
[7]	Equipment	:SYSTem:EQUipment:ECOMbination
		:SYSTem:EQUipment:ECOMbination?
[8]	Operate MP1800A/MP1900A	:SYSTem:EQUipment:ADJust
		:SYSTem:EQUipment:ADJust?
[9]	Selecting G0375A	:SYSTem:EQUipment:SELConverter
		:SYSTem:EQUipment:SELConverter?
[10]	External Att	:SYSTem:EQUipment:EXTatt
		:SYSTem:EQUipment:EXTatt?
[11]	Use Noise Genrator	:SYSTem:EQUipment:USENoise
		:SYSTem:EQUipment:USENoise?
[12]	Selecting G0376A	:SYSTem:EQUipment:SELDecoder
		:SYSTem:EQUipment:SELDecoder?
[13]	Selecting LFPS combining method	:SYSTem:EQUipment:USBConnection
		:SYSTem:EQUipment:USBConnection?
[14]	Selecting number of G0375As	:SYSTem:EQUipment:SELConverter:NUMBer
		:SYSTem:EQUipment:SELConverter:NUMBer?

:SYSTem:MEASure:EXIT

Parameter	None
Function	Closes the application.
Example	> :SYSTem:MEASure:EXIT

:SYSTem:MEASure:INITialize

Parameter	None
Function	Initializes the various measurement setting conditions.
Example	> :SYSTem:MEASure:INITialize

:SYSTem:MMEMory:SETTing:STORe <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name	
Function	Saves the measurement setting conditions.	
Example	> :SYSTem:MMEMory:SETTing:STORe "C:\test_folder\test_setting"	

:SYSTem:MMEMory:SETTing:RECall <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name	
Function	Loads measurement setting conditions.	
Example	> :SYSTem:MMEMory:SETTing:RECall "C:\test_folder\test_setting"	

:SYSTem:EQUIPMENT:SEARCh:SETTing <info>,<number>

Parameter	<info>=<STRING PROGRAM DATA> TCPIP0::<<address>::<<port>::SOCKET <address>=xxx.xxx.xxx.xxx IP address <port>=xxxx port <number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 No.1 to 3
Function	Specifies the controller number, and sets the IP address and port.
Example	Set the MP1800A assigned the IP Address 192.168.2.100 and port 5001 to controller No. 2. >:SYSTem:EQUIPMENT:SEARCh:SETTing TCPIP0::192.168.2.100::5001::SOCKET,2

:SYSTem:EQUIPMENT:SEARCh:SETTing? <number/type>

Parameter	<number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 No.1 to 3 <type>=<CHARACTER PROGRAM DATA > LIST Connection target candidate list
Response	For argument <number> <string>=<STRING RESPONSE DATA> <string>=TCPIP0::<<address>::<<port>::SOCKET <address>=<STRING RESPONSE DATA> Output in form 223.255.255.254 <port>=<NR1 NUMERIC RESPONSE DATA > 1024 to 5001 For argument <type> <string>=<STRING RESPONSE DATA> <string>="TCPIP0::<<address1>::<<port1>::SOCKET, TCPIP0::<<address2>::<<port2>::SOCKET, ... TCPIP0::<<address8>::<<port8>::SOCKET, TCPIP0::<<address9>::<<port9>::SOCKET"
Function	Specifies the controller number, and queries the IP address and port.
Example	Displays the connection target candidate list. To query the IP address and port for the controller No. 2 MP1800A > :SYSTem:EQUIPMENT:SEARCh:SETTing? 2 < TCPIP0::192.168.2.100::5001::SOCKET Displays the connection target candidate list. > :SYSTem:EQUIPMENT:SEARCh:SETTing? LIST "TCPIP0::192.168.2.100::5001::SOCKET,TCPIP0::192.168.2.101::5001::SOCKET,TCPIP0::127.0.0.1::5001::SOCKET

:SYSTem:EQUipment:SEARch:ENABle <boolean>,[<number>]

Parameter	<p>< boolean>=<BOOLEAN PROGRAM DATA> ON or 1 Search ON OFF or 0 Search OFF < number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 No.1 to 3</p> <p>Note: When <number> is omitted, No.1 is set.</p>
Function	Selects the search target equipment (SQA or MT1810A main unit).
Example	To set No.2 as the search target: > :SYSTem:EQUipment:SEARch:ENABle 1,2

:SYSTem:EQUipment:SEARch:ENABle? [<number>]

Parameter	<p>< number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 No.1 to 3</p> <p>Note: When <number> is omitted, No.1 is queried.</p>
Response	<p><boolean>=<NR1 NUMERIC RESPONSE DATA> 1 Search ON 0 Search OFF</p>
Function	Queries the ON/OFF setting of the search target.
Example	To query the search setting of No.2: > :SYSTem:EQUipment:SEARch:ENABle? 2

:SYSTem:EQUipment:SEARch:STARt

Parameter	None
Function	Starts searching for the modules installed on the SQA specified as the controller.
Example	> :SYSTem:EQUipment:SEARch:STARt

:SYSTem:EQUIPMENT:SETTing**<type>,<number>,<unit>,<slot>[,<data_if>][,<mode>]**

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	JITTer	Jitter Modulation Source
	PPG	PPG
	PPG2	PPG2
	ED	ED
	NOISe	Noise Module
	PAMPpg	PAM4 PPG
	PAMEd	PAM4 ED
	<number>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 3	SQA No.1 to 3
	<unit>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 4	Unit 1 MP1900A/MP1800A
		Unit 1 to 4 MT1810A
	<slot>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 6	Slot 1 to 6 MP1800A
	1 to 8	Slot 1 to 8 MP1900A
	[<data_if>]=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 4	Data 1 to 4

Note:

<data_if> can be set when the module installed in slot is below:
 MU183020A, MU183021A, MU183040A/B, MU183041A/B,
 MU195020A

Data 1 is specified when omitted.

If <data_if> is set to other modules, the parameter error occurs.

With PCIe Link Sequence and USB Link Sequence, PPG <data_if>
 can be set to "1" only.

[<mode>]=<CHARACTER PROGRAM DATA>

NRZ	NRZ mode
PAM4	PAM4 mode

Note:

<mode> can be set when the module installed in slot is below:
 NRZ is specified when omitted.
 MU196020A, MU196040A, MU196040B

If <mode> is set to other modules, the parameter error occurs.

Function

Selects the equipment to be used for the measurement.

Example

To assign MP1800A No.1, Unit 1, and Slot 4 to Jitter Modulation Source:
 > :SYSTem:EQUIPMENT:SETTing JITTer,1,1,4

Assign MP1800A No. 1, Unit 1, Slot 4, Data 2 to the 32G PPG.

> :SYSTem:EQUipment:SETTing PPG,1,1,4,2

Assign MP1900A No. 1, Unit 1, Slot 7, PAM4 mode to the PAM4 PPG.

> :SYSTem:EQUipment:SETTing PAMPpg,1,1,7,PAM4

:SYSTem:EQUIPMENT:SETTing? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> JITTer Jitter Modulation Source PPG PPG PPG2 PPG2 ED ED NOISe Noise Module PAMPpg PAM4 PPG PAMEd PAM4 ED
Response	<number>=<NR1 NUMERIC RESPONSE DATA> 1 to 3 SQA No.1 to 3 0 None <unit>=<NR1 NUMERIC RESPONSE DATA> 1 to 4 Unit 1 to 4 <slot>=<NR1 NUMERIC RESPONSE DATA> 1 to 8 Slot 1 to 8 0 None [<data_if>]=<NR1 NUMERIC RESPONSE DATA> 1 to 4 Data 1 to 4 Note: <data_if> returns when the module installed in slot is below: MU183020A, MU183021A, MU183040A/B, MU183041A/B [<mode>]=<CHARACTER RESPONSE DATA> NRZ NRZ mode PAM4 PAM4 mode Note: <mode> returns when the module installed in slot is below: MU196020A, MU196040A, MU196040B
Function	Queries the equipment used for the measurement.
Example	To query the equipment and slot used for the jitter modulation source. > :SYSTem:EQUIPMENT:SETTing? JITTer < 1,1,4 When equipment is not assigned, the response of (None) is as follows: < 0,0,0 To query the SQA and slot to which the PAM4 PPG is assigned. > :SYSTem:EQUIPMENT:SETTing? PAMPpg < 1,1,7,PAM4

:SYSTem:EQUIPMENT:SETTing:MODule? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> JITTer Jitter Modulation Source PPG PPG ED ED NOISe Noise Module PAMPpg PAM4 PPG PAMEd PAM4 ED
Response	<string>=<STRING RESPONSE DATA> "<number>,<unit>,<slot>,<data_if>" (Up to 12) <number>=<NR1 NUMERIC RESPONSE DATA> 1 to 3 SQA No.1 to 3 0 None <unit>=<NR1 NUMERIC RESPONSE DATA> 1 to 4 Unit 1 to 4 <slot>=<NR1 NUMERIC RESPONSE DATA> 1 to 8 Slot 1 to 8 0 None [<data_if>]=<NR1 NUMERIC RESPONSE DATA> 1 to 4 Data 1 to 4 Note: <data_if> returns when the module installed in slot is below: MU183020A, MU183021A, MU183040A/B, MU183041A/B [<mode>]=<CHARACTER RESPONSE DATA> NRZ NRZ mode PAM4 PAM4 mode Note: <mode> returns when the module installed in slot is below: MU196020A, MU196040A, MU196040B
Function	Queries the equipment candidate to be used for the measurement. Selectable main unit No., Unit, and Slot are selected from the already searched equipment units.
Example	To query the equipment candidate for the jitter modulation source: > :SYSTem:EQUIPMENT:SETTing:MODule? JITTer < "1,1,4", "2,1,4", "3,1,4" When the equipment candidate does not exist, the response is as follows: < 0,0,0 When MU183020A-x22/x23 are candidates for PPG, the response is as follows: < "1,1,3,1", "1,1,3,2" When a PAM4 ED candidate is queried, the response is as follows: < "1,1,6, PAM4"

:SYSTem:EQUIPMENT:CONNECT

Parameter	None
Function	Connects to the SQA with the IP address selected by :SYSTem:EQUIPMENT:SEARCh:ENABle. This command can be used after searching for equipment using :SYSTem:EQUIPMENT:SEARCh:SETTing.
Example	To connect to the SQA > :SYSTem:EQUIPMENT:CONNECT

:SYSTem:EQUIPMENT:DCONnect

Parameter	None
Function	Disconnects from the SQA.
Example	To disconnect from the SQA > :SYSTem:EQUIPMENT:DCONnect

:SYSTem:EQUIPMENT:ECOMbination <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Does not test in 2ch Combination. ON or 1 Tests in 2ch Combination.
Function	Sets up testing in 2ch Combination. This command is available after having searched the equipment by “:SYSTem:EQUIPMENT:SEARCh:SETTing” and before connecting MX183000A to the equipment by “:SYSTem:EQUIPMENT:CONNECT”. Also, this command is available only when Jitter Tolerance Test application is running.
Example	> :SYSTem:EQUIPMENT:ECOMbination 1

:SYSTem:EQUIPMENT:ECOMbination?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Does not test in 2ch Combination. 1 Tests in 2ch Combination.
Function	Queries whether to test in 2ch Combination. This command is available only when Jitter Tolerance Test application is running.
Example	> :SYSTem:EQUIPMENT:ECOMbination? < 1

:SYSTem:EQUipment:ADJust <boolean>

Parameter	<p><boolean>=<BOOLEAN PROGRAM DATA></p> <p>OFF or 0 Releases Operate MP1800A/MP1900A mode.</p> <p>ON or 1 Sets Operate MP1800A/MP1900A mode.</p>
Function	<p>Selects the mode so that MX180000A or MX190000A can be directly remote-controlled from a remote tool by disconnecting the TCPIP connection between MX183000A and MX180000A or MX190000A temporarily.</p> <p>This command is available after connecting MX183000A to MX180000A or MX190000A by “:SYSTem:EQUipment:CONNect”.</p> <p>Note:</p> <p>After completing remote control of MX180000A or MX190000A, make sure to set this parameter to OFF.</p> <p>For details of this function, refer to 4.3.4 “RF setting of MX180000A and MX190000A” as well.</p>
Example	<p>> :SYSTem:EQUipment:ADJust 1</p>

:SYSTem:EQUipment:ADJust?

Response	<p><numeric>=<NR1 NUMERIC RESPONSE DATA></p> <p>0 Not in Operate MP1800A/MP1900A mode.</p> <p>1 In Operate MP1800A/MP1900A mode.</p>
Function	<p>Query if the system is in Operate MP1800A/MP1900A mode.</p> <p>This command is available after connecting MX183000A to MX180000A or MX190000A by “:SYSTem:EQUipment:CONNect”.</p>
Example	<p>> :SYSTem:EQUipment:ADJust?</p> <p>< 1</p>

:SYSTem:EQUIPMENT:SELConverter <item>

Parameter	<item>=<CHARACTER PROGRAM DATA>	
	G0375A	Using G0375A
	COMBiner	Using G0375A and Combiner
Function	Selects the PAM4 Converter used for measurement.	
Example	To select G0375A as the PAM Converter.	
	> :SYSTem:EQUIPMENT:SELConverter G0375A	

:SYSTem:EQUIPMENT:SELConverter?

Response	<item>=<CHARACTER RESPONSE DATA>	
	G0375A	Using G0375A
	COMBiner	Using G0375A and Combiner
Function	Queries the PAM4 Converter used for measurement.	
Example	> :SYSTem:EQUIPMENT:SELConverter?	
	< G0375A	

:SYSTem:EQUIPMENT:EXTatt <att>

Parameter	<att>=<DECIMAL NUMERIC PROGRAM DATA>	
	0	An External attenuator is not used.
	6	An external 6 dB attenuator is used.
Function	Selects the external attenuator used for measurement.	
Example	> :SYSTem:EQUIPMENT:EXTatt 6	

:SYSTem:EQUIPMENT:EXTatt?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	An External attenuator is not used.
	6	An external 6 dB attenuator is used.
	Queries the external attenuator used for measurement.	
Example	> :SYSTem:EQUIPMENT:EXTatt?	
	< 6	

:SYSTem:EQUIPMENT:USENoise <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	The Noise Generator is not used.
	ON or 1	The Noise Generator is used.
Function	Sets if the Nose Generator is used or not.	
Example	> :SYSTem:EQUIPMENT:USENoise 1	

:SYSTem:EQUIPMENT:USENoise?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	The Noise Generator is not used.
	1	The Noise Generator is used.
Function	Queries if the Nose Generator is used or not.	
Example	> :SYSTem:EQUIPMENT:USENoise? < 1	

:SYSTem:EQUIPMENT:SELDecoder <item>

Parameter	<item>=<CHARACTER PROGRAM DATA>	
	COM1 to 16	Select the COM No. of the G0376A for measurement, from 1 to 16.
	None	G0376A is not used.
Function	Selects the PAM4 Decoder for measurement.	
Example	To set COM1 as the PAM4 Decoder. > :SYSTem:EQUIPMENT:SELDecoder COM1	

:SYSTem:EQUIPMENT:SELDecoder?

Response	<item>=<CHARACTER RESPONSE DATA>	
	COM1 to 16	Select the COM No. of the G0376A for measurement
	None	G0376A is not used.
Function	Queries the PAM4 Decoder for measurement.	
Example	> :SYSTem:EQUIPMENT:SELDecoder? < COM1	

:SYSTem:EQUIPMENT:USBConnection <item>

Parameter	<item>=<CHARACTER PROGRAM DATA>	
	PICK	Selects the system to use Pick Off Tee.
	NOISe	Selects the system to use Noise Module.
Function	Selects the connection system in the USB Link Training application. A method for combining LFPS signals differs depending on the connection system.	
Example	To select the connection system using Pick Off Tee by the USB Link Training application. > :SYSTem:EQUIPMENT:USBConnection PICK	

:SYSTem:EQUIPMENT:USBConnection?

Response	<item>=<CHARACTER RESPONSE DATA>	
	PICK	Selects the system to use Pick Off Tee.
	NOISe	Selects the system to use Noise Module.
Function	Queries the connection system setting using Pick Off Tee by the USB Link Training application.	
Example	> :SYSTem:EQUIPMENT:USBConnection? < PICK	

:SYSTem:EQUIPMENT:SELConverter:NUMBer <num>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 4	Number of G0375As to be controlled
Function	Specifies the number of G0375As used for the measurement.	
Example	To set the number of G0375As used for the measurement to 2: > :SYSTem:EQUIPMENT:SELConverter:NUMBer 2	

:SYSTem:EQUIPMENT:SELConverter:NUMBer?

Response	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 4	Number of G0375As to be controlled
Function	Queries the number of G0375As used for the measurement.	
Example	> :SYSTem:EQUIPMENT:SELConverter:NUMBer? < 2	

5.8 PCIe Link Sequence Setup Screen (With MX183000A-PL011 Installed)

This setup screen is available only when MX183000A-PL011 is installed, when **PCIe Link Sequence** is started on the table 4.3.1-1 Selector screen, and when the SQA has been connected using Equipment Setup.

5.8.1 Link Sequence Screen




Figure 5.8.1-1 Link Sequence Screen

Table 5.8.1-1 Sequence Screen Setup Commands

No.	Setting Item	Command
[1]	Default	:LTraining:SEQuence:INITialize
[2]	Sequence Start	:LTraining:SEQuence:STARt
	Sequence Stop	:LTraining:SEQuence:STOP
	Sequence State	:LTraining:SEQuence:STATe?
[3]	28G/32G ED	:CALCulate:RESult:EMONitor?
[4]	BER Measurement Start	:SENSe:MEASure:BER:STARt
	BER Measurement Stop	:SENSe:MEASure:BER:STOP
	BER Measurement State	:SENSe:MEASure:BER:STATe?
[5]	Specification	:LTraining:SEQuence:SPECification
		:LTraining:SEQuence:SPECification?
[6]	Loopback through	:LTraining:SEQuence:LTHRough
		:LTraining:SEQuence:LTHRough?
[7]	Test Pattern	:SOURce:PATtern:TYPE
		:SOURce:PATtern:TYPE?
		:LTraining:SEQuence:TEST:PATtern
		:LTraining:SEQuence:TEST:PATtern?
		:SOURce:PATtern:PRBS:LENGth
		:SOURce:PATtern:PRBS:LENGth?
[8]	Insert Delay Symbol	:LTraining:SEQuence:DSYMBOL
		:LTraining:SEQuence:DSYMBOL?
[9]	Sequence	:LTraining:SEQuence:DESIgn:REV1:CONF
		:LTraining:SEQuence:DESIgn:REV1:CONF?
		:LTraining:SEQuence:DESIgn:REV2:CONF
		:LTraining:SEQuence:DESIgn:REV2:CONF?
		:LTraining:SEQuence:DESIgn:REV2:REC
		:LTraining:SEQuence:DESIgn:REV2:REC?
		:LTraining:SEQuence:DESIgn:REV3:CONF
		:LTraining:SEQuence:DESIgn:REV3:CONF?
		:LTraining:SEQuence:DESIgn:REV3:REC
		:LTraining:SEQuence:DESIgn:REV3:REC?
		:LTraining:SEQuence:DESIgn:REV4:CONF
		:LTraining:SEQuence:DESIgn:REV4:CONF?
		:LTraining:SEQuence:DESIgn:REV4:REC
		:LTraining:SEQuence:DESIgn:REV4:REC?

:LTRaining:SEquence:START

Parameter	None
Function	Starts transmitting a link training sequence for looping back DUT. Once the transmission is complete, the pattern selected by Test Pattern is sent.
Example	> :LTRaining:SEquence:START

:LTRaining:SEquence:STOP

Parameter	None
Function	Stops transmitting link training sequence and test pattern and sets to Electrical Idle.
Example	> :LTRaining:SEquence:STOP

:LTRaining:SEquence:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Stop
	1 Sending
	2 Sending test pattern
Function	Queries the link training sequence transmission status.
Example	> :LTRaining:SEquence:STATe? < 1

:LTRaining:SEQuence:SPECification <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> REV1 Revision1.0/1.1 REV2 Revision2.0 REV3 Revision3.0/3.1 REV4 Revision4.0
Function	Selects the environment (revision) to loopback the DUT (Revision).
Example	To set the environment to REV4(16.0 GT/s): > :LTRaining:SEQuence:SPECification REV4 Note: The clock frequency input to MU181500B must be changed by the user when MU181000A/B is not installed.

:LTRaining:SEQuence:SPECification?

Response	<type>=<CHARACTER RESPONSE DATA> REV1, REV2, REV3, REV4
Function	Queries the environment to loopback the DUT.
Example	> :LTRaining:SEQuence:SPECification? < REV4

:LTRaining:SEQuence:LTHRough <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> CONFIguration Configuration route RECOvery Recovery route
Function	Select the LTSSM route to loopback the DUT.
Example	To set the state route to Configuration route: > :LTRaining:SEQuence:LTHRough CONFIguration

:LTRaining:SEQuence:LTHRough?

Response	<type>=<CHARACTER RESPONSE DATA> REC, CONF
Function	Queries the LTSSM route to loopback the DUT.
Example	> :LTRaining:SEQuence:LTHRough? < CONF

:SOURce:PATtern:TYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> COMpliance Compliance pattern PRBS PRBS pattern
Function	Selects the test pattern to be sent after completing the link training sequence transmission.
Example	To set the test pattern to Compliance Pattern: > :SOURce:PATtern:TYPE COMpliance

:SOURce:PATtern:TYPE?

Response	<type>=<CHARACTER RESPONSE DATA> COMP, PRBS
Function	Queries the test pattern to be sent after completing the link training sequence transmission.
Example	> :SOURce:PATtern:TYPE? < COMP

:LTRaining:SEQuence:TEST:PATtern <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> CP Compliance Pattern MCP Modified Compliance Pattern JTMP Jitter Tolerance Measurement Pattern* *: This parameter can be set when 32G SI PPG is installed and Rev. 3.x or 4.0 is selected.
Function	Selects the type of Compliance Pattern to be sent when test pattern “:SOURce:PATtern:TYPE” is set to Compliance.
Example	> :LTRaining:SEQuence:TEST:PATtern CP

:LTRaining:SEQuence:TEST:PATtern?

Response	<type>=<CHARACTER RESPONSE DATA> CP Compliance Pattern MCP Modified Compliance Pattern JTMP Jitter Tolerance Measurement Pattern
Function	Queries the type of Compliance Pattern to be sent.
Example	> :LTRaining:SEQuence:TEST:PATtern? < CP

:SOURce:PATtern:PRBS:LENGth <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	7	2^n-1 (n=7)
	9	2^n-1 (n=9)
	10	2^n-1 (n=10)
	11	2^n-1 (n=11)
	15	2^n-1 (n=15)
	20	2^n-1 (n=20)
	23	2^n-1 (n=23)
	31	2^n-1 (n=31)
Function	Sets the number of stages (2^n-1 (n=7, 9, 10, 11, 15, 20, 23, or 31)) for PRBS pattern reception.	
Example	To set the number of stages for PRBS pattern reception to 2^7-1 :	
	> :SOURce:PATtern:PRBS:LENGth 7	

:SOURce:PATtern:PRBS:LENGth?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	7, 9, 10, 11, 15, 20, 23, 31	
Function	Queries the number of stages for PRBS pattern reception.	
Example	> :SOURce:PATtern:PRBS:LENGth?	
	< 7	

:LTRaining:SEquence:DSYMBOL <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Delay Symbol not inserted
	ON or 1	Delay Symbol inserted
Function	Selects whether to insert a Delay Symbol.	
Example	> :LTRaining:SEquence:DSYMBOL ON	

:LTRaining:SEquence:DSYMBOL?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Delay Symbol not inserted
	1	Delay Symbol inserted
Function	Queries whether the Delay Symbol is to be inserted.	
Example	> :LTRaining:SEquence:DSYMBOL? < 1	

:LTRaining:SEquence:INITialize [<spec>][,<state>]

Parameter	<spec>=<CHARACTER PROGRAM DATA>	
	REV1	Revision1.0/1.1
	REV2	Revision2.0
	REV3	Revision3.0/3.1
	REV4	Revision4.0
	<state>=<CHARACTER PROGRAM DATA>	
	CONFiguration	Configuration root
	RECOvery	Recovery root

Note:

If <state> is omitted, the <spec> pattern specified is initialized.

If <spec><state> is omitted, all patterns are initialized.

Function	Sets all parameters for the link training sequence to the initial values.
Example	To initialize the parameters for REV2 Recovery Root: > :LTRaining:SEquence:INITialize REV2,RECOvery

:LTRaining:SEquence:DESign:REV1:CONFiguration <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV1).	
Example	To set the wait for DETECT_QUIET to 100 μ s:	
	> :LTRaining:SEquence:DESign:REV1:CONFiguration DQU,100	
	To set the number of times POLLING_ACTIVE patterns are sent to 1024:	
	> :LTRaining:SEquence:DESign:REV1:CONFiguration	
	PACTive,1024	

:LTRaining:SEquence:DESign:REV1:CONFiguration? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV1)	
Example	>:LTRaining:SEquence:DESign:REV1:CONFiguration? DQUiet	
	< 100	
	>:LTRaining:SEquence:DESign:REV1:CONFiguration? PACTive	
	< 1024	

:LTRaining:SEquence:DESign:REV2:CONFiguration<type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV2).	
Example	<p>To set the wait for DETECT_QUIET to 100 μs:</p> <pre>> :LTRaining:SEquence:DESign:REV2:CONFiguration DQUiet,100</pre> <p>To set the number of times POLLING_ACTIVE patterns are sent to 1024:</p> <pre>> :LTRaining:SEquence:DESign:REV2:CONFiguration PACTive,1024</pre>	

:LTRaining:SEquence:DESign:REV2:CONFiguration? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV2)	
Example	<pre>>:LTRaining:SEquence:DESign:REV2:CONFiguration? DQU < 100 >:LTRaining:SEquence:DESign:REV2:CONFiguration? PACT < 1024</pre>	

:LTRaining:SEquence:DESign:REV2:RECover <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	CLISStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVR_LOCK
	RRCeqts2	RECOVERY_RCVR_CFG_EQTS2
	RSPeed	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVR_LOCK
	RRCTs2	RECOVERY_RCVR_CFG_TS2
	LEMasteR	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV2).	
Example	<p>To set the wait for DETECT_QUIET to 100 μs:</p> <pre>> :LTRaining:SEquence:DESign:REV2:RECover DQUiet,100</pre> <p>To set the number of times POLLING_ACTIVE patterns are sent to 1024:</p> <pre>> :LTRaining:SEquence:DESign:REV2:RECover PACTive,1024</pre>	

:LTRaining:SEquence:DESign:REV2:RECover? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	CLIStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVR_LOCK
	RRCeqls2	RECOVERY_RCVR_CFG_EQTS2
	RSPeed	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVR_LOCK
	RRCTs2	RECOVERY_RCVR_CFG_TS2
	LEMaster	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV2)	
Example	<pre>>:LTRaining:SEquence:DESign:REV2:RECover? DQUiet < 100 >:LTRaining:SEquence:DESign:REV2:RECover? PACTive < 1024</pre>	

:LTRaining:SEquence:DESign:REV3:CONFiguration <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV3).	
Example	<p>To set the wait for DETECT_QUIET to 100 μs:</p> <pre>> :LTRaining:SEquence:DESign:REV3:CONFiguratuion DQUiet,100</pre> <p>To set the number of times POLLING_ACTIVE patterns are sent to 1024:</p> <pre>> :LTRaining:SEquence:DESign:REV3:CONFiguratuion PACTive,1024</pre>	

:LTRaining:SEquence:DESign:REV3:CONFiguration? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV3)	
Example	<pre>>:LTRaining:SEquence:DESign:REV3:CONFiguratuion? DQUiet < 100 >:LTRaining:SEquence:DESign:REV3:CONFiguratuion? PACTive < 1024</pre>	

:LTRaining:SEquence:DESign:REV3:RECoverY <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	CLIStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVRLock
	RRCeQts2	RECOVERY_RCVRCFG EQTS2
	RSPeed	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVRLock
	REPHase1	RECOVERY_EQUALIZATION PHASE1
	RRLock3	RECOVERY_RCVRLock
	RRCTs2	RECOVERY_RCVRCFG TS2
	LEMaster	LOOPBACK_ENTRY MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV3).	
Example	To set the wait for DETECT_QUIET to 100 μ s:	
	> :LTRaining:SEquence:DESign:REV3:RECoverY DQUiet,100	
	To set the number of times POLLING_ACTIVE patterns are sent to 1024:	
	> :LTRaining:SEquence:DESign:REV3:RECoverY PACTive,1024	

:LTRaining:SEquence:DESign:REV3:RECover? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	CLIStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVRLOCK
	RRCeqls2	RECOVERY_RCVRCFG EQTS2
	RSPeed	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVR_LOCK
	REPHase1	RECOVERY_EQUALIZATION PHASE1
	RRLock3	RECOVERY_RCVRLOCK
	RRCTs2	RECOVERY_RCVRCFG TS2
	LEMaster	LOOPBACK_ENTRY MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV3)	
Example	>:LTRaining:SEquence:DESign:REV3:RECover? DQUiet < 100 >:LTRaining:SEquence:DESign:REV3:RECover? PACTive < 1024	

:LTRaining:SEquence:DESign:REV4:CONFiguration <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV4).	
Example	To set the wait for DETECT_QUIET to 100 μ s: > :LTRaining:SEquence:DESign:REV4:CONFiguratuion DQUiet,100 To set the number of times POLLING_ACTIVE patterns are sent to 1024: > :LTRaining:SEquence:DESign:REV3:CONFiguratuion PACTive,1024	

:LTRaining:SEquence:DESign:REV4:CONFiguration? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	LEMaster1	LOOPBACK_ENTRY_MASTER
	LEMChange	LOOPBACK_ENTRY_MASTER_CHANGE (wait)
	LEMaster2	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV4)	
Example	>:LTRaining:SEquence:DESign:REV3:CONFiguratuion? DQUiet < 100 >:LTRaining:SEquence:DESign:REV3:CONFiguratuion? PACTive < 1024	

:LTRaining:SEquence:DESign:REV4:RECover <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA >	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PCONfiguration	POLLING_CONFIGURATION
	CLIStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVR_LOCK
	RRCeqls21	RECOVERY_RCVR_CFG_EQTS2
	RSPeed1	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVR_LOCK
	REPHase11	RECOVERY_EQUALIZATION_PHASE1
	RRLock3	RECOVERY_RCVR_LOCK
	RRCTs21	RECOVERY_RCVR_CFG_TS2
	RIDLe	RECOVERY_IDLE (wait)
	RRLock4	RECOVERY_RCVR_LOCK
	RRCeqls22	RECOVERY_RCVR_CFG_EQTS2
	RSPeed2	RECOVERY_SPEED (wait)
	RRLock5	RECOVERY_RCVR_LOCK
	REPHase12	RECOVERY_EQUALIZATION_PHASE1
	RRLock6	RECOVERY_RCVR_LOCK
	RRCTs22	RECOVERY_RCVR_CFG_TS2
	LEMasteR	LOOPBACK_ENTRY_MASTER
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait time, 1 μ s step
Function	Sets a sequence pattern to loopback the DUT (REV4).	
Example	To set the wait for DETECT_QUIET to 100 μ s:	
	> :LTRaining:SEquence:DESign:REV4:RECover DQUiet,100	
	To set the number of times POLLING_ACTIVE patterns are sent to 1024:	
	> :LTRaining:SEquence:DESign:REV4:RECover PACTive,1024	

:LTRaining:SEquence:DESIGN:REV4:RECOVERY? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	DQUiet	DETECT_QUIET (wait)
	DACTive	DETECT_ACTIVE
	PACTive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	CLIStart	CONFIGURATION_LINKWIDTH_START
	CLIAccept	CONFIGURATION_LINKWIDTH_ACCEPT
	CLAWait	CONFIGURATIONS_LANE_WAIT
	CLAAccept	CONFIGURATIONS_LANE_ACCEPT
	CCOMplete	CONFIGURATION_COMPLETE
	CIDLe	CONFIGURATION_IDLE (wait)
	RRLock1	RECOVERY_RCVR_LOCK
	RRCepts21	RECOVERY_RCVR_CFG_EQTS2
	RSPeed1	RECOVERY_SPEED (wait)
	RRLock2	RECOVERY_RCVR_LOCK
	REPHase11	RECOVERY_EQUALIZATION_PHASE1
	RRLock3	RECOVERY_RCVR_LOCK
	RRCTs21	RECOVERY_RCVR_CFG_TS2
	RIDLe	RECOVERY_IDLE (wait)
	RRLock4	RECOVERY_RCVR_LOCK
	RRCepts22	RECOVERY_RCVR_CFG_EQTS2
	RSPeed2	RECOVERY_SPEED (wait)
	RRLock5	RECOVERY_RCVR_LOCK
	REPHase12	RECOVERY_EQUALIZATION_PHASE1
	RRLock6	RECOVERY_RCVR_LOCK
	RRCTs22	RECOVERY_RCVR_CFG_TS2
	LEMasteR	LOOPBACK_ENTRY_MASTER
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles
	1 to 1000000	1 to 1000000 μ s Wait time
Function	Queries the sequence pattern to loopback the DUT. (REV4)	
Example	>:LTRaining:SEquence:DESIGN:REV4:RECOVERY? DQUiet < 100 >:LTRaining:SEquence:DESIGN:REV4:RECOVERY? PACTive < 1024	

5.8.2 BER Measurement Screen




Figure 5.8.2-1 BER Measurement Screen

Table 5.8.2-1 BER Measurement Commands

No.	Setting Item	Command
[1]	BER Measurement Start	:SENSe:MEASure:BER:STARt
	BER Measurement Stop	:SENSe:MEASure:BER:STOP
	BER Measurement State	:SENSe:MEASure:BER:STATe?
[2]	Configure BER Measurement	:DISPlay:RESult:BER
		:DISPlay:RESult:BER?
[3]	Error Count Threshold	:SENSe:MEASure:BER:ECTHreshold
		:SENSe:MEASure:BER:ECTHreshold?
[4]	Cycle	:SENSe:MEASure:BER:MODE
		:SENSe:MEASure:BER:MODE?
[5]	Gating Time	:SENSe:MEASure:BER:TIME
		:SENSe:MEASure:BER:TIME?
[6]	Result	:CALCulate:DATA:EALarm?
[7]	Error Addition	:SOURce:PATtern:EADdition:SINGLE
[8]	BERT State	:CALCulate:RESult:EMONitor?

:SENSe:MEASure:BER:START

Parameter	None
Function	Starts BER Measurement.
Example	> :SENSe:MEASure:BER:START

:SENSe:MEASure:BER:STOP

Parameter	None
Function	Stops BER Measurement.
Example	> :SENSe:MEASure:BER:STOP

:SENSe:MEASure:BER:STATE?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being measured
	0	Stopped
Function	Queries the BER measurement status.	
Example	> :SENSe:MEASure:BER:STATE? < 1	

:DISPlay:RESult:BER <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Hides the BER measurement setting window.
	ON or 1	Displays the BER measurement setting window.
Function	Sets whether the BER Measurement results area is displayed or hidden.	
Example	> :DISPlay:RESult:BER 1	

:DISPlay:RESult:BER?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Hides the BER measurement setting window.
	1	Displays the BER measurement setting window.
Function	Queries the BER Measurement results area display status.	
Example	> :DISPlay:RESult:BER? < 1	

:SENSe:MEASure:BER:ECTHreshold <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 1000 0 to 1000, 1 step
Function	Sets an evaluation threshold of the BER measurement. When the number of bit errors exceeds the evaluation threshold, the BER measurement is judged as Fail.
Example	To set the evaluation threshold of the BER measurement to 1: >:SENSe:MEASure:BER:ECTHreshold 1

:SENSe:MEASure:BER:ECTHreshold?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 1000 0 to 1000
Function	Queries the evaluation threshold of the BER measurement.
Example	>:SENSe:MEASure:BER:ECTHreshold? < 1

:SENSe:MEASure:BER:MODE <mode>

Parameter	<mode>=<CHARACTER PROGRAM DATA> SINGle Performs the measurement once. REPeat Performs the measurement repeatedly.
Function	Sets the measurement processing mode for the BER measurement.
Example	To set the measurement processing mode for the BER measurement to Repeat: > :SENSe:MEASure:BER:MODE REPeat

:SENSe:MEASure:BER:MODE?

Response	<mode>=<CHARACTER PROGRAM DATA> SING, REP
Function	Queries the measurement processing mode for the BER measurement.
Example	>:SENSe:MEASure:BER:MODE? < REP

:SENSe:MEASure:BER:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 100 1 to 100 s, 1s step
Function	Sets the Gating Time of the BER measurement.
Example	To set the Gating Time of the BER measurement to 6 s: >:SENSe:MEASure:BER:TIME 6

:SENSe:MEASure:BER:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 100
Function	Queries the Gating Time of the BER measurement.
Example	>:SENSe:MEASure:BER:TIME? < 6

:SOURce:PATtern:EADDITION:SINGLE

Function	Adds a single error to the test pattern.
Example	> :SOURce:PATtern:EADDITION:SINGLE

:CALCulate:DATA:EALarm? <result>

Parameter	<result>=<STRING PROGRAM DATA> For details on <result>, refer to Table 5.8.2-2.
Response	<string>=<STRING RESPONSE DATA>

Table 5.8.2-2 Parameter

Items	<result1>	Format
Error Count	"EC"	Form1
Bit Count	"BITS"	Form1
Bit Error Rate	"BER"	Form2
Sync Loss	"PSLoss"	"Occur" "Not Occur"
Clock Loss	"CLOSs"	
Pass/fail judgment	"JUDGE"	String("PASS", "FAIL", "---")

Table 5.8.2-3 Response Format

Items	Format	Description
Form1 Integer	"XXXXXXXX"	For 0 to 99999999
	"X.XXXEXX"	For 1.0000E07 to 9.9999E17
	"-----"	No data corresponds to a query.
Form2 Decimal	"X.XXXE-XX"	For 0.0001E-18 to 1.0000E00
	"-----"	No data corresponds to a query.

Function	Queries the BER Measurement results (BITS).
Example	> :CALCulate:DATA:EALarm? "BITS" < "1.0000E12"

:CALCulate:RESult:EMONitor?

Response	<string>=<STRING RESPONSE DATA>
Function	Queries the MP1800A/MP1900A state.
Example	> :CALCulate:RESult:EMONitor? < "Outputting Test Pattern"

5.8.3 Option Screen




Figure 5.8.3-1 Option Screen (Rev1, Rev2)




Figure 5.8.3-2 Option Screen (Rev3, Rev4)

Table 5.8.3-1 Sequence Option Screen Setup Command

No.	Setting Item	Command
[1]	FTS	:LTRaining:SEQuence:FTS
		:LTRaining:SEQuence:FTS?
[2]	Link Number	:LTRaining:SEQuence:LiNKnum
		:LTRaining:SEQuence:LiNKnum?
[3]	Lane Number	:LTRaining:SEQuence:LANenum
		:LTRaining:SEQuence:LANenum?
[4]	Full Swing	:LTRaining:SEQuence:FSWing
		:LTRaining:SEQuence:FSWing?
[5]	Low Frequency	:LTRaining:SEQuence:LFRequency
		:LTRaining:SEQuence:LFRequency?
[6]	SRIS	:LTRaining:SEQuence:SRIS
[7]	Disable Scrambling	:LTRaining:SEQuence:DSCRamble
		:LTRaining:SEQuence:DSCRamble?
[8]	CTLE Gain	:INPut:DATA:EQUalizer:AMPLitude
		:INPut:DATA:EQUalizer:AMPLitude?
[9]	EIEOS Reset Interval	:LTRaining:SEQuence:REIEos:INTerval
		:LTRaining:SEQuence:REIEos:INTerval?
[10]	EIEOS 16G Format	:LTRaining:SEQuence:EIEos:FORMat
		:LTRaining:SEQuence:EIEos:FORMat?
[11]	Send TS Polling.Active	:LTRaining:SEQuence:PACTive:TS
		:LTRaining:SEQuence:PACTive:TS?
[12]	Send TS Loopback.Entry	:LTRaining:SEQuence:LENTry:TS
		:LTRaining:SEQuence:LENTry:TS?
[13]	Initial Preset for 2.5GT/s	:LTRaining:SEQuence:TXPReset:IPReset
		:LTRaining:SEQuence:TXPReset:ILPReset?
[14]	Loopback Preset	:LTRaining:SEQuence:TXPReset:LPRreset:PRESet
		:LTRaining:SEQuence:TXPReset:LPRreset:PRESet?
[15]	Loopback Preset Select	:LTRaining:SEQuence:TXPReset:LPRreset
		:LTRaining:SEQuence:TXPReset:LPRreset?
[16]	SKP Insert	:LTRaining:SEQuence:SKP
		:LTRaining:SEQuence:SKP?
[17]	Symbol Length 8b/10b	:LTRaining:SEQuence:SKP:SLENgth:8B10B
		:LTRaining:SEQuence:SKP:SLENgth:8B10B?
[18]	Interval 8b/10b	:LTRaining:SEQuence:SKP:INTerval:8B10B
		:LTRaining:SEQuence:SKP:INTerval:8B10B?

Table 5.8.3-1 Sequence Option Screen Setup Command (Cont'd)

No.	Setting Item	Command
[19]	Double SKP (8b/10b)	:LTRaining:SEquence:SKP:DOUBle:8B10B
		:LTRaining:SEquence:SKP:DOUBle:8B10B?
[20]	De-emphasis	:LTRaining:SEquence:REV2:DEMPhasis
		:LTRaining:SEquence:REV2:DEMPhasis?
[21]	Symbol Length 128b/130b	:LTRaining:SEquence:SKP:SLENgth:128B130B
		:LTRaining:SEquence:SKP:SLENgth:128B130B?
[22]	Interval 128b/130b	:LTRaining:SEquence:SKP:INTerval:128B130B
		:LTRaining:SEquence:SKP:INTerval:128B130B?
[23]	Double SKP (128b/130b)	:LTRaining:SEquence:SKP:DOUBle:128B130B
		:LTRaining:SEquence:SKP:DOUBle:128B130B?
[24]	Preset (Rev 3.x)	:LTRaining:SEquence:REV3:DSTReam:PRESet
		:LTRaining:SEquence:REV3:DSTReam:PRESet?
		:LTRaining:SEquence:REV3:USTReam:PRESet
		:LTRaining:SEquence:REV3:USTReam:PRESet?
[25]	Preset (Rev 4.0)	:LTRaining:SEquence:REV4:DSTReam:PRESet
		:LTRaining:SEquence:REV4:DSTReam:PRESet?
		:LTRaining:SEquence:REV4:USTReam:PRESet
		:LTRaining:SEquence:REV4:USTReam:PRESet?
[26]	Preset Hint (Rev 3.x)	:LTRaining:SEquence:REV3:DSTReam:HPRESet
		:LTRaining:SEquence:REV3:DSTReam:HPRESet?
		:LTRaining:SEquence:REV3:USTReam:HPRESet
		:LTRaining:SEquence:REV3:USTReam:HPRESet?

:LTRaining:SEquence:FTS <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 255 0 to 255, 1 step
Function	Sets the TS FTS value.
Example	To set the TS FTS value to 127: > :LTRaining:SEquence:FTS 127

:LTRaining:SEquence:FTS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 255 0 to 255
Function	Queries the TS FTS setting.
Example	> :LTRaining:SEquence:FTS? < 127

:LTRaining:SEquence:LINKnum <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 255 0 to 255, 1 step
Function	Sets the TS Link Number.
Example	To set the Link Number to 1: > :LTRaining:SEquence:LINKnum 1

:LTRaining:SEquence:LINKnum?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 255 0 to 255
Function	Queries the TS Link Number.
Example	> :LTRaining:SEquence:LINKnum? < 1

:LTRaining:SEquence:LANenum <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 255 0 to 255, 1 step
Function	Sets the TS Lane Number.
Example	To set the Lane Number to 1: > :LTRaining:SEquence:LANenum 100

:LTRaining:SEquence:LANenum?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 255 0 to 255
Function	Queries the TS Lane Number.
Example	> :LTRaining:SEquence:LANenum? < 100

:LTRaining:SEquence:FSWing <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12 to 63 12 to 63, 1 step
Function	Sets the TS Full Swing value.
Example	To set the TS Full Swing value to 30: > :LTRaining:SEquence:FSWing 30

:LTRaining:SEquence:FSWing?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 12 to 63 12 to 63, 1 step
Function	Queries the TS Full Swing value.
Example	> :LTRaining:SEquence:FSWing? < 30

:LTRaining:SEquence:LFFrequency <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12 to 63 12 to 63, 1 Step
Function	Sets the TS Low Frequency value.
Example	To set the Low Frequency value to 30: > :LTRaining:SEquence:LFFrequency 30

:LTRaining:SEquence:LFFrequency?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 12 to 63 12 to 63, 1step
Function	Queries the TS Low Frequency value.
Example	> :LTRaining:SEquence:LFFrequency? < 30

:LTRaining:SEquence:SRIS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Disable
	1 Enable
Function	Queries whether to operate using Separate Refclock with Independent SSC. When PCIe Link Sequence is started, this parameter is fixed to Disable. Also, the setting command is available only when PCIe Link Training is running.
Example	> :LTRaining:SEquence:SRIS? < 0

:LTRaining:SEquence:DSCRamble <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 De-assert
	ON or 1 Assert
Function	Sets the TS Disable scramble bit.
Example	To set Disable scramble to Asset: > :LTRaining:SEquence:DSCRamble 1

:LTRaining:SEquence:DSCRamble?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 De-assert
	1 Assert
Function	Queries the TS Disable scramble bit value.
Example	> :LTRaining:SEquence:DSCRamble? < 1

:LTRaining:SEquence:REleos:INTERval <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Disables the EIEOS Reset Interval Count bit.
	ON or 1	Enables the EIEOS Reset Interval Count bit.
Function	Sets the TS EIEOS Reset Interval Count bit value.	
Example	> :LTRaining:SEquence:REleos:INTERval ON	

:LTRaining:SEquence:REleos:INTERval?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	The EIEOS Reset Interval Count bit disabled.
	1	The EIEOS Reset Interval Count bit enabled.
Function	Queries the TS EIEOS Reset Interval Count bit value.	
Example	> :LTRaining:SEquence:REleos:INTERval? < 1	

:LTRaining:SEquence:EIEos:FORMat <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0	Older than Rev 0.7
	1	Rev 0.7 or later
Function	Sets EIEOS format to PCIe 4 Rev 0.7 or later. This parameter is available only when SI PPG is installed.	
Example	> :LTRaining:SEquence:EIEos:FORMat 1	

:LTRaining:SEquence:EIEos:FORMat?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Older than Rev 0.7
	1	Rev 0.7 or later
Function	Queries if EIEOS format is PCIe 4 Rev 0.7 or later. This parameter is available only when SI PPG is installed.	
Example	> :LTRaining:SEquence:EIEos:FORMat? < 1	

:LTRaining:SEQuence:SKP <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	SKP OS not inserted
	ON or 1	SKP OS inserted
Function	Selects whether to insert SKP OS while transmitting a sequence.	
Example	To insert SKP OS	
	> :LTRaining:SEQuence:SKP ON	

:LTRaining:SEQuence:SKP?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	SKP OS not inserted
	1	SKP OS inserted
Function	Queries whether SKP OS is inserted while transmitting a sequence.	
Example	>: LTRaining:SEQuence:SKP?	
	< 1	

:LTRaining:SEQuence:SKP:SLENgth:8B10B <numeric>

Parameter	<numeric>=<NR1 NUMERIC PROGRAM DATA>	
	1	COM + 1 symbol
	2	COM + 2 symbols
	3	COM + 3 symbols
	4	COM + 4 symbols
	5	COM + 5 symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.	
Example	To set the number of SKP OS SKP symbols to 3: >:LTRaining:SEQuence:SKP:SLENgth:8B10B 3	

:LTRaining:SEQuence:SKP:SLENgth:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1, 2, 3, 4, 5	
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.	
Example	> :LTRaining:SEQuence:SKP:SLENgth:8B10B? < 3	

:LTRaining:SEQuence:SKP:INTerval:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 80 to 3076 80 to 3076, 2 step	
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.	
Example	To generate an SKP OS once after every 1538 symbols sent: >:LTRaining:SEQuence:SKP:INTerval:8B10B 1538	

:LTRaining:SEQuence:SKP:INTerval:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 80 to 3076 80 to 3076, 2 step	
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.	
Example	>:LTRaining:SEQuence:SKP:INTerval:8B10B? < 1538	

:LTRaining:SEquence:SKP:DOUBle:8B10B <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Double SKP OS not inserted. ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	To insert double SKP OS. > :LTRaining:SEquence:DOUBle:8B10B 1

:LTRaining:SEquence:SKP:DOUBle:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Double SKP OS not inserted. 1 Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	> :LTRaining:SEquence:DOUBle:8B10B? < 1

:LTRaining:SEquence:SKP:SLENgth:128B130B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 8 8 Symbols 12 12 Symbols 16 16 Symbols 20 20 Symbols 24 24 Symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 128b/130b Encoding operation.
Example	To set the number of SKP OS SKP symbols to 8: > :LTRaining:SEquence:SKP:SLENgth:128B130B 8

:LTRaining:SEquence:SKP:SLENgth:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 8, 12, 16, 20, 24
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 128b/130b Encoding operation.
Example	> :LTRaining:SEquence:SKP:SLENgth:128B130B? < 8

:LTRaining:SEquence:SKP:INTerval:128B130B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 20 to 750 20 to 750, 1 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 128b/130b Encoding operation.
Example	To generate an SKP OS once after every 375 blocks sent: >:LTRaining:SEquence:SKP:INTerval:128B130B 375

:LTRaining:SEquence:SKP:INTerval:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 20 to 750 20 to 750
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 128b/130b Encoding operation.
Example	>:LTRaining:SEquence:SKP:INTerval:128b130b? < 375

:LTRaining:SEquence:SKP:DOUBle:128B130B <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Double SKP OS not inserted. ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 128b/130b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	To insert double SKP OS. > :LTRaining:SEquence:DOUBle:128B130B 1

:LTRaining:SEquence:SKP:DOUBle:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Double SKP OS not inserted. 1 Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 128b/130b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	> :LTRaining:SEquence:DOUBle:128B130B? < 1

:LTRaining:SEquence:PACTive:TS <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Selects the type of TS transmitted for Polling.Active State.
Example	To set the TS to be transmitted for Polling.Active State to TS1 Ordered Set: > :LTRaining:SEquence:PACTive:TS 0

:LTRaining:SEquence:PACTive:TS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Queries the type of TS transmitted for Polling.Active State.
Example	> :LTRaining:SEquence:PACTive:TS? < 0

:LTRaining:SEquence:LENTry:TS <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Selects the type of TS transmitted for Loopback.Entry State.
Example	To set the TS to be transmitted for Loopback.Entry State to TS1 Ordered Set: > :LTRaining:SEquence:LENTry:TS 0

:LTRaining:SEquence:LENTry:TS?

Response	<type>=<CHARACTER RESPONSE DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Queries the type of TS transmitted for Polling.Active State.
Example	> :LTRaining:SEquence:LENTry:TS? < 0

:LTRaining:SEquence:TXPReset:LPRreset <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 Auto
	1 Manual
Function	Sets whether to change manually the Preset value to be used in Loopback.Active state.
	This parameter is available only when SI PPG is installed.
Example	<pre>> :LTRaining:SEquence:LEntry:TS? To set manually the Preset value to be used in Loopback.Active state. > :LTRaining:SEquence:TXPReset:LPRreset 1</pre>

:LTRaining:SEquence:TXPReset:LPRreset?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Auto
	1 Manual
Function	Queries whether to change manually the Preset value to be used in Loopback.Active state.
	This parameter is available only when SI PPG is installed.
Example	<pre>> :LTRaining:SEquence:LEntry:TS? > :LTRaining:SEquence:TXPReset:LPRreset? < 1</pre>

:LTRaining:SEquence:TXPReset:LPRreset:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 to 10 P0 to P10, 1 step
Function	Sets the Preset value to be used in Loopback.Active state.
	This parameter is available only when SI PPG is installed.
Example	<pre>To set the Preset value to P7. > :LTRaining:SEquence:TXPReset:LPRreset:PRESet 7</pre>

:LTRaining:SEquence:TXPReset:LPRreset:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 to 10 P0 to P10
Function	Queries the Preset value to be used in Loopback.Active state.
Example	<pre>> :LTRaining:SEquence:TXPReset:LPRreset:PRESet? < 7</pre>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value to use at the sequence start (2.5 GT/s transmission). This parameter is available only when SI PPG is installed.
Example	To set the Preset value to P7. > :LTraining:SEquence:TXPReset:IPReset 7

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value to use at the sequence start (2.5 GT/s transmission).
Example	> :LTraining:SEquence:TXPReset:IPReset? < 7

:LTRaining:SEquence:REV2:DEMPhasis <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -6.0 -6.0 dB -3.5 -3.5 dB
Function	Sets De-emphasis for PCIe 2.0 operation. This parameter is available only when SI PPG is installed.
Example	To set De-emphasis to -6.0 dB. > :LTRaining:SEquence:REV2:DEMPhasis -6.0

:LTRaining:SEquence:REV2:DEMPhasis?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> -6.0, -3.5
Function	Queries De-emphasis for PCIe 2.0 operation. This parameter is available only when SI PPG is installed.
Example	> :LTRaining:SEquence:REV2:DEMPhasis? < -6.0

:LTRaining:SEquence:REV3:DSTReam:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that is notified to DUT and used by SI PPG in PCIe 3.0 operation. This parameter is available only when SI PPG is installed.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV3:DSTReam:PRESet 7

:LTRaining:SEquence:REV3:DSTReam:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that is notified to DUT and used by SI PPG in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:DSTReam:PRESet? < 7

:LTRaining:SEquence:REV3:UStream:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that is notified to DUT and used by SI PPG in PCIe 3.0 operation. This parameter is available only when SI PPG is installed.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV3:UStream:PRESet 7

:LTRaining:SEquence:REV3:UStream:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that DUT is requested for in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:UStream:PRESet? < 7

:LTRaining:SEquence:REV3:DStream:HPRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to -6 -12 to -6 dB, 1 step
Function	Sets the Preset Hint value that is notified to DUT in PCIe 3.0 operation. This parameter is available only when SI PPG is installed.
Example	To set Preset Hint to -10 dB. > :LTRaining:SEquence:REV3:DStream:HPRESet -10

:LTRaining:SEquence:REV3:DStream:HPRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to -6 -12 to -6 dB
Function	Queries the Preset Hint value that is notified to DUT in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:DStream:HPRESet? < -10

:LTRaining:SEquence:REV3:USTReam:HPRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to -6 -12 to -6 dB, 1 step
Function	Sets the Preset Hint value that is notified to DUT in PCIe 3.0 operation. This parameter is available only when SI PPG is installed.
Example	To set Preset Hint to -10 dB. > :LTRaining:SEquence:REV3:USTReam:HPRESet -10

:LTRaining:SEquence:REV3:USTReam:HPRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to -6 -12 to -6 dB
Function	Queries the Preset value that DUT is requested for in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:USTReam:HPRESet? < -10

:LTRaining:SEquence:REV4:DSTReam:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that is notified to DUT and used by SI PPG in PCIe 4.0 operation. This parameter is available only when SI PPG is installed.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV4:DSTReam:PRESet 7

:LTRaining:SEquence:REV4:DSTReam:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that is notified to DUT and used by SI PPG in PCIe 4.0 operation.
Example	> :LTRaining:SEquence:REV4:DSTReam:PRESet? < 7

:LTRaining:SEquence:REV4:USTReam:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that is notified to DUT in PCIe 4.0 operation. This parameter is available only when SI PPG is installed.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV4:USTReam:PRESet 7

:LTRaining:SEquence:REV4:USTReam:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that DUT is requested for in PCIe 4.0 operation.
Example	> :LTRaining:SEquence:REV4:USTReam:PRESet? < 7

:INPut:DATA:EQualizer:AMPLitude <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to 0 -12 to 0 dB, 1 step
Function	Sets CTLE Gain to be used in PCIe 3.0 or PCIe 4.0 operation. This parameter is available only when SI ED (with MU195040A-x11/x21) is installed.
Example	To set CTLE Gain to -8 dB. > :INPut:DATA:EQualizer:AMPLitude -8

:INPut:DATA:EQualizer:AMPLitude?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to 0 -12 to 0 dB, 1 step
Function	Queries CTLE Gain to be used in PCIe 3.0 or PCIe 4.0 operation. This parameter is available only when SI ED (with MU195040A-x11/x21) is installed.
Example	> :INPut:DATA:EQualizer:AMPLitude? < -8

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)

This setup screen is available only when MX183000A-PL021 is installed, when **PCIe Link Training** is started on the Figure 4.3.1-1 “Selector Screen”, and when the SQA has been connected using Equipment Setup.

5.9.1 Link Training Screen




Figure 5.9.1-1 Link Training Screen

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)

Table 5.9.1-1 Training Setting Items and Result Query Commands

No.	Setting Item	Command
[1]	Specification	:LTRaining:SEQuence:SPECification
		:LTRaining:SEQuence:SPECification?
[2]	DUT	:LTRaining:SEQuence:DUT
		:LTRaining:SEQuence:DUT?
[3]	Training Result	:LTRaining:SEQuence:RESult?
[4]	Sequence Start	:LTRaining:SEQuence:STARt
	Sequence Stop	:LTRaining:SEQuence:STOP
	Sequence State	:LTRaining:SEQuence:STATe?
[5]	LTSSM Log	:LTRaining:SEQuence:LTSSm:LOG:STARt
		:LTRaining:SEQuence:LTSSm:LOG:STOP
		:LTRaining:SEQuence:LTSSm:LOG:STATe?
		:LTRaining:SEQuence:LTSSm:LOG:GATing?
		:LTRaining:SEQuence:LTSSm:LOG:EXPort
[6]	Loopback through	:LTRaining:SEQuence:LTHRough
		:LTRaining:SEQuence:LTHRough?
[7]	Test Pattern	:SOURce:PATtern:TYPE
		:SOURce:PATtern:TYPE?
		:LTRaining:SEQuence:TEST:PATtern
		:LTRaining:SEQuence:TEST:PATtern?
		:SOURce:PATtern:PRBS:LENGth
		:SOURce:PATtern:PRBS:LENGth?
[8]	Training Result (Control SKP)	:LTRaining:SEQuence:RESult:CSKP?

5

Remote Control

:LTRaining:SEquence:START

Parameter	None
Function	Starts transmitting a link training sequence for looping back DUT. Once the transmission is complete, the pattern selected by Test Pattern is sent.
Example	> :LTRaining:SEquence:START

:LTRaining:SEquence:STOP

Parameter	None
Function	Stops transmitting link training sequence and test pattern and sets to Electrical Idle.
Example	> :LTRaining:SEquence:STOP

:LTRaining:SEquence:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Stop
	1	Sending
	2	Sending test pattern
Function	Queries the link training sequence transmission status.	
Example	> :LTRaining:SEquence:STATe? < 1	

:LTRaining:SEQuence:SPECification <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	REV1 Revision1.0/1.1
	REV2 Revision2.0
	REV3 Revision3.0/3.1
	REV4 Revision4.0
Function	Selects the environment (revision) to loopback the DUT (Revision).
Example	To set the environment to REV4(16.0 GT/s): > :LTRaining:SEQuence:SPECification REV4
Note: The clock frequency input to MU181500B must be changed by the user when MU181000A/B is not installed.	

:LTRaining:SEQuence:SPECification?

Response	<type>=<CHARACTER RESPONSE DATA> REV1, REV2, REV3, REV4
Function	Queries the environment to loopback the DUT.
Example	> :LTRaining:SEQuence:SPECification? < REV4

:LTRaining:SEQuence:LTHRough <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	CONFiguration Configuration route
	RECOvery Recovery route
Function	Select the LTSSM route to loopback the DUT.
Example	To set the state route to Configuration route: > :LTRaining:SEQuence:LTHRough CONFiguration

:LTRaining:SEQuence:LTHRough?

Response	<type>=<CHARACTER RESPONSE DATA> REC, CONF
Function	Queries the LTSSM route to loopback the DUT.
Example	> :LTRaining:SEQuence:LTHRough? < CONF

:SOURce:PATtern:TYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> COMpliance Compliance pattern PRBS PRBS pattern
Function	Selects the test pattern to be sent after completing the link training sequence transmission.
Example	To set the test pattern to Compliance Pattern: > :SOURce:PATtern:TYPE COMpliance

:SOURce:PATtern:TYPE?

Response	<type>=<CHARACTER RESPONSE DATA> COMP, PRBS
Function	Queries the test pattern to be sent after completing the link training sequence transmission.
Example	> :SOURce:PATtern:TYPE? < COMP

:LTRaining:SEquence:TEST:PATtern <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> CP Compliance Pattern MCP Modified Compliance Pattern JTMP Jitter Tolerance Measurement Pattern* *: This parameter can be set when 32G SI PPG is installed and Rev. 3.x or 4.0 is selected.
Function	Selects the type of Compliance Pattern to be sent when test pattern “:SOURce:PATtern:TYPE” is set to Compliance
Example	> :LTRaining:SEquence:TEST:PATtern CP

:LTRaining:SEquence:TEST:PATtern?

Response	<type>=<CHARACTER RESPONSE DATA> CP Compliance Pattern MCP Modified Compliance Pattern JTMP Jitter Tolerance Measurement Pattern
Function	Queries the type of Compliance Pattern to be sent.
Example	> :LTRaining:SEquence:TEST:PATtern? < CP

:SOURce:PATtern:PRBS:LENGth <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	7 2^n-1 (n=7)
	9 2^n-1 (n=9)
	10 2^n-1 (n=10)
	11 2^n-1 (n=11)
	15 2^n-1 (n=15)
	20 2^n-1 (n=20)
	23 2^n-1 (n=23)
	31 2^n-1 (n=31)
Function	Sets the number of stages (2^n-1 (n=7, 9, 10, 11, 15, 20, 23, or 31)) for PRBS pattern reception.
Example	To set the number of stages for PRBS pattern reception to 2^7-1 : > :SOURce:PATtern:PRBS:LENGth 7

:SOURce:PATtern:PRBS:LENGth?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 7, 9, 10, 11, 15, 20, 23, 31
Function	Queries the number of stages for PRBS pattern reception.
Example	> :SOURce:PATtern:PRBS:LENGth? < 7

:LTRaining:SEQuence:DUT <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	END End Point
	ROOT Root Complex
Function	Selects the DUT type.
Example	To set the DUT to End Point. > :LTRaining:SEQuence:DUT END

:LTRaining:SEQuence:DUT?

Response	<type>=<CHARACTER RESPONSE DATA> END, ROOT
Function	Queries the DUT type.
Example	> :LTRaining:SEQuence:DUT? < END

:LTRaining:SEquence:LTSSm:LOG:START

Parameter	None
Function	Starts acquiring LTSSM Log.
Example	> :LTRaining:SEquence:LTSSm:LOG:START

:LTRaining:SEquence:LTSSm:LOG:STOP

Parameter	None
Function	Aborts acquiring LTSSM Log.
Example	> :LTRaining:SEquence:LTSSm:LOG:STOP

:LTRaining:SEquence:LTSSm:LOG:EXPort <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name	
Function	Stores LTSSM Log in CSV format specifying a file name and format.	
Example	To store LTSSM Log. >:LTRaining:SEquence:LTSSm:LOG:EXPort "D:\test_folder\test.csv"	

:LTRaining:SEquence:LTSSm:LOG:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Stop 1 Acquiring Log	
Function	Queries the status of log acquisition.	
Example	> :LTRaining:SEquence:STATe? < 1	

:LTRaining:SEquence:LTSSm:LOG:GATIng?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 100 0 to 100%	
Function	Queries the progress of log acquisition.	
Example	> :LTRaining:SEquence:LTSSm:LOG:GATIng? < 1	

:LTRaining:SEquence:RESult? <type>

Parameter	< type>=<CHARACTER PROGRAM DATA>	
	STATe	LTSSM State
	LSPeed	Linkup Speed
	TXSCount	SKP Count Tx
	RXSCount	SKP Count Rx
	SERR	Symbol Err
	CRERr	Current RD Err
	SLOCK	Symbol Lock
	TXDC	DC Balance Tx
	RXDC	DC Balance Rx
	SHERr	Sync Header Err
	PERR	Parity Err
	BLOCK	Block Lock
	LERequest	Link Eq Request
	LEPhase0	Link Eq Phase0
	LEPhase1	Link Eq Phase1
	LEPhase2	Link Eq Phase2
	LEPhase3	Link Eq Phase3
	LEALL	Link Eq PhaseALL
	UPReset	Use Preset
	TXPReset	PPG Final Preset
	PRECursor	PPG Final Pre-Cursor
	CURSor	PPG Final Cursor
	POSTcursor	PPG Final Post-Cursor
	RFSWing	Full Swing
	RLFrequency	Low Frequency
	RLINK	Link Number
	RLANe	Lane Number
	RREQualization	Root Complex Request Equalization
Response	<string>=<STRING RESPONSE DATA>	
Function	Queries the measurement data of the desired parameter.	
Example	<pre>> :LTRaining:SEquence:RESult? STATE < Loopback.Active.Master</pre>	

:LTRaining:SEquence:RESult:CSKP? <type>

Parameter	<type>=<CHARACTER RESPONSE DATA>	
	TXCount	Control SKP Count Tx
	RXCount	Control SKP Count Rx
	TXMType	Control SKP Margin Type Tx
	RXMType	Control SKP Margin Type Rx
	TXUModel	Control SKP Usage Model Tx
	RXUModel	Control SKP Usage Model Rx
	TXPayload	Control SKP Payload Tx
	RXPayload	Control SKP Payload Rx
	TXRNumber	Control SKP Receiver Number Tx
	RXRNumber	Control SKP Receiver Number Rx
	CRC	Control SKP CRC
	PARity	Control SKP Parity
Response	<type>=<CHARACTER RESPONSE DATA>	
Function	Queries the measurement data related to the Control SKP parameters.	
Example	> :LTRaining:SEquence:RESult:CSKP? TXCount < 100	

5.9.2 BER Measurement Screen

For explanation of [1] to [8], refer to 5.8.2 “BER Measurement Screen”.




Figure 5.9.2-1 BER Measurement Screen




Figure 5.9.2-2 Equalization Setup Screen (Preset)




Figure 5.9.2-3 Equalization Setup Screen (Cursor)




Figure 5.9.2-4 Equalization Setup Screen (User)

Table 5.9.2-1 Equalization Setting and Query Commands

No.	Setting Item	Command
[9]	Tx Equalization for Loopback.Active State (Auto/Manual)	:LTRaining:SEquence:TXPReset:LPRreset
		:LTRaining:SEquence:TXPReset:LPRreset?
[10]	Equalization for Loopback.Active State	:LTRaining:SEquence:TXPReset:SElect
		:LTRaining:SEquence:TXPReset:SElect?
[11]	Preset	:LTRaining:SEquence:TXPReset:LPRreset:PRESet
		:LTRaining:SEquence:TXPReset:LPRreset:PRESet?
[12]	Cursor	:LTRaining:SEquence:TXCursor
		:LTRaining:SEquence:TXCursor?
[13]	PS (Pre-Shoot)	:LTRaining:SEquence:TXPReset:PSHoot
		:LTRaining:SEquence:TXPReset:PSHoot?
[14]	DE (De-Emphasis)	:LTRaining:SEquence:TXPReset:DEMPhasis
		:LTRaining:SEquence:TXPReset:DEMPhasis?
[15]	Alarm	:SOURce:EMPHasis:EALarm?

:LTRaining:SEquence:TXPReset:LPRreset <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 Auto
	1 Manual
Function	Sets whether to manually switch Equalization to be used in Loopback.Active state.
Example	To manually set Equalization to be used in Loopback.Active state: > :LTRaining:SEquence:TXPReset:LPRreset 1

:LTRaining:SEquence:TXPReset:LPRreset?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Auto
	1 Manual
Function	Queries whether to manually switch Equalization to be used in Loopback.Active state.
Example	> :LTRaining:SEquence:TXPReset:LPRreset? < 1

:LTRaining:SEquence:TXPReset:SElect <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	PRESet	Sets Equalization mode to Preset.
	CURSor	Sets Equalization mode to Cursor.
	USER	Sets Equalization mode to User, which enables Equalization to be set in dB.
Function	Sets PPG's Equalization mode to Preset.	
Example	> :LTRaining:SEquence:TXPReset:SElect PRESet	

:LTRaining:SEquence:TXPReset:SElect?

Response	<type>=<CHARACTER PROGRAM DATA>	
	PRES	Sets Equalization mode to Preset.
	CURS	Sets Equalization mode to Cursor.
	USER	Sets Equalization mode to User, which enables Equalization to be set in dB.
Function	Queries PPG's Equalization mode.	
Example	> :LTRaining:SEquence:TXPReset:SElect? < PRES	

:LTRaining:SEquence:TXPReset:LPRreset:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 to 10	P0 to P10, 1 step
Function	Sets the Preset value to be used in Loopback.Active state. This command is available when Preset is selected by :LTRaining:SEquence:TXPReset:SElect.	
Example	To set the Preset value to P7: > :LTRaining:SEquence:TXPReset:LPRreset:PRESet 7	

:LTRaining:SEquence:TXPReset:LPRreset:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0 to 10	P0 to P10
Function	Queries the Preset value to be used in Loopback.Active state. This command is available when Preset is selected by :LTRaining:SEquence:TXPReset:SElect.	
Example	> :LTRaining:SEquence:TXPReset:LPRreset:PRESet? < 7	

:LTRaining:SEquence:TXCursor <type>,<number>

Parameter	<type>=<CHARACTER PROGRAM DATA> C-1 Sets the Cursor value for C-1. C+1 Sets the Cursor value for C+1. <number>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 8 Cursor 0 to 8 Note: The maximum values for C-1 and C+1 are respectively 6 and 8, and each of them depends on the setting of the other. For the setting ranges, refer to “Figure 5.9.2-3 Equalization Setup Screen (Cursor)”.
Function	Sets the Cursor value to be used in Loopback.Active state. This command is available when Cursor is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	To set C-1 to 1 and C+1 to 6: > :LTRaining:SEquence:TXCursor C-1,1 > :LTRaining:SEquence:TXCursor C+1,6

:LTRaining:SEquence:TXCursor? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> C-1 Queries the Cursor value of C-1. C+1 Queries the Cursor value of C+1. Note: The maximum values for C-1 and C+1 are respectively 6 and 8. Also, they are affected by the settings of C-1 and C+1. For the setting ranges, refer to “Figure 5.9.2-3 Equalization Setup Screen (Cursor)”.
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 8
Function	Queries the Cursor value to be used in Loopback.Active state. This command is available when Cursor is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	To query the value set for C+1: > :LTRaining:SEquence:TXCursor? C+1 < 6

:LTRaining:SEquence:TXPReset:PShoot <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.0 to 20.0 0.0 to 20.0 dB, 0.1 dB step
Function	Sets the Pre-Shoot value (dB) to be used in Loopback.Active state. This command is available when User is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	To set the Pre-Shoot value to 3.5 dB: > :LTRaining:SEquence:TXPReset:PShoot 3.5

:LTRaining:SEquence:TXPReset:PShoot?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0.0 to 20.0 0.0 to 20.0 dB
Function	Queries the Pre-Shoot value (dB) to be used in Loopback.Active state. This command is available when User is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	> :LTRaining:SEquence:TXPReset:PShoot? < 3.5

:LTRaining:SEquence:TXPReset:DEMPhasis <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -20.0 to 0.0 -20.0 to 0.0 dB, 0.1 dB step
Function	Sets the Pre-Shoot value (dB) to be used in Loopback.Active state. This command is available when User is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	To set the Pre-Shoot value to -6.0 dB: > :LTRaining:SEquence:TXPReset:DEMPhasis -6.0

:LTRaining:SEquence:TXPReset:DEMPhasis?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -20.0 to 0.0 -20.0 to 0.0 dB
Function	Queries the Pre-Shoot value (dB) to be used in Loopback.Active state. This command is available when User is selected by :LTRaining:SEquence:TXPReset:SElect.
Example	> :LTRaining:SEquence:TXPReset:DEMPhasis? < -6.0

:SOURce:EMPHasis:EALarm?

Response	<div><sel> = <CHARACTER RESPONSE DATA></div> <div>PASS The Emphasis parameters have integrity.</div> <div>L_OVER 1.5 Vpp Limit Over</div> <div>L_UNDER 0.1 Vpp Limit Under</div> <div>L_HW Hardware Limit Over</div>
Function	<div>Queries whether the PPG’s output amplitude is within the setting range of the emphasis peak voltage.</div> <div>This command is available when User is selected by :LTRaining:SEQuence:TXPReset:SElect.</div>
Example	<div>> :SOURce:EMPHasis:EALarm?</div> <div>< PASS</div>

5.9.3 Timeout Screen




Figure 5.9.3-1 Timeout Setup Screen

Table 5.9.3-1 Training Timeout Setup Commands

No.	Setting Item	Command
[1]	Detect.Quiet	:LTRaining:SEquence:TOUT:DQUiet
		:LTRaining:SEquence:TOUT:DQUiet?
[2]	Polling.Config	:LTRaining:SEquence:TOUT:POLLing:CONFIguration
		:LTRaining:SEquence:TOUT:POLLing:CONFIguration?
[3]	Polling.Active	:LTRaining:SEquence:TOUT:POLLing:ACTive
		:LTRaining:SEquence:TOUT:POLLing:ACTive?
[4]	.Linkwidth.Start	:LTRaining:SEquence:TOUT:CONFIguration:LSTart
		:LTRaining:SEquence:TOUT:CONFIguration:LSTart?
[5]	.Lanenum.Wait	:LTRaining:SEquence:TOUT:CONFIguration:LWAI
		:LTRaining:SEquence:TOUT:CONFIguration:LWAI?
[6]	.Linkwidth.Accept	:LTRaining:SEquence:TOUT:CONFIguration:LACcept
		:LTRaining:SEquence:TOUT:CONFIguration:LACcept?
[7]	.Complete	:LTRaining:SEquence:TOUT:CONFIguration:COMplete
		:LTRaining:SEquence:TOUT:CONFIguration:COMplete?
[8]	.Idle	:LTRaining:SEquence:TOUT:CONFIguration:IDLE
		:LTRaining:SEquence:TOUT:CONFIguration:IDLE?

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)

Table 5.9.3-1 Training Timeout Setup Commands (Cont'd)

No.	Setting Item	Command
[9]	Hotreset	:LTRaining:SEquence:TOUT:HOTReset
		:LTRaining:SEquence:TOUT:HOTReset?
[10]	Disable	:LTRaining:SEquence:TOUT:DISable
		:LTRaining:SEquence:TOUT:DISable?
[11]	.RcvrLock	:LTRaining:SEquence:TOUT:RECoverY:RLOCK
		:LTRaining:SEquence:TOUT:RECoverY:RLOCK?
[12]	.RcvrCfg	:LTRaining:SEquence:TOUT:RECoverY:RCFG
		:LTRaining:SEquence:TOUT:RECoverY:RCFG?
[13]	.Idle	:LTRaining:SEquence:TOUT:RECoverY:IDLE
		:LTRaining:SEquence:TOUT:RECoverY:IDLE?
[14]	.Speed	:LTRaining:SEquence:TOUT:RECoverY:SPEEd
		:LTRaining:SEquence:TOUT:RECoverY:SPEEd?
[15]	Root .Eq.Phase0	:LTRaining:SEquence:TOUT:RECoverY:REQP0
		:LTRaining:SEquence:TOUT:RECoverY:REQP0?
[16]	Root .Eq.Phase1	:LTRaining:SEquence:TOUT:RECoverY:REQP1
		:LTRaining:SEquence:TOUT:RECoverY:REQP1?
[17]	Endpoint .Eq.Phase1	:LTRaining:SEquence:TOUT:RECoverY:EEQP1
		:LTRaining:SEquence:TOUT:RECoverY:EEQP1?
[18]	Root .Eq.Phase2	:LTRaining:SEquence:TOUT:RECoverY:REQP2
		:LTRaining:SEquence:TOUT:RECoverY:REQP2?
[19]	Endpoint .Eq.Phase2	:LTRaining:SEquence:TOUT:RECoverY:EEQP2
		:LTRaining:SEquence:TOUT:RECoverY:EEQP2?
[20]	Root .Eq.Phase3	:LTRaining:SEquence:TOUT:RECoverY:REQP3
		:LTRaining:SEquence:TOUT:RECoverY:REQP3?
[21]	Endpoint .Eq.Phase3	:LTRaining:SEquence:TOUT:RECoverY:EEQP3
		:LTRaining:SEquence:TOUT:RECoverY:EEQP3?
[22]	->Exit	:LTRaining:SEquence:TOUT:LBENtry:EXIT
		:LTRaining:SEquence:TOUT:LBENtry:EXIT?
[23]	->Active	:LTRaining:SEquence:TOUT:LBENtry:ACTive
		:LTRaining:SEquence:TOUT:LBENtry:ACTive?
[24]	Initialize Timeout	:LTRaining:SEquence:TOUT:INITialize

:LTRaining:SEquence:TOUT:INITialize

Parameter	None
Function	Initialize the set values of Timeout.
Example	To initialize the set values of Timeout. > :LTRaining:SEquence:TOUT:INITialize

:LTRaining:SEquence:TOUT:DQUiet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 6.0 to 24.0 6.0 to 24.0 ms, 0.1 ms
Function	Sets the timeout of Detect Quiet state.
Example	To set the timeout to 12.0 ms. > :LTRaining:SEquence:TOUT:DQUiet 12.0

:LTRaining:SEquence:TOUT:DQUiet?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 6.0 to 24.0
Function	Queries the timeout of Detect Quiet state.
Example	> :LTRaining:SEquence:TOUT:DQUiet? < 12.0

:LTRaining:SEquence:TOUT:POLLing:CONFIguration <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 24.0 to 72.0 24.0 to 72.0 ms, 0.1 ms
Function	Sets the timeout of Polling.Configuration state.
Example	To set the timeout to 48.0 ms. > :LTRaining:SEquence:TOUT:POLLing:CONFIguration 48.0

:LTRaining:SEquence:TOUT:POLLing:CONFIguration?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 24.0 to 72.0
Function	Queries the timeout of Polling.Configuration state.
Example	> :LTRaining:SEquence:TOUT:POLLing:CONFIguration? < 48.0

:LTRaining:SEquence:TOUT:POLLIing:ACTive <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Polling.Active state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:POLLIing:ACTive 24.0

:LTRaining:SEquence:TOUT:POLLIing:ACTive?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Polling.Active state.
Example	> :LTRaining:SEquence:TOUT:POLLIing:ACTive? < 24.0

:LTRaining:SEquence:TOUT:CONFIguration:LStart <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Configuration.Linkwidth.Start state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:CONFIguration:LStart 24.0

:LTRaining:SEquence:TOUT:CONFIguration:LStart?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Configuration.Linkwidth.Start state.
Example	> :LTRaining:SEquence:TOUT:CONFIguration:LStart? < 24.0

:LTRaining:SEquence:TOUT:CONFiguration:LWAI t <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Configuration.Lanenum.Wait state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:CONFiguration:LWAI t 2.0

:LTRaining:SEquence:TOUT:CONFiguration:LWAI t?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Configuration.Lanenum.Wait state.
Example	> :LTRaining:SEquence:TOUT:CONFiguration:LWAI t? < 2.0

:LTRaining:SEquence:TOUT:CONFiguration:LACCept <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Configuration.Linkwidth.Accept state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:CONFiguration:LACCept 2.0

:LTRaining:SEquence:TOUT:CONFiguration:LACCept?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Configuration.Linkwidth.Accept state.
Example	> :LTRaining:SEquence:TOUT:CONFiguration:LACCept? < 2.0

:LTRaining:SEquence:TOUT:CONFiguration:COMPLete <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Configuration.Complete state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:CONFiguration:COMPLete 2.0

:LTRaining:SEquence:TOUT:CONFiguration:COMPLete?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Configuration.Complete state.
Example	> :LTRaining:SEquence:TOUT:CONFiguration:COMPLete? < 2.0

:LTRaining:SEquence:TOUT:CONFiguration:IDLE <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Configuration.Idle state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:CONFiguration:IDLE 2.0

:LTRaining:SEquence:TOUT:CONFiguration:IDLE?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Configuration.Idle state.
Example	> :LTRaining:SEquence:TOUT:CONFiguration:IDLE? < 2.0

:LTRaining:SEquence:TOUT:REcovery:RLOCK <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.RcvrLock state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:REcovery:RLOCK 24.0

:LTRaining:SEquence:TOUT:REcovery:RLOCK?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Recovery.RcvrLock state.
Example	> :LTRaining:SEquence:TOUT:REcovery:RLOCK? < 24.0

:LTRaining:SEquence:TOUT:REcovery:RCFG <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 24.0 to 72.0 24.0 to 72.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.RcvrCfg state.
Example	To set the timeout to 48.0 ms. > :LTRaining:SEquence:TOUT:REcovery:RCFG 48.0

:LTRaining:SEquence:TOUT:REcovery:RCFG?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 24.0 to 72.0
Function	Queries the timeout of Recovery.RcvrCfg state.
Example	> :LTRaining:SEquence:TOUT:REcovery:RCFG? < 48.0

:LTRaining:SEquence:TOUT:REcovery:SPEed <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 24.0 to 72.0 24.0 to 72.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Speed state.
Example	To set the timeout to 48.0 ms. > :LTRaining:SEquence:TOUT:REcovery:SPEed 48.0

:LTRaining:SEquence:TOUT:REcovery:SPEed?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 24.0 to 72.0
Function	Queries the timeout of Recovery.Speed state.
Example	> :LTRaining:SEquence:TOUT:REcovery:SPEed? < 48.0

:LTRaining:SEquence:TOUT:REcovery:IDLE <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Idle state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:REcovery:IDLE 2.0

:LTRaining:SEquence:TOUT:REcovery:IDLE?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Recovery.Idle state.
Example	> :LTRaining:SEquence:TOUT:REcovery:IDLE? < 2.0

:LTRaining:SEquence:TOUT:RECover:EEQP1 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase1 (End point) state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:RECover:EEQP1 24.0

:LTRaining:SEquence:TOUT:RECover:EEQP1?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Recovery.Equalization.Phase1 (End point) state.
Example	> :LTRaining:SEquence:TOUT:RECover:EEQP1? < 24.0

:LTRaining:SEquence:TOUT:RECover:EEQP2 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 16.0 to 48.0 16.0 to 48.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase2 (End point) state.
Example	To set the timeout to 32.0 ms. > :LTRaining:SEquence:TOUT:RECover:EEQP2 32.0

:LTRaining:SEquence:TOUT:RECover:EEQP2?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 16.0 to 48.0
Function	Queries the timeout of Recovery.Equalization.Phase2 (End point) state.
Example	> :LTRaining:SEquence:TOUT:RECover:EEQP2? < 32.0

:LTRaining:SEquence:TOUT:RECover:EEQP3 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase3 (End point) state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:RECover:EEQP3 24.0

:LTRaining:SEquence:TOUT:RECover:EEQP3?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Recovery.Equalization.Phase3 (End point) state.
Example	> :LTRaining:SEquence:TOUT:RECover:EEQP3? < 24.0

:LTRaining:SEquence:TOUT:RECover:REQP0 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 6.0 to 18.0 6.0 to 18.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase0 (Root Complex) state.
Example	To set the timeout to 12.0 ms. > :LTRaining:SEquence:TOUT:RECover:REQP0 12.0

:LTRaining:SEquence:TOUT:RECover:REQP0?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 6.0 to 18.0
Function	Queries the timeout of Recovery.Equalization.Phase0 (Root Complex) state.
Example	> :LTRaining:SEquence:TOUT:RECover:REQP0? < 12.0

:LTRaining:SEquence:TOUT:RECover:REQP1 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 6.0 to 18.0 6.0 to 18.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase1 (Root Complex) state.
Example	To set the timeout to 12.0 ms. > :LTRaining:SEquence:TOUT:RECover:REQP1 12.0

:LTRaining:SEquence:TOUT:RECover:REQP1?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 6.0 to 18.0
Function	Queries the timeout of Recovery.Equalization.Phase1 (Root Complex) state.
Example	> :LTRaining:SEquence:TOUT:RECover:REQP1? < 12.0

:LTRaining:SEquence:TOUT:RECover:REQP2 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 12.0 to 36.0 12.0 to 36.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase2 (Root Complex) state.
Example	To set the timeout to 24.0 ms. > :LTRaining:SEquence:TOUT:RECover:REQP2 24.0

:LTRaining:SEquence:TOUT:RECover:REQP2?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 12.0 to 36.0
Function	Queries the timeout of Recovery.Equalization.Phase2 (Root Complex) state.
Example	> :LTRaining:SEquence:TOUT:RECover:REQP2? < 24.0

:LTRaining:SEquence:TOUT:RECover:REQP3 <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 16.0 to 48.0 16.0 to 48.0 ms, 0.1 ms step
Function	Sets the timeout of Recovery.Equalization.Phase3 (Root Complex) state.
Example	To set the timeout to 32.0 ms. > :LTRaining:SEquence:TOUT:RECover:REQP3 32.0

:LTRaining:SEquence:TOUT:RECover:REQP3?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 16.0 to 48.0
Function	Queries the timeout of Recovery.Equalization.Phase3 (Root Complex) state.
Example	> :LTRaining:SEquence:TOUT:RECover:REQP3? < 32.0

:LTRaining:SEquence:TOUT:LBENtry:ACTive <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Loopback.Entry to Active state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:LBENtry:ACTive 2.0

:LTRaining:SEquence:TOUT:LBENtry:ACTive?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Loopback.Entry to Active state.
Example	> :LTRaining:SEquence:TOUT:LBENtry:ACTive? < 2.0

:LTRaining:SEquence:TOUT:LBENtry:EXIT <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 50.0 to 150.0 50.0 to 150.0 ms, 0.1 ms step
Function	Sets the timeout of Loopback.Entry to Exit state.
Example	To set the timeout to 100.0 ms. > :LTRaining:SEquence:TOUT:LBENtry:EXIT 100.0

:LTRaining:SEquence:TOUT:LBENtry:EXIT?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 50.0 to 150.0
Function	Queries the timeout of Loopback.Entry to Exit state.
Example	> :LTRaining:SEquence:TOUT:LBENtry:EXIT? < 100.0

:LTRaining:SEquence:TOUT:HOTReset <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Hotreset state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:HOTReset 2.0

:LTRaining:SEquence:TOUT:HOTReset?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Hotreset state.
Example	> :LTRaining:SEquence:TOUT:HOTReset? < 2.0

:LTRaining:SEquence:TOUT:DISable <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1.0 to 3.0 1.0 to 3.0 ms, 0.1 ms step
Function	Sets the timeout of Disable state.
Example	To set the timeout to 2.0 ms. > :LTRaining:SEquence:TOUT:DISable 2.0

:LTRaining:SEquence:TOUT:DISable?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 1.0 to 3.0
Function	Queries the timeout of Disable state.
Example	> :LTRaining:SEquence:TOUT:DISable? < 2.0

5.9.4 Option Screen




Figure 5.9.4-1 Option Setup Screen (State Machine)




Figure 5.9.4-2 Option Setup Screen (SKP)

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)




Figure 5.9.4-3 Option Setup Screen (Link EQ – PCIe 2.0)




Figure 5.9.4-4 Option Setup Screen (Link EQ – PCIe 4.0)




Figure 5.9.4-5 Option Setup Screen (PPG/ED)




Figure 5.9.4-6 Option Setup Screen (Trigger)

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)

Table 5.9.4-1 Sequence Option Screen Setup Commands

No.	Setting Item	Command
[1]	FTS	:LTRaining:SEQuence:FTS
		:LTRaining:SEQuence:FTS?
[2]	Link Number	:LTRaining:SEQuence:LiNKnum
		:LTRaining:SEQuence:LiNKnum?
[3]	Lane Number	:LTRaining:SEQuence:LANenum
		:LTRaining:SEQuence:LANenum?
[4]	Full Swing	:LTRaining:SEQuence:FSWing?
[5]	Low Frequency	:LTRaining:SEQuence:LFRequency?
[6]	EIEOS Reset Interval	:LTRaining:SEQuence:REIeos:INTErval
		:LTRaining:SEQuence:REIeos:INTErval?
[7]	EIEOS 16G Format	:LTRaining:SEQuence:REIeos:FORMat
		:LTRaining:SEQuence:REIeos:FORMat?
[8]	Send TS Polling.Active	:LTRaining:SEQuence:PACTive:TS
		:LTRaining:SEQuence:PACTive:TS?
[9]	Send TS Loopback.Entry	:LTRaining:SEQuence:LENTry:TS
		:LTRaining:SEQuence:LENTry:TS?
[10]	Disable Scrambling	:LTRaining:SEQuence:DSCRamble
		:LTRaining:SEQuence:DSCRamble?
[11]	Insert Delay Symbol	:LTRaining:SEQuence:DSYMBol
		:LTRaining:SEQuence:DSYMBol?
[12]	Extended Sync Patterns	:LTRaining:SEQuence:ESYNc:PATTern
		:LTRaining:SEQuence:ESYNc:PATTern?
[13]	Timeout to	:LTRaining:SEQuence:TOUT:LBENTry:SELEct
		:LTRaining:SEQuence:TOUT:LBENTry:SELEct?
[14]	Speed Change	:LTRaining:SEQuence:CSPeed
		:LTRaining:SEQuence:CSPeed?
[15]	SRIS	:LTRaining:SEQuence:SRIS
		:LTRaining:SEQuence:SRIS?

Table 5.9.4-1 Sequence Option Screen Setup Commands (Cont'd)

No.	Setting Item	Command
[16]	SKP Insert	:LTraining:SEQuence:SKP
		:LTraining:SEQuence:SKP?
[17]	Symbol Length 8b/10b	:LTraining:SEQuence:SKP:SLENgth:8B10B
		:LTraining:SEQuence:SKP:SLENgth:8B10B?
[18]	Interval 8b/10b	:LTraining:SEQuence:SKP:INTerval:8B10B
		:LTraining:SEQuence:SKP:INTerval:8B10B?
[19]	Symbol Length 128b/130b	:LTraining:SEQuence:SKP:SLENgth:128B130B
		:LTraining:SEQuence:SKP:SLENgth:128B130B?
[20]	Interval 128b/130b	:LTraining:SEQuence:SKP:INTerval:128B130B
		:LTraining:SEQuence:SKP:INTerval:128B130B?
[21]	Double SKP (8b/10b)	:LTraining:SEQuence:SKP:DOUBle:8B10B
		:LTraining:SEQuence:SKP:DOUBle:8B10B?
[22]	Double SKP (128b/130b)	:LTraining:SEQuence:SKP:DOUBle:128B130B
		:LTraining:SEQuence:SKP:DOUBle:128B130B?
[23]	Filter	:LTraining:SEQuence:FILTer
		:LTraining:SEQuence:FILTer?

Table 5.9.4-1 Sequence Option Screen Setup Commands (Cont'd)

No.	Setting Item	Command
[24]	De-emphasis	:LTraining:SEQuence:REV2:DEMPHasis
		:LTraining:SEQuence:REV2:DEMPHasis?
[25]	Recovery Phase2, 3	:LTraining:SEQuence:REV3:RECOvery:PH2_3
		:LTraining:SEQuence:REV3:RECOvery:PH2_3?
		:LTraining:SEQuence:REV3:REPeat:ROOT
		:LTraining:SEQuence:REV3:REPeat:ROOT?
		:LTraining:SEQuence:REV3:REPeat:ENDPoint
		:LTraining:SEQuence:REV3:REPeat:ENDPoint?
		:LTraining:SEQuence:REV3:RECOvery:ALGorithm
		:LTraining:SEQuence:REV3:RECOvery:ALGorithm?
		:LTraining:SEQuence:REV4:RECOvery:PH2_3
		:LTraining:SEQuence:REV4:RECOvery:PH2_3?
		:LTraining:SEQuence:REV4:REPeat:ROOT
		:LTraining:SEQuence:REV4:REPeat:ROOT?
		:LTraining:SEQuence:REV4:REPeat:ENDPoint
		:LTraining:SEQuence:REV4:REPeat:ENDPoint?
		:LTraining:SEQuence:REV4:RECOvery:ALGorithm
		:LTraining:SEQuence:REV4:RECOvery:ALGorithm?
[26]	Preset (Rev 3.x)	:LTraining:SEQuence:REV3:DSTReam:PRESet
		:LTraining:SEQuence:REV3:DSTReam:PRESet?
		:LTraining:SEQuence:REV3:USTReam:PRESet
		:LTraining:SEQuence:REV3:USTReam:PRESet?
[27]	Preset Hint (Rx) (Rev 3.x)	:LTraining:SEQuence:REV3:DSTReam:HPRESet
		:LTraining:SEQuence:REV3:DSTReam:HPRESet?
		:LTraining:SEQuence:REV3:USTReam:HPRESet
		:LTraining:SEQuence:REV3:USTReam:HPRESet?
[28]	Preset (Rev 4.0)	:LTraining:SEQuence:REV4:DSTReam:PRESet
		:LTraining:SEQuence:REV4:DSTReam:PRESet?
		:LTraining:SEQuence:REV4:USTReam:PRESet
		:LTraining:SEQuence:REV4:USTReam:PRESet?
[29]	Usepreset (PCIe 3.0)	:LTraining:SEQuence:REV3:UPReset
		:LTraining:SEQuence:REV3:UPReset?
	Usepreset (PCIe 4.0)	:LTraining:SEQuence:REV4:UPReset
		:LTraining:SEQuence:REV4:UPReset?

Table 5.9.4-1 Sequence Option Screen Setup Commands (Cont'd)

No.	Setting Item	Command
[30]	Tx Equalization for 2.5GT/s	:LTraining:SEQuence:TXPReset:IPReset
		:LTraining:SEQuence:TXPReset:ILPReset?
[31]	Tx Equalization for Loopback.Active State (Auto/Manual)	:LTraining:SEQuence:TXPReset:LPReset
		:LTraining:SEQuence:TXPReset:LPReset?
[32]	Equalization for Loopback.Active State	:LTraining:SEQuence:TXPReset:SELEct
		:LTraining:SEQuence:TXPReset:SELEct?
		:LTraining:SEQuence:TXPReset:LPReset:PRESet
		:LTraining:SEQuence:TXPReset:LPReset:PRESet?
[33]	CTLE Gain	:INPut:DATA:EQUalizer:AMPLitude
		:INPut:DATA:EQUalizer:AMPLitude?
[34]	Trigger	:LTraining:SEQuence:TRIGger:SELEct
		:LTraining:SEQuence:TRIGger:SELEct?
[35]	Link Speed	:LTraining:SEQuence:TRIGger:SPEed
		:LTraining:SEQuence:TRIGger:SPEed?
[36]	State	:LTraining:SEQuence:TRIGger:STATe
		:LTraining:SEQuence:TRIGger:STATe?
[37]	Change Preset	:LTraining:SEQuence:TRIGger:CPReset
		:LTraining:SEQuence:TRIGger:CPReset?
[38]	Auto Reset	:LTraining:SEQuence:AUTO:RESet
		:LTraining:SEQuence:AUTO:RESet?
[39]	Power Reset Power Cycle Comp Trigger	:LTraining:SEQuence:AUTO:PRESet
		:LTraining:SEQuence:AUTO:PCYCLE
		:LTraining:SEQuence:AUTO:CTRigger
		:LTraining:SEQuence:AUTO:PRESet:TIME
		:LTraining:SEQuence:AUTO:PRESet:TIME?
		:LTraining:SEQuence:AUTO:PCYCLE:TIME
		:LTraining:SEQuence:AUTO:PCYCLE:TIME?
		:LTraining:SEQuence:AUTO:CTRigger:TIME
		:LTraining:SEQuence:AUTO:CTRigger:TIME?
[40]	Waiting Time	:LTraining:SEQuence:AUTO:AWAit:TIME
		:LTraining:SEQuence:AUTO:AWAit:TIME?
[41]	PPG Electrical Idle Time	:LTraining:SEQuence:EITime
		:LTraining:SEQuence:EITime?

:LTRaining:SEquence:FTS <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 2550 to 255, 1 step
Function	Sets the TS FTS value.
Example	To set the TS FTS value to 127: > :LTRaining:SEquence:FTS 127

:LTRaining:SEquence:FTS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 2550 to 255
Function	Queries the TS FTS setting.
Example	> :LTRaining:SEquence:FTS? < 127

:LTRaining:SEquence:LINKnum <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 2550 to 255, 1 step
Function	Sets the TS Link Number.
Example	To set the Link Number to 1: > :LTRaining:SEquence:LINKnum 1

:LTRaining:SEquence:LINKnum?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 2550 to 255
Function	Queries the TS Link Number.
Example	> :LTRaining:SEquence:LINKnum? < 1

:LTRaining:SEquence:LANenum <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 255 0 to 255, 1 step
Function	Sets the TS Lane Number.
Example	To set the Lane Number to 1: > :LTRaining:SEquence:LANenum 100

:LTRaining:SEquence:LANenum?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 255 0 to 255
Function	Queries the TS Lane Number.
Example	> :LTRaining:SEquence:LANenum? < 100

:LTRaining:SEquence:FSWing?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 24
Function	Queries the TS Full Swing value.
Example	> :LTRaining:SEquence:FSWing? < 24

:LTRaining:SEquence:LFRrequency?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 8
Function	Queries the TS Low Frequency value.
Example	> :LTRaining:SEquence:LFRrequency? < 8

:LTRaining:SEquence:SRIS <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 Disable
	ON or 1 Enable
Function	Selects whether to operate using Separate Refclock with Independent SSC.
Example	To operate using Separate Refclock with Independent SSC. > :LTRaining:SEquence:SRIS 1

:LTRaining:SEquence:SRIS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Disable
	1 Enable
Function	Queries whether to operate using Separate Refclock with Independent SSC.
Example	> :LTRaining:SEquence:SRIS? < 1

:LTRaining:SEquence:DSCRamble <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 De-assert
	ON or 1 Assert
Function	Sets the TS Disable scramble bit.
Example	To set Disable scramble to Asset: > :LTRaining:SEquence:DSCRamble 1

:LTRaining:SEquence:DSCRamble?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 De-assert
	1 Assert
Function	Queries the TS Disable scramble bit value.
Example	> :LTRaining:SEquence:DSCRamble? < 1

:LTRaining:SEquence:REleos:INTERval <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Disables the EIEOS Reset Interval Count bit.
	ON or 1	Enables the EIEOS Reset Interval Count bit.
Function	Sets the TS EIEOS Reset Interval Count bit value.	
Example	> :LTRaining:SEquence:REleos:INTERval ON	

:LTRaining:SEquence:REleos:INTERval?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	The EIEOS Reset Interval Count bit disabled.
	1	The EIEOS Reset Interval Count bit enabled.
Function	Queries the TS EIEOS Reset Interval Count bit value.	
Example	> :LTRaining:SEquence:REleos:INTERval? < 1	

:LTRaining:SEquence:REleos:FORMat <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0	Older than Rev 0.7
	1	Rev 0.7 or later
Function	Sets EIEOS format to PCIe 4 Rev 0.7 or later.	
Example	> :LTRaining:SEquence:REleos:FORMat 1	

:LTRaining:SEquence:REleos:FORMat?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Older than Rev 0.7
	1	Rev 0.7 or later
Function	Queries if EIEOS format is PCIe 4 Rev 0.7 or later.	
Example	> :LTRaining:SEquence:REleos:FORMat? < 1	

:LTRaining:SEquence:AUTO:RESet <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	OFF	Does not send any signal.
	RESet	Sends a power reset signal.
	PCYCl	Sends a power OFF signal.
Function	Upon receipt of the :LTRaining:SEquence:STARt command, sends the specified signal to the CBB control pins before starting Link Training.	
Example	> :LTRaining:SEquence:AUTO:RESet RESet	

:LTRaining:SEquence:AUTO:RESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	OFF	Does not send any signal.
	RES	Sends a power reset signal.
	PCYC	Sends a power OFF signal.
Function	Queries whether to send a signal to the CBB control pins before starting Link Training.	
Example	> :LTRaining:SEquence:AUTO:RESet? < RES	

:LTRaining:SEquence:AUTO:PRESet

Parameter	None
Function	Sends a power reset signal to the PCIe CBB 4.0.
Example	> :LTRaining:SEquence:AUTO:PRESet

:LTRaining:SEquence:AUTO:PCYCl

Parameter	None
Function	Sends a power OFF signal to the PCIe CBB 4.0.
Example	> :LTRaining:SEquence:AUTO:PCYCl

:LTRaining:SEquence:AUTO:CTRigger

Parameter	None
Function	Sends a Comp Trigger signal to the PCIe CBB 4.0.
Example	> :LTRaining:SEquence:AUTO:CTRigger

:LTRaining:SEquence:AUTO:PRESet:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.1 to 20.0 0.1 to 20.0, 0.1 step
Function	Sets the time (seconds) to send a power reset signal.
Example	To send a power reset signal for 3 seconds. >:LTRaining:SEquence:AUTO:PRESet:TIME 3.0

:LTRaining:SEquence:AUTO:PRESet:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0.1 to 20.0 0.1 to 20.0, 0.1 step
Function	Queries the time (seconds) to send a power reset signal.
Example	>:LTRaining:SEquence:AUTO:PRESet:TIME? < 3.0

:LTRaining:SEquence:AUTO:PCYClE:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.1 to 20.0 0.1 to 20.0, 0.1 step
Function	Sets the time (seconds) to send a power OFF signal.
Example	To send a power OFF signal for 3 seconds. >:LTRaining:SEquence:AUTO:PCYClE:TIME 3.0

:LTRaining:SEquence:AUTO:PCYClE:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0.1 to 20.0 0.1 to 20.0, 0.1 step
Function	Queries the time (seconds) to send a power OFF signal.
Example	>:LTRaining:SEquence:AUTO:PCYClE:TIME? < 3.0

:LTRaining:SEquence:AUTO:CTRigger:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.1 to 1.0 0.1 to 1.0, 0.1 step
Function	Sets the time (seconds) to send a Compliance Trigger signal.
Example	To send a Compliance Trigger signal for 0.1 second. >:LTRaining:SEquence:AUTO:CTRigger:TIME 0.1

:LTRaining:SEquence:AUTO:CTRigger:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0.1 to 1.0 0.1 to 1.0, 0.1 step
Function	Queries the time (seconds) to send a Compliance Trigger signal.
Example	>:LTRaining:SEquence:AUTO:CTRigger:TIME? < 0.1

:LTRaining:SEquence:AUTO:AWAit:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.1 to 300.0 0.1 to 300.0, 0.1 step
Function	Sets the time to wait after Link Start is clicked, a power reset or power OFF signal is sent and the power is turned ON, and before Link Training is started (DUT is stabilized).
Example	To set the wait time to 5 seconds. >:LTRaining:SEquence:AUTO:AWAit:TIME 5.0

:LTRaining:SEquence:AUTO:AWAit:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0.1 to 300.0 0.1 to 300.0, 0.1 step
Function	Queries the time to wait after Link Start is clicked, a power reset or power OFF signal is sent and the power is turned ON, and before Link Training is started (DUT is stabilized).
Example	>:LTRaining:SEquence:AUTO:AWAit:TIME? < 5.0

:LTRaining:SEquence:SKP <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	SKP OS not inserted
	ON or 1	SKP OS inserted
Function	Selects whether to insert SKP OS while transmitting a sequence.	
Example	To insert SKP OS	
	> :LTRaining:SEquence:SKP ON	

:LTRaining:SEquence:SKP?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	SKP OS not inserted
	1	SKP OS inserted
Function	Queries whether SKP OS is inserted while transmitting a sequence.	
Example	> :LTRaining:SEquence:SKP?	
	< 1	

:LTRaining:SEquence:SKP:SLENgth:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1	COM + 1 symbol
	2	COM + 2 symbols
	3	COM + 3 symbols
	4	COM + 4 symbols
	5	COM + 5 symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.	
Example	To set the number of SKP OS SKP symbols to 3:	
	>:LTRaining:SEquence:SKP:SLENgth:8B10B 3	

:LTRaining:SEquence:SKP:SLENgth:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1, 2, 3, 4, 5	
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.	
Example	> :LTRaining:SEquence:SKP:SLENgth:8B10B?	
	< 3	

:LTRaining:SEquence:SKP:INTerval:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 80 to 3076 80 to 3076, 2 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	To generate an SKP OS once after every 1538 symbols sent: >:LTRaining:SEquence:SKP:INTerval:8B10B 1538

:LTRaining:SEquence:SKP:INTerval:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 80 to 3076 80 to 3076, 2 step
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	>:LTRaining:SEquence:SKP:INTerval:8B10B? < 1538

:LTRaining:SEquence:SKP:DOUBle:8B10B <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Double SKP OS not inserted. ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state.
Example	To insert double SKP OS. > :LTRaining:SEquence:DOUBle:8B10B 1

:LTRaining:SEquence:SKP:DOUBle:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Double SKP OS not inserted. 1 Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state.
Example	> :LTRaining:SEquence:DOUBle:8B10B? < 1

:LTRaining:SEQuence:SKP:SLENgth:128B130B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	8	8 Symbols
	12	12 Symbols
	16	16 Symbols
	20	20 Symbols
	24	24 Symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 128b/130b Encoding operation.	
Example	To set the number of SKP OS SKP symbols to 8: > :LTRaining:SEQuence:SKP:SLENgth:128B130B 8	

:LTRaining:SEQuence:SKP:SLENgth:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 8, 12, 16, 20, 24	
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 128b/130b Encoding operation.	
Example	> :LTRaining:SEQuence:SKP:SLENgth:128B130B? < 8	

:LTRaining:SEQuence:SKP:INTerval:128B130B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 20 to 750 20 to 750, 1 step	
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 128b/130b Encoding operation.	
Example	To generate an SKP OS once after every 375 blocks sent: >:LTRaining:SEQuence:SKP:INTerval:128B130B 375	

:LTRaining:SEQuence:SKP:INTerval:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 20 to 750 20 to 750	
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 128b/130b Encoding operation.	
Example	>:LTRaining:SEQuence:SKP:INTerval:128b130b? < 375	

:LTRaining:SEquence:SKP:DOUBle:128B130B <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 Double SKP OS not inserted.
	ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 128b/130b encoding and in Loopback.Active state.
Example	To insert double SKP OS. > :LTRaining:SEquence:DOUBle:128B130B 1

:LTRaining:SEquence:SKP:DOUBle:128B130B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Double SKP OS not inserted.
	1 Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 128b/130b encoding and in Loopback.Active state.
Example	> :LTRaining:SEquence:DOUBle:128B130B? < 1

:LTRaining:SEquence:PACTive:TS <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Selects the type of TS transmitted for Polling.Active State.
Example	To set the TS to be transmitted for Polling.Active State to TS1 Ordered Set: > :LTRaining:SEquence:PACTive:TS 0

:LTRaining:SEquence:PACTive:TS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Transmits TS1 Ordered Set.
	1 Transmits EQ TS1 Ordered Set.
Function	Queries the type of TS transmitted for Polling.Active State.
Example	> :LTRaining:SEquence:PACTive:TS? < 0

:LTRaining:SEquence:LEnTry:TS <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> 0 Transmits TS1 Ordered Set. 1 Transmits EQ TS1 Ordered Set.
Function	Selects the type of TS transmitted for Loopback.Entry State.
Example	To set the TS to be transmitted for Loopback.Entry State to TS1 Ordered Set: > :LTRaining:SEquence:LEnTry:TS 0

:LTRaining:SEquence:LEnTry:TS?

Response	<type>=<CHARACTER RESPONSE DATA> 0 Transmits TS1 Ordered Set. 1 Transmits EQ TS1 Ordered Set.
Function	Queries the type of TS transmitted for Polling.Active State.
Example	> :LTRaining:SEquence:LEnTry:TS? < 0

:LTRaining:SEquence:TXPReset:LPReset <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 Auto 1 Manual
Function	Sets whether to change manually the Equalization to use in Loopback.Active state.
Example	To set manually the Equalization to use in Loopback.Active state. > :LTRaining:SEquence:TXPReset:LPReset 1

:LTRaining:SEquence:TXPReset:LPReset?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Auto 1 Manual
Function	Queries whether to change manually the Equalization to use in Loopback.Active state.
Example	> :LTRaining:SEquence:TXPReset:LPReset? < 1

:LTRaining:SEQuence:TXPReset:SElect <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	PRESet	Sets Equalization mode to Preset.
	CURSor	Sets Equalization mode to Cursor.
	USER	Sets Equalization mode to User, which enables Equalization to be set in dB.
Function	To set PPG's Equalization mode to Preset:	
Exempl	> :LTRaining:SEQuence:TXPReset:LElect PRESet	

:LTRaining:SEQuence:TXPReset:SElect?

Response	<type>=<CHARACTER PROGRAM DATA>	
	PRESet	Sets Equalization mode to Preset.
	CURSor	Sets Equalization mode to Cursor.
	USER	Sets Equalization mode to User, which enables Equalization to be set in dB.
Function	Queries PPG's Equalization mode.	
Exempl	> :LTRaining:SEQuence:TXPReset:LElect? < PRES	

:LTRaining:SEQuence:TXPReset:LPRreset:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 to 10	P0 to P10, 1 step
Function	Sets the Preset value to be used in Loopback.Active state. This command is available when Preset is selected by :LTRaining:SEQuence:TXPReset:SElect.	
Example	To set the Preset value to P7. > :LTRaining:SEQuence:TXPReset:LPRreset:PRESet 7	

:LTRaining:SEQuence:TXPReset:LPRreset:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0 to 10	P0 to P10
Function	Queries the Preset value to be used in Loopback.Active state. This command is available when Preset is selected by :LTRaining:SEQuence:TXPReset:SElect.	
Example	> :LTRaining:SEQuence:TXPReset:LPRreset:PRESet? < 7	

:LTRaining:SEquence:TXPReset:IPReset <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value to use at the sequence start (2.5 GT/s transmission).
Example	To set the Preset value to P7. > :LTRaining:SEquence:TXPReset:IPReset 7

:LTRaining:SEquence:TXPReset:IPReset?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value to use at the sequence start (2.5 GT/s transmission).
Example	> :LTRaining:SEquence:TXPReset:IPReset? < 7

:LTRaining:SEquence:REV2:DEMPhasis <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -6.0 -6.0 dB -3.5 -3.5 dB
Function	Sets De-emphasis for PCIe 2.0 operation.
Example	To set De-emphasis to -6.0 dB. > :LTRaining:SEquence:REV2:DEMPhasis -6.0

:LTRaining:SEquence:REV2:DEMPhasis?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> -6.0, -3.5
Function	Queries De-emphasis for PCIe 2.0 operation.
Example	> :LTRaining:SEquence:REV2:DEMPhasis? < -6.0

:LTRaining:SEQuence:REV3:DSTReam:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that is notified to DUT and used by SI PPG in PCIe 3.0 operation.
Example	To set the Preset value to P7. > :LTRaining:SEQuence:REV3:DSTReam:PRESet 7

:LTRaining:SEQuence:REV3:DSTReam:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that is notified to DUT and used by SI PPG in PCIe 3.0 operation.
Example	> :LTRaining:SEQuence:REV3:DSTReam:PRESet? < 7

:LTRaining:SEQuence:REV3:USTReam:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that DUT is requested for in PCIe 3.0 operation.
Example	To set the Preset value to P7. > :LTRaining:SEQuence:REV3:USTReam:PRESet 7

:LTRaining:SEQuence:REV3:USTReam:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that DUT is requested for in PCIe 3.0 operation.
Example	> :LTRaining:SEQuence:REV3:USTReam:PRESet? < 7

:LTRaining:SEquence:REV3:DSTream:HPRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to -6 -12 to -6 dB, 1 step
Function	Sets the Preset Hint value that is notified to DUT in PCIe 3.0 operation.
Example	To set Preset Hint to -10 dB. > :LTRaining:SEquence:REV3:DSTream:HPRESet -10

:LTRaining:SEquence:REV3:DSTream:HPRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to -6 -12 to -6 dB
Function	Queries the Preset Hint value that is notified to DUT in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:USTream:DPRESet? < -10

:LTRaining:SEquence:REV3:USTream:HPRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to -6 -12 to -6 dB, 1 step
Function	Sets the Preset Hint value that DUT is requested for in PCIe 3.0 operation.
Example	To set Preset Hint to -10 dB. > :LTRaining:SEquence:REV3:USTream:HPRESet -10

:LTRaining:SEquence:REV3:USTream:HPRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to -6 -12 to -6 dB
Function	Queries the Preset Hint value that DUT is requested for in PCIe 3.0 operation.
Example	> :LTRaining:SEquence:REV3:USTream:HPRESet? < -10

:LTRaining:SEquence:REV4:DSTream:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Queries the Preset value that is notified to DUT and used by SI PPG in PCIe 4.0 operation.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV4:DSTream:PRESet 7

:LTRaining:SEquence:REV4:DSTream:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that is notified to DUT and used by SI PPG in PCIe 4.0 operation.
Example	> :LTRaining:SEquence:REV4:DSTream:PRESet? < 7

:LTRaining:SEquence:REV4:USTream:PRESet <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 10 P0 to P10, 1 step
Function	Sets the Preset value that DUT is requested for in PCIe 4.0 operation.
Example	To set the Preset value to P7. > :LTRaining:SEquence:REV4:USTream:PRESet 7

:LTRaining:SEquence:REV4:USTream:PRESet?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 10 P0 to P10
Function	Queries the Preset value that DUT is requested for in PCIe 4.0 operation.
Example	> :LTRaining:SEquence:REV4:USTream:PRESet? < 7

:LTRaining:SEQuence:ESYNc:PATtern <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> NORMal Sets normal transition conditions. EXTended Sets extended transition conditions.
Function	Sets whether to transmit at least 1024 continuous TS1 OS as the transition conditions from Recovery.RcvrLock to Recovery.RcvrCfg State.
Example	To set the Preset value to EXTended. > :LTRaining:SEQuence:ESYNc:PATtern EXTended

:LTRaining:SEQuence:ESYNc:PATtern?

Response	<type>=<CHARACTER RESPONSE DATA> NORM, EXT
Function	Queries whether to transmit at least 1024 continuous TS1 OS as the transition conditions from Recovery.RcvrLock to Recovery.RcvrCfg State.
Example	> :LTRaining:SEQuence:ESYNc:PATtern? < EXT

:LTRaining:SEquence:REV3:RECover:PH2_3 <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	TRY Tries Recovery.Equalization.Phase2 and 3.
	SKIP Skips Recovery.Equalization.Phase2 and 3.
Function	Sets whether to try Recovery.Equalization.Phase2 and 3.
Example	To set Recovery.Equalization.Phase2 and 3 to TRY. > :LTRaining:SEquence:REV3:RECover:PH2_3 TRY

:LTRaining:SEquence:REV3:RECover:PH2_3?

Response	<type>=<CHARACTER RESPONSE DATA>
	TRY, SKIP
Function	Queries whether to try Recovery.Equalization.Phase2 and 3.
Example	> :LTRaining:SEquence:REV3:RECover:PH2_3? < TRY

:LTRaining:SEquence:REV3:REPeat:ROOT <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	1 to 10 1 to 10, 1 step
Function	Sets the number of times Recovery.Equalization is tried during Root Complex test.
Example	To set the number of times Recovery.Equalization is tried to 5. > :LTRaining:SEquence:REV3:REPeat:ROOT 5

:LTRaining:SEquence:REV3:REPeat:ROOT?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	1 to 10
Function	Queries the number of times Recovery.Equalization is tried during Root Complex test.
Example	> :LTRaining:SEquence:REV3:REPeat:ROOT? < 5

:LTRaining:SEquence:REV3:REPeat:ENDPoint <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	1 to 10 1 to 10, 1 step
Function	Sets the number of times Recovery.Equalization is tried during End Point test.
Example	To set the number of times Recovery.Equalization is tried to 5. > :LTraining:SEquence:REV3:REpeat:ENDPoint 5

:LTRaining:SEquence:REV3:REPeat:ENDPoint?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 10
Function	Queries the number of times Recovery.Equalization is tried during End Point test.
Example	> :LTRaining:SEquence:REV3:REPeat:ENDPoint? < 5

:LTRaining:SEQuence:REV3:RECover:ALGorithm <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	0 Increment
	1 Change Preset
Function	Sets Preset change method of Recovery.Equalization.Phase2 and 3 (Gen3).
Example	To set Preset change method to Change Preset. > :LTraining:SEquence:REV3:REcovery:ALGORITHM 1

:LTRaining:SEQuence:REV3:RECOvery:ALGorithm?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0: Increment
	1: Change Preset
Function	Queries Preset change method of Recovery.Equalization.Phase2 and 3 (Gen3).
Example	> :LTRaining:SEquence:REV3:REcovery:ALGorithm? < 1

:LTRaining:SEquence:REV4:RECover:PH2_3 <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	TRY Tries Recovery.Equalization.Phase2 and 3.
	SKIP Skips Recovery.Equalization.Phase2 and 3.
Function	Sets whether to try Recovery.Equalization.Phase2 and 3.
Example	To set Recovery.Equalization.Phase2 and 3 to TRY. > :LTRaining:SEquence:REV4:RECover:PH2_3 TRY

:LTRaining:SEquence:REV4:RECover:PH2_3?

Response	<type>=<CHARACTER RESPONSE DATA>
	TRY, SKIP
Function	Queries whether to try Recovery.Equalization.Phase2 and 3.
Example	> :LTRaining:SEquence:REV4:RECover:PH2_3? < TRY

:LTRaining:SEquence:REV4:REPeat:ROOT <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	1 to 10 1 to 10, 1 step
Function	Sets the number of times Recovery.Equalization is tried during Root Complex test.
Example	To set the number of times Recovery.Equalization is tried to 5. > :LTRaining:SEquence:REV4:REPeat:ROOT 5

:LTRaining:SEquence:REV4:REPeat:ROOT?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	1 to 10
Function	Queries the number of times Recovery.Equalization is tried during Root Complex test.
Example	> :LTRaining:SEquence:REV4:REPeat:ROOT? < 5

:LTRaining:SEquence:REV4:REPeat:ENDPoint <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 10 1 to 10, 1 step
Function	Sets the number of times Recovery.Equalization is tried during End Point test.
Example	To set the number of times Recovery.Equalization is tried to 5. > :LTRaining:SEquence:REV4:REPeat:ENDPoint 5

:LTRaining:SEquence:REV4:REPeat:ENDPoint?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 10
Function	Queries the number of times Recovery.Equalization is tried during End Point test.
Example	> :LTRaining:SEquence:REV4:REPeat:ENDPoint? < 5

:LTRaining:SEquence:REV4:RECover:ALGorithm <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 Increment 1 Change Preset
Function	Sets Preset change method of Recovery.Equalization.Phase2 and 3 (Gen4).
Example	To set Preset change method to Change Preset. > :LTRaining:SEquence:REV4:RECover:ALGorithm 1

:LTRaining:SEquence:REV4:RECover:ALGorithm?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0: Increment 1: Change Preset
Function	Queries Preset change method of Recovery.Equalization.Phase2 and 3 (Gen4).
Example	> :LTRaining:SEquence:REV4:RECover:ALGorithm? < 1

:INPut:DATA:EQualizer:AMPLitude <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -12 to 0 -12 to 0 dB, 1 step
Function	Sets CTLE Gain to be used in PCIe 3.0 or PCIe 4.0 operation. This parameter is available only when SI ED (with MU195040A-x11/x21) is installed.
Example	To set CTLE Gain to -8 dB. > :INPut:DATA:EQualizer:AMPLitude -8

:INPut:DATA:EQualizer:AMPLitude?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -12 to 0 -12 to 0 dB, 1 step
Function	Queries CTLE Gain to be used in PCIe 3.0 or PCIe 4.0 operation. This parameter is available only when SI ED (with MU195040A-x11/x21) is installed.
Example	> :INPut:DATA:EQualizer:AMPLitude? < -8

:LTRaining:SEquence:FILTer <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Does not remove SKP OS. ON or 1 Removes SKP OS.
Function	Sets whether to remove SKP OS at the BER measurement.
Example	To remove SKP OS. > :LTRaining:SEquence:FILTer ON

:LTRaining:SEquence:FILTer?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 SKP OS is not removed. 1 SKP OS is removed.
Function	Queries whether to remove SKP OS at the BER measurement.
Example	> :LTRaining:SEquence:FILTer? < 1

:LTRaining:SEquence:DSYMBOL <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Delay Symbol not inserted
	ON or 1	Delay Symbol inserted
Function	Selects whether to insert a Delay Symbol.	
Example	> :LTRaining:SEquence:DSYMBOL ON	

:LTRaining:SEquence:DSYMBOL?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Delay Symbol not inserted
	1	Delay Symbol inserted
Function	Queries whether the Delay Symbol is to be inserted.	
Example	> :LTRaining:SEquence:DSYMBOL? < 1	

:LTRaining:SEquence:TOUT:LBENTRY:SElect <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0	Times out to the Loopback.Exit state.
	1	Times out to the Loopback.Active state.
Function	Sets the next state when the MP1900A times out in the Loopback.Entry state.	
Example	To change the state to the Loopback.Active state when the MP1900A times out in the Loopback.Entry state. > :LTRaining:SEquence:TOUT:LBENTRY:SElect 1	

:LTRaining:SEquence:TOUT:LBENTRY:SElect?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Times out to the Loopback.Exit state.
	1	Times out to the Loopback.Active state.
Function	Queries the next state when the MP1900A times out in the Loopback.Entry state.	
Example	> :LTRaining:SEquence:TOUT:LBENTRY:SElect? < 1	

:LTRaining:SEquence:EITime <type>

Parameter	<type>=<DECIMAL NUMERIC PROGRAM DATA>
	0 < 1 ms
	1 ≥ 1 ms
Function	Sets the PPG's Electrical Idle time before the MP1900A changes the bit rate. For details of parameter settings, refer to the description of PPG Electrical Idle Time in 4.8.2 "Setting PCIe Link Training".
Example	To set the Electrical Idle Time of the MP1900A to less than 1 ms: > :LTRaining:SEquence:EITime 0

:LTRaining:SEquence:EITime?

Response	<type>=<NR1 NUMERIC RESPONSE DATA>
	0 < 1 ms
	1 ≥ 1 ms
Function	Queries the PPG's Electrical Idle time before the MP1900A changes the bit rate.
Example	> : LTRaining: SEquence: EITime? < 0

:LTRaining:SEquence:CSpeed <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	FAST Sets the time for changing data rate to Fast.
	MIDDLE Sets the time for changing data rate to Middle.
	SLOW Sets the time for changing data rate to Slow.
Function	Sets the time required for the MP1900A to change the data rate. For details on how to use, see the explanation of Speed Change in "4.8.1 PCIe Link Training Setting Screen".
Example	To set the time for changing data rate of the MP1900A to Slow. > :LTRaining:SEquence:CSpeed SLOW

:LTRaining:SEquence:CSpeed?

Response	<type>=<CHARACTER PROGRAM DATA>
	FAST Sets the time for changing data rate to Fast.
	MIDDLE Sets the time for changing data rate to Middle.
	SLOW Sets the time for changing data rate to Slow.
Function	Queries the time for changing data rate by the MP1900A.
Example	> :LTRaining:SEquence:CSpeed? < SLOW

:LTRaining:SEquence:REV3:UPReset <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	PRESet	Requests an Equalizer change to the DUT using Preset.
	CURSor	Requests an Equalizer change to the DUT using Cursor.
	Requests an Equalizer change to the DUT using Cursor when the MP1900A operates using PCIe 3.0 and is in the Recovery.Equalization state.	
Example	To set Usepreset of PCIe 3.0 to Cursor. > :LTRaining:SEquence:REV3:UPReset CURSor	

:LTRaining:SEquence:REV3:UPReset?

Response	<type>=<CHARACTER PROGRAM DATA>	
	PRES	Requests an Equalizer change to the DUT using Preset.
	CURS	Requests an Equalizer change to the DUT using Cursor.
Function	Queries the method for requesting an Equalizer change to the DUT when the MP1900A operates using PCIe 3.0 and is in the Recovery.Equalization state.	
Example	> :LTRaining:SEquence:REV3:UPReset? < CURS	

:LTRaining:SEQuence:REV4:UPReset <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	PRESet	Requests an Equalizer change to the DUT using Preset.
	CURSor	Requests an Equalizer change to DUT using Cursor.
	Requests an Equalizer change to the DUT using Preset or Cursor when the MP1900A operates using PCIe 4.0 and is in the Recovery.Equalization state.	
Example	To set Usepreset of PCIe 4.0 to Cursor. > :LTRaining:SEQuence:REV4:UPReset CURSor	

:LTRaining:SEQuence:REV4:UPReset?

Response	<type>=<CHARACTER PROGRAM DATA>	
	PRES	Requests an Equalizer change to the DUT using Preset.
	CURS	Requests an Equalizer change to the DUT using Cursor.
Function	Queries the method for requesting an Equalizer change to the DUT when the MP1900A operates using PCIe 4.0 and is in the Recovery.Equalization state.	
Example	> :LTRaining:SEQuence:REV4:UPReset? < CURS	

:LTRaining:SEQuence:TRIGger:SElect <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	OFF	Does not output a trigger.
	LEQ	Outputs a trigger when the MP1900A is in the condition specified at Change Preset during LEQ.
	LTSSm	Outputs a trigger when the MP1900A changes to the specified LTSSM during Training.
Function	Sets the condition when the MP1900A outputs a trigger from the AUX Output of SI PPG.	
Example	To set the trigger output condition to LEQ.	
	> :LTRaining:SEQuence:TRIGger:SElect LEQ	

:LTRaining:SEQuence:TRIGger:SElect?

Response	<type>=<CHARACTER PROGRAM DATA>	
	OFF	Does not output a trigger.
	LEQ	Outputs a trigger when the MP1900A is in the condition specified at Change Preset during LEQ.
	LTSS	Outputs a trigger when the MP1900A changes to the specified LTSSM during Training.
Function	Queries the condition when the MP1900A outputs a trigger from the AUX Output of SI PPG.	
Example	> :LTRaining:SEQuence:TRIGger:SElect?	
	< LEQ	

:LTRaining:SEQuence:TRIGger:SPEed <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	2.5	2.5 GT/s
	5.0	5.0 GT/s
	8.0	8.0 GT/s
	16.0	16.0 GT/s
Function	Sets the operating data rate condition when the MP1900A outputs a trigger during Link Training.	
Example	To set the trigger output condition to 16.0 GT/s. > :LTRaining:SEQuence:TRIGger:SPEed 16.0	

:LTRaining:SEQuence:TRIGger:SPEed?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA>	
	2.5	2.5 GT/s
	5.0	5.0 GT/s
	8.0	8.0 GT/s
	16.0	16.0 GT/s
Function	Queries the operating data rate condition when the MP1900A outputs a trigger during Link Training.	
Example	> :LTRaining:SEQuence:TRIGger:SPEed? < 16.0	

:LTRaining:SEQuence:TRIGger:STATe <type>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	1 Detect.Quiet
	2 Detect.Active
	17 Polling.Active_TS1
	18 Polling.Active_EQTS1
	19 Polling.Compliance.Pattern(CP)
	20 Polling.Compliance.Change
	21 Polling.Compliance.Exit
	22 Polling.Configuration
	27 Polling.Compliance.Pattern(MCP)
	33 Configuration.Linkwidth.Start
	34 Configuration.Linkwidth.Accept
	35 Configuration.Lanenum.Wait
	36 Configuration.Lanenum.Accept
	37 Configuration.Complete
	38 Configuration.Idle
	49 Recovery.Rcvr.Lock
	50 Recovery.Speed
	51 Recovery.Rcvr.Cfg.TS2
	52 Recovery.Rcvr.Cfg.EQTS2
	53 Recovery.Idle
	56 Recovery.Equalization.Phase0
	57 Recovery.Equalization.Phase1
	58 Recovery.Equalization.Phase2
	59 Recovery.Equalization.Phase3
	65 L0
	97 Loopback.Entry.Master.TS1
	98 Loopback.Entry.Master.EQTS1
	99 Loopback.Entry.Master.Change
	100 Loopback.Active.Master
	101 Loopback.Exit.Master
	105 Loopback.Entry.Slave
	106 Loopback.Active.Slave
	107 Loopback.Exit.Slave
Function	Sets the state condition when the MP1900A outputs a trigger during Link Training.
	This is enabled when LTSSM is selected at Trigger Select.
Example	To output a trigger when the MP1900A changes to the Loopback.Active state during Link Training.
	> :LTRaining:SEQuence:TRIGger:STATe 100

:LTRaining:SEQuence:TRIGger:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> For the return value, refer to the parameter of the :LTRaining:SEQuence:TRIGger:STATe command.
Function	Sets the state condition when the MP1900A outputs a trigger during Link Training. This is enabled when LTSSM is selected at Trigger Select.
Example	> :LTRaining:SEQuence:TRIGger:STATe? < 100

:LTRaining:SEQuence:TRIGger:CPReset <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> SEND Outputs a trigger when the MP1900A sends Change Preset. RECeive Outputs a trigger when the MP1900A receives Change Preset.
Function	Sets the condition when the MP1900A outputs a trigger during LEQ. This is enabled when LEQ is selected at Trigger.
Example	To output a trigger when the MP1900A sends the Change Preset signal during LEQ. > :LTRaining:SEQuence:TRIGger:CPReset SEND

:LTRaining:SEQuence:TRIGger:CPReset?

Response	<type>=<CHARACTER PROGRAM DATA> SEND Outputs a trigger when the MP1900A sends Change Preset. REC Outputs a trigger when the MP1900A receives Change Preset.
Function	Sets the condition when the MP1900A outputs a trigger during LEQ. This is enabled when LEQ is selected at Trigger.
Example	> :LTRaining:SEQuence:TRIGger:CPReset? < SEND

5.9.5 Link Equalization Test Setup Screen




Figure 5.9.5-1 Link Equalization Test Setup Screen

Table 5.9.5-1 Link Equalization Test Setup Screen and Query Command

No.	Setting Item	Command
[1]	LEQ Test Window	:DISPlay:SETTing:LEQ
		:DISPlay:SETTing:LEQ?
[2]	LEQ Test	:LTRaining:SEQuence:LEQTest:REV3
		:LTRaining:SEQuence:LEQTest:REV3?
		:LTRaining:SEQuence:LEQTest:REV4
		:LTRaining:SEQuence:LEQTest:REV4?

:DISPlay:SETTing:LEQ <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Does not display the LEQ Test window.
	ON or 1	Displays the LEQ Test window.
Function	Displays or hides the LEQ Test window.	
Example	To display the LEQ Test window. > :DISPlay:SETTing:LEQ ON	

:DISPlay:SETTing:LEQ?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Does not display the LEQ Test window.
	1	Displays the LEQ Test window.
Function	Queries whether the LEQ Test window is displayed.	
Example	> :DISPlay:SETTing:LEQ? < 1	

:LTRaining:SEquence:LEQTest:REV3**<type1>*¹,<type2>,<type2>,<type2>*²,<type3>*³**

Parameter	<type1>=<CHARACTER PROGRAM DATA>	
	TXINitial	Initial Tx LEQ Test
	TXResponse	Tx LEQ Response Test
	RXLeq	Rx LEQ Test
	*1: When DUT is System, TXIN cannot be set.	
	<type2>=<CHARACTER PROGRAM DATA>	
	P0 to P10	Preset Number
	*2: When TXIN is selected at the first argument, the third type 2 cannot be set.	
	Sets PPG Starting Preset, DUT Initial Preset (Preset Hinx Tx), and DUT Target preset (Change Preset).	
	<type3>=<CHARACTER PROGRAM DATA>	
	PRESet	Preset
	CURSor	Cursor
	SCURSor	Saved Cursor
	*3: When TXIN is selected at the first argument, this setting cannot be performed.	
	Note:	
	When this command is sent, the processing equivalent to clicking the Apply is performed.	
	This command can be set independently for PCIe 3.0 and 4.0.	
Function	Sets the conditions of LEQ Tests.	
Example	To set as follows in the Initial Tx LEQ Test:	
	P7:	PPG Starting Preset
	P0:	DUT Initial Preset
	This command cannot be used when System is selected as the DUT item.	
	> :LTRaining:SEquence:LEQTest:REV3 TXINitial,P7,P0	
	To set as follows in the Tx LEQ Response Test:	
	P7:	PPG Starting Preset
	P4:	DUT Initial Preset
	P5:	DUT Target Preset
	Link EQ method:	Preset
	>:LTRaining:SEquence:LEQTest:REV3	
	TXResponse,P7,P4,P5,PRESet	

To set as follows in the Rx LEQ Test:

P7: PPG Starting Preset, DUT Initial Preset to P7

P8: DUT Target Preset

Link EQ method: Cursor

> :LTRaining:SEquence:LEQTest:REV3 RXLeq, P7, P7, P8, CURSor

:LTRaining:SEquence:LEQTest:REV3? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	TXINitial Initial Tx LEQ Test
	TXResponse Tx LEQ Response Test
	RXLeq Rx LEQ Test
Response	< type2>=<CHARACTER PROGRAM DATA>
	P0 to P10 Preset Number
	<type3>=<CHARACTER PROGRAM DATA>
	PRES Preset
	CURS Cursor
	SCUR Saved Cursor
Function	Queries the parameters set for the LEQ Test.
Example	To query the settings of the Initial Tx LEQ Test.
	> :LTRaining:SEquence:LEQTest:REV3? TXINitial
	< P7, P0
	To query the settings of the Tx LEQ Response Test.
	> :LTRaining:SEquence:LEQTest:REV3? TXResponse
	< P7, P4, P5, PRES
	To query the settings of the Rx LEQ Test.
	> :LTRaining:SEquence:LEQTest:REV3? RXLeq
	< P7, P7, P8, CURS

:LTRaining:SEquence:LEQTest:REV4**<type1>*¹,<type2>,<type2>,<type2>*²,<type3>*³**

Parameter	<type1>=<CHARACTER PROGRAM DATA>	
	TXINitial	Initial Tx LEQ Test
	TXResponse	Tx LEQ Response Test
	RXLeq	Rx LEQ Test
	*1: When DUT is System, TXIN cannot be set.	
	<type2>=<CHARACTER PROGRAM DATA>	
	P0 to P10	Preset Number
	*2: When TXIN is selected at the first argument, the third type 2 cannot be set.	
	Sets PPG Starting Preset, DUT Initial Preset (Preset Hinx Tx), and DUT Target preset (Change Preset).	
	<type3>=<CHARACTER PROGRAM DATA>	
	PRESet	Preset
	CURSor	Cursor
	SCURsor	Saved Cursor
	*3: When TXIN is selected at the first argument, this setting cannot be performed.	
	Note:	
	When this command is sent, the processing equivalent to clicking the Apply is performed.	
	This command can be set independently for PCIe 3.0 and 4.0.	
Function	Sets the conditions of the LEQ Tests.	
Example	To set as follows in the Initial Tx LEQ Test:	
	P7:	PPG Starting Preset
	P0:	DUT Initial Preset
	This command cannot be used when System is selected as the DUT item.	
	> :LTRaining:SEquence:LEQTest:REV4 TXINitial,P7,P0	
	To set as follows in the Tx LEQ Response Test:	
	P7:	PPG Starting Preset
	P4:	DUT Initial Preset
	P5:	DUT Target Preset
	Link EQ method:	Preset
	>:LTRaining:SEquence:LEQTest:REV4	
	TXResponse,P7,P4,P5,PRESet	

5.9 PCIe Link Training Setup Screen (With MX183000A-PL021 Installed)

To set as follows in the Rx LEQ Test:

P7: PPG Starting Preset, DUT Initial Preset

P8: DUT Target Preset

Link EQ method: Cursor

> :LTRaining:SEquence:LEQTest:REV4 RXLeq, P7, P7, P8, CURSor

:LTRaining:SEquence:LEQTest:REV4? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	TXINitial Initial Tx LEQ Test
	TXResponse Tx LEQ Response Test
	RXLeq Rx LEQ Test
Response	< type2>=<CHARACTER PROGRAM DATA>
	P0 to P10 Preset Number
	<type3>=<CHARACTER PROGRAM DATA>
	PRES Preset
	CURS Cursor
	SCUR Saved Cursor
Function	Queries the parameters set for the LEQ Test.
Example	To query the settings of the Initial Tx LEQ Test.
	> :LTRaining:SEquence:LEQTest:REV4? TXINitial
	< P7, P0
	To query the settings of the Tx LEQ Response Test.
	> :LTRaining:SEquence:LEQTest:REV4? TXResponse
	< P7, P4, P5, PRES
	To query the settings of the Rx LEQ Test.
	> :LTRaining:SEquence:LEQTest:REV4? RXLeq
	< P7, P7, P8, CURS

5.9.6 Saved Cursor Dialog Box




Figure 5.9.6-1 Saved Cursor Dialog Box

Table 5.9.6-1 Saved Cursor Query Commands

No.	Setting Item	Command
[1]	PCIe 3.0	:LTRaining:SEQuence:SCURsor:REV3?
[2]	PCIe 4.0	:LTRaining:SEQuence:SCURsor:REV4?

:LTRaining:SEQuence:SCURsor:REV3? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> P0 to P10 Preset Number
Response	<C-1>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C-1) value <C0>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C0) value <C+1>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C+1) value <Done>=<NR1 NUMERIC RESPONSE DATA> 1 The value sent from the DUT has been kept. 0 The value sent from the DUT has not been kept yet.
Function	Queries the cursor value sent from the DUT corresponding to Presets of 0 to 10 in PCIe 3.0. To use this function, the Link Training between the DUT and the measuring instrument must be complete with Usepreset being set to Preset.
Example	To query the cursor value sent from the DUT for Preset 7: > :LTRaining:SEQuence:SCURsor:REV3? P7 < 5,17,2,1

:LTRaining:SEQuence:SCURsor:REV4? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> P0 to P10 Preset Number
Response	<C-1>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C-1) value <C0>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C0) value <C+1>=<NR1 NUMERIC RESPONSE DATA> 0 to 63 Cursor (C+1) value <Done>=<NR1 NUMERIC RESPONSE DATA> 1 The value sent from the DUT has been kept. 0 The value sent from the DUT has not been kept yet.
Function	Queries the cursor value sent from the DUT corresponding to Presets of 0 to 10 in PCIe 4.0. To use this function, the device testing and Link Training must be complete with Preset.
Example	To query the cursor value sent from the DUT for Preset 7: > :LTRaining:SEQuence:SCURsor:REV4? P7 < 5,17,2,1

5.9.7 Matrix Scan




Figure 5.9.7-1 Matrix Scan Setup Screen

Table 5.9.7-1 Matrix Scan Setup Screen and Query Commands

No.	Setting Item	Command
[1]	Close* ¹	:LTRaining:SEQuence:BMATrix:DISPlay
		:LTRaining:SEQuence:BMATrix:DISPlay?
[2]	Start / Stop	:LTRaining:SEQuence:BMATrix:STARt
		:LTRaining:SEQuence:BMATrix:MRESume
		:LTRaining:SEQuence:BMATrix:STATe?
		:LTRaining:SEQuence:BMATrix:STOP
[3]	BER Meas. Time [sec]	:LTRaining:SEQuence:BMATrix:BER:TIME
		:LTRaining:SEQuence:BMATrix:BER:TIME?
[4]	Relax Time [sec]	:LTRaining:SEQuence:BMATrix:BER:RTIME
		:LTRaining:SEQuence:BMATrix:BER:RTIME?
[5]	Loopback Through* ²	:LTRaining:SEQuence:LTHRough
[6]	PPG Starting Preset	:LTRaining:SEQuence:BMATrix:PRESet
		:LTRaining:SEQuence:BMATrix:PSEL
		:LTRaining:SEQuence:BMATrix:PSEL?

*1: **Close** is used only to close the Matrix Scan Setup screen. To open the Matrix Scan Setup screen, use **Matrix Scan** shown in Figure 5.9.1-1.

*2: Refer to “Loopback through” in 5.9.1 “Link Training Screen”.

Table 5.9.7-1 Matrix Scan Setup Screen and Query Commands (Cont'd)

No.	Setting Item	Command
[7]	CBB Controller* ³	:LTRaining:SEquence:AUTO:RESet
[8]	Display	:LTRaining:SEquence:BMATrix:PDISplay
		:LTRaining:SEquence:BMATrix:PDISplay?
[9]	Search Direction	:LTRaining:SEquence:BMATrix:SDIRection
		:LTRaining:SEquence:BMATrix:SDIRection?
[10]	Full Scan	:LTRaining:SEquence:BMATrix:SCAN
		:LTRaining:SEquence:BMATrix:SCAN?
[11]	FS (Full Swing)	:LTRaining:SEquence:BMATrix:FSWing
		:LTRaining:SEquence:BMATrix:FSWing?
[12]	LF (Low Frequency)* ⁴	:LTRaining:SEquence:BMATrix:LFRequency?
[13]	Matrix Table* ⁵	:LTRaining:SEquence:BMATrix:TSEL
		:LTRaining:SEquence:BMATrix:TSEL?
[14]	Matrix Table* ⁶	:LTRaining:SEquence:BMATrix:RESult?
[15]	Progress bar	:LTRaining:SEquence:BMATrix:PROGress?
[16]	Elapsed Time	:LTRaining:SEquence:BMATrix:ELAPsed?
[17]	Remaining Time	:LTRaining:SEquence:BMATrix:REMAining?
[18]	Report	:LTRaining:SEquence:BMATrix:EXPort

*3: Refer to “CBB Controller” in 5.9.4 “Option Screen”.

*4: Query only

*5: Selecting a cell in the table

*6: Querying the result of the cell in the table

:LTRaining:SEquence:BMATrix:DISPlay <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Does not show Matrix Scan setup screen.
	ON or 1	Shows Matrix Scan setup screen.
Function	Shows or hides the Matrix Scan setup screen.	
Example	To show the Matrix Scan setup screen: > :LTRaining:SEquence:BMATrix:DISPlay ON	

:LTRaining:SEquence:BMATrix:DISPlay?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Does not show Matrix Scan setup screen.
	1	Shows Matrix Scan setup screen.
Function	Queries whether the Matrix Scan setup screen is currently shown.	
Example	> :LTRaining:SEquence:BMATrix:DISPlay? < 1	

:LTRaining:SEquence:BMATrix:START

Parameter	None
Function	Starts Matrix Scan.
Example	> :LTRaining:SEquence:BMATrix:START

:LTRaining:SEquence:BMATrix:MRESume

Parameter	None
Function	When 2 is returned as the response of :LTRaining:SEquence:BMATrix:STATe? (Requesting to reset DUT), sending this command resumes the measurement.
Example	> :LTRaining:SEquence:BMATrix:MRESume

:LTRaining:SEquence:BMATrix:STOP

Parameter	None
Function	Stops Matrix Scan,
Example	> :LTRaining:SEquence:BMATrix:STOP

:LTRaining:SEquence:BMATrix:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Stopped
	1	Being performed
	2	Being requesting DUT resetting
Function	Queries the measurement status of Matrix Scan. Note that when 2 is returned, reset the DUT to start Link Training before sending the :LTRaining:SEquence:BMATrix:REStart command.	
Example	> :LTRaining:SEquence:BMATrix:STATe? < 1	

:LTRaining:SEQuence:BMATrix:BER:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 300 seconds 1 sec/step
Function	Sets the BER measurement time for each cell.
Example	> :LTRaining:SEQuence:BMATrix:BER:TIME 5

:LTRaining:SEQuence:BMATrix:BER:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 300 second
Function	Queries the BER measurement time for each cell.
Example	> :LTRaining:SEQuence:BMATrix:BER:TIME? < 5

:LTRaining:SEQuence:BMATrix:BER:RTIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 60 seconds 1 sec/step
Function	Sets the waiting time until the BER measurement starts, after setting the Cursor value for each cell during the Matrix Scan.
Example	> :LTRaining:SEQuence:BMATrix:BER:RTIME 3

:LTRaining:SEQuence:BMATrix:BER:RTIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 60 seconds
Function	Queries the waiting time until the BER measurement starts, after setting the Cursor value for each cell during the Matrix Scan.
Example	> :LTRaining:SEQuence:BMATrix:BER:RTIME? < 3

:LTRaining:SEquence:BMATrix:PRESet <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Turns off all PPG Starting Presets.
	ON or 1	Turns on all PPG Starting Presets.
Function	Turns on or off all PPG Starting Presets.	
Example	> :LTRaining:SEquence:BMATrix:PRESet ON	

:LTRaining:SEquence:BMATrix:PSEL

<numeric>,<numeric>,<numeric>,<numeric>,<numeric>,<numeric>,<numeric>,<numeric>,<numeric>,<numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 or 1	
Function	Specifies each PPG Starting Preset value of Preset 0 to 10 in that order separated by commas.	
Example	To turn on only Preset0 and Preset7: > :LTRaining:SEquence:BMATrix:PSEL 1,0,0,0,0,0,0,1,0,0,0	

:LTRaining:SEquence:BMATrix:PSEL?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Preset is off.
	1	Preset is on.
Function	Returns the values of PPG Starting Presets in the order of Preset0 to Preset10 separated by commas.	
Example	When only Preset0 and Preset7 are on, the values are returned as below: > :LTRaining:SEquence:BMATrix:PSEL? < 1,0,0,0,0,0,0,1,0,0,0	

:LTRaining:SEQuence:BMATrix:PDISplay <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> P0 to P10
Function	Selects the result (Preset0 to 10) to be displayed in the matrix table area.
Example	> :LTRaining:SEQuence:BMATrix:PDISplay P7

:LTRaining:SEQuence:BMATrix:PDISplay?

Response	<type>=<CHARACTER RESPONSE DATA> P0 to P10
Function	Queries the result currently displayed in the matrix table area.
Example	> :LTRaining:SEQuence:BMATrix:PDISplay? < P7

:LTRaining:SEQuence:BMATrix:SDIRection <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> HORizontal Performs measurement from the selected cell to the right. VERTical Performs measurement downward from the selected cell. BOOSt Performs measurement diagonally downward to the left, from the selected cell.
Function	Sets the order of cells to be measured in Matrix Scan.
Example	> :LTRaining:SEQuence:BMATrix:SDIRection HORizontal

:LTRaining:SEQuence:BMATrix:SDIRection?

Response	<type>=<CHARACTER RESPONSE DATA> HOR, VERT, BOOS
Function	Queries the order of cells to be measured in Matrix Scan.
Example	> :LTRaining:SEQuence:BMATrix:SDIRection? < HOR

:LTRaining:SEquence:BMATrix:SCAN <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Does not perform Full Scan.
	ON or 1	Performs Full Scan.
Function	Turns on or off Full Scan (sets whether to measure all cells from the top-left cell on the matrix table).	
Example	To turn on Full Scan: > :LTRaining:SEquence:BMATrix:SCAN ON	

:LTRaining:SEquence:BMATrix:SCAN?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Does not perform Full Scan.
	1	Performs Full Scan.
Function	Queries whether to measure all cells in Matrix Scan.	
Example	> :LTRaining:SEquence:BMATrix:SCAN? < 1	

:LTRaining:SEquence:BMATrix:FSWing

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	24, 48, 63	
Function	Sets the Full Swing.	
Example	To set Full Swing to 63: > :LTRaining:SEquence:BMATrix:FSWing 63	

:LTRaining:SEquence:BMATrix:FSWing?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	24, 48, 63	
Function	Queries the value of Full Swing.	
Example	> :LTRaining:SEquence:BMATrix:FSWing? < 63	

:LTRaining:SEquence:BMATrix:LFRrequency?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	8, 16, 21	
Function	Queries the value of Low Frequency.	
Example	> :LTRaining:SEquence:BMATrix:LFRrequency? < 21	

:LTRaining:SEQuence:BMATrix:TSEL <numeric1>,<numeric2>

Parameter	<numeric1>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 21 When Full Swing 63 is selected. 0 to 16 When Full Swing 48 is selected. 0 to 8 When Full Swing 24 is selected. <numeric2>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 16 When Full Swing 63 is selected. 0 to 12 When Full Swing 48 is selected. 0 to 6 When Full Swing 24 is selected.
Function	Selects a cell on the matrix. The setting range is limited by the value of Full Swing.
Example	To select the cell ((C+1) : 4, (C-1) : 3) on the matrix: > :LTRaining:SEQuence:BMATrix:TSEL 4,3

:LTRaining:SEQuence:BMATrix:TSEL?

Response	<numeric>,<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 21
Function	Queries the cell currently selected on the matrix. The values of the selected cell are returned in the order of C+1, C-1, and a comma separates the values.
Example	For example, when the cell ((C+1) : 4, (C-1) : 3) is selected, the values are returned as below: > :LTRaining:SEQuence:BMATrix:TSEL? < 4,3

:LTRaining:SEquence:BMATrix:RESult?

<numeric1>,<numeric2>,<type>

Parameter	<numeric1>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 to 21	When Full Swing 63 is selected.
	0 to 16	When Full Swing 48 is selected.
	0 to 8	When Full Swing 24 is selected.
	<numeric2>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 to 16	When Full Swing 63 is selected.
	0 to 12	When Full Swing 48 is selected.
	0 to 6	When Full Swing 24 is selected.
	<type>=<CHARACTER RESPONSE DATA>	
	EC	Error Count
	BER	BER
	PS	Pre-Shoot (dB)
	DE	De-Emphasis (dB)
	BOOST	Boost (dB)
Response	<string>=<STRING RESPONSE DATA>	
Function	Queries the information with specifying the cell.	
Example	> :LTRaining:SEquence:BMATrix:RESult? 1,3,BER	
	< "1.0E-9"	
	> :LTRaining:SEquence:BMATrix:RESult? 1,3,DE	
	< "-1.0"	

:LTRaining:SEquence:BMATrix:PROGress?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0 to 100	
Function	Queries the progress (%) of the measurement.	
Example	> :LTRaining:SEquence:BMATrix:PROGress?	
	< 100	

:LTRaining:SEquence:BMATrix:ELAPsed?

Response	“<hour>,<min>,<second>”=< NR1 NUMERIC RESPONSE DATA > <hour> 0 to 23 0 to 23 hours <min> 0 to 59 0 to 59 minutes <second> 0 to 59 0 to 59 seconds	
Function	Queries the time elapsed from the start time of the measurement.	
Example	> :LTRaining:SEquence:BMATrix:ELAPsed? < "00:02:05"	

:LTRaining:SEquence:BMATrix:REMAining?

Response	“<hour>,<min>,<second>”=< NR1 NUMERIC RESPONSE DATA > <hour> 0 to 23 0 to 23 hours <min> 0 to 59 0 to 59 minutes <second> 0 to 59 0 to 59 seconds	
Function	Queries the assumed remaining time until the measurement ends.	
Example	> :LTRaining:SEquence:BMATrix:REMAining? < "00:01:30"	

:LTRaining:SEquence:BMATrix:EXPort <file_name>,<type>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name <type>=<CHARACTER PROGRAM DATA> HTML HTML format CSV CSV format	
Function	Saves the Matrix scan measurement results on the PC or MP1900A where MX183000A is installed, specifying the file name and file format.	
Example	To save the measurement results in html format: > :LTRaining:SEquence:BMATrix:EXPort? "C:\test\Matrix",HTML	

5.10 USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)

This setup screen is available only when MX183000A-PL012 is installed, when USB Link Sequence is started on the Selector screen (Figure 4.3.1-1), and when the SQA has been connected using Equipment Setup.




Figure 5.10-1 Sequence Screen

5.10 USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)

Table 5.10-1 Sequence Screen Setup Commands

No.	Setting Item	Command
[1]	Sequence Start	:LTRaining:SEQuence:STARt
	Sequence Stop	:LTRaining:SEQuence:STOP
	Sequence State	:LTRaining:SEQuence:STATe?
[2]	Not Wait For The LFPS signal	:LTRaining:SEQuence:NWAI:LFPS
		:LTRaining:SEQuence:NWAI:LFPS?
[3]	Specification	:LTRaining:SEQuence:SPECification
		:LTRaining:SEQuence:SPECification?
[4]	Transmit Test Pattern	:LTRaining:SEQuence:TEST:PATtern:TRANsmit
	Stop Test Pattern	:LTRaining:SEQuence:TEST:PATtern:STOP
[5]	Test pattern	:SOURce:PATtern:TYPE
		:SOURce:PATtern:TYPE?
[6]	Test pattern	:LTRaining:SEQuence:TEST:PATtern
		:LTRaining:SEQuence:TEST:PATtern?
[7]	Add Single Bit Error	:LTRaining:SEQuence:TEST:PATtern:EADDition
[8]	Reset	:LTRaining:SEQuence:INITialize
[9]	Sequence	:LTRaining:SEQuence:DESIgn:GEN1
		:LTRaining:SEQuence:DESIgn:GEN1?
		:LTRaining:SEQuence:DESIgn:GEN2
		:LTRaining:SEQuence:DESIgn:GEN2?

:LTRaining:SEquence:START

Parameter	None
Function	Changes PPG to the wait status for receiving LFPS from DUT. The link training sequence for looping back DUT is transmitted after receiving LFPS. After the transmission, the pattern selected at Test Pattern is sent continuously.
Example	> :LTRaining:SEquence:START

:LTRaining:SEquence:STOP

Parameter	None
Function	Stops transmitting link training sequence and test pattern and sets to Electrical Idle.
Example	> :LTRaining:SEquence:STOP

:LTRaining:SEquence:STATE?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Stop
	1	Sending Sequence Pattern
	2	Sending Test Pattern
Function	Queries the link training sequence transmission status.	
Example	> :LTRaining:SEquence:STATE? < 1	

:LTRaining:SEquence:NWAI:LFPS <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 Starts the link training sequence transmission after receiving the LFPS signal.
	ON or 1 Starts the link training sequence transmission without waiting for receiving the LFPS signal.
Function	Sets the conditions for starting the link training sequence transmission.
Example	To set the mode for starting the link training sequence transmission without waiting for the LFPS signal: > :LTRaining:SEquence:NWAI:LFPS 1

:LTRaining:SEquence:NWAI:LFPS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Starts a sequence after receiving the LFPS signal.
	1 Starts a sequence without waiting for receiving the LFPS signal.
Function	Queries the conditions for starting the link training sequence transmission.
Example	> :LTRaining:SEquence:NWAI:LFPS? < 1

:LTRaining:SEquence:SPECification <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	GEN1 SuperSpeed (5.0 GT/s)
	GEN2 SuperSpeedPlus (10.0 GT/s)
Function	Selects an environment to loopback the DUT supporting USB3.0/3.1.
Example	To set the link training sequence to GEN1(5.0 GT/s): > :LTRaining:SEquence:SPECification GEN1

:LTRaining:SEquence:SPECification?

Response	<type>=<CHARACTER RESPONSE DATA>
	GEN1, GEN 2
Function	Queries the environment to loopback the DUT supporting USB3.0/3.1.
Example	> :LTRaining:SEquence:SPECification? < GEN1

:LTRaining:SEQuence:TEST:PATtern:TRANsmit

Parameter	None
Function	Transmits the pattern selected at Test Pattern continuously.
Example	> :LTRaining:SEQuence:TEST:PATtern:TRANsmit

:LTRaining:SEQuence:TEST:PATtern:STOP

Parameter	None
Function	Stops sending the test pattern.
Example	> :LTRaining:SEQuence:TEST:PATtern:STOP

:SOURce:PATtern:TYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	COMpliance	Compliance pattern
	USER	USER pattern
Function	Selects the test pattern to be sent after completing the link training sequence transmission. Selecting USER outputs the test pattern selected on the MX180000A MU183020A setup screen.	
Example	To set the test pattern to Compliance Pattern: >:SOURce:PATtern:TYPE COMPLIance	

:SOURce:PATtern:TYPE?

Response	<type>=<CHARACTER RESPONSE DATA> COMP, USER	
Function	Queries the test pattern to be sent after completing the link training sequence transmission.	
Example	> :SOURce:PATtern:TYPE? < COMP	

:LTRaining:SEQuence:TEST:PATtern <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> When Specification setting is GEN1: 0 to 6 CP0 to CP6 When Specification setting is GEN2: 9 CP9
Function	Selects the type of Compliance Pattern to be sent when test pattern is set to Compliance.
Example	> :LTRaining:SEQuence:TEST:PATtern 0

:LTRaining:SEQuence:TEST:PATtern?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> When Specification setting is GEN1: 0 to 6 CP0 to CP6 When Specification setting is GEN2: 9 CP9
Function	Queries the test pattern to be sent.
Example	> :LTRaining:SEQuence:TEST:PATtern? < 0

:LTRaining:SEQuence:TEST:PATtern:EADDITION

Parameter	None
Function	Adds a single error to the sending test pattern.
Example	> :LTRaining:SEQuence:TEST:PATtern:EADDITION

:LTRaining:SEQuence:INITialize [<spec>]

Parameter	<spec>=<CHARACTER PROGRAM DATA> GEN1 GEN2 Note: When <spec> is omitted, all parameters for the link training sequences are initialized.
Function	Sets all parameters for the specified link training sequences to the initial values.
Example	To initialize the parameter set by GEN2 > :LTRaining:SEQuence:INITialize GEN2

:LTRaining:SEquence:DESign:GEN1 <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RDActive	RX_DETECT_ACTIVE (wait)
	PLFPs	POLLING_LFPS (LFPS transmission time)
	PRXeq	POLLING_RXEQ
	PActive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	PIDLe	POLLING_IDLE (wait)
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s
		Wait or signal transmission time/1 μ s Step
Function	Sets a sequence pattern to loopback the DUT (GEN1).	
Example	To set the number of times POLLING_ACTIVE patterns are sent to 1024: > :LTRaining:SEquence:DESign:GEN1 PActive,1024	

:LTRaining:SEquence:DESign:GEN1? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RDActive	RX_DETECT_ACTIVE
	PLFPs	POLLING_LFPS (LFPS transmission time)
	PRXeq	POLLING_RXEQ
	PActive	POLLING_ACTIVE
	PONfiguration	POLLING_CONFIGURATION
	PIDLe	POLLING_IDLE (wait)
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles
		TS transmission cycles
	1 to 1000000	1 to 1000000 μ s
		Wait or signal transmission time
Function	Queries the sequence pattern to loopback the DUT. (GEN1)	
Example	>:LTRaining:SEquence:DESign:GEN1? PActive < 1024	

:LTRaining:SEquence:DESign:GEN2 <type>,<numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RDActive	RX_DETECT_ACTIVE
	PLSCd1	POLLING_LFPS SCD1 (SCD1 transmission time)
	PLSCd2	POLLING_LFPS SCD2 (SCD2 transmission time)
	PPMatch	POLLING_PORTMATCH (LBPM transmission time)
	PRXeq	POLLING_RXEQ
	PActive	POLLING_ACTIVE
	PConfiguration	POLLING_CONFIGURATION
	PIDLe	POLLING_IDLE (wait)
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles per step
	1 to 1000000	1 to 1000000 μ s Wait or signal transmission time/1 μ s Step
Function	Sets a sequence pattern to loopback the DUT (GEN2).	
Example	To set the number of times POLLING_ACTIVE patterns are sent to 1024: > :LTRaining:SEquence:DESign:GEN2 PActive,1024	

:LTRaining:SEquence:DESign:GEN2? <numeric>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RDActive	RX_DETECT_ACTIVE
	PLSCd1	POLLING_LFPS SCD1 (SCD1 transmission time)
	PLSCd2	POLLING_LFPS SCD2 (SCD2 transmission time)
	PPMatch	POLLING_PORTMATCH (LBPM transmission time)
	PRXeq	POLLING_RXEQ
	PActive	POLLING_ACTIVE
	PConfiguration	POLLING_CONFIGURATION
	PIDLe	POLLING_IDLE (wait)
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 1000000	1 to 1000000 cycles TS transmission cycles
	1 to 1000000	1 to 1000000 µs Wait or signal transmission time
Function	Queries the sequence pattern to loopback the DUT. (GEN2)	
Example	:LTRaining:SEquence:DESign:GEN2? PActive < 1024	

5.10 USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)




Figure 5.10-2 Option Screen (Gen1)




Figure 5.10-3 Option Screen (Gen2)

Table 5.10-2 Sequence Screen Setup Commands

No.	Setting Item	Command
[1]	Disable Scrambling	:LTRaining:SEquence:DSCRamble
		:LTRaining:SEquence:DSCRamble?
[2]	SKP Insert	:LTRaining:SEquence:SKP
		:LTRaining:SEquence:SKP?
[3]	Symbol Length 8b/10b	:LTRaining:SEquence:SKP:SLENgth:8B10B
		:LTRaining:SEquence:SKP:SLENgth:8B10B?
[4]	Interval 8b/10b	:LTRaining:SEquence:SKP:INTerval:8B10B
		:LTRaining:SEquence:SKP:INTerval:8B10B?
[5]	Symbol Length 128b/132b	:LTRaining:SEquence:SKP:SLENgth:128B132B
		:LTRaining:SEquence:SKP:SLENgth:128B132B?
[6]	Interval 128b/132b	:LTRaining:SEquence:SKP:INTerval:128B132B
		:LTRaining:SEquence:SKP:INTerval:128B132B?

:LTRaining:SEquence:DSCRamble <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Disabled
	ON or 1	Enabled
Function	Sets the Disable scramble bit of the training sequence pattern.	
Example	To enable Disable scramble	
	> :LTRaining:SEquence:DSCRamble ON	

:LTRaining:SEquence:DSCRamble?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Not scrambled
	1	Scrambled
Function	Queries the training sequence pattern Disable scramble bit during sequence transmission.	
Example	> :LTRaining:SEquence:DSCRamble?	
	< 1	

:LTRaining:SEQuence:SKP:SLENgth:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	2 2 symbols
	4 4 symbols
	6 6 symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.
Example	To set the number of SKP OS SKP symbols to 2: >:LTRaining:SEQuence:SKP:SLENgth:8B10B 2

:LTRaining:SEQuence:SKP:SLENgth:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 2, 4, 6
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.
Example	> :LTRaining:SEQuence:SKP:SLENgth:8B10B? < 2

:LTRaining:SEQuence:SKP:INTerval:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 176 to 708 176 to 708, 2 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	To generate an SKP OS once after every 354 symbols sent: >:LTRaining:SEQuence:SKP:INTerval:8B10B 354

:LTRaining:SEQuence:SKP:INTerval:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 176 to 708 176 to 708, 2 step
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	>:LTRaining:SEQuence:SKP:INTerval:8B10B? < 354

:LTRaining:SEquence:SKP:SLENgth:128B132B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	8 8 Symbols
	12 12 Symbols
	16 16 Symbols
	20 20 Symbols
	24 24 Symbols
	28 28 Symbols
	32 32 Symbols
	36 36 Symbols
	40 40 Symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 128b/132b Encoding operation.
Example	To set the number of SKP OS SKP symbols to 8: > :LTRaining:SEquence:SKP:SLENgth:128B132B 8

:LTRaining:SEquence:SKP:SLENgth:128B132B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 8, 12, 16, 20, 24, 28, 32, 26, 40
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 128b/132b Encoding operation.
Example	> :LTRaining:SEquence:SKP:SLENgth:128B132B? < 8

:LTRaining:SEquence:SKP:INTerval:128B132B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 20 to 80 20 to 80, 1 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 128b/132b Encoding operation.
Example	To generate an SKP OS once after every 40 blocks sent: >:LTRaining:SEquence:SKP:INTerval:128B132B 40

:LTRaining:SEquence:SKP:INTerval:128B132B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 20 to 80 20 to 80
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 128b/132b Encoding operation.
Example	>:LTRaining:SEquence:SKP:INTerval:128B132B? < 40

5.10 USB Link Sequence Setup Screen (With MX183000A-PL012 Installed)




Figure 5.10-4 BER Measurement Setting Window

Table 5.10-3 BER Measurement Setting Command

No.	Setting Item	Command
[1]	BER Measurement Start	:SENSe:MEASure:BER:STARt
	BER Measurement Stop	:SENSe:MEASure:BER:STOP
	BER Measurement State	:SENSe:MEASure:BER:STATe?
[2]	Configure BER Measurement	:DISPlay:RESult:BER
		:DISPlay:RESult:BER?
[3]	Error Count Threshold	:SENSe:MEASure:BER:ECTHreshold
		:SENSe:MEASure:BER:ECTHreshold?
[4]	Cycle	:SENSe:MEASure:BER:MODE
		:SENSe:MEASure:BER:MODE?
[5]	Gating Time	:SENSe:MEASure:BER:TIME
		:SENSe:MEASure:BER:TIME?
[6]	Result	:CALCulate:DATA:EALarm?
[7]	Detector IP Address	:SENSe:MEASure:BER:IPAdDress
		:SENSe:MEASure:BER:IPAdDress?

:SENSe:MEASure:BER:START

Parameter	None
Function	Starts the BER measurement.
Example	>:SENSe:MEASure:BER:START

:SENSe:MEASure:BER:STOP

Parameter	None
Function	Stops the BER measurement.
Example	>:SENSe:MEASure:BER:STOP

:SENSe:MEASure:BER:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being measured
	0	Stopped
Function	Queries the BER measurement status.	
Example	>:SENSe:MEASure:BER:STATe? < 1	

:DISPlay:RESult:BER <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Hides the BER measurement setting window.
	ON or 1	Displays the BER measurement setting window.
Function	Displays or hides the BER measurement setting window.	
Example	To display the BER measurement setting window >:DISPlay:RESult:BER ON	

:DISPlay:RESult:BER?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Hides the BER measurement setting window.
	1	Displays the BER measurement setting window.
Function	Queries the BER measurement setting window display status.	
Example	>:DISPlay:RESult:BER? < 1	

:SENSe:MEASure:BER:ECTHreshold <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 1000 0 to 1000, 1 step
Function	Sets an evaluation threshold of the BER measurement. When the number of bit errors exceeds the evaluation threshold, the BER measurement is judged as Fail.
Example	To set the evaluation threshold of the BER measurement to 1: >:SENSe:MEASure:BER:ECTHreshold 1

:SENSe:MEASure:BER:ECTHreshold?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 1000 0 to 1000
Function	Queries the evaluation threshold of the BER measurement.
Example	>:SENSe:MEASure:BER:ECTHreshold? < 1

:SENSe:MEASure:BER:MODE <mode>

Parameter	<mode>=<CHARACTER PROGRAM DATA> SINGLE Performs the measurement once. REPeat Performs the measurement repeatedly.
Function	Sets the measurement processing mode for the BER measurement.
Example	To set the measurement processing mode for the BER measurement to Repeat: > :SENSe:MEASure:BER:MODE REPeat

:SENSe:MEASure:BER:MODE?

Response	<mode>=<CHARACTER RESPONSE DATA> SING, REP
Function	Queries the measurement processing mode for the BER measurement.
Example	>:SENSe:MEASure:BER:MODE? < REP

:SENSe:MEASure:BER:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 100 1 to 100 s, 1s step
Function	Sets the Gating Time of the BER measurement.
Example	To set the Gating Time of the BER measurement to 6 s: >:SENSe:MEASure:BER:TIME 6

:SENSe:MEASure:BER:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 100
Function	Queries the Gating Time of the BER measurement.
Example	>:SENSe:MEASure:BER:TIME? < 6

:CALCulate:DATA:EALarm? <result>

Parameter	<result>=<STRING PROGRAM DATA> Refer to Table 5.10-4 for details of <result>.
Response	<string>=<STRING RESPONSE DATA>

Table 5.10-4 Parameter

Items	<result1>	Format
Error Count	"EC"	Form1
Bit Count	"BITS"	Form1
Bit Error Rate	"BER"	Form2
Pass/fail judgment	"JUDGE"	String("PASS","FAIL","---")

Table 5.10-5 Response Format

Items	Format	Description
Form1 Integer	"XXXXXXX"	For 0 to 9999999
	"X.XXXEXX"	For 1.0000E07 to 9.9999E17
	"-----"	No data corresponds to a query.
Form2 Decimal	"X.XXXE-XX"	For 0.0001E-18 to 1.0000E00
	"-----"	No data corresponds to a query.

Function	Queries the BER Measurement results (BITS).
Example	> :CALCulate:DATA:EALarm? "BITS" < "1.0000E12"

:SENSe:MEASure:BER:IPADdress <address>

Parameter	<address>=<STRING PROGRAM DATA> "xxx.xxx.xxx.xxx" IP address
Function	Sets an IP address of the USB3.1 Receiver Test Adapter to be connected.
Example	To set the IP address 192.168.0.10: >:SENSe:MEASure:BER:IPADdress "192.168.0.10"

:SENSe:MEASure:BER:IPADdress?

Response	<address>=<STRING RESPONSE DATA> "xxx.xxx.xxx.xxx" Outputs the format 223.255.255.254.
Function	Queries the setting value of the connection destination IP address.
Example	>:SENSe:MEASure:BER:IPADdress? < "192.168.0.10"

5.11 USB Link Training Setup Screen (With MX183000A-PL022 Installed)

This setup screen is available when all of the following conditions are met.

- MX183000A-PL022 is installed.
- **USB Link Training** on the Figure 4.3.1-1 “Selector Screen” is started.
- The SQA has been connected using Equipment Setup.

5.11.1 Link Training Screen




Figure 5.11.1-1 Link Training Screen

5.11 USB Link Training Setup Screen (With MX183000A-PL022 Installed)

Table 5.11.1-1 Training Setting Items and Result Query Commands

No.	Setting Item	Command
[1]	Sequence Start	:LTraining:SEQuence:STARt
	Sequence Stop	:LTraining:SEQuence:STOP
	Sequence State	:LTraining:SEQuence:STATe?
[2]	Specification	:LTraining:SEQuence:SPECification
		:LTraining:SEQuence:SPECification?
[3]	Ping LFPS	:LTraining:SEQuence:PING
[4]	Not Wait For The LFPS signal	:LTraining:SEQuence:NWAI:LFPS
		:LTraining:SEQuence:NWAI:LFPS?
[5]	Test pattern	:SOURce:PATTern:TYPE
		:SOURce:PATTern:TYPE?
[6]	Test pattern	:LTraining:SEQuence:TEST:PATTern
		:LTraining:SEQuence:TEST:PATTern?
[7]	LTSSM Log	:LTraining:SEQuence:LTSSm:LOG:STARt
		:LTraining:SEQuence:LTSSm:LOG:STOP
		:LTraining:SEQuence:LTSSm:LOG:STATe?
		:LTraining:SEQuence:LTSSm:LOG:GATing?
		:LTraining:SEQuence:LTSSm:LOG:EXPort
[8]	Training Result	:LTraining:SEQuence:RESult?

:LTRaining:SEquence:START

Parameter	None
Function	Transits PPG to the status of waiting for LFPS signal from DUT. And, Link Training Sequence for DUT loop-back is started after receiving LFPS signal. Once the transmission is complete, the pattern selected by Test Pattern is sent.
Example	> :LTRaining:SEquence:START

:LTRaining:SEquence:STOP

Parameter	None
Function	Stops transmitting link training sequence and test pattern and sets to Electrical Idle.
Example	> :LTRaining:SEquence:STOP

:LTRaining:SEquence:STATE?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Stop
	1	Sending Sequence Pattern
	2	Sending test pattern
Function	Queries the link training sequence transmission status.	
Example	> :LTRaining:SEquence:STATE? < 1	

:LTRaining:SEquence:SPECification <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	GEN1 SuperSpeed (5.0 GT/s)
	GEN2 SuperSpeedPlus (10.0 GT/s)
Function	Selects the environment for loopback of the USB3.0/3.1-supported DUT.
Example	To select GEN1(5.0 GT/s) as the Link Training Sequence: > :LTRaining:SEquence:SPECification GEN1

:LTRaining:SEquence:SPECification?

Response	<type>=<CHARACTER RESPONSE DATA>
	GEN1, GEN 2
Function	Queries the environment for loopback of the USB3.0/3.1-supported DUT.
Example	> :LTRaining:SEquence:SPECification? < GEN1

:LTRaining:SEquence:PING

Parameter	None
Function	Outputs the Ping.LFPS signal.
Example	>:LTRaining:SEquence:PING

:LTRaining:SEquence:NWAI:LFPS <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 Starts Link Training after receiving LFPS signal.
	ON or 1 Starts Link Training without waiting LFPS.
Function	Selects the condition to start Link Training.
Example	To start Link Training without waiting LFPS signal: > :LTRaining:SEquence:NWAI:LFPS 1

:LTRaining:SEquence:NWAI:LFPS?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 Starts Link Training after receiving LFPS signal.
	1 Starts Link Training without waiting LFPS.
Function	Queries the condition to start Link Training.
Example	> :LTRaining:SEquence:NWAI:LFPS? < 1

:SOURce:PATtern:TYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> COMpliance Compliance pattern USER USER pattern
Function	Selects the test pattern to be sent after completing the link training sequence transmission. Selecting USER outputs the test pattern selected on the MX180000A MU183020A setup screen.
Example	To set the test pattern to Compliance Pattern: >:SOURce:PATtern:TYPE COMpliance

:SOURce:PATtern:TYPE?

Response	<type>=<CHARACTER RESPONSE DATA> COMP, USER
Function	Queries the test pattern to be sent after completing the link training sequence transmission.
Example	> :SOURce:PATtern:TYPE? < COMP

:LTRaining:SEquence:TEST:PATtern <pattern>

Parameter	<p><pattern>=<CHARACTER PROGRAM DATA></p> <p>When Specification setting is GEN1:</p> <p>CP0P, CP0M CP0 RD+, DP0 RD–</p> <p>CP1 to CP6 CP1 to CP6</p> <p>When Specification setting is GEN2:</p> <p>CP9 CP9</p>
Function	Selects the type of Compliance pattern to be sent when test pattern is set to Compliance.
Example	> :LTRaining:SEquence:TEST:PATtern CP9

:LTRaining:SEquence:TEST:PATtern?

Response	<p><pattern>=<CHARACTER RESPONSE DATA></p> <p>When Specification setting is GEN1:</p> <p>CP0P, CP0M CP0 RD+, DP0 RD–</p> <p>CP1 to CP6 CP1 to CP6</p> <p>When Specification setting is GEN2:</p> <p>CP9 CP9</p>
Function	Queries the test pattern to be sent.
Example	> :LTRaining:SEquence:TEST:PATtern? < CP9

:LTRaining:SEquence:LTSSm:LOG:START

Parameter	None
Function	Starts acquiring LTSSM Log.
Example	> :LTRaining:SEquence:LTSSm:LOG:START

:LTRaining:SEquence:LTSSm:LOG:STOP

Parameter	None
Function	Aborts acquiring LTSSM Log.
Example	> :LTRaining:SEquence:LTSSm:LOG:STOP

:LTRaining:SEquence:LTSSm:LOG:EXPort <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name
Function	Stores LTSSM Log in CSV format specifying a file name and format.
Example	To store LTSSM Log. > :LTRaining:SEquence:LTSSm:LOG:EXPort "D:\test_folder\test.csv"

:LTRaining:SEquence:LTSSm:LOG:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Stop 1 Acquiring Log
Function	Queries the status of log acquisition.
Example	> :LTRaining:SEquence:STATe? < 1

:LTRaining:SEquence:LTSSm:LOG:GATing?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 100 0 to 100%
Function	Queries the progress of log acquisition.
Example	> :LTRaining:SEquence:LTSSm:LOG:GATing? < 1

:LTRaining:SEquence:RESult? <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> STATE LTSSM State LSPeed Linkup Speed TXSCount SKP Count Tx RXSCount SKP Count Rx
Response	<string>=<STRING RESPONSE DATA>
Function	Queries the measurement data of the desired parameter.
Example	> :LTRaining:SEquence:RESult? STATE < Loopback.Active.Master

5.11.2 BER Measurement Screen




Figure 5.11.2-1 BER Measurement Screen

Table 5.11.2-1 BER Measurement Commands

No.	Setting Item	Command
[1]	BER Measurement Start	:SENSe:MEASure:BER:STARt
	BER Measurement Stop	:SENSe:MEASure:BER:STOP
	BER Measurement State	:SENSe:MEASure:BER:STATe?
[2]	Configure	:DISPlay:RESult:BER
		:DISPlay:RESult:BER?
[3]	Error Count Threshold	:SENSe:MEASure:BER:ECTHreshold
		:SENSe:MEASure:BER:ECTHreshold?
[4]	Cycle	:SENSe:MEASure:BER:MODE
		:SENSe:MEASure:BER:MODE?
[5]	Gating Time	:SENSe:MEASure:BER:TIME
		:SENSe:MEASure:BER:TIME?
[6]	Result	:CALCulate:DATA:EALarm?
[7]	Error Addition	:SOURce:PATtern:EADdition:SINGLE
[8]	ED Status	:CALCulate:RESult:EMONitor?

:SENSe:MEASure:BER:START

Parameter	None
Function	Starts BER Measurement.
Example	> :SENSe:MEASure:BER:START

:SENSe:MEASure:BER:STOP

Parameter	None
Function	Stops BER Measurement.
Example	> :SENSe:MEASure:BER:STOP

:SENSe:MEASure:BER:STATE?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being measured
	0	Stopped
Function	Queries the BER measurement status.	
Example	> :SENSe:MEASure:BER:STATE? < 1	

:DISPlay:RESult:BER <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Hides the BER measurement setting window.
	ON or 1	Displays the BER measurement setting window.
Function	Sets whether the BER Measurement results area is displayed or hidden.	
Example	> :DISPlay:RESult:BER 1	

:DISPlay:RESult:BER?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA >	
	0	Hides the BER measurement setting window.
	1	Displays the BER measurement setting window.
Function	Queries the BER Measurement results area display status.	
Example	> :DISPlay:RESult:BER? < 1	

:SENSe:MEASure:BER:ECTHreshold <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 1000 0 to 1000, 1 step
Function	Sets an evaluation threshold of the BER measurement. When the number of bit errors exceeds the evaluation threshold, the BER measurement is judged as Fail.
Example	To set the evaluation threshold of the BER measurement to 1: >:SENSe:MEASure:BER:ECTHreshold 1

:SENSe:MEASure:BER:ECTHreshold?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 1000 0 to 1000
Function	Queries the evaluation threshold of the BER measurement.
Example	>:SENSe:MEASure:BER:ECTHreshold? < 1

:SENSe:MEASure:BER:MODE <mode>

Parameter	<mode>=<CHARACTER PROGRAM DATA> SINGLE Performs the measurement once. REPeat Performs the measurement repeatedly.
Function	Sets the measurement processing mode for the BER measurement.
Example	To set the measurement processing mode for the BER measurement to repeat: > :SENSe:MEASure:BER:MODE REPeat

:SENSe:MEASure:BER:MODE?

Response	<mode>=<CHARACTER RESPONSE DATA> SING, REP
Function	Queries the measurement processing mode for the BER measurement.
Example	>:SENSe:MEASure:BER:MODE? < REP

:SENSe:MEASure:BER:TIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 100 1 to 100 s, 1 s step
Function	Sets the Gating Time of the BER measurement.
Example	To set the Gating Time of the BER measurement to 6 s: >:SENSe:MEASure:BER:TIME 6

:SENSe:MEASure:BER:TIME?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 100
Function	Queries the Gating Time of the BER measurement.
Example	>:SENSe:MEASure:BER:TIME? < 6

:SOURce:PATtern:EADDITION:SINGLE

Function	Adds a single error to the test pattern.
Example	> :SOURce:PATtern:EADDITION:SINGLE

:CALCulate:DATA:EALarm? <result>

Parameter	<result>=<STRING PROGRAM DATA> For details on <result>, refer to Table 5.8.2-2.
Response	<string>=<STRING RESPONSE DATA>

Table 5.11.2-2 Parameter

Items	<result1>	Format
Error Count	"EC"	Form1
Bit Count	"BITS"	Form1
Bit Error Rate	"BER"	Form2
Pass/fail judgment	"JUDGe"	String ("PASS","FAIL","---")

Table 5.11.2-3 Response Format

Items	Format	Description
Form1 Integer	"XXXXXXXX"	For 0 to 9999999
	"X.XXXxEXX"	For 1.0000E07 to 9.9999E17
	"-----"	No data corresponds to a query.
Form2 Decimal	"X.XXXxE-XX"	For 0.0001E-18 to 1.0000E00
	"-----"	No data corresponds to a query.

Function	Queries the BER Measurement results (BITS).
Example	> :CALCulate:DATA:EALarm? "BITS" < "1.0000E12"

:CALCulate:RESult:EMONitor?

Response	<string>=<STRING RESPONSE DATA>
Function	Queries the MP1800A/MP1900A state.
Example	> :CALCulate:RESult:EMONitor? < "Outputting Test Pattern"

5.11.3 Option Screen




Figure 5.11.3-1 Option Screen

Table 5.11.3-1 Option Screen Command

No.	Setting Item	Command
[1]	SKP Insert	:LTRaining:SEquence:SKP
		:LTRaining:SEquence:SKP?
[2]	SKP Filter	:LTRaining:SEquence:FILTer
		:LTRaining:SEquence:FILTer?
[3]	Symbol Length 8b/10b	:LTRaining:SEquence:SKP:SLENgth:8B10B
		:LTRaining:SEquence:SKP:SLENgth:8B10B?
[4]	Interval 8b/10b	:LTRaining:SEquence:SKP:INTerval:8B10B
		:LTRaining:SEquence:SKP:INTerval:8B10B?
[5]	Double SKP (8b/10b)	:LTRaining:SEquence:SKP:DOUBle:8B10B
		:LTRaining:SEquence:SKP:DOUBle:8B10B?
[6]	Symbol Length 128b/132b	:LTRaining:SEquence:SKP:SLENgth:128B132B
		:LTRaining:SEquence:SKP:SLENgth:128B132B?
[7]	Interval 128b/132b	:LTRaining:SEquence:SKP:INTerval:128B132B
		:LTRaining:SEquence:SKP:INTerval:128B132B?
[8]	Double SKP (128b/132b)	:LTRaining:SEquence:SKP:DOUBle:128B132B
		:LTRaining:SEquence:SKP:DOUBle:128B132B?

Table 5.11.3-2 Option Screen Command (Cont'd)

No.	Setting Item	Command
[9]	Polling.LFPS Transition Delay Enable	:LTraining:POLling:LFPS:DElay:ENAB
		:LTraining:POLling:LFPS:DElay:ENAB?
[10]	Polling.LFPS Transition Delay Time	:LTraining:POLling:LFPS:DElay
		:LTraining:POLling:LFPS:DElay?
[11]	PPG AUX Output Trigger	:LTraining:SEQuence:TRIGger:SElect
		:LTraining:SEQuence:TRIGger:SElect?
[12]	Trigger Link Speed	:LTraining:SEQuence:TRIGger:SPEed <numeric>
		:LTraining:SEQuence:TRIGger:SPEed?
[13]	Trigger State	:LTraining:SEQuence:TRIGger:STATe
		:LTraining:SEQuence:TRIGger:STATe?
[14]	Enable Preset	:LTraining:SEQuence:ENABle:PRESet
		:LTraining:SEQuence:ENABle:PRESet?

:LTRaining:SEquence:SKP <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	SKP OS not inserted
	ON or 1	SKP OS inserted
Function	Selects whether to insert SKP OS while transmitting a sequence.	
Example	To insert SKP OS	
	> :LTRaining:SEquence:SKP ON	

:LTRaining:SEquence:SKP?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	SKP OS not inserted
	1	SKP OS inserted
Function	Queries whether SKP OS is inserted while transmitting a sequence.	
Example	> :LTRaining:SEquence:SKP?	
	< 1	

:LTRaining:SEquence:FILTer <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	SKP OS is not removed.
	ON or 1	SKP OS is removed.
Function	Selects whether to remove SKP OS at the BER measurement.	
Example	To remove SKP OS.	
	> :LTRaining:SEquence:FILTer ON	

:LTRaining:SEquence:FILTer?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	SKP OS is not removed.
	1	SKP OS is removed.
Function	Queries whether to remove SKP OS at the BER measurement.	
Example	> :LTRaining:SEquence:FILTer?	
	< 1	

:LTRaining:SEQuence:SKP:SLENgth:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	2 2 symbols
	4 4 symbols
	6 6 symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.
Example	To set the number of SKP OS SKP symbols to 2: >:LTRaining:SEQuence:SKP:SLENgth:8B10B 2

:LTRaining:SEQuence:SKP:SLENgth:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	2, 4, 6
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 8b/10b Encoding operation.
Example	> :LTRaining:SEQuence:SKP:SLENgth:8B10B? < 2

:LTRaining:SEQuence:SKP:INTerval:8B10B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	76 to 708 76 to 708, 2 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	To generate an SKP OS once after every 354 symbols sent: >:LTRaining:SEQuence:SKP:INTerval:8B10B 354

:LTRaining:SEQuence:SKP:INTerval:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	76 to 708 76 to 708, 2 step
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 8b/10b Encoding operation.
Example	>:LTRaining:SEQuence:SKP:INTerval:8B10B? < 354

:LTRaining:SEquence:SKP:DOUBle:8B10B <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Double SKP OS not inserted. ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	To insert double SKP OS. > :LTRaining:SEquence:SKP:DOUBle:8B10B 1

:LTRaining:SEquence:SKP:DOUBle:8B10B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Double SKP OS not inserted. 1 Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 8b/10b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	> :LTRaining:SEquence:SKP:DOUBle:8B10B? < 1

:LTRaining:SEquence:SKP:SLENgth:128B132B <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 8 8 Symbols 12 12 Symbols 16 16 Symbols 20 20 Symbols 24 24 Symbols 28 28 Symbols 32 32 Symbols 36 36 Symbols 40 40 Symbols
Function	Sets the number of SKP symbols to be inserted by SKP Ordered Set for 128b/132b Encoding operation.
Example	To set the number of SKP OS SKP symbols to 8: > :LTRaining:SEquence:SKP:SLENgth:128B132B 8

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 8, 12, 16, 20, 24, 28, 32, 26, 40
Function	Queries the number of SKP symbols to be inserted by SKP Ordered Set for 128b/132b Encoding operation.
Example	> :LTRaining:SEquence:SKP:SLENgth:128B132B? < 8

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 20 to 80 20 to 80, 1 step
Function	Sets the interval for SKP Ordered Set occurring during TS transmission for 128b/132b Encoding operation.
Example	To generate an SKP OS once after every 40 blocks sent: >:LTraining:SEquence:SKP:INterval:128B132B 40

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 20 to 80 20 to 80
Function	Queries the interval for SKP Ordered Set occurring during TS transmission for 128b/132b Encoding operation.
Example	>:LTraining:SEquence:SKP:INterval:128B132B? < 40

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Double SKP OS not inserted. ON or 1 Double SKP OS inserted.
Function	Selects whether to insert double SKP OS while transmitting a test pattern with 128b/132b encoding and in Loopback.Active state. This parameter is available only when SI PPG is installed.
Example	To insert double SKP OS. > :LTraIning:SEquence:SKP:DOUBle:128B132B 1

:LTRaining:SEQuence:SKP:DOUBle:128B132B?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Double SKP OS not inserted.
	1	Double SKP OS inserted.
Function	Queries whether to insert double SKP OS while transmitting a test pattern with 128b/132b encoding and in Loopback.Active state.	
Example	> :LTRaining:SEQuence:SKP:DOUBle:128B132B? < 1	

:LTRaining:POLling:LFPS:DElay:ENAB <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Delays the transition to the Polling.LFPS state.
	ON or 1	Does not delay the transition to the Polling.LFPS state.
Function	Sets whether to delay BERT's transition from reception of LFPS output by DUT to the Polling.LFPS state.	
Example	To delay the transition to the Polling.LFPS state. > :LTRaining:POLling:LFPS:DElay:ENAB ON	

:LTRaining:POLling:LFPS:DElay:ENAB?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Delays the transition to the Polling.LFPS state.
	1	Does not delay the transition to the Polling.LFPS state.
Function	Queries whether to delay BERT's transition from reception of LFPS output by DUT to the Polling.LFPS state.	
Example	> :LTRaining:POLling:LFPS:DElay:ENAB? < 1	

:LTRaining:POLLing:LFPS:DElay <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 2501 to 250 s, 1 s step
Function	Sets the delay in BERT's transition from reception of LFPS output by DUT to the Polling.LFPS state.
Example	To set the delay in transition to the Polling.LFPS state to 5 ms. >:LTRaining:POLLing:LFPS:DElay 5

:LTRaining:POLLing:LFPS:DElay?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 250
Function	Queries the delay in transition to the Polling.LFPS state.
Example	>:LTRaining:POLLing:LFPS:DElay? < 5

:LTRaining:SEquence:TRIGger:SElect <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	OFF	Does not output a trigger.
	LTSSm	Outputs a trigger when the MP1900A changes to the specified LTSSM during Training.
Function	Sets the condition when the MP1900A outputs a trigger from the AUX Output of SI PPG.	
Example	To set the trigger output condition to LTSSM.	
	> :LTRaining:SEquence:TRIGger:SElect LTSSm	

:LTRaining:SEquence:TRIGger:SElect?

Response	<type>=<CHARACTER RESPONSE DATA>	
	OFF	Does not output a trigger.
	LTSS	Outputs a trigger when the MP1900A changes to the specified LTSSM during Training.
Function	Queries the condition when the MP1900A outputs a trigger from the AUX Output of SI PPG.	
Example	> :LTRaining:SEquence:TRIGger:SElect?	
	< LTSS	

:LTRaining:SEquence:TRIGger:SPEed <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	5.0	5.0 GT/s
	10.0	10.0 GT/s
Function	Sets the operating data rate condition when the MP1900A outputs a trigger during Link Training.	
Example	To set the trigger output condition to 10.0 GT/s.	
	> :LTRaining:SEquence:TRIGger:SPEed 10.0	

:LTRaining:SEquence:TRIGger:SPEed?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA>	
	5.0	5.0 GT/s
	10.0	10.0 GT/s
Function	Queries the operating data rate condition when the MP1900A outputs a trigger during Link Training.	
Example	> :LTRaining:SEquence:TRIGger:SPEed?	
	< 10.0	

:LTRaining:SEQuence:TRIGger:STATe <type>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>
	1 Detect.Quiet
	2 Detect.Active
	3 Detect.Reset
	17 Polling.LFPS
	18 Polling.LFPS(SCD1
	19 Polling.LFPS(SCD2)
	20 Polling.LFPSPlus
	21 Polling.LFPS(END of SCD)
	22 Polling.PortMatch
	23 Polling.PortConfig(PHY Ready LBPM)
	24 Polling.PortConfig(End of LBPM)
	25 Polling.PortConfig(Change)
	26 Polling.RxEQ
	27 Polling.Active
	28 Polling.Configuration
	29 Polling.Idle
	30 Polling.LFPS(End)
	33 Compliance Mode
	49 Ping.LFPS
	65 L0
	81 eSS.Disabled
	97 Loopback.Active(BRST)
	98 Loopback.Active(BDAT)
	99 Loopback.Active(BREC)
	100 Loopback.Active(CP0 to 9)
	101 Loopback.Exit
	113 Hot Reset.Active(assert)
	114 Hot Reset.Active(de-assert)
	115 Hot Reset.Exit
Function	Sets the state condition when the MP1900A outputs a trigger during Link Training.
	This is enabled when LTSSM is selected at Trigger Select.
Example	To output a trigger when the MP1900A changes to the Loopback.Active state during Link Training.
	> :LTRaining:SEQuence:TRIGger:STATe 100

:LTRaining:SEQuence:TRIGger:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> For the return value, refer to the parameter of the :LTRaining:SEQuence:TRIGger:STATe command.
Function	Sets the state condition when the MP1900A outputs a trigger during Link Training. This is enabled when LTSSM is selected at Trigger Select.
Example	> :LTRaining:SEQuence:TRIGger:STATe? < 100

:LTRaining:SEQuence:ENABle:PRESet <numeric>

Parameter	<numeric>=<CHARACTER PROGRAM DATA> P0 to P1 P0 to P1, 1 step
Function	Sets the Preset value to be used in 5.0 GT/s or 10.0 GT/s state.
Example	To set the Preset value to P0. > :LTRaining:SEQuence:ENABle:PRESet P0

:LTRaining:SEQuence:ENABle:PRESet?

Response	<numeric>=<CHARACTER RESPONSE DATA> P0 to P1 P0 to P1
Function	Queries the Preset value to be used in 5.0 GT/s or 10.0 GT/s state.
Example	> :LTRaining:SEQuence:ENABle:PRESet? < P0

5.12 Jitter Tolerance Setup Screen

5.12.1 Run Test Screen

This setup screen is available only when MX183000A-PL001 is installed, when **Jitter Tolerance Test** or **PCIe Link Sequence** is started on the Selector screen (Figure 4.3.1-1), and when the SQA has been connected using Equipment Setup.




Figure 5.12.1-1 Run Test Screen

Table 5.12.1-1 Run Test Screen Setup Commands

No.	Setting Item	Command
[1]	Jitter Tolerance Table	:SENSe:JITTer:TABLE:FREQuency? :SENSe:JITTer:TABLE:INDex?
[2]	Add	:SENSe:JITTer:TABLE:ADD
[3]	Delete	:SENSe:JITTer:TABLE:DELeTe
[4]	All Clear	:SENSe:JITTer:TABLE:ADELeTe
[5]	Order	:SENSe:MEASure:BERCond:SEQuence :SENSe:MEASure:BERCond:SEQuence?
[6]	Set All Limit	:SENSe:MEASure:BERCond:RATiosetting :SENSe:MEASure:BERCond:RATiosetting?
[7]	Run Test	:SENSe:MEASure:JITTer:STARt :SENSe:MEASure:JITTer:STOP :SENSe:MEASure:JITTer:STATe?
[8]	Status	:CALCulate:RESult:STATus?
[9]	Data	:CALCulate:RESult:DATA?
[10]	Save	:SENSe:MEASure:TABLeData:SAVE
	Open	:SENSe:MEASure:TABLeData:Open
	Title	:SENSe:MEASure:TABLeData:SELeCt?
[11]	Bit Rate	:SENSe:MEASure:SYSCond:BITRate?
[12]	Clock Selection	:INPut:CLOCK:SELection
		:INPut:CLOCK:SELection?
[13]	Detail	:CALCulate:RESult:MAXPass?
		:CALCulate:RESult:MINFail?
		:CALCulate:RESult:DETail?

:SENSe:JITTer:TABLE:FREQuency? <freq>

Parameter	<p><freq>=<DECIMAL NUMERIC PROGRAM DATA> 10 to 250000000 10 to 250000000 Hz, 1Hz step</p>
Response	<p><string>=<STRING RESPONSE DATA> <string>="<number>,<freq>,<mask>,<upperlimit><lowerlimit>" <number>=<NR1 NUMERIC RESPONSE DATA> 1 to 50 Jitter Tolerance Table index No.1 to 50 <freq>=<NR1 NUMERIC RESPONSE DATA> 10 to 250000000 Modulation frequency registered in the Jitter Tolerance Table <mask>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Mask value registered in the Jitter Tolerance Table <upperlimit>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Upper Limit value registered in the Jitter Tolerance Table <lowerlimit>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Lower Limit value registered in the Jitter Tolerance Table</p>
Function	<p>Reads in values registered in the Jitter Tolerance Table by specifying the modulation frequency.</p>
Example	<p>> :SENSe:JITTer:TABLE:FREQuency? 150000000 < "1,150000000, 0.100, 0.200, 0.030"</p>

:SENSe:JITTer:TABLE:INDex? <number>

Parameter	<number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 50
Response	<string>=<STRING RESPONSE DATA> <string>="<number>,<freq>,<mask>,<upperlimit><lowerlimit>" <number>=<NR1 NUMERIC RESPONSE DATA> 1 to 50 Jitter Tolerance Table index No.1 to 50 <freq>=<NR1 NUMERIC RESPONSE DATA> 10 to 250000000 Modulation frequency registered in the Jitter Tolerance Table <mask>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Mask value registered in the Jitter Tolerance Table <upperlimit>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Upper Limit value registered in the Jitter Tolerance Table <lowerlimit>=<NR1 NUMERIC RESPONSE DATA> 0 to 2000 Lower Limit value registered in the Jitter Tolerance Table
Function	Reads in values registered in the Jitter Tolerance Table by specifying the Index.
Example	>:SENSe:JITTer:TABLE:IND? 1 < "1,150000000, 0.100, 0.200, 0.030"

:SENSe:JITTer:TABLE:ADD <freq>,<mask>,<upperlimit>,<lowerlimit>

Parameter	<freq>=<DECIMAL NUMERIC PROGRAM DATA> 10 to 250000000 Modulation frequency registered in the Jitter Tolerance Table	
	<mask>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 2000 Mask value registered in the Jitter Tolerance Table	
	<upperlimit>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 2000 Upper Limit value registered in the Jitter Tolerance Table	
	<lowerlimit>=<DECIMAL NUMERIC PROGRAM DATA> 0 to 2000 Lower Limit value registered in the Jitter Tolerance Table	
Function	Adds modulation frequencies to be measured to the Jitter Tolerance measurement.	
Example	> :SENSe:JITTer:TABLE:ADD 100000000,0.100,0.5,0.1	
	Note: In accordance with the SJ specifications in 1.3.2 “Jitter Modulation Performance” of <i>MU181500B Jitter Modulation Source Instruction Manual</i> .	

:SENSe:JITTer:TABLE:DELeTe <number>

Parameter	<number>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 50 1 to 50, 1 step	
Function	Deletes those items on the Jitter Tolerance Table specified by number.	
Example	> :SENSe:JITTer:TABLE:DELeTe 1	

:SENSe:JITTer:TABLE:ADELeTe

Parameter	None	
Function	Deletes all elements on the Jitter Tolerance Table.	
Example	> :SENSe:JITTer:TABLE:ADELeTe	

:SENSe:MEASure:BERCond:SEQuence <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	LOWerfreq	Measures in sequence from the lower modulation frequency.
	HIGHerfreq	Measures in sequence from the higher modulation frequency.
Function	Selects the tolerance measurement sequence direction.	
Example	To set to measure from the higher modulation frequency side: > :SENSe:MEASure:BERCond:SEQuence HIGHerfreq	

:SENSe:MEASure:BERCond:SEQuence?

Response	<type>=<CHARACTER PROGRAM DATA> LOW, HIGH	
Function	Queries the tolerance measurement start point.	
Example	> :SENSe:MEASure:BERCond:SEQuence? < HIGH	

:SENSe:MEASure:BERCond:RATiosetting <upper>,<lower>

Parameter	<upper>=<DECIMAL NUMERIC PROGRAM DATA> 1.000 to 1000.000 1.000 to 1000 times	
	<lower>=<DECIMAL NUMERIC PROGRAM DATA> 0.001 to 1.000 0.001 to 1.000 times	
Function	Sets the upper and lower limits of the jitter modulation amplitude on the Jitter Tolerance Table as ratios of the mask.	
Example	To set the upper limit to x10 from the mask line and the lower limit to 1/10 from the mask line: > :SENSe:MEASure:BERCond:RATiosetting 10,0.1	

:SENSe:MEASure:BERCond:RATiosetting?

Response	<upper>,<lower> <upper>=<NR2 NUMERIC RESPONSE DATA> 1.000 to 1000.000 <lower>=<NR2 NUMERIC RESPONSE DATA> 0.001 to 1.000	
Function	Queries the upper and lower limits of the jitter modulation amplitude of jitter measurements as ratios of the mask.	
Example	> :SENSe:MEASure:BERCond:RATiosetting? < 10,0.1	

:SENSe:MEASure:JITTer:STARt

Parameter	None
Function	Starts the tolerance measurement.
Example	> :SENSe:MEASure:JITTer:STARt

:SENSe:MEASure:JITTer:STOP

Parameter	None
Function	Stops the tolerance measurement.
Example	> :SENSe:MEASure:JITTer:STOP

:SENSe:MEASure:JITTer:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being measured
	0	Stopped
Function	Queries the tolerance measurement status.	
Example	> :SENSe:MEASure:JITTer:STATe? < 1	

:CALCulate:RESult:STATus?

Response	<string>=<STRING RESPONSE DATA>	
	"---"	Before measurement start
	"Setting system..."	Setup in progress
	"Auto Search Started."	Auto Search start
	"Auto Search Completed."	Auto Search complete
	"Measurement Completed."	Measurement complete
	"Measurement: <Freq>Hz, <Currval>UIp-p"	Measurement result
Function	Queries the tolerance measurement status.	
Example	> :CALCulate:RESult:STATus? < "---"	

:CALCulate:RESult:DATA? <type>[,<numeric>]

Parameter	<type>=<CHARACTER PROGRAM DATA> ALL All measurement points POINT Specified point <numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 50 Measurement points No.1 to 50 When <type> is ALL, <numeric> can be omitted.
Response	<string>=<STRING RESPONSE DATA> <string>="<number>,<freq>,<measui>,<measjudge>,<estimateui>,<r2>,<estimatejudge>,<flow>" <number>=<NR1 NUMERIC RESPONSE DATA> 1 to 50 Measurement point No.1 to 50 <freq>=<NR1 NUMERIC RESPONSE DATA> 10 to 250000000 Hz modulation frequency <measui>=<NR2 NUMERIC RESPONSE DATA> 0.001 to 2000.000 UIp-p modulation amount <measjudge>=<NR1 NUMERIC RESPONSE DATA> 1 Pass 0 Fail -1 Not measured <estimateui>=<NR2 NUMERIC RESPONSE DATA> 0.000 to 2000.000 UIp-p modulation amount <r2>=<NR2 NUMERIC RESPONSE DATA> 0 to 1 Coefficient of determination with degree of freedom determined, no units <estimatejudge>=<NR1 NUMERIC RESPONSE DATA> 1 Pass 0 Fail -1 Not measured <flow>=<NR1 NUMERIC RESPONSE DATA> 1 overflow 0 no overflow -1 Not measured
Function	Acquires tolerance measurement results.
Example	To acquire all measurement results of the Tolerance measurement. <pre> > :CALCulate:RESult:DATA? ALL < "1,1000,5.000,1,2.000,0.995,1,1", "2,1000,5.000,1, 2.000, 0.995,1,1", "3,1000,5.000,1, 2.000, 0.995,1,1", ... "20,200000000,0.150,1,0.100, 0.995,1,1" </pre> To acquire measurement data for tolerance measurement No. 10 <pre> > :CALCulate:RESult:DATA? POINT,10 < "10,100000,1.000,0,0.600, 0.995,0,0" </pre>

:SENSe:MEASure:SYSCond:BITRate?

Response	<numeric>=<NR2 NUMERIC RESPONSE DATA> 2.400000 to 32.100000 2.400000 to 32.100000 Gbit/s	
Function	Queries the tolerance measurement bitrate monitor value.	
Example	> :SENSe:MEASure:SYSCond:BITRate? < 8.000000	

:SENSe:MEASure:TABLedata:SAVe <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name	
Function	Saves the jitter tolerance table contents (measurement points and masks).	
Example	> :SENSe:MEASure:TABLedata:SAVe "C:\test_folder\test_table"	

:SENSe:MEASure:TABLedata:OPEN <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file><extension>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name <extension>=.umsk, .mask	
Function	Reads in jitter tolerance table contents (measurement points and masks).	
Example	> :SENSe:MEASure:TABLedata:OPEN "C:\test_folder\test_table.umsk"	

:SENSe:MEASure:TABLedata:SELeCt?

Response	<item>=<STRING RESPONSE DATA> "xxxxxxxxxxx" File name	
Function	Queries the selected table data.	
Example	> :SENSe:MEASure:TABLedata:SELeCt? < "PCI"	

:INPut:CLOcK:SElection <sel>

Parameter	<sel>=<CHARACTER PROGRAM DATA>	
	RECovered	Recovered Clock
	EXTernal	External Clock
Function	Sets the clock input type.	
Example	To set the clock input type to the Recovered Clock:	
	> :INPut:CLOcK:SElection RECovered	

:INPut:CLOcK:SElection?

Response	<sel>=<CHARACTER RESPONSE DATA>	
	REC	Recovered Clock
	EXT	External Clock
Function	Queries the clock input type.	
Example	> :INPut:CLOcK:SElection?	
	< EXT	

:CALCulate:RESult:MAXPass? <Num>

Parameter	<Num>=<NR1 NUMERIC RESPONSE DATA>	
	1 to 50	Jitter Tolerance Table index No.1 to 50
	If this query is executed with “2” set to the parameter when the settings are made as shown in “Figure 5.12.1-1 Run Test Screen”, this query returns 10,000,000 [Hz].	
Response	<type>=<CHARACTER RESPONSE DATA>	
	SJ modulation amount (UI) and the error count at the time the SJ modulation amount was set are returned as a comma-separated list. The Max Pass criterion is that the SJ modulation amount is equal to or less than the Error Count value set for Error Threshold in the JTOL Settings screen.	
	If the corresponding data is not available, “-----” is returned.	
	If Sync Loss has occurred, “Sync Loss” is returned in the Error Count box.	
Function	Queries the max SJ modulation amount not exceeding Error Threshold, and the Error Count value at the time.	
Example	> :CALCulate:RESult:MAXPass? 2	
	< 0.680,0	

:CALCulate:RESult:MINFail? <Num>

Parameter	<p><Num>=<NR1 NUMERIC RESPONSE DATA></p> <p>1 to 50 Jitter Tolerance Table index No.1 to 50</p> <p>If this query is executed with “2” set to the parameter when the settings are made as shown in “Figure 5.12.1-1 Run Test Screen”, this query returns 10,000,000 [Hz].</p>
Response	<p><type>=<CHARACTER RESPONSE DATA></p> <p>SJ modulation amount (UI) and the error count at the time the SJ modulation amount was set are returned as a comma-separated list. The Min Fail criterion is that the SJ modulation amount exceeds the Error Count value set for Error Threshold in the JTOL Settings screen. If the corresponding data is not available, “-----” is returned.</p> <p>If Sync Loss has occurred, “Sync Loss” is returned in the Error Count box.</p>
Function	Queries the min SJ modulation amount exceeding Error Threshold, and the Error Count value at the time.
Example	<pre>> :CALCulate:RESult:MINFail? < 0.700,51</pre>

:CALCulate:RESult:DETail? <Num>

Parameter	<p><Num>=< NR1 NUMERIC RESPONSE DATA ></p> <p>1 to 50 Jitter Tolerance Table index No.1 to 50</p> <p>If this query is executed with “2” set to the parameter when the settings are made as shown in “Figure 5.12.1-1 Run Test Screen”, this query returns 10,000,000 [Hz].</p>
Response	<p><type>=<CHARACTER RESPONSE DATA></p> <p>SJ modulation amount (UI) and the error count at the time the SJ modulation amount was set of all specified Index Nos. are returned as a comma-separated list.</p> <p>[SJ modulation amount],[Error Count],[SJ modulation amount],[Error Count], ...</p>
Function	<p>Queries SJ modulation amount (UI) and the error count at the time the SJ modulation amount was set of all specified Index Nos.</p> <p>If the corresponding data is not available, “-----” is returned.</p> <p>If Sync Loss has occurred, “Sync Loss” is returned in the Error Count box.</p>
Example	<pre>> :CALCulate:RESult:DETail? < 0.100,0,0.120,0,0.140,0,0.160,0,0.180,0,0.200,0,0.220,0, 0.240,0,0.260,0,0.280,0,0.300,0,0.320,0,0.340,0,0.360,0, 0.380,0,0.400,0,0.420,0,0.440,0,0.460,0,0.480,0,0.500,0, 0.520,0,0.540,0,0.560,0,0.580,0,0.600,0,0.620,0,0.640,0, 0.660,1,0.680,12,0.700,51,0.740,Sync Loss</pre>




Figure 5.12.1-2 JTOL Settings Screen




Figure 5.12.1-3 PAM4 Manual Setting Screen




Figure 5.12.1-4 JTOL Settings Screen (When Using PAM4 ED in PAM4 Mode)




Figure 5.12.1-5 SJ Division Setting Dialog Box

Table 5.12.1-2 JTOL Settings Screen Setup Commands

No.	Setting Item	Command
[1]	Unit	:SENSe:MEASure:BERCond:UNIT
		:SENSe:MEASure:BERCond:UNIT?
[2]	Error Threshold	:SENSe:MEASure:BERCond:THReshold
		:SENSe:MEASure:BERCond:THReshold?
[3]	BER for JTOL Estimation	:DISPlay:RESult:ESTimate:ERATe
		:DISPlay:RESult:ESTimate:ERATe?
[4]	Direction Search	:SENSe:MEASure:BERCond:SEARch
		:SENSe:MEASure:BERCond:SEARch?
[5]	Waiting Timer	:SENSe:MEASure:BERCond:WTIME
		:SENSe:MEASure:BERCond:WTIME?
[6]	Settling Timer	:SENSe:MEASure:BERCond:STIME
		:SENSe:MEASure:BERCond:STIME?
[7]	Gating Timer	:SENSe:MEASure:BERCond:GTIME
		:SENSe:MEASure:BERCond:GTIME?
[8]	Auto Search	:SENSe:MEASure:BERCond:ASEarch
		:SENSe:MEASure:BERCond:ASEarch?
[9]	Step	:SENSe:MEASure:BERCond:SSETting
		:SENSe:MEASure:BERCond:SSETting?
[10]	Measurement Type	:SENSe:MEASure:BERCond:MTYPE
		:SENSe:MEASure:BERCond:MTYPE?
[11]	PAM4 Pattern	:SENSe:MEASure:BERCond:PATtern
		:SENSe:MEASure:BERCond:PATtern?
[12]	ED Input Condition	:SENSe:MEASure:BERCond:MANual:INTerface?
[13]	Threshold for ED Data Input	:SENSe:MEASure:BERCond:MANual:DATA
		:SENSe:MEASure:BERCond:MANual:DATA?
[14]	Threshold for ED XData Input	:SENSe:MEASure:BERCond:MANual:XDATA
		:SENSe:MEASure:BERCond:MANual:XDATA?
[15]	ED Phase	:SENSe:MEASure:BERCond:MANual:DElay
		:SENSe:MEASure:BERCond:MANual:DElay?
[16]	Pretest	:SENSe:MEASure:BERCond:TEST
		:SENSe:MEASure:BERCond:TEST?
[17]	Unit (When using PAM4 ED)	:SENSe:MEASure:BERCond:TARGet
		:SENSe:MEASure:BERCond:TARGet?

Table 5.12.1-2 JTOL Settings Screen Setup Commands (Cont'd)

No.	Setting Item	Command
[18]	Set SJ step by step (ON/OFF) When decreasing SJ When setting to 0 UI	:SENSe:MEASure:BERCond:SJ:SSTep:TOZero
		:SENSe:MEASure:BERCond:SJ:SSTep:TOZero?
[19]	Set SJ step by step (ON/OFF) When increasing SJ When setting the next measurement point	:SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue
		:SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue?
[20]	Division number	:SENSe:MEASure:BERCond:SJ:SSTep
		:SENSe:MEASure:BERCond:SJ:SSTep?
[21]	Step setting time	:SENSe:MEASure:BERCond:SJ:SSTep:WTIME
		:SENSe:MEASure:BERCond:SJ:SSTep:WTIME?

:SENSe:MEASure:BERCond:UNIT <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> RATE Error rate COUNT Error count ESTimate Estimate
Function	Sets whether error rate, error count, or Estimate is used for pass/fail judgment.
Example	To set the error rate for the Pass/Fail judgment: > :SENSe:MEASure:BERCond:UNIT RATE

:SENSe:MEASure:BERCond:UNIT?

Response	<type>=<CHARACTER RESPONSE DATA> RATE, COUN, EST
Function	Queries the setting of the Pass/Fail judgement
Example	> :SENSe:MEASure:BERCond:UNIT? < RATE

:SENSe:MEASure:BERCond:THReshold <value>

Parameter	<value>=<DECIMAL NUMERIC PROGRAM DATA> When Unit is set to Error Rate: 3 to 12 Error Rate E-3 to E-12/E-1 step When Unit is set to Error Count: 0 to 10000000 Number of Error Count 0 to 10000000, 1 Step
Function	Sets the evaluation threshold value.
Example	Sets the error rate threshold to 1E-9 when Unit is set to Error Rate. > :SENSe:MEASure:BERCond:THReshold 9 Sets the error rate threshold to 100 when Unit is set to Error Count. > :SENSe:MEASure:BERCond:THReshold 100

:SENSe:MEASure:BERCond:THReshold?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> When Unit is set to Error Rate: 3 to 12 Error Rate E-3 to E-12/E-1 When Unit is set to Error Count: 0 to 10000000 Error count 0 to 10000000
Function	Queries the evaluation threshold value of error rate
Example	> :SENSe:MEASure:BERCond:THReshold? < 9

:DISPlay:RESult:ESTimate:ERATe <numeric1>,<numeric2>

Parameter	<numeric1>=<DECIMAL PROGRAM DATA> 1.0 to 9.9 XX:XXE-YY <numeric2>=<DECIMAL PROGRAM DATA> 9 to 20 YY:XXE-YY
Function	Sets the BER for JTOL Estimation.
Example	To set the BER for JTOL Estimation to 5.5E-15: > :DISPlay:RESult:ESTimate:ERATe 5.5,15
Compatibility	Incompatible with existing models.

:DISPlay:RESult:ESTimate:ERATe?

Response	<numeric1>,<numeric2> <numeric1>=<DECIMAL RESPONSE DATA> 1.0 to 9.9 XX:XXE-YY <numeric2>=<DECIMAL RESPONSE DATA> 9 to 20 YY:XXE-YY
Function	Queries the error rate setting set for BER for JTOL Estimation.
Example	> :DISPlay:RESult:ESTimate:ERATe? < 5.5,15
Compatibility	Incompatible with existing models.

:SENSe:MEASure:BERCond:SEARch <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> BINary Binary DLINear Downwards Linear DLOG Downwards Log ULINear Upwards Linear ULOG Upwards Log BINLinear Binary + Linear
Function	Sets the tolerance measurement method.
Example	To set the tolerance measurement method to Binary: > :SENSe:MEASure:BERCond:SEARch BIN

:SENSe:MEASure:BERCond:SEARch?

Response	<type>=<CHARACTER RESPONSE DATA> BIN, DLIN, DLOG, ULIN, ULOG, BINL
Function	Queries the tolerance measurement method.
Example	> :SENSe:MEASure:BERCond:SEARch? < BIN

:SENSe:MEASure:BERCond:WTime <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 99 1 to 99 s, 1 s step
Function	Sets the Waiting Time for the Tolerance measurement.
Example	To set the Waiting Time to 5 s: > :SENSe:MEASure:BERCond:WTime 5

:SENSe:MEASure:BERCond:WTime?

Parameter	None
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 99 1 to 99 s
Function	Queries the Waiting Time of the Tolerance measurement.
Example	> :SENSe:MEASure:BERCond:WTime? < 5

:SENSe:MEASure:BERCond:STime <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 99 1 to 99 s, 1 s step
Function	Set the Settling Time for the Tolerance measurement.
Example	To set the Settling Time to 5 s: > :SENSe:MEASure:BERCond:STime 5

:SENSe:MEASure:BERCond:STime?

Parameter	None
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 to 99 1 to 99 s
Function	Queries the Settling Time of the Tolerance measurement.
Example	> :SENSe:MEASure:BERCond:STime? < 5

:SENSe:MEASure:BERCond:GTIMe <time>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 86400 1 to 86400 s, 1 s step
Function	Set the Gating Time for the bit errors measurement.
Example	To set the Gating Time to 5 s: > :SENSe:MEASure:BERCond:GTIMe 5

:SENSe:MEASure:BERCond:GTIMe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 to 86400
Function	Queries the Gating Time.
Example	> :SENSe:MEASure:BERCond:GTIMe? < 30

:SENSe:MEASure:BERCond:ASearch <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> OFF Auto Search Setting off FINE Auto Search Setting on (Fine mode) COARse Auto Search Setting on (Coarse mode) PAMFine PAM4 Auto Search Setting on (Fine mode) PAMCoarse PAM4 Auto Search Setting on (Coarse mode)
Function	Sets Auto Search on and off for tolerance measurement. Sets Auto Search On/Off of the tolerance measurement.
Example	To set Auto Search to On (Fine mode): > :SENSe:MEASure:BERCond:ASearch FINE

:SENSe:MEASure:BERCond:ASearch?

Response	<type>=<CHARACTER RESPONSE DATA> OFF, FINE, COAR, PAMF, PAMC
Function	Queries the Auto Search On/Off of the tolerance measurement.
Example	> :SENSe:MEASure:BERCond:ASearch? < FINE

:SENSe:MEASure:BERCond:SSETting <range>,<step/ratio>

Parameter	<range>=<CHARACTER NUMERIC PROGRAM DATA> VERYlow Range Low: 10 Hz<Jitter Freq.≤100 kHz LOW Range Low: 100 kHz<Jitter Freq.≤1 MHz MIDDLE Range Middle: 1 MHz<Jitter Freq.≤10 MHz HIGH Range High: 10 MHz<Jitter Freq. <step>=<DECIMAL NUMERIC PROGRAM DATA> 0.001 to 2000.000 0.001 to 2000 UIp-p <ratio>=<DECIMAL NUMERIC PROGRAM DATA> 0.01 to 1.00 The resolution for the <step> setting will depend on the value set. Note: The step and ratio setting ranges are in accordance with the SJ specifications in 1.3.2 “Jitter Modulation Performance” of <i>MU181500B Jitter Modulation Source Instruction Manual</i> .
Function	Sets the measurement range, including upper and lower limits for tolerance measurement modulation for each modulation frequency band.
Example	To set the modulation steps to UI for the modulation frequency band 10 Hz to 1 MHz when the tolerance measurement method is “Downwards Linear”: <pre>> :SENSe:MEASure:BERCond:SSETting LOW,0.2</pre>

:SENSe:MEASure:BERCond:SSETting? <range>

Parameter	<range>=<CHARACTER PROGRAM DATA> VERYlow Range Low: 10 Hz<Jitter Freq.≤100 kHz LOW Range Low: 100 kHz<Jitter Freq.≤1 MHz MIDDLE Range Middle: 1 MHz<Jitter Freq.≤10 MHz HIGH Range High: 10 MHz<Jitter Freq.
Response	<step/ratio> <step>=<NR2 NUMERIC RESPONSE DATA> 0.001 to 2000.000 0.001 to 2000 UIp-p <ratio>=<NR2 NUMERIC RESPONSE DATA> 0.01 to 1.00
Function	Queries the measurement range such as jitter modulation amplitude upper and lower limits of the Tolerance measurement for each modulation frequency band.
Example	<pre>> :SENSe:MEASure:BERCond:SSETting? LOW < 0.200</pre>

:SENSe:MEASure:BERCond:MTYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA> NRZ NRZ signal PAM4 PAM4 signal
Function	Sets the type of signal to be measured in tolerance test.
Example	To set the type of signal to PAM4: > :SENSe:MEASure:BERCond:MTYPE PAM4

:SENSe:MEASure:BERCond:MTYPE?

Response	<type>=<CHARACTER RESPONSE DATA> NRZ, PAM4
Function	Queries the type of signal to be measured in tolerance test.
Example	> :SENSe:MEASure:BERCond:MTYPE? < PAM4

:SENSe:MEASure:BERCond:PATtern <type>

Parameter	<p><type>=<STRING PROGRAM DATA> “file name” Specify the file name according to “Appendix F” in the <i>MU183040B Operation Manual</i>. The following are example settings:</p> <table> <tr><td>"PRBS7"</td><td>PRBS7</td></tr> <tr><td>"PRBS9"</td><td>PRBS9</td></tr> <tr><td>"PRBS10"</td><td>PRBS10</td></tr> <tr><td>"PRBS11"</td><td>PRBS11</td></tr> <tr><td>"PRBS15"</td><td>PRBS15</td></tr> <tr><td>"PRBS20"</td><td>PRBS20</td></tr> <tr><td>"PRQS10"</td><td>PRQS10</td></tr> </table>	"PRBS7"	PRBS7	"PRBS9"	PRBS9	"PRBS10"	PRBS10	"PRBS11"	PRBS11	"PRBS15"	PRBS15	"PRBS20"	PRBS20	"PRQS10"	PRQS10
"PRBS7"	PRBS7														
"PRBS9"	PRBS9														
"PRBS10"	PRBS10														
"PRBS11"	PRBS11														
"PRBS15"	PRBS15														
"PRBS20"	PRBS20														
"PRQS10"	PRQS10														
Function	Sets the pattern to be used by ED for PAM4 Tolerance measurement.														
Example	<p>To set the PRQS10 pattern for PAM4 signal:</p> <pre>> :SENSe:MEASure:BERCond:PATtern "PRQS10"</pre>														

:SENSe:MEASure:BERCond:PATtern?

Response	<p><type>=<STRING RESPONSE DATA> “file name” Specify the file name according to “Appendix F” in the <i>MU183040B Operation Manual</i>.</p>
Function	Queries the pattern to be used by ED for PAM4 Tolerance measurement.
Example	<pre>> :SENSe:MEASure:BERCond:PATtern? < "PRQS10"</pre>

:SENSe:MEASure:BERCond:MANual:INTerface?

Response	<interface>=<CHARACTER RESPONSE DATA> SING, DIF50, DIF100
Function	Queries the Data Input Condition of ED used for PAM4 Tolerance measurement.
Example	> :SENSe:MEASure:BERCond:MANual:INTerface? < "SING"

:SENSe:MEASure:BERCond:MANual:DATA <thre>,<volt>

Parameter	<thre>=<CHARACTER PROGRAM DATA> UPPer Upper Eye threshold MIDDLE Middle Eye threshold LOWer Lower Eye threshold <volt>=<DECIMAL NUMERIC PROGRAM DATA> -3.500 to 3.300 -3.500 to 3.300 V, 0.001 V step
Function	Sets the eye threshold for the Data Input of ED used for PAM4 Tolerance measurement.
Example	To set the Upper Eye threshold of Data Input to 0.100 V: > :SENSe:MEASure:BERCond:MANual:DATA UPPer,0.100

:SENSe:MEASure:BERCond:MANual:DATA? <thre>

Parameter	<thre>=<CHARACTER PROGRAM DATA> UPPer Upper Eye threshold MIDDLE Middle Eye threshold LOWer Lower Eye threshold
Response	<volt>=<NR2 NUMERIC RESPONSE DATA> -3.500 to 3.300 -3.500 to 3.300 V, 0.001 V step
Function	Queries the eye threshold set for Data Input of ED and used for PAM4 Tolerance measurement.
Example	To query the Upper Eye threshold of Data Input: > :SENSe:MEASure:BERCond:MANual:DATA? UPPer < 0.100

:SENSe:MEASure:BERCond:MANual:XDATA <thre>,<volt>

Parameter	<thre>=<CHARACTER PROGRAM DATA>	
	UPPer	Upper Eye threshold
	MIDdle	Middle Eye threshold
	LOWer	Lower Eye threshold
	<volt>=<DECIMAL NUMERIC PROGRAM DATA>	
	–3.500 to 3.300	–3.500 to 3.300 V, 0.001 V step
Function	Sets the eye threshold for the XData Input of ED used for PAM4 Tolerance measurement.	
Example	To set the Lower Eye threshold of XData Input to 0.100 V: > :SENSe:MEASure:BERCond:MANual:XDATA LOWer,0.100	

:SENSe:MEASure:BERCond:MANual:XDATA? <thre>

Parameter	<thre>=<CHARACTER PROGRAM DATA>	
	UPPer	Upper Eye threshold
	MIDdle	Middle Eye threshold
	LOWer	Lower Eye threshold
Response	<volt>=<NR2 NUMERIC RESPONSE DATA>	
	–3.500 to 3.300	–3.500 to 3.300 V, 0.001 V step
Function	Queries the eye threshold set for XData Input of ED and used for PAM4 Tolerance measurement.	
Example	To query the Lower Eye threshold of XData Input: > :SENSe:MEASure:BERCond:MANual:XDATA? LOWer < 0.100	

:SENSe:MEASure:BERCond:MANual:DELaY <thre>,<delay>

Parameter	<thre>=<CHARACTER PROGRAM DATA>	
	UPPer	Upper Eye threshold
	MIDdle	Middle Eye threshold
	LOWer	Lower Eye threshold
	<delay>=<DECIMAL NUMERIC PROGRAM DATA>	
	–1000 to 1000	–1000 to 1000 mUI, 1 mUI step
Function	Sets the phase of ED used for PAM4 Tolerance measurement, specifying the eye threshold.	
Example	To set the phase of the Middle Eye threshold to 300 mUI: > :SENSe:MEASure:BERCond:MANual:DELaY MIDdle,300	

:SENSe:MEASure:BERCond:MANual:DELaY? <thre>

Parameter	<thre>=<CHARACTER PROGRAM DATA>	
	UPPer	Upper Eye threshold
	MIDdle	Middle Eye threshold
	LOWer	Lower Eye threshold
Response	<volt>=<NR1 NUMERIC RESPONSE DATA>	
	–1000 to 1000	–1000 to 1000 mUI, 1 mUI step
Function	Queries the phase of ED used for PAM4 Tolerance measurement, specifying the eye threshold.	
Example	To query the phase of the Middle Eye threshold: > :SENSe:MEASure:BERCond:MANual:DELaY? MIDdle < 300	

:SENSe:MEASure:BERCond:TEST <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	ON or 1	Verifies the Threshold/Phase settings before measurement.
	OFF or 0	Does not verify the Threshold/Phase settings before measurement.
Function	Sets whether to verify the Threshold/Phase settings before PAM4 Tolerance measurement.	
Example	To turn on the pretest function:	
	> :SENSe:MEASure:BERCond:TEST ON	

:SENSe:MEASure:BERCond:TEST?

Response	<boolean>=<NR1 NUMERIC RESPONSE DATA>	
	1	Verifies the Threshold/Phase settings before measurement.
	0	Does not verify the Threshold/Phase settings before measurement.
Function	Queries whether to verify the Threshold/Phase settings before PAM4 Tolerance measurement.	
Example	> :SENSe:MEASure:BERCond:TEST?	
	< 1	

:SENSe:MEASure:BERCond:TARGet <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	SYMBOL	Symbol error rate
	BIT	Bit error rate
	MSB	MSB error rate
	LSB	LSB error rate
Function	Sets the pass/fail evaluation criterion (symbol error rate, bit error rate, MSB error rate or LSB error rate) when using the PAM4 ED.	
Example	To set to perform a pass/fail evaluation based on the symbol error rate.	
	> :SENSe:MEASure:BERCond:TARGet SYMBOL	

:SENSe:MEASure:BERCond:TARGet?

Response	<type>=<CHARACTER RESPONSE DATA>	
	SYMB, BIT, MSB, LSB	
Function	Queries the pass/fail evaluation setting.	
Example	> :SENSe:MEASure:BERCond:TARGet?	
	< SYMB	

:SENSe:MEASure:BERCond:SJ:SSTep:TOZero <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> ON or 1 Step by step setting ON OFF or 0 Step by step setting OFF
Function	Sets whether or not to use the step by step setting function when resetting the jitter modulation amplitude to 0 UI after measuring the jitter tolerance at a certain modulation frequency.
Example	To use (ON) the step by step setting function of jitter modulation amplitude. > :SENSe:MEASure:BERCond:SJ:SSTep:TOZero ON
Compatibility	Incompatible with existing models.

:SENSe:MEASure:BERCond:SJ:SSTep:TOZero?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 Step by step setting ON 0 Step by step setting OFF
Function	Queries the step by step setting of jitter modulation amplitude.
Example	> :SENSe:MEASure:BERCond:SJ:SSTep:TOZero? < 1
Compatibility	Incompatible with existing models.

:SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA> ON or 1 Step by step setting ON OFF or 0 Step by step setting OFF
Function	Sets whether or not to use the step by step setting function when setting the jitter modulation amplitude for next measurement after changing modulation frequencies.
Example	To use (ON) the step by step setting function of jitter modulation amplitude. > :SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue ON
Compatibility	Incompatible with existing models.

:SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 1 Step by step setting ON 0 Step by step setting OFF
Function	Queries step-by-step setting of jitter modulation amplitude.
Example	> :SENSe:MEASure:BERCond:SJ:SSTep:FIRStvalue? < 1
Compatibility	Incompatible with existing models.

:SENSe:MEASure:BERCond:SJ:SSTep <range>,<step>

Parameter	<p><range>=<CHARACTER NUMERIC PROGRAM DATA ></p> <p>VERYlow Range Low: 10 Hz < Jitter Freq.≤100 kHz</p> <p>LOW Range Low: 100 kHz < Jitter Freq.≤1 MHz</p> <p>MIDDLE Range Middle: 1 MHz < Jitter Freq.≤10 MHz</p> <p>HIGH Range High: 10 MHz < Jitter Freq.</p> <p><step>=<DECIMAL NUMERIC PROGRAM DATA></p> <p>1 to 20 1 to 20 / 1 step</p>
Function	Sets the number of divisions to divide the jitter modulation amplitude into for changing the jitter modulation frequency, respectively for each modulation frequency band.
Example	<p>To set 5 for the number of divisions for the modulation frequency band 10 Hz to 1 MHz.</p> <p>> :SENSe:MEASure:BERCond:SJ:SSTep LOW,5</p>

:SENSe:MEASure:BERCond:SJ:SSTep? <range>

Parameter	<p><range>=<CHARACTER PROGRAM DATA></p> <p>VERYlow Range Low: 10 Hz < Jitter Freq.≤100 kHz</p> <p>LOW Range Low: 1 00 kHz < Jitter Freq.≤1 MHz</p> <p>MIDDLE Range Middle: 1 MHz < Jitter Freq.≤10 MHz</p> <p>HIGH Range High: 10 MHz < Jitter Freq.</p>
Response	<p><step>=<NR2 NUMERIC RESPONSE DATA></p> <p>1 to 20 1 to 20</p>
Function	Queries the number of divisions to divide the jitter modulation amplitude into, respectively for each modulation frequency band.
Example	<p>> :SENSe:MEASure:BERCond:SJ:SSTep? LOW</p> <p>< 5</p>

:SENSe:MEASure:BERCond:SJ:SSTep:WTIME <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 0.1 to 1.0 0.1 to 1.0 s/ 0.1s step
Function	Sets the time to wait until division settings for the jitter modulation amplitude are applied.
Example	To set 0.2 s for the time to wait until division settings for the jitter modulation amplitude are applied. > :SENSe:MEASure:BERCond:SJ:SSTep:WTIME 0.2

:SENSe:MEASure:BERCond:SJ:SSTep:WTIME?

Response	<step>=<NR2 NUMERIC RESPONSE DATA> 0.1 to 1.0 0.1 to 1.0 s/ 0.1s step
Function	Queries the time to wait until division settings for the jitter modulation amplitude are applied.
Example	> :SENSe:MEASure:BERCond:SJ:SSTep:WTIME? < 0.2

5.12.2 Graph Screen

This setup screen is available only when MX183000A-PL001 is installed, when **Jitter Tolerance Test** or **PCIe Link Sequence** is started on the Selector screen (Figure 4.3.1-1), and when the SQA has been connected using Equipment Setup.




Figure 5.12.2-1 Graph Screen

The following commands are the same as with JTOL Setting.
For details refer to the JTOL Settings Setup Screen.

:DISPlay:RESult:ESTimate:ERATe
:DISPlay:RESult:ESTimate:ERATe?

Table 5.12.2-1 Graph Screen Setup Commands

No.	Setting Item	Command
[1]	Estimation result display on/off	:DISPlay:RESult:ESTimate
		:DISPlay:RESult:ESTimate?

:DISPlay:RESult:ESTimate <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	ON or 1	Display selection on
	OFF or 0	Display selection off
Function	Sets whether the Estimation results are displayed on the graph.	
Example	To display the Estimation results are displayed on the graph > :DISPlay:RESult:ESTimate 1	
Compatibility	Incompatible with existing models.	

:DISPlay:RESult:ESTimate?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Displayed
	0	Not displayed
Function	Queries whether Estimation is displayed or not.	
Example	> :DISPlay:RESult:ESTimate? < 1	
Compatibility	Incompatible with existing models.	

5.12.3 Result Screen

This setup screen is available only when MX183000A-PL001 is installed, when **Jitter Tolerance Test** or **PCIe Link Sequence** is started on the Selector screen (Figure 4.3.1-1), and when the SQA has been connected using Equipment Setup.




Figure 5.12.3-1 Result Screen

Table 5.12.3-1 Result Screen Setup Commands

No.	Setting Item	Command
[1]	Save Result	:SYSTem:MMEMory:RESult:STORe

:SYSTem:MMEMory:RESult:STORe <file_name>,<type>

Parameter	<p><file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxx Directory name <file>=xxxxxxx File name <type>=<CHARACTER PROGRAM DATA> HTML HTML format CSV CSV format</p>
Function	Stores the Tolerance measurement result with specification of file name and file format.
Example	<p>Saves the measurement results in HTML format.</p> <pre>> :SYSTem:MMEMory:RESult:STORe "D:\test_folder\test",HTML</pre>

5.13 PAM4 Setup Screen

This setup screen is shown when **PAM4 Control** is launched on the Figure 4.3.1-1 “Selector Screen”, and this application connects to the SQA using Equipment Setup.

5.13.1 TX1 Setup




Figure 5.13.1-1 PAM4 Control TX1 Setting

Table 5.13.1-1 PAM4 Control TX1 Setting and Query Commands

No.	Setting Item	Command
[1]	PAM4/NRZ	:OUTPut:DATA:TYPE[:PPG1]
		:OUTPut:DATA:TYPE[:PPG1]?
[2]	PAM4 Eye Selecting	:OUTPut:DATA:SElect
		:OUTPut:DATA:SElect[:PPG1]?
[3]	Emphasis Tracking (Setting ON/OFF)	:OUTPut:DATA:TRACking[:PPG1]
		:OUTPut:DATA:TRACking[:PPG1]?
[4]	Output ON/OFF	:OUTPut:DATA:OUTPut
		:OUTPut:DATA:OUTPut[:PPG1]?
[5]	Default	:OUTPut:DATA:DEFault[:PPG1]
[6]	Total Amplitude	:OUTPut:DATA:AMPLitude[:PPG1]
		:OUTPut:DATA:AMPLitude[:PPG1]?
[7]	Range	:OUTPut:DATA:AMPLitude:RANGe[:PPG1]?
[8]	Level Setting	:OUTPut:DATA:LEVel[:PPG1]
		:OUTPut:DATA:LEVel[:PPG1]?
[9]	Each Eye Amplitude Query	:OUTPut:DATA:EAMPLitude[:PPG1]?
[10]	Data Delay	:OUTPut:DATA:DELay[:PPG1]
		:OUTPut:DATA:DELay[:PPG1]?
[11]	Eye Skew (Setting ON/OFF)	:OUTPut:DATA:INTERface[:PPG1]
		:OUTPut:DATA:INTERface[:PPG1]?
[12]	Eye Skew (Setting Skew)	:OUTPut:DATA:SKEW[:PPG1]
		:OUTPut:DATA:SKEW[:PPG1]?
[13]	Pattern	:SOURce:PATTern:TYPE[:PPG1]
		:SOURce:PATTern:TYPE[:PPG1]?
[14]	Pattern Tracking	:SOURce:PATTern:TYPE:TRACking[:PPG1]
		:SOURce:PATTern:TYPE:TRACking[:PPG1]?

:OUTPut:DATA:TYPE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>
	PAM4 Outputs PAM4 signal.
	NRZ Outputs NRZ signal.
Function	Selects the output signal type, PAM4 or NRZ.
Example	To select the output signal type PAM4: > :OUTPut:DATA:TYPE PAM4

:OUTPut:DATA:TYPE?

Response	<type>=<CHARACTER RESPONSE DATA>
	PAM4, NRZ
Function	Queries the output signal type
Example	> :OUTPut:DATA:TYPE? < PAM4

:OUTPut:DATA:SElect <eye>

Parameter	<eye>=<CHARACTER PROGRAM DATA>
	UPPer Set the Upper EYE
	MIDdle Set the Middle EYE
	LOWer Set the Lower EYE
Function	Selects the Eye to set the amplitude when outputting non-linear PAM4 signal.
Example	To select Upper Eye to set the amplitude: > :OUTPut:DATA:SElect UPPer

:OUTPut:DATA:SElect?

Response	<eye>=<CHARACTER RESPONSE DATA>
	UPP, MIDD, LOW
Function	Queries the Eye to set the amplitude when outputting non-linear PAM4 signal.
Example	> :OUTPut:DATA:SElect? < UPP

:OUTPut:DATA:TRACking <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Emphasis Tracking OFF
	ON or 1	Emphasis Tracking ON
Function	Sets Tracking ON/OFF for the Emphasis setting of Middle Eye and Upper/Lower Eye.	
Example	To Set Tracking ON for the Emphasis: > :OUTPut:DATA:TRACking ON	

:OUTPut:DATA:TRACking?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Emphasis Tracking OFF
	1	Emphasis Tracking ON
Function	Queries Tracking ON/OFF for the Emphasis setting of Middle Eye and Upper/Lower Eye.	
Example	> :OUTPut:DATA:TRACking? < 1	

:OUTPut:DATA:OUTPut <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	PAM4/NRZ signal OFF
	ON or 1	PAM4/NRZ signal ON
Function	Sets ON/OFF of PAM4/NRZ output signal.	
Example	To set the PAM4/NRZ output signal ON: > :OUTPut:DATA:OUTPut ON	

:OUTPut:DATA:OUTPut?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	PAM4/NRZ signal OFF
	1	PAM4/NRZ signal ON
Function	Queries ON/OFF of PAM4/NRZ output signal.	
Example	> :OUTPut:DATA:OUTPut? < 1	

:OUTPut:DATA:DEFault

Parameter	None
Function	Sets PAM4/NRZ signal amplitude as factory default.
Example	> :OUTPut:DATA:DEFault

:OUTPut:DATA:AMPLitude <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> 51 to 2200 51 to 2200 mV, 1 mV step
Function	Sets PAM4/NRZ signal amplitude.
Example	To PAM4/NRZ signal amplitude 600 mV: > :OUTPut:DATA:AMPLitude 600

:OUTPut:DATA:AMPLitude?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 51 to 2200 51 to 2200 mV
Function	Queries PAM4/NRZ signal amplitude.
Example	> :OUTPut:DATA:AMPLitude? < 600

:OUTPut:DATA:AMPLitude:RANGe?

Response	<min>=<NR1 NUMERIC RESPONSE DATA> 51 to 1000 51 to 1000 mV <max>=<NR1 NUMERIC RESPONSE DATA> 300 to 2200 300 to 2200 mV
Function	Queries the range of PAM4/NRZ amplitude that can be set for the signal. maximum
Example	> :OUTPut:DATA:AMPLitude:RANGe? < 300,1950

:OUTPut:DATA:LEVel <level>,<numeric>

Parameter	<level>=<DECIMAL NUMERIC PROGRAM DATA>	
	1	Level 1 of PAM4 signal (Available for Non-linear PAM4)
	2	Level 2 of PAM4 signal
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	-1100 to 1100	-1100 to 1100 mV, 1 mV step
Function	Sets the voltage of PAM4 Level 1 and Level 2.	
Example	To set the PAM4 Level 2 150 mV: > :OUTPut:DATA:LEVel 2,150	

:OUTPut:DATA:LEVel? <level>

Parameter	<level>=<DECIMAL NUMERIC PROGRAM DATA>	
	0 to 3	Level 0 to 3 of PAM4 signal
Response	<numeric>=<DECIMAL RESPONSE PROGRAM DATA>	
	-1100 to 1100	-1100 to 1100 mV
Function	Queries the voltage of each PAM4 Level.	
Example	> :OUTPut:DATA:LEVel? 2 < -150	

:OUTPut:DATA:EAMPlitude? <eye>[,<unit>]

Parameter	<eye>=<CHARACTER PROGRAM DATA>	
	UPPer	Queries the Upper EYE.
	MIDdle	Queries the Middle EYE.
	LOWer	Queries the Lower EYE.
	[<unit>]=<CHARACTER PROGRAM DATA>	
	MV	mV
	PERCent	%
	Note: The unit is mV when it is not configured.	
Response	<numeric>=<DECIMAL RESPONSE PROGRAM DATA>	
	When <unit> is MV	
	30 to 1320	30 to 1320 mV
	When <unit> is PERCent	
	20 to 60	20 to 60%
Function	Queries the PAM4 signal amplitude of each Eye (Upper/Middle/Lower).	
Example	> :OUTPut:DATA:EAMPlitude? Upper,MV < 145	

:OUTPut:DATA:DElay <numeric>

Parameter	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -64000 to 64000 -64,000 to 64,000 mUI, 2 mUI step
Function	Sets delay of PAM4/NRZ signal.
Example	To set Delay to 200 mUI: > :OUTPut:DATA:DElay 200

:OUTPut:DATA:DElay?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> -64000 to 64000 -64,000 to 64,000 mUI
Function	Queries Delay for PAM4/NRZ signal.
Example	> :OUTPut:DATA:DElay? < 200

:OUTPut:DATA:INterface <data>,<boolean>

Parameter	<data>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 PAM4 data number (Data 1 to Data 3) to set ON/OFF. <boolean>=<BOOLEAN PROGRAM DATA> OFF or 0 Signal output OFF ON or 1 Signal output ON
Function	Sets outputs ON/OFF of PAM4 Data 1 to Data 3.
Example	To set output of Data 1 ON: > :OUTPut:DATA:INT 1,ON

:OUTPut:DATA:INterface? <data>

Parameter	<data>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3 PAM4 data number (Data 1 to Data 3) to query ON/OFF
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 Signal output OFF 1 Signal output ON
Function	Queries outputs ON/OFF of PAM4 Data 1 to Data 3.
Example	> :OUTPut:DATA:INT? 2 < 1

:OUTPut:DATA:SKEW <data>,<numeric>

Parameter	<data>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3	PAM4 data number (Data 1 to Data 3) to set skew
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA> -64000 to 64000	-64,000 to 64,000 mUI, 2 mUI step
Function	Sets skew of PAM4 Data 1 to Data 3.	
Example	To set 150 mUI to Data 1 skew: > :OUTPut:DATA:SKEW 1,150	

:OUTPut:DATA:SKEW? <data>

Parameter	<data>=<DECIMAL NUMERIC PROGRAM DATA> 1 to 3	PAM4 data number (Data 1 to Data 3) to query ON/OFF and skew
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA> 0 1	Signal output OFF Signal output ON
	<numeric>=<DECIMAL RESPONSE PROGRAM DATA> -64000 to 64000	-64,000 to 64,000 mUI
Function	Queries ON/OFF and skew of PAM4 Data 1 to Data 3.	
Example	> :OUTPut:DATA:SKEW? 2 < 1,-150	

:SOURce:PATtern:TYPE <type>

Parameter	<type>=<STRING PROGRAM DATA> "pattern name" The following are example settings. The number of pattern types may increase depending on future update. Input the pattern name displayed in GUI, enclosing in double quotes. "PRBS7" PRBS7 "PRBS9" PRBS9 "PRBS10" PRBS10 "PRBS11" PRBS11 "PRBS13" PRBS13 "PRBS15" PRBS15 "PRBS20" PRBS20 "PRBS31" PRBS31 "SSPRQ" SSPRQ "GrayPRBSX" GrayPRBSX (X = 7, 9, 10, 11, 15, 20) "GrayPreQPRBS13-IEEE100GBASE-KP4_LaneX" GrayPreQPRBS13-IEEE100GBASE-KP4_LaneX (X = 0, 1, 2, 3) "PRBS13Q" PRBS13Q "PRBS31Q" PRBS31Q
Function	Sets the PAM4 pattern used for the measurement.
Example	To set the pattern to be measured to PRBS31: > :SOURce:PATtern:TYPE "PRBS31"

:SOURce:PATtern:TYPE?

Response	<type>=<STRING RESPONSE DATA>
Function	Queries the PAM4 pattern used for the measurement.
Example	> :SOURce:PATtern:TYPE? < "PRBS31"

:SOURce:PATtern:TYPE:TRACking <type>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Pattern Tracking OFF
	ON or 1	Pattern Tracking ON
Function	Sets ON/OFF of the Pattern Tracking setting.	
Example	To set Pattern Tracking for PPG1 to ON: > :SOURce:PATtern:TYPE:TRACking ON	

:SOURce:PATtern:TYPE:TRACking?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Pattern Tracking OFF
	1	Pattern Tracking ON
Function	Queries the Pattern Tracking setting for PPG1.	
Example	> :SOURce:PATtern:TYPE:TRACking? < 1	

5.13.2 TX2 Setup

For details of commands, refer to 5.13.1 “TX1 Setup”.

Table 5.13.2-1 PAM4 Control TX2 Setting and Query Commands

No.	Setting Item	Command
[1]	PAM4/NRZ	:OUTPut:DATA:TYPE:PPG2
		:OUTPut:DATA:TYPE:PPG2?
[3]	Emphasis Tracking (Setting ON/OFF)	:OUTPut:DATA:TRACking:PPG2
		:OUTPut:DATA:TRACking:PPG2?
[5]	Default	:OUTPut:DATA:DEFault:PPG2
[6]	Total Amplitude	:OUTPut:DATA:AMPLitude:PPG2
		:OUTPut:DATA:AMPLitude:PPG2?
[7]	Range	:OUTPut:DATA:AMPLitude:RANGe:PPG2?
[8]	Level Setting	:OUTPut:DATA:LEVel:PPG2
		:OUTPut:DATA:LEVel:PPG2?
[9]	Each Eye Amplitude Query	:OUTPut:DATA:EAMPLitude:PPG2?
[10]	Data Delay	:OUTPut:DATA:DELay:PPG2
		:OUTPut:DATA:DELay:PPG2?
[11]	Eye Skew (Setting ON/OFF)	:OUTPut:DATA:INTerface:PPG2
		:OUTPut:DATA:INTerface:PPG2?
[12]	Eye Skew (Setting Skew)	:OUTPut:DATA:SKEW:PPG2
		:OUTPut:DATA:SKEW:PPG2?
[13]	Pattern	:SOURce:PATtern:TYPE:PPG2
		:SOURce:PATtern:TYPE:PPG2?
[14]	Pattern Tracking	:SOURce:PATtern:TYPE:TRACking:PPG2
		:SOURce:PATtern:TYPE:TRACking:PPG2?

5.13.3 TX3 Setup

For details of commands, refer to 5.13.1 “TX1 Setup”.

Table 5.13.3-1 PAM4 Control TX3 Setting and Query Commands

No.	Setting Item	Command
[1]	PAM4/NRZ	:OUTPut:DATA:TYPE:PPG3
		:OUTPut:DATA:TYPE:PPG3?
[2]	PAM4 Eye Selecting	:OUTPut:DATA:SElect:PPG3
		:OUTPut:DATA:SElect:PPG3?
[3]	Emphasis Tracking (Setting ON/OFF)	:OUTPut:DATA:TRACking:PPG3
		:OUTPut:DATA:TRACking:PPG3?
[5]	Default	:OUTPut:DATA:DEFault:PPG3
[6]	Total Amplitude	:OUTPut:DATA:AMPLitude:PPG3
		:OUTPut:DATA:AMPLitude:PPG3?
[7]	Range	:OUTPut:DATA:AMPLitude:RANGe:PPG3?
[8]	Level Setting	:OUTPut:DATA:LEVel:PPG3
		:OUTPut:DATA:LEVel:PPG3?
[9]	Each Eye Amplitude Query	:OUTPut:DATA:EAMPLitude:PPG3?
[10]	Data Delay	:OUTPut:DATA:DELay:PPG3
		:OUTPut:DATA:DELay:PPG3?
[11]	Eye Skew (Setting ON/OFF)	:OUTPut:DATA:INTerface:PPG3
		:OUTPut:DATA:INTerface:PPG3?
[12]	Eye Skew (Setting Skew)	:OUTPut:DATA:SKEW:PPG3
		:OUTPut:DATA:SKEW:PPG3?
[13]	Pattern	:SOURce:PATtern:TYPE:PPG3
		:SOURce:PATtern:TYPE:PPG3?
[14]	Pattern Tracking	:SOURce:PATtern:TYPE:TRACking:PPG3
		:SOURce:PATtern:TYPE:TRACking:PPG3?

5.13.4 TX4 Setup

For details of commands, refer to 5.13.1 “TX1 Setup”.

Table 5.13.4-1 PAM4 Control TX4 Setting and Query Commands

No.	Setting Item	Command
[1]	PAM4/NRZ	:OUTPut:DATA:TYPE:PPG4
		:OUTPut:DATA:TYPE:PPG4?
[2]	PAM4 Eye Selecting	:OUTPut:DATA:SElect:PPG4
		:OUTPut:DATA:SElect:PPG4?
[3]	Emphasis Tracking (Setting ON/OFF)	:OUTPut:DATA:TRACking:PPG4
		:OUTPut:DATA:TRACking:PPG4?
[5]	Default	:OUTPut:DATA:DEFault:PPG4
[6]	Total Amplitude	:OUTPut:DATA:AMPLitude:PPG4
		:OUTPut:DATA:AMPLitude:PPG4?
[7]	Range	:OUTPut:DATA:AMPLitude:RANGe:PPG4?
[8]	Level Setting	:OUTPut:DATA:LEVel:PPG4
		:OUTPut:DATA:LEVel:PPG4?
[9]	Each Eye Amplitude Query	:OUTPut:DATA:EAMPLitude:PPG4?
[10]	Data Delay	:OUTPut:DATA:DELay:PPG4
		:OUTPut:DATA:DELay:PPG4?
[11]	Eye Skew (Setting ON/OFF)	:OUTPut:DATA:INTerface:PPG4
		:OUTPut:DATA:INTerface:PPG4?
[12]	Eye Skew (Setting Skew)	:OUTPut:DATA:SKEW:PPG4
		:OUTPut:DATA:SKEW:PPG4?
[13]	Pattern	:SOURce:PATtern:TYPE:PPG4
		:SOURce:PATtern:TYPE:PPG4?
[14]	Pattern Tracking	:SOURce:PATtern:TYPE:TRACking:PPG4
		:SOURce:PATtern:TYPE:TRACking:PPG4?

5.13.5 RX Setup




Figure 5.13.5-1 PAM4 Control Screen RX Setting

Table 5.13.5-1 PAM4 Control Screen RX Setting and Query Commands

No.	Setting Item	Command
[1]	CTLE Gain	:INPut:CTLE:SETTing
		:INPut:CTLE:SETTing?
[2]	Tracking Setting	:INPut:CTLE:TRACking
		:INPut:CTLE:TRACking?
[3]	Selecting Auto Search	:SENSe:ASEarch:MODE
		:SENSe:ASEarch:MODE?
[4]	CTLE Auto Search	:SENSe:ASEarch:CTLE
		:SENSe:ASEarch:CTLE?
[5]	DFF Auto Search	:SENSe:ASEarch:DFF
		:SENSe:ASEarch:DFF?
[6]	Starting Auto Search	:SENSe:ASEarch:STARt
[7]	Stoping Auto Search	:SENSe:ASEarch:STOP
[8]	Querying Auto Search Status	:SENSe:ASEarch:STATe?

Table 5.13.5-1 PAM4 Control Screen RX Setting and Query Commands (Cont'd)

No.	Setting Item	Command
[9]	Setting PAM4 Vref	:INPut:VREF:SETTing
		:INPut:VREF:SETTing?
[10]	Querying G0376A SN	:SENSe:DECoder:SERial?
[11]	Upper/Lower Vref Tracking	:INPut:VREF:TRACKing
		:INPut:VREF:TRACKing?
[12]	DFF	:INPut:DFF:SETTing
		:INPut:DFF:SETTing?
[13]	Input Condition	:INPut:DATA:INTerface
		:INPut:DATA:INTerface?
[14]	Pair PPG	:SENSe:MEASure:SELPpg
		:SENSe:MEASure:SELPpg?
[15]	Rx Pattern	:SENSe:PATtern:TYPE?

:INPut:CTLE:SETTing <interface>,<numeric>

Parameter	<interface>=<CHARACTER PROGRAM DATA>	
	DATA	Sets gain of Data input.
	XDATA	Sets gain of XData input.
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	-12.0 to 0.0	-12.0 to 0.0 dB, 0.1 dB step
Function	Sets the CTLE gain of Data/XData input.	
Example	To set -6.0 dB to the CTLE gain of Data input:	
	> :INPut:CTLE:SETTing DATA,-6.0	

:INPut:CTLE:SETTing? <interface>

Parameter	<interface>=<CHARACTER PROGRAM DATA>	
	DATA	Queries gain of Data input.
	XDATA	Queries gain of XData input.
Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	-12.0 to 0.0	-12.0 to 0.0 dB,
Function	Queries the CTLE gain of Data/XData input.	
Example	> :INPut:CTLE:SETTing? DATA	
	< -6.0	

:INPut:CTLE:TRACking <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	CTLE Tracking OFF
	ON or 1	CTLE Tracking ON
Function	Sets Tracking ON/OFF of CTLE setting.	
Example	To set Tracking ON of CTLE.	
	> :INPut:CTLE:TRACking ON	

:INPut:CTLE:TRACking?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	CTLE Tracking OFF
	1	CTLE Tracking ON
Function	Queries Tracking ON/OFF of CTLE setting.	
Example	> :INPut:CTLE:TRACking?	
	< 1	

:SENSe:ASEarch:MODE <mode>

Parameter	<mode>=<CHARACTER PROGRAM DATA>
	FINE Fine Search
	COARse Coarse Search
Function	Selects the Auto Search mode.
Example	To set Fine Search:
	> :SENSe:ASEarch:MODE FINE

:SENSe:ASEarch:MODE?

Response	<mode>=<CHARACTER RESPONSE DATA>
	FINE, COAR
Function	Queries the Auto Search mode.
Example	> :SENSe:ASEarch:MODE?
	< FINE

:SENSe:ASEarch:CTLE <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>
	OFF or 0 CTLE Auto Search OFF
	ON or 1 CTLE Auto Search ON
Function	Sets ON/OFF of CTLE Auto Search.
Example	To set ON of CTLE Auto Search:
	> :SENSe:ASEarch:CTLE ON

:SENSe:ASEarch:CTLE?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>
	0 CTLE Auto Search OFF
	1 CTLE Auto Search ON
Function	Queries ON/OFF of CTLE Auto Search.
Example	> :SENSe:ASEarch:CTLE?
	< 1

:SENSe:ASEarch:DFF <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	DFF Auto Search OFF
	ON or 1	DFF Auto Search ON
Function	Sets ON/OFF of DFF Auto Search.	
Example	To set ON of DFF Auto Search: > :SENSe:ASEarch:DFF ON	

:SENSe:ASEarch:DFF?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	DFF Auto Search OFF
	1	DFF Auto Search ON
Function	Queries ON/OFF of DFF Auto Search.	
Example	> :SENSe:ASEarch:DFF? < 1	

:SENSe:ASEarch:START

Parameter	None
Function	Starts PAM4 Auto Search.
Example	>:SENSe:ASEarch:START

:SENSe:ASEarch:STOP

Parameter	None
Function	Stops PAM4 Auto Search.
Example	>:SENSe:ASEarch:STOP

:SENSe:ASEarch:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being searched
	0	Stopped
Function	Queries the status of PAM4 Auto Search.	
Example	>:SENSe:ASEarch:STATe? < 1	

:INPut:VREF:SETTing <eye>,<numeric>

Parameter	<eye>=<CHARACTER PROGRAM DATA>	
	UPPer	Sets Vref of Upper Eye.
	MIDdle	Sets Vref of Middle Eye.
	LOWer	Sets Vref of Lower Eye.
	<numeric>=<DECIMAL NUMERIC PROGRAM DATA>	
	-0.400 to 0.400	-0.400 to 0.400 V, 0.001V step
Function	Sets Vref of each Eye (Upper/Middle/Lower).	
Example	To set 0.150 V to the Vref of Upper Eye: > :INPut:VREF:SETTing UPPer,0.150	

:INPut:VREF:SETTing? <eye>

Parameter	<eye>=<CHARACTER PROGRAM DATA>	
	UPPer	Queries Vref of Upper Eye.
	MIDdle	Queries Vref of Middle Eye.
	LOWer	Queries Vref of Lower Eye.
Response	<numeric>=<DECIMAL RESPONSE PROGRAM DATA>	
	-0.400 to 0.400	-0.400 to 0.400 V
Function	Queries Vref of each Eye (Upper/Middle/Lower).	
Example	> :INPut:VREF:SETTing? UPper < 0.150	

:SENSe:DECoder:SERial?

Response	<STRING>=<STRING RESPONSE DATA>	
	"AIxxxxxx-x"	
Function	Queries SN of G0376A Decoder.	
Example	> :SENSe:DECoder:SERial? < "AI12345-6"	

:INPut:VREF:TRACking <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	Upper/Lower Tracking OFF
	ON or 1	Upper/Lower Tracking ON
Function	Sets Tracking ON/OFF of Upper/Lower Vref.	
Example	To set Tracking ON of Upper/Lower Vref: > :INPut:VREF:TRACking ON	

:INPut:VREF:TRACking?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	Upper/Lower Tracking OFF
	1	Upper/Lower Tracking ON
Function	Queries Tracking ON/OFF of Upper/Lower Vref.	
Example	> :INPut:VREF:TRACking? < 1	

:INPut:DFF:SETTing <boolean>

Parameter	<boolean>=<BOOLEAN PROGRAM DATA>	
	OFF or 0	DFF OFF
	ON or 1	DFF ON
Function	Sets ON/OFF of the internal DFF.	
Example	To set the internal DFF ON: > :INPut:DFF:SETTing ON	

:INPut:DFF:SETTing?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	0	DFF OFF
	1	DFF ON
Function	Queries ON/OFF of the internal DFF:	
Example	> :INPut:DFF:SETTing? < 1	

:INPut:DATA:INTERface <interface>

Parameter	<interface>=<CHARACTER PROGRAM DATA> SINGle Single-Ended DIFFerential Differential
Function	Sets the input interface of Decoder Input.
Example	To set Differential to the input interface: > :INPut:DATA:INTERface DIFFerential

:INPut:DATA:INTERface?

Response	<interface>=<CHARACTER RESPONSE DATA> SING, DIFF
Function	Queries the input interface of Decoder Input.
Example	> :INPut:DATA:INTERface? < DIFF

:SENSe:MEASure:SELPpg <ppg>

Parameter	<ppg>=<CHARACTER PROGRAM DATA> 1 PPG specified for TX1 2 PPG specified for TX2 3 PPG specified for TX3 4 PPG specified for TX4
Function	Sets the target PPG for the BER measurement for which ED is used.
Example	To set the target PPG for the BER measurement for which ED is used, to PPG specified for TX1: > :SENSe:MEASure:SELPpg 1

:SENSe:MEASure:SELPpg?

Response	<ppg>=<CHARACTER PROGRAM DATA> 1, 2, 3, 4
Function	Queries the target PPG for the BER measurement for which ED is used.
Example	> :SENSe:MEASure:SELPpg? < 1

:SENSe:PATtern:TYPE?

Response	<type>=<STRING RESPONSE DATA>
Function	Queries the PAM4 pattern used for the measurement.
Example	> :SENSe:PATtern:TYPE? < "PRBS31"

5.13.6 Common Setting




Figure 5.13.6-1 PAM4 Control Screen Common Setting

Table 5.13.6-1 PAM4 Control Screen Common Setting and Query Commands

No.	Setting Item	Command
[1]	View	:DISPlay:SIZE :DISPlay:SIZE?
[2]	Querying bit rate	:OUTPut:DATA:BAUDrate?
[3]	Specifying setup screen to be displayed on left	:DISPlay:SETTing:LEFT :DISPlay:SETTing:LEFT?
[4]	Specifying setup screen to be displayed on right	:DISPlay:SETTing:RIGHT :DISPlay:SETTing:RIGHT?

:DISPlay:SIZE <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	FULL	Displays full-size TX and RX.
	HALF	Displays half-size.
Function	Sets the display size.	
Example	To set half-size to display.	
	> :DISPlay:SIZE HALF	

:DISPlay:SIZE?

Response	<type>=<CHARACTER RESPONSE DATA>	
	FULL, HALF	
Function	Queries the display size.	
Example	> :DISPlay:SIZE?	
	< HALF	

:OUTPut:DATA:BAUDrate?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	2.400000 to 32.100000	2.400000 to 32.100000 Gbaud
Function	Queries Baud Rate of PAM4 signal.	
Example	> :OUTPut:DATA:BAUDrate?	
	< 25.000000	

:DISPlay:SETTing:LEFT <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RX	Displays the RX setup screen.
	TX1	Displays the TX1 setup screen.
	TX2	Displays the TX2 setup screen.
	TX3	Displays the TX3 setup screen.
	TX4	Displays the TX4 setup screen.
Function	Sets the setup screen to be displayed on the left side of the full screen or on the half screen.	
Example	To display the RX setup screen on the left side of the full screen or on the half screen:	
	> :DISPlay:SETTing:LEFT RX	

:DISPlay:SETTing:LEFT?

Response	<type>=<CHARACTER RESPONSE DATA>	
	RX, TX1, TX2, TX3, TX4	
Function	Queries the setup screen being displayed on the left side of the full screen or on the half screen.	
Example	> :DISPlay:SETTing:LEFT?	
	< RX	

:DISPlay:SETTing:RIGHT <type>

Parameter	<type>=<CHARACTER PROGRAM DATA>	
	RX	Displays the RX setup screen.
	TX1	Displays the TX1 setup screen.
	TX2	Displays the TX2 setup screen.
	TX3	Displays the TX3 setup screen.
	TX4	Displays the TX4 setup screen.
Function	Sets the setup screen to be displayed on the right side of the full screen.	
Example	To display the RX setup screen on the right side of the full screen:	
	> :DISPlay:SETTing:RIGHT RX	

:DISPlay:SETTing:RIGHT?

Response	<type>=<CHARACTER RESPONSE DATA>	
	RX, TX1, TX2, TX3, TX4	
Function	Queries the setup screen being displayed on the right side of the full screen.	
Example	> :DISPlay:SETTing:LEFT?	
	< RX	

5.14 DUT Error Counts Import Setup Screen

This setup screen is available only when MX183000A-PL031 is installed, when **DUT Error Counts Import** is started on the Figure 4.3.1-1 “Selector Screen”.

5.14.1 DUT Control tab




Figure 5.14.1-1 DUT Control tab

Table 5.14.1-1 DUT Control tab Setup Commands

No.	Setting Item	Command
[1]	Selecting Initialization program	:SYSTem:EQUIPMENT:DUT:INITialize
[2]	Selecting Measurement program	:SYSTem:EQUIPMENT:DUT:MEASure
[3]	Selecting Finalization program	:SYSTem:EQUIPMENT:DUT:FINAlize
[4]	Starting Initialization program	:SYSTem:EQUIPMENT:DUT:INITialize:STARt
	Aborting Initialization program	:SYSTem:EQUIPMENT:DUT:INITialize:ABORt
	Status of Initialization program	:SYSTem:EQUIPMENT:DUT:INITialize:STATe?
	Checking execution history of Initialization program	:SYSTem:EQUIPMENT:DUT:INITialize:CONDition?
[5]	Starting Measurement program	:SENSe:MEASure:BER:STARt
	Aborting Measurement program	:SENSe:MEASure:BER:ABORt
	Status of Measurement program	:SENSe:MEASure:BER:STATe?
[6]	Starting Finalization program	:SYSTem:EQUIPMENT:DUT:FINAlize:STARt
	Aborting Finalization program	:SYSTem:EQUIPMENT:DUT:FINAlize:ABORt
	Status of Finalization program	:SYSTem:EQUIPMENT:DUT:FINAlize:STATe?
	Checking execution history of Finalization program	:SYSTem:EQUIPMENT:DUT:FINAlize:CONDition?
[7]	Loading parameter settings for DUT Control and Measurement tabs from file	:SYSTem:EQUIPMENT:DUT:SETTing:RECall
[8]	Saving parameter settings on DUT Control and Measurement tabs to a file	:SYSTem:EQUIPMENT:DUT:SETTing:STORe
[9]	Initializing parameter settings on DUT Control and Measurement tabs	:SYSTem:EQUIPMENT:DUT:SETTing:INITialize

:SYSTem:EQUIPMENT:DUT:INITialize <program_path>,<arguments>

Parameter	<p><program_path>=<STRING PROGRAM DATA> Sets a path to program. Unavailable characters :/*? "<> Number of characters: 260 <arguments>=<STRING PROGRAM DATA> Specifies the argument for program. Number of characters: 2000</p>
Function	Specifies the path and argument of the Initialization program.
Example	<pre>> :SYSTem:EQUIPMENT:DUT:INITialize "C:\test\sample_ini.exe","ini.py"</pre>

:SYSTem:EQUIPMENT:DUT:MEASure <program_path>,<arguments>

Parameter	<p><program_path>=<STRING PROGRAM DATA> Sets a path to program. Unavailable characters :/*? "<> Number of characters: 260 <arguments>=<STRING PROGRAM DATA> Specifies the argument for program. Number of characters: 2000</p>
Function	Specifies the path and argument of the Measurement program.
Example	<pre>> :SYSTem:EQUIPMENT:DUT:MEASure "C:\test\sample_meas.exe","meas.py"</pre>

:SYSTem:EQUIPMENT:DUT:FINalize <program_path>,<arguments>

Parameter	<p><program_path>=<STRING PROGRAM DATA> Sets a path to program. Unavailable characters :/*? "<> Number of characters: 260 <arguments>=<STRING PROGRAM DATA> Specifies the argument for program. Number of characters: 2000</p>
Function	Specifies the path and argument of the Finalization program.
Example	<pre>> :SYSTem:EQUIPMENT:DUT:FINalize "C:\test\sample_final.exe","final.py"</pre>

:SYSTem:EQUipment:DUT:INITialize:START

Parameter	None
Function	Starts the Initialization program.
Example	>:SYSTem:EQUipment:DUT:INITialize:START

:SYSTem:EQUipment:DUT:INITialize:ABORt

Parameter	None
Function	Aborts the Initialization program.
Example	>:SYSTem:EQUipment:DUT:INITialize:ABORt

:SYSTem:EQUipment:DUT:INITialize:STATe?

Response	<boolean>=<NR1 NUMERIC RESPONSE DATA> 1 Started 0 Not started yet
Function	Queries whether the Initialization program has been run or not.
Example	> :SYSTem:EQUipment:DUT:INITialize:STATe? < 1

:SYSTem:EQUipment:DUT:INITialize:CONDition?

Response	<boolean>=<NR1 NUMERIC RESPONSE DATA> 1 Successful completion 0 Other than successful completion, or not started yet
Function	Checks the execution history of the Initialization program.
Example	> :SYSTem:EQUipment:DUT:INITialize:CONDition? < 1

:SENSe:MEASure:BER:START

Parameter	None
Function	Starts measurement.
Example	<code>>:SENSe:MEASure:BER:START</code>

:SENSe:MEASure:BER:ABORT

Parameter	None
Function	Aborts the measurement.
Example	<code>>:SENSe:MEASure:BER:ABORT</code>

:SENSe:MEASure:BER:STATe?

Response	<numeric>=<NR1 NUMERIC RESPONSE DATA>	
	1	Being measured
	0	Stopped
Function	Queries the measurement state.	
Example	<code>> :SENSe:MEASure:BER:STATe?</code> <code>< 1</code>	

:SYSTem:EQUipment:DUT:FINalize:START

Parameter	None
Function	Starts the Finalization program.
Example	>:SYSTem:EQUipment:DUT:FINalize:START

:SYSTem:EQUipment:DUT:FINalize:ABORT

Parameter	None
Function	Aborts the Finalization program.
Example	>:SYSTem:EQUipment:DUT:FINalize:ABORT

:SYSTem:EQUipment:DUT:FINalize:STATe?

Response	<boolean>=<NR1 NUMERIC RESPONSE DATA> 1 Started 0 Not started yet
Function	Queries whether the Finalization program has been run or not.
Example	> :SYSTem:EQUipment:DUT:FINalize:STATe? < 1

:SYSTem:EQUipment:DUT:FINalize:CONDition?

Response	<boolean>=<NR1 NUMERIC RESPONSE DATA> 1 Successful completion 0 Other than successful completion, or not started yet
Function	Checks the execution history of the Finalization program.
Example	> :SYSTem:EQUipment:DUT:FINalize:CONDition? < 1

:SYSTem:EQUipment:DUT:SETTing:RECall <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxxx Directory name <file>=xxxxxxxx File name
Function	Loads parameter settings for the DUT Control and Measurement tabs.
Example	>:SYSTem:EQUipment:DUT:SETTing:RECall "C:\test_folder\test_setting"

:SYSTem:EQUipment:DUT:SETTing:STORe <file_name>

Parameter	<file_name>=<STRING PROGRAM DATA> "<drv>:\<dir1>\<dir2>\<file>" <drv>=C, D, E, F Drive name <dir>=xxxxxxxx Directory name <file>=xxxxxxxx File name
Function	Saves the parameter settings on the DUT Control and Measurement tabs.
Example	>:SYSTem:EQUipment:DUT:SETTing:STORe "C:\test_folder\test_setting"

:SYSTem:EQUipment:DUT:SETTing:INITialize

Parameter	None
Function	Initializes the parameter settings on the DUT Control and Measurement tabs.
Example	>:SYSTem:EQUipment:DUT:SETTing:INITialize

5.14.2 Measurement tab




Figure 5.14.2-1 Measurement tab

Table 5.14.2-1 Measurement tab Setup Commands

No.	Setting Item	Command
[1]	Starting Measurement program*	:SENSe:MEASure:BER:START
[2]	Stopping Measurement program	:SENSe:MEASure:BER:STOP
[3]	Status of Measurement program*	:SENSe:MEASure:BER:STATe?
[4]	Aborting Measurement program*	:SENSe:MEASure:BER:ABORt
[5]	Setting measurement cycle	:SENSe:MEASure:BER:MODE
		:SENSe:MEASure:BER:MODE?
[6]	Acquiring results of DUT Error Counts Import	:CALCulate:DATA:EALarm?

*: For command descriptions, refer to 5.14.1 “DUT Control tab”.

:SENSe:MEASure:BER:STOP

Paramete	None
Function	Stops measurement.
Example	<code>>:SENSe:MEASure:BER:STOP</code>

:SENSe:MEASure:BER:MODE <cycle>

Parameter	<cycle>=<CHARACTER PROGRAM DATA>	
	REPeat	Repeated measurement
	SINGle	1-cycle measurement
Function	Sets the measurement cycle.	
Example	Sets the measurement cycle to Repeat.	
	<code>> :SENSe:MEASure:BER:MODE REPeat</code>	

:SENSe:MEASure:BER:MODE?

Response	<sel>=<CHARACTER RESPONSE DATA>	
	REP	Repeated measurement
	SING	1-cycle measurement
Function	Queries the measurement cycle.	
Example	<code>> :SENSe:MEASure:BER:MODE?</code>	
	<code>< REP</code>	

:CALCulate:DATA:EALarm? <result>

Parameter	<p><result>=<CHARACTER PROGRAM DATA></p> <p>EC1 to EC8 Error rate 1 to 8</p> <p>ER1 to ER8 Error count 1 to 8</p> <p>AL1 to AL4 Alarm 1 to 4</p>
Response	<p><string>=<STRING RESPONSE DATA></p> <p>“<comment>,<value>”</p> <p><comment></p> <p>Xxxxx any comment, alphanumeric characters</p> <p><value></p> <p>For EC*</p> <p> ----- (Seven hyphen characters indicate an invalid value.)</p> <p> 0 to 18446744073709551615</p> <p>For ER*</p> <p> ----- (Seven hyphen characters indicate an invalid value.)</p> <p> 0.0001E-18 to 1.0000E00</p> <p>For AL*</p> <p> ----- (Seven hyphen characters indicate an invalid value.)</p> <p> 0, 1</p>
Function	Acquires result of DUT Error Counts Import.
Example	<p>Acquires error counts of Channel 1.</p> <p>> :CALCulate:DATA:EALarm? EC1</p> <p>< "MSB Error Count,1234567"</p>

Appendix A Specifications

Table A-1 Configuration

Item	Model	Name	Quantity
Standard Configuration	P0031A	USB Memory (MX183000A/MX180000A Installer, Operation manual)	1
Application Parts	W3813AE	MX183000A Operation Manual (Printed, English)	—
	41KC-3	Precision Fixed Attenuator 3 dB	—
	41KC-6	Precision Fixed Attenuator 6 dB	—
	41KC-20	Precision Fixed Attenuator 20 dB	—
	K241C	Power Splitter	—
	J1510A	Pick Off Tee	—
	J1721A	USB Measurement Component Set*	—
	J1722A	PCIe Measurement Component Set*	—
	J1508A	BNC-SMA connector cable (30 cm)	—
	J1615A	Coaxial Cable set (Jitter-PPG-Emphasis)	—
	J1627A	GND connection cable	—
	Z2025A	PCIe CBB Controller	—
	Z2029A	PCIe Reference Clock Buffer	—

*: For the USB and PCIe Measurement Component Set configuration, refer to Table 3.1-4 “J1722A PCIe Measurement Component Set Configuration” and Table 3.1-5 “J1721A USB Measurement Component Set Configuration”.

Table A-2 Operation Environment

Item	Specifications
Installation target	MP1800A, MP1900A or a PC
PC specifications	
OS	Windows 7 Professional/Enterprise/Ultimate English or Japanese version
CPU	1 GHz or higher
Memory	1 GB or more (For Windows 7, 32-bit) 2 GB or more (For Windows 7, 64-bit)
Hard Disk	Free space 2 GB or more
Remote interface	Ethernet (10BASE-T, 100BASE-TX)
Display	Resolution 800 × 600 or more, Display color 32 bits
Target Equipment	MP1800A, MP1900A, or MT1810A
Required accessory	MP1800A-x02 LAN MP1800A-x07 OS Upgrade to Windows 7 (MP1800A only) MP1800A-x32 32Gbit/s PPG and/or ED Support
Number of Target Equipment	Three or less
Version	To control MP1800A: MX180000A Installer: Version 8.02.00 or later To control MP1900A: MX190000A Installer: Version 1.00.00 or later

Table A-3 Selector Screen Settings

Item	Specifications
Application Selector	PCIe Link Sequence, PCIe Link Training, USB Link Sequence, USB Link Training, Jitter Tolerance Test, PAM4 Control, DUT Error Counts Import

Table A-4 Equipment Setup Tab

Item	Specifications
MP1800A	Selects whether to execute search on the selected network device.
No.1:	OFF/ON
No.2:	OFF/ON
No.3:	OFF/ON
MP1800A/MT1810A Connection Setting	Selects a network device to connect. Example: TCPIP::127.0.0.1::5001::SOCKET,TCPIP::192.168.2.100::5001::SOCKET
Search Start	Click the button to start search and to display the discovered equipment.
Equipment	Display the discovered equipment and select a desired one.
Jitter:	Example: MU181500B(No.1:Unit1:Slot2)
PPG:	Example: MU183020A Data1(No.1:Unit1:Slot3)
ED:	Example: MU183040A Data1(No.1:Unit1:Slot4)
Noise:	Example: MU195050A(No.1:Unit1:Slot8)
Decoder:	Example: G0376A COM1 SN:AI12345-6
Connect/Disconnect	Click the button to connect/disconnect the equipment.
Connection Guide	Displays connection diagram.

Table A-5 Sequence Tab (PCIe)

Item	Specifications
Sequence Start/Stop/Unlink	Sends the sequence set by Editor.
BER Measurement	Continues sending test patterns after a link sequence is sent. Click the button after a sequence is sent to execute the BER measurement.
BER Monitor	OFF/ON
LTSSM State	Detect, Polling, Configuration, Recovery, Loopback
Specification Rev.	1.0/1.1(2.5 GT/s), 2.0(5 GT/s), 3.0/3.1(8 GT/s), 4.0(16 GT/s)
Loopback Through	Configuration /Recovery
Test Pattern	Compliance/PRBS
Compliance	MCP/CP
PRBS	PRBS7, PRBS9, PRBS10, PRBS11, PRBS15, PRBS20, PRBS23, PRBS31
Inset Delay Symbol	Disable/Enable
All parameter	Displays all the sequence setup parameters.
Default	Initialize the sequence setting.
Sequence Editor	Sets a pattern number to send in each state or sets idle time. Can set each parameter for setting the Specification Rev.

Table A-5 Sequence Tab (PCIe) (Cont'd)

Item	Specifications
Rev1.0/1.1 Configuration	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Loopback.Entry	1 to 1000000, 1 step
Rev2.0 Configuration	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Loopback.Entry(2.5G)	1 to 1000000, 1 step
Loopback.Entry (Electrical Idle)	1 to 1000000, 1 step
Loopback.Entry(5G)	1 to 1000000, 1 step
Rev2.0 Recovery	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Configuration.Linkwidth.Start	1 to 1000000, 1 step
Configuration.Linkwidth.Accept	1 to 1000000, 1 step
Configuration.Lane.Wait	1 to 1000000, 1 step
Configuration.Lane.Accept	1 to 1000000, 1 step
Configuration.Complete	1 to 1000000, 1 step
Configuration.Idle	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(EQTS2)	1 to 1000000, 1 step
Recovery.Speed	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(TS2)	1 to 1000000, 1 step
Loopback.Entry(5G)	1 to 1000000, 1 step

Table A-5 Sequence Tab (PCIe) (Cont'd)

Item	Specifications
Rev3.0/3.1 Configuration	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Loopback.Entry(2.5G)	1 to 1000000, 1 step
Loopback.Entry (Electrical Idle)	1 to 1000000, 1 step
Loopback.Entry(8G)	1 to 1000000, 1 step
Rev3.0/3.1 Recovery	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Configuration.Linkwidth.Start	1 to 1000000, 1 step
Configuration.Linkwidth.Accept	1 to 1000000, 1 step
Configuration.Lane.Wait	1 to 1000000, 1 step
Configuration.Lane.Accept	1 to 1000000, 1 step
Configuration.Complete	1 to 1000000, 1 step
Configuration.Idle	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(EQTS2)	1 to 1000000, 1 step
Recovery.Speed(8G)	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.Equalization Phase1	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(TS2)	1 to 1000000, 1 step
Loopback.Entry(8G)	1 to 1000000, 1 step

Table A-5 Sequence Tab (PCIe) (Cont'd)

Item	Specifications
Rev4.0 Recovery	
Detect.Quiet	1 to 1000000, 1 step
Detect.Active	1 to 1000000, 1 step
Polling.Active	1 to 1000000, 1 step
Polling.Configuration	1 to 1000000, 1 step
Configuration.Linkwidth.Start	1 to 1000000, 1 step
Configuration.Linkwidth.Accept	1 to 1000000, 1 step
Configuration.Lane.Wait	1 to 1000000, 1 step
Configuration.Lane.Accept	1 to 1000000, 1 step
Configuration.Complete	1 to 1000000, 1 step
Configuration.Idle	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(EQTS2)	1 to 1000000, 1 step
Recovery.Speed(8G)	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.Equalization Phase1	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(TS2)	1 to 1000000, 1 step
Recovery.Idle	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(EQTS2)	1 to 1000000, 1 step
Recovery.Speed(16G)	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.Equalization Phase1	1 to 1000000, 1 step
Recovery.RcvrLock	1 to 1000000, 1 step
Recovery.RcvrCfg(TS2)	1 to 1000000, 1 step
Loopback.Entry(16G)	1 to 1000000, 1 step

Table A-5 Sequence Tab (PCIe) (Cont'd)

Item	Specifications
Option	
TS Parameter	
FTS	0 to 255, 1 step
Link Number	0 to 255, 1 step
Lane Number	0 to 255, 1 step
Full Swing	12 to 63, 1 step
Low Frequency	12 to 63, 1 step
SRIS	Disable
Disable Scrambling	OFF/ON
Reset EIEOS Interval	Disable/Enable
SKP	
SKP Insert	Enable/Disable
SKP Length(128b/130b)	8 to 24 Symbol, 4 step
SKP Length(8b/10b)	COM + 1 to 5, 1 step
SKP Interval(128b/130b)	20 to 750, 1 step
SKP Interval(8b/10b)	176 to 3076, 2 step
Send TS	
Polling.Active	TS1/EQTS1
Loopback.Entry	TS1/EQTS1
Rev3.x/Rev4.0 Preset	
Downstream	
Preset(DE, PS [dB])	P7: −6.0, 3.5
Preset Hint	−6 dB
Precursor	0
Cursor	0
Postcursor	0
Upstream	
Usepreset	Preset
Preset(DE, PS [dB])	P7: −6.0, 3.5
Preset Hint	−6 dB
Precursor	0
Cursor	0
Postcursor	0

Table A-6 Sequence Tab (USB)

Item	Specifications
LTSSM State	eSS.Inactive, Rx.Detect, Polling, Loopback
Sequence Start/Stop/Unlink	Sends the sequence set by Editor. Starts sending a sequence when a trigger is detected by Aux Input of the MU183020A. Continues sending test patterns after a link sequence is sent.
USB3.1 Specification	Gen1(5.0 GT/s), Gen2(10.0 GT/s)
Test Pattern	Compliance/USER
CPx	Gen1: CP0 D0.0, CP1 D10.2, CP2 D24.3, CP3 K28.5, CP4 LFPS, CP5 K28.7*, CP6 K28.7* Gen2: CP9
All parameter	Displays all sequence setup parameters.
Default	Initialize sequence setting.
Sequence Editor	Sets a pattern number to send in each state or sets idle time.
Gen1	
Rx.Detect.Active(Idler)	1 to 1000000, 1 step
Polling.LFPS	100 to 1000000, 10 step
Polling.RxEQ	1 to 1000000, 1 step
Polling.Active(TS1)	1 to 1000000, 1 step
Polling.Configuration(TS2)	1 to 1000000, 1 step
Polling.Idle	1 to 1000000, 1 step
Gen2	
Rx.Detect.Active(Idler)	1 to 1000000, 1 step
Polling.LFPS(SCD1)	162 to 1000000, 1 step
Polling.LFPSPlus(SCD2)	172 to 1000000, 1 step
Polling.PortMatch (PHY Capability LBPM)	2 to 1000000, 1 step
Polling.PortConfig (PHY Ready LBPM)	2 to 1000000, 1 step
Polling.RxEQ	1 to 1000000, 1 step
Polling.Active(TS1)	1 to 1000000, 1 step
Polling.Configuration(TS2)	1 to 1000000, 1 step
Polling.Idle	1 to 1000000, 1 step

*: Selecting CP5 or CP6 does not change de-emphasis setting that is actually output.

Table A-6 Sequence Tab (USB) (Cont'd)

Item	Specifications
Option	
Loopback	Asserted
Disable Scrambling	OFF/ON
SKP	
SKP Insert	Enable/Disable
Symbol Length(128b/132b)	8 to 40, 2 step
Symbol Length(8b/10b)	2 to 6, 2 step
SKP Interval(128b/132b)	20 to 80, 1 step
SKP Interval(8b/10b)	176 to 708, 2 step
tPeriod	20 ns
Duty	50%
WarmReset	
tBurst	100 ms
LFPS	
tBurst	1.000 μ s
SuperSpeed	
tRepeat	10.000 μ s
SuperSpeedPlus	
Logic0	7.000 μ s
Logic1	12.000 μ s
SCD1	33.000 μ s
SCD2	43.000 μ s
LBPM	
tLFPS-1	1.500 μ s
tLFPS-0	0.700 μ s
tPWM	2.200 μ s

Table A-7 Run Test Tab


Item	Specifications
Run Test/Stop Test	Starts or stops Jitter Tolerance Test.
Detail	Displays settings and results of Jitter Tolerance Table.
Check All	Select the Jitter Tolerance Table checkbox.
Uncheck	Deselect the Jitter Tolerance Table checkbox.
Jitter Tolerance Table	
JTOL measurement point	Sets SJ modulation frequency to perform measurement, modulation amount (UI) for pass/fail judgement, and range of modulation amount to search.
Jitter frequency setup range	Sets Jitter Freq. [Hz], Mask[UI], Upper Limit [UI], Lower Limit [UI], Upper Ratio, and Lower Ratio. Click the Add to add points. Click Delete > All Clear to delete points.
Jitter amplitude setup range	<p>For setting range, refer to the sinusoidal jitter (SJ or SJ2) modulation frequency setup range shown in Table 1.3-2 “Jitter Modulation Performance” in the <i>MU181500B Jitter Modulation Source Operation Manual</i>.</p>  <p>Note that available jitter frequency and jitter amplitude for jitter measurement depend on the clock frequency set by controller and MU181500B.</p>
Set All Limit	Resets the Upper Limit and Lower Limit values at the ratio set for Mask.
Upper Ratio	Set the ratio to reset for Upper Ratio and Lower Ratio.
Lower Ratio	1.000 to 1000, 0.001 step
Measurement Sequence	0.001 to 1.000, 0.001 step
Mask file Save/Open	From higher Freq. side, From lower Freq. side
	Saves and opens the mask file for JTOL test.

Table A-7 Run Test Tab (Cont'd)

Item	Specifications
JTOL Setting	
Detection	
Unit	Error Rate, Error Count, Estimate, Symbol Error Rate, Bit Error Rate, MSB Error Rate, LSB Error Rate
Error Threshold	1E-3 to 10E-12, E-1 step
Error Count	0 to 10000000, 1 step
BER for JTOL Estimation	1.0E-20 to 9.9E-9
Search Type	
Auto Search	OFF/FINE/COARSE/PAM4 FINE/PAM4 COARSE
Meas. Type	NRZ/PAM4
PAM4 Pattern	Select the PAM4 signal pattern to be used by ED.
Search	
Direction Search	Binary, Downwards Linear, Downwards Log, Upwards Linear, Upwards Log, Binary + Linear
Step	When Downwards/Upwards Linear is selected:
Jitter Freq. ≤ 100 kHz	0.001 to 2000.000 0.001 step
100 k < Jitter Freq. ≤ 1 MHz	0.001 to 200.000 0.001 step
1M < Jitter Freq. ≤ 10 MHz	0.001 to 15.000 0.001 step
10 MHz < Jitter Freq.	0.001 to 1.000 0.001 step
Ratio	When Downwards/Upwards Log is selected:
Jitter Freq. ≤ 100 kHz	0.01 to 1.00 0.01 step
100 k < Jitter Freq. ≤ 1 MHz	0.01 to 1.00 0.01 step
1 M < Jitter Freq. ≤ 10 MHz	0.01 to 1.00 0.01 step
10 MHz < Jitter Freq.	0.01 to 1.00 0.01 step
Timer[sec.]	
Waiting	1 to 99 seconds, in steps of one second
Setting	1 to 99 seconds, in steps of one second
Gating	1 to 86400 seconds, in steps of one second
SJ Amplitude Setting	SJ amplitude setting ON/OFF
Change SJ Amplitude in Steps	When SJ Amplitude is changed to 0 UI. When SJ Amplitude is set to the first point of measurement modulation frequency.
Number of steps	1 to 20
Wait time of a step	0.1 to 1.0 seconds, in steps of 0.1 seconds

Table A-8 Graph Tab

Item	Specifications
Display BER for JTOL Estimation	OFF/ON 1.0E-20 to 9.9E-9, 0.1 step, E-1 step

Table A-9 Report Tab

Item	Specifications
Make HTML	Displays the Jitter Tolerance results in HTML.
Make CSV	Displays the Jitter Tolerance results in CSV.
Save	Saves the Jitter Tolerance results in the format displayed on the screen.

Table A-10 Link Training Tab (PCIe)

Item	Specifications
Link Training Tab	Can execute PCIe Link Training (PCIe1.0 to 4.0).
Link Start/Stop/Unlink	Starts Link Training. Continues sending test patterns after Link Training.
BER Measurement	Same as sequence.
BER Monitor	Same as sequence.
LTSSM Log	Displays transition logs of LTSSM State during Link Training.
LTSSM Log Display Items	Time, ΔTime, State, Detect Preset, Error Count, Use Preset, Preset, Precursor, Cursor, Postcursor
Export CSV	Saves logs in csv format.
Specification	Same as sequence.
Loopback through	Same as sequence.
Test Pattern	Same as sequence.
Timeout	Sets Timeout in each LTSSM State.
Option	Performs particular settings of Link Training.
Result Display of PCIe Link Training	
Common Parameter	LTSSM State, Linkup Speed
SKP128b/130b	SKP Count, DC Balance, Sync Header Error, Parity Error, Block Lock
SKP 8b/10b	SKP Count, DC Balance, Sync Header Error, Parity Error, Block Lock
Link Equalization	Can display results per phase.
Received	Tx Preset, Full Swing, Low Frequency, Link Number, Lane Number, Request Equalization
PCIe 4.0 Control SKP	Count, Margin Type, Usage Model, Payload, Receiver Number, CRC, Parity

Table A-11 PAM4 Control Tab

Item	Specifications
PAM4 Control Tab	Allows transmission/reception setting of PAM4 signal.

Table A-12 Link Training Tab (USB)

Item	Specifications
Link Training Tab	Can execute USB Link Training (USB3.1 Gen1/Gen2).
Start Link Training/Stop/Unlink	Starts Link Training when LFPS is detected by Data Input of MU195040A. Continues sending test patterns after Link Training.
Specification	Same as sequence.
Not Wait for The LFPS Signal	Starts Link Training by clicking the Start Link Training button as a trigger instead of waiting for LFPS signal.
BER Measurement	Same as sequence.
BER Monitor	Same as sequence.
LTSSM Log	Displays transition logs of LTSSM.
Display Items of LTSSM Log	Time, ΔTime, State, Speed, Error Count
Export CSV	Saves logs in csv format.
Send Ping LFPS	Outputs Ping LFPS signal.
	Switches DUT CP when performing Tx test of USB Compliance Test.
Test Pattern	Same as sequence.
Timeout	Sets Timeout for each LTSSM State.
Option	Performs particular settings of Link Training.
Result Display of USB Link Training	
Common Parameter	LTSSM State, Linkup Speed
SKP	SKP Count

Table A-13 DUT Control Tab (DUT Error Counts Import)

Item	Specifications
DUT Control Tab	Allows you to select and run external programs for controlling DUT.
Initialize	Allows you to select a program for initializing DUT.
Measurement	Allows you to select a program for measuring DUT.
Finalize	Allows you to select a program for finalizing DUT.
Log Viewer button	Displays the log window.
Finalize button	Runs the selected Finalize program.
Initialize button	Runs the selected Initialize program.

Table A-14 BER Measure Tab (DUT Error Counts Import)

Item	Specifications
BER Measure Tab	Allows starting and stopping BER measurement, and displaying the measurement results.
Result	Displays the measurement results, which are: error rates, error counts, and whether alarms are given or not.
Cycle	Changes measurement cycle (Single/Repeat).
Start/Stop	Starts or stops the measurement.
Abort	Aborts the measurement.
Debug	Executes the measure programs, ignoring syntax errors.

Appendix B Default Settings

Table B-1 Selector

Item	Default
Application Selector	PCIe Link Sequence

Table B-2 Equipment Setup Tab

Item	Default
MP1800A/MP1900A Check box	No.1: ON No.2: OFF No.3: OFF
Equipment Jitter PPG ED Noise Decoder	None None None None None

Table B-3 Sequence Tab (PCle)

Item	Default
BER Monitor	OFF
LTSSM State	—
Specification Rev.	3.0/3.1(8.0 GT/s)
Loopback through	Configuration
Test pattern	Compliance
Compliance	MCP
PRBS	PRBS23
Insert Delay symbol	
Sequence Editor	Disable
Rev1.0/1.1 Configuration	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	1100
Polling.Configuration	49152
Loopback.Entry	20
Rev2.0 Configuration	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	1100
Polling.Configuration	49152
Loopback.Entry(2.5G)	20
Loopback.Entry(Electrical Idle)	1000
Loopback.Entry(5G)	35000

Table B-3 Sequence Tab (PCIe) (Cont'd)

Item	Default
Rev2.0 Recovery	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	4000
Polling.Configuration	49152
Configuration Linkwidth.Start	40
Configuration Linkwidth.Accept	2
Configuration Lane.Wait	40
Configuration Lane.Accept	2
Configuration Complete	48
Configuration Idle	5
Recovery RcvrLock	60
Recovery RcvrCfg(EQTS2)	60
Recovery Speed	363
Recovery RcvrLock	40960
Recovery RcvrCfg(TS2)	32
Loopback.Entry(5G)	35000
Rev3.0/3.1 Configuration	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	1100
Polling.Configuration	49152
Loopback.Entry(2.5G)	20
Loopback.Entry(Electrical Idle)	1000
Loopback.Entry(8G)	200000

Table B-3 Sequence Tab (PCIe) (Cont'd)

Item	Default
Rev3.0/3.1 Recovery	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	4000
Polling.Configuration	49152
Configuration Linkwidth.Start	40
Configuration Linkwidth.Accept	2
Configuration Lane.Wait	40
Configuration Lane.Accept	2
Configuration Complete	48
Configuration Idle	5
Recovery RcvrLock	60
Recovery RcvrCfg(EQTS2)	60
Recovery Speed(8G)	363
Recovery RcvrLock	32
Recovery Equalization Phase1	131072
Recovery RcvrLock	80
Recovery RcvrCfg(TS2)	32
Loopback.Entry(8G)	32000
Rev4.0 Recovery	
Detect.Quiet	1000 μ s
Detect.Active	12000 μ s
Polling.Active	4000
Polling.Configuration	49152
Configuration Linkwidth.Start	40
Configuration Linkwidth.Accept	2
Configuration Lane.Wait	40
Configuration Lane.Accept	2
Configuration Complete	48
Configuration Idle	5
Recovery RcvrLock	60
Recovery RcvrCfg(EQTS2)	60
Recovery Speed(8G)	363
Recovery RcvrLock	32
Recovery Equalization Phase1	131072
Recovery RcvrLock	80
Recovery RcvrCfg(TS2)	32
Recovery Idle	1
Recovery RcvrLock	40
Recovery RcvrCfg(EQTS2)	40
Recovery Speed(16G)	5
Recovery RcvrLock	2
Recovery Equalization Phase1	131072
Recovery RcvrLock	40
Recovery RcvrCfg(TS2)	20
Loopback.Entry(16G)	20

Table B-3 Sequence Tab (PCIe) (Cont'd)

Item	Default
TS Option	
TS Parameter	
FTS	127
Link Number	1
Lane Number	0
Full Swing	30
Low Frequency	12
SRIS	Disable
Disable Scrambling	Disable
Reset EIEOS Interval	OFF
SKP	
SKP Insert	Enable
SKP Length(128b/130b)	16 Symbols
SKP Length(8b/10b)	COM + 3
SKP Interval(128b/130b)	375
SKP Interval(8b/10b)	1538
Send TS	
Polling.Active	TS1
Loopback.Entry	TS1
Rev3.x/Rev4.0 Preset	
Downstream	
Preset(DE, PS [dB])	P7 : -6.0, 3.5
Preset Hint	-6 dB
Precursor	0
Cursor	0
Postcursor	0
Upstream	
Usepreset	P7 : -6.0, 3.5
Preset(DE, PS [dB])	-6 dB
Preset Hint	0
Precursor	0
Cursor	0
Postcursor	Preset

Table B-4 Sequence Tab (USB)

Item	Default
LTSSM State	
USB3.1 Specification	Gen1(5.0 GT/s)
Test pattern	Compliance
CPx(Gen1)	CP0 D0.0
CPx(Gen2)	CP9
Sequence Editor	
Gen1	
Rx.Detect.Active(Idle)	1 μ s
Polling.LFPS	560 μ s
Polling.RxEQ	65536 μ s
Polling.Active(TS1)	18000
Polling.Configuration(TS2)	18000
Polling.Idle	1 μ s
Gen2	
Rx.Detect.Active(Idle)	1 μ s
Polling.LFPS(SCD1)	162 μ s
Polling.LFPSPlus(SCD2)	172 μ s
Polling.PortMatch (PHY Capability LBPM)	132 μ s
Polling.PortConfig (PHY Ready LBPM)	343 μ s
Polling.RxEQ	524288
Polling.Active(TS1)	18000
Polling.Configuration(TS2)	1100
Polling.Idle	1 μ s

Table B-4 Sequence Tab (USB) (Cont'd)

Item	Default
Option	
Loopback	Asserted
Disable Scrambling	OFF
SKP	
SKP Insert	Enable
Symbol Length(128b/132b)	16 Symbols
Symbol Length(8b/10b)	4 Symbols
SKP Interval(128b/132b)	40
SKP Interval(8b/10b)	354
tPeriod	20 ns
Duty	50%
WarmReset	
tBurst	100 ms
LFPS	
tBurst	1.000 μ s
SuperSpeed	
tRepeat	10.000 μ s
SuperSpeedPlus	
Logic0	7.000 μ s
Logic1	12.000 μ s
SCD1	33.000 μ s
SCD2	43.000 μ s
LBPM	
tLFPS-1	1.500 μ s
tLFPS-0	0.700 μ s
tPWM	2.200 μ s

Table B-5 Link Training Tab (PCIe)

Item	Default
BER Monitor	OFF
Specification	4.0 (16.0 GT/s)
DUT	Endpoint
Loopback through	Configuration
Test pattern	Compliance
Compliance	MCP
PRBS	PRBS23
Insert Delay symbol	Disable
Timeout	
Detect.Quiet	12.0
Polling.Config.	48.0
Polling.Active	24.0
Configuration.Linkwidth.Start	24.0
Configuration.Lanenum.Wait	2.0
Configuration.Linkwidth.Accept	2.0
Configuration.Complete	2.0
Configuration.Idle	2.0
Recovery.RcvrLock	24.0
Recovery.RcvrCfg	48.0
Recovery.Speed	48.0
Recovery.Idle	2.0
Recovery.Eq.Phase0 (Root)	12.0
Recovery.Eq.Phase1 (Root)	12.0
Recovery.Eq.Phase2 (Root)	24.0
Recovery.Eq.Phase3 (Root)	32.0
Recovery.Eq.Phase1 (Endpoint)	24.0
Recovery.Eq.Phase2 (Endpoint)	32.0
Recovery.Eq.Phase3 (Endpoint)	24.0
Loopback.Entry (Active)	2.0
Loopback.Entry (Exit)	100.0
Hotreset	2.0
Disable	2.0

Table B-5 Training Tab (PCIe) (Cont'd)

Item	Default
TS Parameter	
FTS	127
Link Number	1
Lane Number	0
Full Swing	30
Low Frequency	12
SRIS	Disable
Disable Scrambling	De-asserted
EIEOS	
Reset Interval	Disable
16 G Format	Rev 0.7 or higher
Send TS	
Polling.Active	TS1
Loopback.Entry	TS1
SKP	
SKP Insert	Enable
Symbol Length	16 Symbols
Interval	375
x2	OFF
Extended Sync patterns	Normal
Tx Preset	
Initial Preset for 2.5 GT/s	P4
Loopback Preset	Auto
Downstream	
Preset	P7
Preset Hint (PCIe 3)	-6 dB
Upstream	
Preset	P7
Preset Hint (PCIe 3)	-6 dB
De-emphasis (PCIe 2)	-6 dB
Recovery Phase2, 3	Try
Repeat Phase2 (Root)	1
Repeat Phase3 (Endpoint)	1

Table B-6 Run Test Tab

Item	Default
Jitter Freq [Hz]	10
Mask[UI]	1.000
Upper Limit[UI]	2.000
Lower Limit[UI]	1.000
Upper Ratio	2.000
Lower Ratio	1.000
Title	PCIe_CC
Measurement Sequence	From higher Freq. side
JTOL Settings	
Detection	
Unit	Error Count
Error Threshold	1E-12
Error Count	2
BER for JTOL Estimation	1.0E-15
Auto Search	OFF
Direction Search	Upwards Log
Step	
Jitter Freq. ≤ 100 kHz	1.000
$100\text{k} < \text{Jitter Freq.} \leq 1$ MHz	1.000
$1\text{M} < \text{Jitter Freq.} \leq 10$ MHz	0.100
10 MHz $< \text{Jitter Freq.}$	0.100
Ratio	
Jitter Freq. ≤ 100 kHz	0.20
$100\text{k} < \text{Jitter Freq.} \leq 1$ MHz	0.20
$1\text{M} < \text{Jitter Freq.} \leq 10$ MHz	0.20
10 MHz $< \text{Jitter Freq.}$	0.20
Timer[sec.]	
Waiting	2
Setting	2
Gating	1

Table B-7 Graph Tab

Item	Default
Display	ON
BER for JTOL Estimation	1.0E-15

Table B-8 PAM4 Control Tab

Item	Default
Tx Control	
PAM4/NRZ	PAM4
Output	OFF
Emphasis Tracking	OFF
Data Delay	0 mUI
Total Amplitude	450 mV*
Variable Middle Eye	33%
Enlarge Upper/Lower	45%
Rx Control	
CTLE Gain	0.0 dB
CTLE Tracking	OFF
Vref	
Upper	0.150 V
Middle	0.000 V
Lower	-0.150 V
Input Mode	Single
DFF	ON
CTLE Search	OFF
Upper/Lower Vref Tracking	OFF

*: When Total Amplitude cannot be set to 450 mV, it is set to 910 mV. If neither of them is available, it is set to 1250 mV.

Table B-9 Link Training Tab (USB)

Item	Default
BER Monitor	OFF
Specification	Gen1(5.0 GT/s)
Test pattern	Compliance
CPx(Gen1)	CP0 D0.0
CPx(Gen2)	CP9

Table B-10 DUT Control Tab

Item	Default
Log Viewer	OFF

Table B-11 Measurement Tab

Item	Default
Cycle	Single
Debug Mode check box	OFF
Log Viewer	OFF

Appendix C User Program Specifications

Appendix C explains the specifications of the programs that a user creates (hereinafter, user programs) for controlling DUT which is loaded into MX183000A by MX183000A-PL031 or for obtaining data from DUT.

C.1	Data Transfer Between MX183000A and user programs.....	C-2
C.2	Initialization Program	C-3
C.3	Measurement Program	C-4
C.4	Finalization Program.....	C-5
C.5	Syntax for Standard Input/Output	C-6
	C.5.1 Character encoding	C-6
	C.5.2 Syntax in standard input/output.....	C-6
	C.5.3 Reserved words.....	C-8
	C.5.4 Optional reserved words	C-10
	C.5.5 Invalid values	C-11
	C.5.6 Examples of Syntax Errors.....	C-12
C.6	Sample Program	C-14
	C.6.1 Measurement system of sample program	C-14
	C.6.2 Detail of sample program	C-16
	C.6.3 Operation procedure using sample program..	C-17

C.1 Data Transfer Between MX183000A and user programs

For data transfer between MX183000A and user programs, standard input/output is used.

User programs write measurement results in specific format (reserved word) to standard output, and MX183000A reads the results output from the user programs and treats contents written in specific format as measurement results. Items treated as measurement results are specified by users. The results written in other format (optional reserved word) can also be used.

There are no restrictions on development languages and environments, however, MX183000A must be installed on MP1900A or on the control PC.




Figure C.1-1 Data Display on MX183000A using User Program

C.2 Initialization Program

On the **DUT Control** tab, clicking **Run** in the Initialization Program area runs the Initialization program.

The Initialization program performs initialization processing, such as starting DUT and loading firmware. Configure the program so that the Initialization program will return a return code of 0 and end when the initialization processing has completed successfully.

Run the Initialization program so that BER can be acquired by running only the Measurement program.

If the Initialization program returns a return code other than 0, the following dialog box will appear. “X” is the exit code.

ERROR! Initialize program ended with code X.

The life cycle of the Initialization program is shown below.




Figure C.2-1 Initialization Program Life Cycle

C.3 Measurement Program

You can run the Measurement program in the following ways:

- Clicking **Run** for Measurement Program on the **DUT Control** tab
- Clicking **Run** on the **Measurement** tab
- Clicking **Run Test** on the **Run Test** tab

Configure the Measurement program so that measurement results acquired from DUT are output to standard output according to the syntax described in C.5 “Syntax for Standard Input/Output”.

Also, configure the Measurement program so that it will return a return code of 0 and end when measurement has completed successfully.

If the Measurement program does not end normally, the following dialog box will appear. “X” is the exit code

ERROR! Measure program ended with code X.

If the Measurement program returns a return code other than 0, the following behaviors will be made.

Table C.3-1 Behaviors When Measure Program Does Not End Normally

Operations	Behaviors
Using the Run button for Measurement when Debug Mode is selected	An error message appears in logs.
Using the Run button for Measurement	After an error message appears in logs, the error measurement is interrupted.
JTOL Measurement	After an error message appears in logs, the JTOL measurement is interrupted.

For details on the syntax that the Measurement program outputs to standard output, refer to C.5.2 “Syntax in standard input/output”.

C.4 Finalization Program

On the **DUT Control** tab, clicking **Run** in the Finalization area runs the Finalization program.

The Finalization program performs post-processing to disconnect communication with DUT.

If post-processing is not required, you do not need to prepare the Finalization program.

If post-processing has completed successfully, the Finalization program will return a return code of 0 and end.

If the Finalization program returns a return code other than 0, the following dialog box will appear. “X” is the exit code.

ERROR! Finalize program ended with code X.

C.5 Syntax for Standard Input/Output

To allow MX183000A to communication with DUT, you need to create programs that satisfy the requirements described in the following pages.

C.5.1 Character encoding

ASCII code is used for character encoding. LF (Line Feed) or CR (Carriage Return) + LF is used for line breaks.

C.5.2 Syntax in standard input/output

Syntax used for user programs is the following.




Figure C.5.2-1 Syntax

A program line begins with @ followed by a reserved word, an equal sign, a value, and then ends with a line feed code (0x0a).

To use multiple reserved words, separate the words by commas.

Example:

```
@EC1 = 1000, @NAME = "Total EC", @COLOR = @YELLOW \n
```

The maximum line length is 10000 characters. The line feed code is not included.

For reserved words, refer to C.5.3 “Reserved words and C.5.4 “Optional reserved words”. Reserved words are not case-sensitive.

Put an equal sign “=” (0x3d) between a reserved word and a value.

The same reserved word cannot be specified more than once.

Values to be used should be within the range that are described in the sections “Reserved words” and “Optional reserved words”. The following characters are available for values. If starting without @, the reserved word is ignored and is not output in logs.

Also, reserved words can be modified using optional reserved words. You can put a space (0x20) in between line head, reserved word, equal sign, value, and line end. However, a line length must not exceed the maximum.

If there is a syntax error, the following dialog box will appear and the value specified for the reserved word will not be set. For detail of syntax error logs, refer to C.5.6 “Examples of Syntax Errors”.

SYNTAX ERROR! @RESERVED_WORD = XXXX.

XXXX: indicates the value written in the program.
RESERVED_WORD: indicates the reserved word written in the program.

Example:
SYNTAX ERROR! @EC = ABC

Table C.5.2-1 Behaviors When Syntax Error Occurs

Operation	Behavior
Using the Run button for Measurement when Debug Mode is selected	The syntax error is output in logs and the operation continues.
Using the Run button for Measurement	After the error dialog box appears, the measurement is interrupted.
JTOL Measurement	After the error dialog box appears, the JTOL measurement is interrupted.

C.5.3 Reserved words

This section describes reserved words that MX183000A can receive in standard input.

Specify the DUT channel number as the reserved word number.

Inputs that do not satisfy the rules described in this section will be output as syntax errors in the log and values will not be displayed on the **Measurement** tab.

ER1-8

Explanation

These reserved words display error rates on the **Measurement** tab.

Value

0, 0.0001E-18 to 1.0000E00

Example

To display an error rate for Channel 2:

@ER2 = 1.0E-12

EC1-8

Explanation

These reserved words display the error counts on the **Measurement** tab.

Value

0 to 18,446,744,073,709,551,615

Example

To display the error counts for Channel 4:

@EC4 = 64000

AL1-4

Explanation

These reserved words display whether alarms are given or not on the **Measurement** tab.

Value

0, 1

0 Alarm not given

1 Alarm given

Example

To display an alarm for Channel 4:

@AL4 = 0

LOG

Explanation

Displays a character string on the log screen. If the string contains more than 10000 characters, up to 10000 characters are displayed, but the characters that come after are discarded.

Value

All characters except control characters are usable.

Example

```
@LOG = BER Measurement finished! \n
```

C.5.4 Optional reserved words

The following optional reserved words can be used with the reserved words defined in C.5.3 “Reserved words”.

Optional reserved words cannot be used independently. Moreover, optional reserved words can be specified in any order, however, the same one cannot be specified more than once.

NAME

Explanation

Up to 12 characters including spaces can be specified for a name.

Value

Alphanumeric characters + spaces

It must be enclosed in double quotation marks (“”).

Example

To specify the name of error counts for Channel 1:

```
@EC1 = 0, @NAME = "Lane1" \n
```

COLOR

Explanation

Specify the background color to be displayed.

Value

Table C.5.4-1 Reserved Values for Colors


Reserved Values	Color Names	Color Codes	Actual Color Tones
@RED	Red	#FF0000	0
@BLUE	Blue	#0000FF	0
@GREEN	Green	#00FF00	0
@YELLOW	Yellow	#FFFF00	0
@MAGENTA	Magenta	#FF00FF	0
@CYAN	Cyan	#00FFFF	0

If any value that is not in the table above is specified, it will be output to the log as a syntax error and the background color will not be set.

Example

To specify the color of error rate for Channel 1:

```
@ER1 = 1.0085E-9, @COLOR = @BLUE \n
```



C.5.5 Invalid values

@NA

Explanation

Even if it is set to the value of reserved word and optional reserved word, it will not result in a syntax error. If the value of reserved word cannot be acquired, send an invalid value.

Example

To specify the invalid value for the background of Channel 4 and error counts:

```
@EC4 = @NA, @COLOR = @NA \n
```

C.5.6 Examples of Syntax Errors

The table below lists the program examples that are not processed and the error messages that appear in logs.

Table C.5.6-1 Examples of Syntax Errors

Example	Reason
EC1 = 0\n	There is no @ (at mark) at beginning of line. The input characters without @ are ignored and are not output in logs.
@ER1 = \n	Any reserved word value is not specified. If no value, specify @NA as a value. Example: 2019/01/11 14:19:49 SYNTAX ERROR! @ER value does not matched with allowed value.
@EC0 = 0\n	A reserved word that does not exist is used. Example: 2019/01/11 14:20:45 SYNTAX ERROR! Contains keys are not reserved words
@ER1 = 2\n	Value type does not match. Example: 2019/01/11 14:22:25 SYNTAX ERROR! @ER value does not matched with allowed value.
@ER1 = 1.0000E+01 \n	The value specified is not within the allowed range. Example: 2019/01/11 14:23:18 RANGE ERROR! @ER value is over the range.
@EC1 = 0, @NAME = "A", @NAME = "B" \n	The same reserved word is used more than once. Example: 2019/01/11 14:24:11 SYNTAX ERROR! Reserved words are duplicated.
@COLOR = @RED, @NAME = "A" \n	An optional reserved word is used independently. Example: 2019/01/11 14:25:43 SYNTAX ERROR! Reserved word does not contain ER1-8, EC1-8, or AL1-4.
@EC1 = 0, @NAME = "A+B" \n	A symbol is used for the value of @NAME. Example: 2019/01/11 14:28:50 SYNTAX ERROR! @NAME value does not matched with allowed value.
@EC1 = 0, @COLOR = #00FF00 \n	A value that is not reserved word for color is used. Example: 2019/01/11 14:29:41 SYNTAX ERROR! @COLOR value does not matched with allowed value.

Table C.5.6-2 Examples of Messages Output to Log

Example	Reason
The external program started.	[External program type] program is started successfully. Example: 2018/11/12 14:41:37 Initialize program is started successfully.
The external program ended normally.	[External program type] program ended with code 0. Example: 2018/11/12 14:43:27 Measure program ended with code 0.
The external program was aborted.	ERROR! [External program type] program is aborted.
The file was not discovered.	ERROR! Can't find the file at [External program path] Example: 2018/11/12 14:44:30 ERROR! Can't find the file at C:\test.exe
The argument exceeds 2000 characters.	ERROR! Argument is too long.
Failed to create new process.	SYSTEM ERROR! Can't create new process.
Failed to start the external program.	SYSTEM ERROR! Can't start program.
Input more than 10000 characters in standard input.	SYNTAX ERROR! Inputs exceeding 10000 characters are not accepted.

C.6 Sample Program

This section explains the sample program of MX183000A-PL031 and its example of use.

It is explained how to use the sample program in an environment that Python 3.6 is installed in this section. However, upon your development language for user programs, you need to install software required for the language.

C.6.1 Measurement system of sample program

This sample program is designed for the measuring system that uses the MP1900A and MU196020A as signal generators and Anritsu's MT1100A Network Master Flex or MT1000A Network Master Pro as a device to obtain error counts.

For details on MT1100A and MT1000A, visit our website:
<https://www.anritsu.com/>

The following are the equipment configuration and system diagram for measurement. The numbers in parentheses are the quantities required for the measuring system using MT1000A.

Table C.6.1-1 Equipment Configuration

Model	Name	Qt'y
MP1900A	Signal Quality Analyzer-R	1
MU196020A	PAM4 PPG	4 (1)
MU181000B	12.5GHz 4port Synthesizer	1
MU181500B	Jitter Modulation Source	1
MT1100A	Network Master Flex	1
-	CFP Module	1
-	CFP Evaluation Board	1
MT1000A	Network Master Pro	(1)
-	SFP Module	(1)
-	SFP Evaluation Board	(1)




Figure C.6.1-1 Measuring System Using MT1100A




Figure C.6.1-2 Measuring System Using MT1000A

C.6.2 Detail of sample program

The sample program is stored in:

C:\Anritsu\MX183000A\Sample\Script

The sample program can run in a Python environment, and its operation check has been performed in Python 3.6.

The sample program consists of the following files.

Table C.6.2-1 Contents of Sample Program

File Name	Function
initialize.py	MX183000A loads this file. This file configures settings before measurement. The sample file starts the measurement application installed on MT1100A/MT1000A and configures the settings.
measure.py	MX183000A loads this file. This file starts the measurement and acquires its results. The sample file acquires error rate, error counts, and alarms of Lane0.
finalize.py	MX183000A loads this file. This file performs post-processing. The sample file quits the measurement application installed on MT1100A/MT1000A.
communicationMT1100.py	Configures settings for remote communications with MT1100A/MT1000A, such as opening or closing a network socket, or sending commands.
createString.py	Creates strings of the measurement results to be displayed in MX183000A.

The following figure shows the relationship among those files.




Figure C.6.2-1 Relationship of Files Contained in Sample Program

C.6.3 Operation procedure using sample program


The following is the measurement procedure using the sample program. The operation procedure is described, taking the measuring system using MT1100A as an example.

Note:

This section describes the measurement procedure when Python 3.6 is installed on MP1900A.


Connecting and setting up equipment

1. For MT1100A:
Connect the Output connector on the CFP module where MU196020A is connected, to the CFP2 module installed on MT1100A.
2. For MP1900A:
 - (a) Connect the Data Output connectors for Slot 1 to 4 on MU196020A to the CFP evaluation board.
 - (b) In the Combination Setting window for MP1900A, set all the slots (Slot 1 to 4) for MU196020A to **Channel Synchronization**.



- (c) Configure settings of Slot 1 to 4 for MU196020A as follows:

Interface:	NRZ
Bit rate:	25.78125 Gbit/s
Test pattern:	PRBS7
Logic:	NEG



3. Loading the programs

- (a) On the **DUT Control** tab in MX183000A, specify the path to the executable file (python.exe) in the Program box for each program, to load the file.

In this example, specify the location as below:

C:\Python\python.exe

- (b) Load the following files by specifying their storage location in the Arguments boxes corresponding to the programs:


Initialization Program: initialize.py

Measurement Program: measure.py

Finalization Program: finalize.py


In this example, specify the locations where the sample programs are stored as below:

C:\Anritsu\MX183000A\Sample\Script\forMT1100A\xxxxx.py




4. Running the program to start the measurement
 - (a) On the **DUT Control** tab, click **Run** for Initialization Program to perform initialization processing. In this example, the program sets measurement parameters for MT1100A as follows:


Application: No Frame
 Interface Type: CFP2
 Bit Rate: 100G Ethernet
 Lane Select: 4 Lane
 Test pattern: PRBS7
 Interval length: 2 seconds



- (b) On the MP1900A screen, click **Output** to turn on the MU196020A output.




- (c) On the **Measurement** tab, click **Run** to start the measurement. The button name changes to **Stop** during the measurement.



5. Checking measurement results


In this example, the results of ER Lane0, EC Lane0, and LSS0 are displayed under Error Rate, Error Count, and Alarm.




6. Performing the jitter tolerance measurement

If the MX183000A-PL001 Jitter Tolerance Test is installed, the jitter tolerance measurement can be performed using the error counts obtained by MT1100A.

- (a) On the **Equipment Setup** tab, click **Search Start** to select the Jitter module and PPG module, and then click **Connect**.



- (b) On the **Run Test** tab, click **Run Test** to start the jitter tolerance measurement. In this example, the jitter tolerance measurement is performed using values of ER Lane0, EC Lane0, and LSS0.



7. Performing post-processing

The post-processing is performed to disconnect communication with the DUT.

On the **DUT Control** tab, click **Run** for Finalization Program to perform the post-processing.

In this example, the program quits the measurement application installed on MT1100A.

