

**MS2690A/MS2691A/MS2692A
and
MS2830A/MS2840A/MS2850A
Signal Analyzer
Operation Manual
Phase Noise Measurement Function
Operation**

11th Edition

- For safety and warning information, please read this manual before attempting to use the equipment.
- Additional safety and warning information is provided within the MS2690A/MS2691A/MS2692A Signal Analyzer Operation Manual (Mainframe Operation), MS2830A Signal Analyzer Operation Manual (Mainframe Operation), MS2840A Signal Analyzer Operation Manual (Mainframe Operation), or MS2850A Signal Analyzer Operation Manual (Mainframe Operation). Please also refer to this document before using the equipment.
- Keep this manual with the equipment.

ANRITSU CORPORATION

Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

Symbols used in manual



DANGER

This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.



WARNING

This indicates a hazardous procedure that could result in serious injury or death if not performed properly.



CAUTION

This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MS2690A/MS2691A/MS2692A and MS2830A/MS2840A/MS2850A

Signal Analyzer

Operation Manual Phase Noise Measurement Function Operation

25 April 2008 (First Edition)

30 October 2017 (11th Edition)

Copyright © 2008-2017, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

Equipment Certificate

Anritsu Corporation guarantees that this equipment was inspected at shipment and meets the published specifications.

Anritsu Warranty

- During the warranty period, Anritsu Corporation will repair or exchange this software free-of-charge if it proves defective when used as described in the operation manual.
- The warranty period is 6 months from the purchase date.
- The warranty period after repair or exchange will remain 6 months from the original purchase date, or 30 days from the date of repair or exchange, depending on whichever is longer.
- This warranty does not cover damage to this software caused by Acts of God, natural disasters, and misuse or mishandling by the customer.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation shall assume no liability for injury or financial loss of the customer due to the use of or a failure to be able to use this equipment.

Anritsu Corporation Contact

In the event of this equipment malfunctions, contact an Anritsu Service and Sales office. Contact information can be found on the last page of the printed version of this manual, and is available in a separate file on the PDF version.

Notes On Export Management

This product and its manuals may require an Export License/Approval by the Government of the product's country of origin for re-export from your country.

Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not.

When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

Cautions against computer virus infection

- Copying files and data
Only files that have been provided directly from Anritsu or generated using Anritsu equipment should be copied to the instrument.
All other required files should be transferred by means of USB or CompactFlash media after undergoing a thorough virus check.
- Adding software
Do not download or install software that has not been specifically recommended or licensed by Anritsu.
- Network connections
Ensure that the network has sufficient anti-virus security protection in place.

Software End-User License Agreement (EULA)

Please read this Software End-User License Agreement (hereafter this EULA) carefully before using (includes executing, copying, registering, etc.) this software (includes programs, databases, scenarios, etc., used to operate, set, etc., Anritsu electronic equipment). By reading this EULA and using this software, you are agreeing to be bound by the terms of its contents and Anritsu Corporation (hereafter Anritsu) hereby grants you the right to use this Software with the Anritsu-specified equipment (hereafter Equipment) for the purposes set out in this EULA.

1. Grant of License and Limitations

1. Regardless of whether this Software was purchased from or provided free-of-charge by Anritsu, you agree not to rent, lease, lend, or otherwise distribute this Software to third parties and further agree not to disassemble, recompile, reverse engineer, modify, or create derivative works of this Software.
2. You may make one copy of this Software for backup purposes only.
3. You are not permitted to reverse engineer this software.
4. This EULA allows you to install one copy of this Software on one piece of Equipment.

2. Disclaimers

To the extent not prohibited by law, in no event shall Anritsu be liable for personal injury, or any incidental, special, indirect or consequential damages whatsoever, including, without limitation, damages for loss of profits, loss of data, business interruption or any other commercial damages or losses, arising out of or related to your use or inability to use this Software.

3. Limitation of Liability

- a. If a fault (bug) is discovered in this Software, preventing operation as described in the operation manual or specifications whether or not the customer uses this software as described in the manual, Anritsu shall at its own discretion, fix the bug, or exchange the software, or suggest a workaround, free-of-charge. However, notwithstanding the above, the following items shall be excluded from repair and warranty.
 - i) If this Software is deemed to be used for purposes not described in the operation manual or specifications.
 - ii) If this Software is used in conjunction with other non-Anritsu-approved software.
 - iii) Recovery of lost or damaged data.
 - iv) If this Software or the Equipment has been modified, repaired, or otherwise altered without Anritsu's prior approval.
 - v) For any other reasons out of Anritsu's direct control and responsibility, such as but not limited to, natural disasters, software virus infections, etc.
- b. Expenses incurred for transport, hotel, daily allowance, etc., for on-site repairs by Anritsu engineers necessitated by the above faults shall be borne by you.
- c. The warranty period for faults listed in article 3a above covered by this EULA shall be either 6 months from the date of purchase of this Software or 30 days after the date of repair, whichever is longer.

4. Export Restrictions

You may not use or otherwise export or re-export directly or indirectly this Software except as authorized by Japanese and United States law. In particular, this software may not be exported or re-exported (a) into any Japanese or US embargoed countries or (b) to anyone on the Japanese or US Treasury Department's list of Specially Designated Nationals or the US Department of Commerce Denied Persons List or Entity List. By using this Software, you warrant that you are not located in any such country or on any such list. You also agree that you will not use this Software for any purposes prohibited by Japanese and US law, including, without limitation, the development, design and manufacture or production of missiles or nuclear, chemical or biological weapons of mass destruction.

5. Termination

Anritsu shall deem this EULA terminated if you violate any conditions described herein. This EULA shall also be terminated if the conditions herein cannot be continued for any good reason, such as violation of copyrights, patents, or other laws and ordinances.

6. Reparations

If Anritsu suffers any loss, financial or otherwise, due to your violation of the terms of this EULA, Anritsu shall have the right to seek proportional damages from you.

7. Responsibility after Termination

Upon termination of this EULA in accordance with item 5, you shall cease all use of this Software immediately and shall as directed by Anritsu either destroy or return this Software and any backup copies, full or partial, to Anritsu.

8. Dispute Resolution

If matters of dispute or items not covered by this EULA arise, they shall be resolved by negotiations in good faith between you and Anritsu.


9. Court of Jurisdiction

This EULA shall be interpreted in accordance with Japanese law and any disputes that cannot be resolved by negotiation described in Article 8 shall be settled by the Japanese courts.

About This Manual

■ Associated Documents

The operation manual configuration of the MS2690A/MS2691A/MS2692A, MS2830A, MS2840A and MS2850A Signal Analyzer is shown below.



- Signal Analyzer Operation Manual (Mainframe)
- Signal Analyzer Operation Manual (Mainframe Remote Control)
Description of basic operations, maintenance procedures, common functions and common remote functions of the mainframe
- Signal Analyzer Operation Manual (Signal Analyzer Function)
- Signal Analyzer Operation Manual (Signal Analyzer Function Remote Control)
Description of basic operations, common functions and common remote functions of the signal analyzer
- Signal Analyzer Operation Manual (Spectrum Analyzer Function)
- Signal Analyzer Operation Manual (Spectrum Analyzer Function Remote Control)
Description of basic operations, common functions and common remote functions of the spectrum analyzer
- Signal Analyzer Operation Manual (Phase Noise Measurement Function)
<This document>
- Signal Analyzer Operation Manual (Phase Noise Measurement Function Remote Control)
Description of basic operations, common functions and common remote functions of the Phase Noise Measurement function

Convention Used in This Manual

Throughout this document, the use of MS269x Series is assumed unless otherwise specified.

If using MS2830A, MS2840A or MS2850A change MS269xA to read MS2830A, MS2840A or MS2850A.

In this document,  indicates a panel key.

Table of Contents

About This Manual.....	I
Chapter 1 Overview	1-1
1.1 Overview of Phase Noise Measurement function.....	1-2
1.2 Specification.....	1-2
Chapter 2 Preparation	2-1
2.1 Part Names	2-2
2.2 Signal Path Setup	2-14
2.3 Application Startup and Selection.....	2-15
2.4 Initialization and Calibration.....	2-16
Chapter 3 Measurement.....	3-1
3.1 Basic Operation	3-2
3.2 Setting Frequency.....	3-5
3.3 Setting Level	3-7
3.4 Setting Common Items	3-11
3.5 Setting Markers.....	3-12
3.6 Measurement Results	3-15
3.7 Saving Measurement Results.....	3-17
Chapter 4 Other Functions	4-1
4.1 Selecting Other Functions	4-2
4.2 Setting Title	4-2
4.3 Erasing Warmup Message	4-2
Appendix A Error Message.....	A-1
Appendix B Default Value List.....	B-1
Index	Index-1

1
2
3
4
Appendix
Index

Chapter 1 Overview

This chapter describes an overview of the Phase Noise Measurement function.

1.1	Overview of Phase Noise Measurement function.....	1-2
1.2	Specification.....	1-2

1.1 Overview of Phase Noise Measurement function

The MS2690A/MS2691A/MS2692A, MS2830A, MS2840A or MS2850A Signal Analyzer enables high-speed, high-accuracy, and simple measurements of transmission characteristics of base stations and mobile stations for various types of mobile communications.

The phase noise measurement function is provided for measuring phase noise, which is an important factor for evaluating the short-term stability of signals. With this application, the MS2690A/MS2691A/MS2692A, MS2830A, MS2840A or MS2850A can be used in various applications, including design verification, troubleshooting, and testing on production lines.

This function has following features:

- High speed, high accuracy phase noise measurement

1.2 Specification

Table 1.2-1 shows the specifications for Phase Noise Measurement Function Option.

Table 1.2-1 Phase Noise Measurement Function Option Specifications

Item	Specification
Function	Displays the phase noise characteristics on a logarithmic scale.
Frequency	
Range	10 MHz to Upper frequency limit
Offset frequency range	10 Hz to 10 MHz
Marker Mode	Normal, Integral Noise, RMS Noise, Jitter, Residual FM, Off

Chapter 2 Preparation

This chapter describes the preparations required for using the application you are using. Refer to the *MS2690A/MS2691A/MS2692A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2830A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2840A Signal Analyzer Operation Manual (Mainframe Operation)*, or *MS2850A Signal Analyzer Operation Manual (Mainframe Operation)* for common features not included in this manual.

2

Preparation

2.1	Part Names	2-2
2.1.1	Front panel	2-2
2.1.2	Rear panel	2-9
2.2	Signal Path Setup	2-14
2.3	Application Startup and Selection.....	2-15
2.3.1	Launching application.....	2-15
2.3.2	Selecting application.....	2-15
2.4	Initialization and Calibration.....	2-16
2.4.1	Initialization.....	2-16
2.4.2	Calibration	2-16

2.1 Part Names

This section describes the panel keys for operating the instrument and connectors used to connect external devices. For general points of caution, refer to the *MS2690A/MS2691A/MS2692A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2830A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2840A Signal Analyzer Operation Manual (Mainframe Operation)*, or *MS2850A Signal Analyzer Operation Manual (Mainframe Operation)*.

2.1.1 Front panel

This section describes the front-panel keys and connectors.




Figure 2.1.1-1 MS269x series front panel












Figure 2.1.1-2 MS2830A/MS2840A/MS2850A front panel (MS2830A Example)

- | | | |
|---|---|--|
| 1 |  | <p>Power Switch</p> <p>Press to switch between the standby state (AC power supplied) and power-on state. The Power lamp  lights orange at Standby and green at Power On. Press the power switch for about 2 seconds.</p> |
| 2 | <p>HDD</p>  <p>SSD</p>  | <p>Hard disk access lamp (MS269x series, MS2830A)</p> <p>Lights up when accessing the internal hard disk.</p> <p>SSD access lamp (MS2840A, MS2850A)</p> <p>Lights up when accessing the internal SSD.</p> |
| 3 |  | <p>Copy key</p> <p>Press to capture display screen and save to file.</p> |
| 4 |  | <p>Recall key</p> <p>Press to recall parameter file.</p> |
| 5 |  | <p>Save key</p> <p>Press to save parameter file.</p> |
| 6 | <p>Cal</p>  | <p>Cal key</p> <p>Press to display the Calibration menu.</p> |

7



Local key

Press to return to local operation from remote control via GPIB, Ethernet, or USB (B), and enable panel settings.

8



Remote lamp

Lights when in remote-control state.

9



Preset key


Resets parameters to initial settings.



10



Function keys

Selects or configures function menu displayed on the right of the screen. The function menu is provided in multiple pages and layers.

Press  to fetch next function menu page. The current page number is displayed at the bottom of the function menu, as in "1 of 2".

Sub-menus may be displayed when a function menu is pressed. Press  to go back to the previous menu. Press  to go back to the top menu.

11




Main function keys 1


Press to set or execute main functions.


Executable functions vary with the current application. When nothing happens with the press, it indicates that the application in use does not support the key.


 Press to set frequency parameters.

 Press to set level parameters.

 No function is assigned to this key.

 Press to set trigger parameters.

 No function is assigned to this key.

 Press to set measurement item parameters.

12





Main function keys 2


Press to set or execute main functions.


Executable functions vary with the current application. When nothing happens with the press, it indicates that the application in use does not support the key.

 Press to switch application.


 Press to display Configuration screen.

 Press to set the trace items or to switch the operation window.

 Press to set measurement item parameters.


 Use when switching graph marker operation.

 Press to set parameters related to the peak search function.

 Press to start single measurement.


 Press to start continuous measurements.

13



Rotary knob/Cursor key/Enter key/Cancel key

The rotary knob and cursor keys select display items or change settings.

Press  to set the entered or selected data.

Press  to cancel input or selected data.


14



Shift key


Operates keys with functions in blue characters on panel. Press the Shift key so the key lamp is green and then press the target key.




15



Numeric keypad

Enters numbers on parameter setup screens.

Press  to delete the last entered digit or character.

[A] to [F] can be entered by pressing keys  to  while the Shift key lamp  is green.

16 RF Input



RF Input connector


Inputs RF signal. This is an N type input connector.

This is a K type input connector when MS2830A-045, MS2840A-046 is installed or MS2850A.

17 SG On/Off



RF Output Control key (when MS269xA-020/120, MS2830A-020/120/021/121, MS2840A-020/120/021/121 is installed)

Press  to switch on/off the modulation of RF signal when the Vector Signal Generator option is installed. The RF output control key lamp lights orange when the RF signal output is set to On.

This cannot be installed on any of these models: the MS2830A with MS2830A-044/045, the MS2840A with MS2840A-044/046, or the MS2850A.

18 SG Output(Opt)



RF Output connector (when MS269xA-020/120, MS2830A-020/120/021/121, MS2840A-020/120/021/121 is installed)

Outputs RF signal, when the Vector Signal Generator option is installed. This is an N type output connector.

This cannot be installed on any of these models: the MS2830A with MS2830A-044/045, the MS2840A with MS2840A-044/046, or the MS2850A.

19



USB connector (type A)


Connect the accessory USB keyboard, mouse or USB memory.

20

Mod
On/Off



Modulation control key (when MS2830A-020/120/021/121, MS2840A-020/120/021/121 is installed)

Press to switch on/off the modulation of RF signal when the Vector Signal Generator option is installed. The lamp  on the key lights up in green in the modulation On state.

This cannot be installed on any of these models: the MS2830A with MS2830A-044/045, the MS2840A with MS2840A-044/046, or the MS2850A.

21



Application key (MS2830A, MS2840A, MS2850A)

Press to switch between applications.



Press to display the Spectrum Analyzer main screen.



Press to display the Signal Analyzer main screen, when MS2830A-005/105/007/006/106/009/109/077/078 or MS2840A-005/105/006/106/009/109/077/177/078/178 is installed or MS2850A.



Press to display the Signal Generator main screen, when Vector Signal Generator option is installed. (MS2830A, MS2840A)



This is a blank key. Not used. (MS2830A, MS2840A)



Displays the main screen of the application that is selected using the Application Switch (Auto), or displays that of the pre-selected application (Manual).

For details, refer to 3.5.4 “Changing application layout” in *MS2830A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2840A Signal Analyzer Operation Manual (Mainframe Operation)*, or *MS2850A Signal Analyzer Operation Manual (Mainframe Operation)*.

22



1st Local Output connector (MS2830A, MS2840A, MS2850A)

This is available when MS2830A-044/045, MS2840A-044/046 is installed, or MS2850A.

Supplies local signal and bias current to the external mixer, and receives the IF signal with its frequency converted.

2.1.2 Rear panel

This section describes the rear-panel connectors.




Figure 2.1.2-1 MS269x series rear panel




Figure 2.1.2-2 MS2830A/MS2840A/MS2850A rear panel (MS2850A Example)

1 Ref Input



Ref Input connector (reference frequency signal input connector)

Inputs external reference frequency signal. It is for inputting reference frequency signals with higher accuracy than the instrument's internal reference signal, or for synchronizing the frequency of the MS2690A/MS2691A/MS2692A, MS2830A, MS2840A, or MS2850A to that of other equipment. The following frequencies are supported:

MS269x series: 10 MHz/13 MHz

MS2830A, MS2840A, MS2850A: 5 MHz/10 MHz/13 MHz

2 Buffer Out



Buffer Out connector (reference frequency signal output connector)

Outputs the internal reference frequency signal (10 MHz). It is for synchronizing frequencies between other equipment and the MS2690A/MS2691A/MS2692A, MS2830A, MS2840A, or MS2850A.

3 Trigger Input



Trigger Input connector (MS269x series only)

Inputs trigger signal from external device.

4 Sweep Status Out



Sweep Status Out connector

Outputs signal when internal measurement is performed or measurement data is obtained.

**5 IF Out
875/900MHz**



IF Out connector (MS269x series only)

Not used.


6



AUX connector

Not used.

7



GP-IB connector



For external control via GP-IB.








8 USB(Remote)



USB connector (type B)

For external control via USB.

- | | | | | | | |
|-------------------------------|--|--|-------------------------------|-------------------------------------|-----------------------------|-------------------------------------|
| 9 |  <p>LAN</p> | <p>Ethernet connector</p> <p>Connects PC or Ethernet network.</p> | | | | |
| 10 |  <p>USB</p> | <p>USB connector (type A)</p> <p>Used to connect a USB keyboard or mouse or the USB memory supplied.</p> | | | | |
| 11 |  <p>Monitor Out</p> | <p>Monitor Out connector</p> <p>Connects external display.</p> | | | | |
| 12 |  <p>~ Line Input</p> | <p>AC inlet</p> <p>Supplies power.</p> | | | | |
| 13 |  <p>SA
Trigger
Input
TTL</p> | <p>SA Trigger Input connector (MS2830A, MS2840A, MS2850A)</p> <p>This is a BNC connector for inputting external trigger signal (TTL) for SPA and SA applications.</p> | | | | |
| 14 |  <p>SG
Trigger
Input(Opt)
TTL</p> | <p>SG Trigger Input connector (MS2830A, MS2840A)</p> <p>This is a BNC connector for inputting external trigger signal (TTL) for Vector Signal Generator option.</p> | | | | |
| 15 | <p>HDD or
Primary HDD/SSD</p> | <table border="0"> <tr> <td style="padding-right: 20px;">HDD slot (MS2830A)</td> <td>This is a standard HDD</td> </tr> <tr> <td>SSD slot (MS2840A, MS2850A)</td> <td>This is a standard SSD slot.</td> </tr> </table> | HDD slot (MS2830A) | This is a standard HDD | SSD slot (MS2840A, MS2850A) | This is a standard SSD slot. |
| HDD slot (MS2830A) | This is a standard HDD | | | | | |
| SSD slot (MS2840A, MS2850A) | This is a standard SSD slot. | | | | | |
| 16 | <p>HDD(Opt) or
Secondary HDD/SSD</p> | <table border="0"> <tr> <td style="padding-right: 20px;">HDD slot for Option (MS2830A)</td> <td>This is a HDD slot for the options.</td> </tr> <tr> <td>SSD slot (MS2840A, MS2850A)</td> <td>This is a SSD slot for the options.</td> </tr> </table> | HDD slot for Option (MS2830A) | This is a HDD slot for the options. | SSD slot (MS2840A, MS2850A) | This is a SSD slot for the options. |
| HDD slot for Option (MS2830A) | This is a HDD slot for the options. | | | | | |
| SSD slot (MS2840A, MS2850A) | This is a SSD slot for the options. | | | | | |

- 17**  IF Output connector (MS2830A, MS2840A, MS2850A)
Monitor output of the internal IF signal.
This is installed when MS2830A-044/045, MS2840A-044/046 is installed or MS2850A.
- 18**  Noise Source connector
Supply (+28 V) of the Noise Source Drive.
This is available when the Option 017/117 is installed.
- 19**  CAL Port connector (Future extensions) (MS2850A)
- 20**  Input 2
Trigger Input 2 connector (MS2850A)
Input the trigger signal (3.3 V LVCMOS) for SPA and SA applications.
- 21**  Output 1
Trigger Output 1 connector (MS2850A)
Output the trigger signal (3.3 V LVCMOS).
- 22**  Output 2
Trigger Output 2 connector (MS2850A)
Output the trigger signal (3.3 V LVCMOS).
- 23**  USB 3.0 connector (MS2850A)
This is available when the MS2850A-054/154 is installed.

24



PCIe X8 connector (MS2850A)

This is available when the MS2850A-053/153 is installed.

2

Preparation

2.2 Signal Path Setup

As shown in Figure 2.2-1, connect the instrument and the DUT using an RF cable, so that the signal to be tested is input to the RF Input connector. To prevent an excessive level signal from being input, do not input the signal before setting the input level using this application.




Figure 2.2-1 Signal path setup example

Set the reference signal and/or trigger signal paths from external sources, as required.




Figure 2.2-2 External signal input

2.3 Application Startup and Selection

To use this application, it is necessary to load (start up) and select the application.





2.3.1 Launching application

The application startup procedure is described below.

Note:

The XXX indicates the application name currently in use.


<Procedure>

1. Press  to display the Configuration screen.
2. Press  (Application Switch Settings) to display the Application Switch Registration screen.
3. Press  (Load Application Select), and move the cursor to “XXX” in the **Unloaded Applications** list.
If “XXX” is displayed in the **Loaded Applications** list, this means that the application is already loaded.
If “XXX” appears in neither the **Loaded Applications** nor **Unloaded Applications** list, this means that the application has not been installed.
4. Press  (Set) to load the application. If “XXX” is displayed in the **Loaded Applications** list, this means that the application is already loaded.

2.3.2 Selecting application

The selection procedure is described below.

<Procedure>

1. Press  to display the Application Switch menu.
2. Press the menu function key displaying “XXX”.

The application can also be selected with mouse, by clicking “XXX” on the task bar.

2.4 Initialization and Calibration

This section describes the parameter settings and the preparations required before starting measurement.

2.4.1 Initialization



After selecting this application, first perform initialization. Initialization returns the settable parameters to their default value in order to clear the measurement status and measurement results.

Note:

When another software application is switched to or this application is unloaded (ended), the application keeps the parameter settings at that time. The parameter values that were last set will be applied when this application is selected next time.

The initialization procedure is as follows.

<Procedure>

1. Press  to display the Preset function menu.
2. Press  (Preset).

2.4.2 Calibration

Perform calibration before performing measurement. Calibration sets the level accuracy frequency characteristics for the input level to flat, and adjusts level accuracy deviation caused by internal temperature fluctuations. Calibration should be performed when first performing measurement after turning on power, or if beginning measurement when there is a difference in ambient temperature from the last time calibration was performed.

<Procedure>

1. Press  to display the Application Cal function menu.
2. Press  (SIGANA All).

For details on calibration functionality only executable with this instrument, refer to the *MS2690A/MS2691A/MS2692A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2830A Signal Analyzer Operation Manual (Mainframe Operation)*, *MS2840A Signal Analyzer Operation Manual (Mainframe Operation)*, or *MS2850A Signal Analyzer Operation Manual (Mainframe Operation)*.

Chapter 3 Measurement

This chapter describes the measurement function, the parameter contents and the setting methods for the MS2690A/MS2691A/MS2692A, MS2830A, MS2840A, or MS2850A.

3.1	Basic Operation	3-2
3.1.1	Screen layout.....	3-2
3.1.2	Function menu.....	3-3
3.1.3	Performing Measurement.....	3-4
3.2	Setting Frequency.....	3-5
3.3	Setting Level	3-7
3.3.1	Setting Reference Level	3-8
3.3.2	Setting Input Attenuator.....	3-8
3.3.3	Pre-Amp	3-9
3.3.4	Setting scale	3-9
3.3.5	Setting Reference Level Offset	3-10
3.4	Setting Common Items	3-11
3.5	Setting Markers.....	3-12
3.5.1	Setting Active Marker	3-13
3.5.2	Setting marker mode	3-13
3.6	Measurement Results	3-15
3.6.1	Graphical Results	3-16
3.6.2	Numerical Results	3-16
3.6.3	Marker List.....	3-16
3.7	Saving Measurement Results.....	3-17

3.1 Basic Operation

3.1.1 Screen layout

This section describes the screen layout of the phase noise measurement function.




Figure 3.1.1-1 Screen Layout

1. Measurement parameter window
Displays the currently set measurement parameters.
2. Graph window
Displays the results in a log plot graph.
3. Numeric result window
Displays the numeric results.
4. Marker list window
Displays the numeric results at each marker.
5. Function menu
Displays the functions executable with function keys.

3.1.2 Function menu

This section describes the main function menu on the main screen.




Figure 3.1.2-1 Main function menu

Table 3.1.2-1 Main function menu

Menu Display	Function
Frequency	Sets frequency 3.2 "Setting Frequency"
Amplitude	Sets level. 3.3 "Setting Level"
Common Setting	Sets common items. 3.4 "Setting Common Items"
Marker	Sets a marker. 3.5 "Setting Markers"
Accessory	Sets other functions. 4.1 "Selecting Other Functions"

3.1.3 Performing Measurement

There are two measurement modes: single and continuous. Measurement is performed once in the single measurement mode, and continuously in the continuous measurement mode.

Single

The selected measurement items are measured only once before measurement is stopped.

<Procedure>

Press .


Continuous

The selected measurement items are measured continuously. Measurement will continue even if parameters are changed or the window display is changed. Measurement stops if other applications are selected.

<Procedure>

Press .

3.2 Setting Frequency

Configures settings related to frequency. Pressing  (Frequency) on the main function menu displays the Frequency function menu and opens the Carrier Frequency dialog box.

Carrier Frequency

- Summary
Sets a carrier frequency.
- Setting range
10 MHz to the upper limit, depending on the main unit

Start Offset

- Summary
Sets an offset lower limit.
- Setting range
10 Hz to 1 kHz

Stop Offset

- Summary
Sets an offset upper limit.
- Setting range
100 kHz to 10 MHz

External Mixer On/Off

- Summary
Sets High Performance Waveguide Mixer to On.
- Options
On Enables the External Mixer function.
Off Disables the External Mixer function.
- Remarks
External Mixer function is MS2830A-044/045, MS2840A-044/046, MS2850A dedicated function. MA2806A and MA2808A are products designed for exclusive use with MS2830A or MS2840A or MS2850A.

Table 3.2-1 High Performance Waveguide Mixer

Model	Name	Frequency Range	Waveguide Flange
MA2806A	High Performance Waveguide Mixer (50 to 75 GHz)	50 to 75 GHz	UG385/U
MA2808A	High Performance Waveguide Mixer (60 to 90 GHz)	60 to 90 GHz	UG387/U

To set the parameters of High Performance Waveguide Mixer, use the Spectrum Analyzer function of the mainframe.

For details, refer to Chapter 8 “External Mixer” in the *MS2830A/MS2840A/MS2850A Signal Analyzer Operation Manual (Spectrum Analyzer Function Operation)*.

External Mixer Select

- Summary

Selects the band for High Performance Waveguide Mixer.

- Options

Band V+ High Performance	50 to 75 GHz
Band E– High Performance	60 to 90 GHz

3.3 Setting Level

Configures settings related to level. Pressing **F2** (Amplitude) on the main function menu, or pressing **Amplitude** displays the Amplitude function menu.




Figure 3.3-1 Amplitude function menu

Table 3.3-1 Amplitude function menu

Menu Display	Function
Reference Level	Sets reference level. 3.3.1 "Setting Reference Level"
Attenuator (Auto/Manual)	Selects whether to set input attenuator automatically or manually. 3.3.2 "Setting Input Attenuator"
Attenuator	The input attenuator can be set. 3.3.2 "Setting Input Attenuator"
Pre-Amp (On/Off)	Sets Pre-Amp function On/Off. 3.3.3 "Pre-Amp"
Scale	Sets scale. 3.3.4 "Setting scale"
Offset (On/Off)	Sets reference level offset function On/Off. 3.3.5 "Setting Reference Level Offset"
Offset Value	Sets reference level offset value. 3.3.5 "Setting Reference Level Offset"

3.3.1 Setting Reference Level

Reference Level

■ Summary

Sets the input level from the target DUT.

■ Setting range

For Pre-Amp: On :

(-120.00 + Offset Value) to (30.00 + Offset Value) dBm

For Pre-Amp: Off:

(-120.00 + Offset Value) to (50.00 + Offset Value) dBm

3.3.2 Setting Input Attenuator

1 Auto

Sets the input attenuator automatically according to the reference level setting. When a signal having the same level as the reference level is input, the input attenuator is automatically set so that the input level to the internal mixer is -10 dBm or less.

2 Manual setting

When measuring a minute-level signal, select Manual and set the input attenuator manually.

The setting range of the input attenuator in Manual setting is as follows.

Setting range and resolution for input attenuator

Input attenuator setting range: Refer to Table 3.3.2-1 or Table 3.3.2-2.

Input attenuator minimum resolution: 2 dB

Table 3.3.2-1 Input attenuator setting range (When Pre-Amp is set to Off)

Attenuator Manual	
Lower Limit	Upper Limit
Logic* ($\alpha a = 0$, $\beta = 1$, $\gamma = 2$) The minimum value is 0 dB.	60 dB

Table 3.3.2-2 Setting range for input attenuator
(When Pre-Amp is set to On)

Attenuator Manual	
Lower Limit	Upper Limit
Logic* ($\alpha = 20, \beta = 21, \gamma = 22$) The minimum value is 0 dB.	60 dB

∗: Can be obtained as follows, according to the setting condition.

- [1] When the reference level can be divided by 2:
Attenuator (dB) = $RL^{\ast 1+\alpha}$
- [2] Other than [1] above, and when INT (RL)^{∗2} is an odd number:
Attenuator (dB) = INT (RL)^{∗2} + β
- [3] Other than [1] above, and when INT (RL)^{∗2} is an even number:
Attenuator (dB) = INT (RL)^{∗2}+ γ
- ∗1: Reference level (dBm)
∗2: Integer part of reference level

3.3.3 Pre-Amp

- Pre-Amp
- Summary
Turns the Pre-Amp function On/Off. This is available when MS2830A-008/108/068/168, MS2840A-008/108/068/168/069/169, or MS2850A-068/168 is installed.
 - Selection options
On Enables the Pre-Amp function.
Off Disables the Pre-Amp function.

3.3.4 Setting scale

- Log Scale Line (10/16)
- Summary
Sets the number of log scale lines.
 - Selection options
10 10 scale lines (−150 dBc/Hz to Reference Value)
16 16 scale lines (−180 dBc/Hz to Reference Value)
- Reference Value
- Summary
Sets the upper limit value of vertical graph axis.
 - Selection options
Log Scale Line: 10
−140 to −50 dBc/Hz
Log Scale Line: 16
−170 to −20 dBc/Hz

3.3.5 Setting Reference Level Offset

Offset

- Summary

Turns the Offset function On/Off.

- Selection options

On Enables the offset function.

Off Disables the offset function.

Offset Value

- Summary

Sets the level offset coefficient.

- Setting range

–99.99 to + 99.99 dB

- Setting example





Figure 3.3.5-1 Reference Level and Offset Value setting example

3.4 Setting Common Items

This section describes the settings for the common items. Pressing  (Common Setting) on the main function menu displays the Common Setting function menu.

Average

■ Summary

Sets the averaging count (the number of times to repeat measurements internally per one measurement result).

■ Setting range

1 to 999

Phase Noise Optimization

■ Summary

Selects the optimization mode of the phase noise measurement. Only MS2840A, MS2850A is displayed.

■ Options

Auto	Performs measurement by automatically switching the best loop filters for the phase noise measurement near and far from the carrier respectively.
Best Close-in	Performs measurement by using the best close-in loop filter for the phase noise measurement near the carrier.
Best Wide-offset	Performs measurement by using the best wide-offset loop filter for the phase noise measurement far from the carrier.
Balance	Performs measurement by using a balanced loop filter for the phase noise measurement both near and far from the carrier.

3.5 Setting Markers

Configures settings related to marker. Pressing **F5** (Marker) on the main function menu or **Marker** displays the Marker function menu.




Figure 3.5-1 Marker function menu

Table 3.5-1 Marker function menu

Menu Display	Function
Active Marker	Sets the active marker. 👉 3.5.1 “Setting marker mode”
Marker Mode	Sets the marker mode. 👉 3.5.2 “Setting marker mode”
Analysis Width	Sets the marker range (integral bandwidth). 👉 3.5.2 “Setting marker mode”
Marker Frequency Offset	Sets the marker offset frequency 👉 3.5.2 “Setting marker mode”

3.5.1 Setting Active Marker

Active Marker

- Summary
Selects the active marker.
- Setting range
Marker1 to Marker8

3.5.2 Setting marker mode

Marker Mode

- Summary
Selects the marker function.
- Options

Normal:	Normal marker. Displays the phase noise level with the specified frequency offset.
Integral Noise:	Calculates the Integral Noise with the specified integral bandwidth.
RMS Noise:	Calculates the RMS Noise with the specified integral bandwidth.
Jitter:	Calculates the Jitter with the specified integral bandwidth.
Residual FM:	Calculates the residual FM with the specified integral bandwidth.
Off:	Turns Off the active marker.

Marker Frequency Offset

- Summary
Sets the offset frequency of the marker.
- Resolution

1 Hz (For offset frequency of 10 to 100 Hz)
10 Hz (For offset frequency of 100 Hz to 1 kHz)
100 Hz (For offset frequency of 1 to 10 kHz)
1 kHz (For offset frequency of 10 to 100 kHz)
10 kHz (For offset frequency of 100 kHz to 1 MHz)
100 kHz (For offset frequency of 1 MHz to 10 MHz)
- Remarks
Enabled for the marker mode of Normal or OFF.

Analysis Width

- Summary

Displays the integral bandwidth (Start to Stop).

Start and Stop set Analysis Width,

- Setting range

1 to 99999990 Hz

- Remarks

Enabled for the marker mode of Integral Noise, RMS Noise, Jitter, or Residual FM.

Start, Stop

- Summary

Sets Start or Stop frequency of Analysis Width.

- Setting range

Start Offset to Stop Offset

however, Start < Stop

 3.2 "Setting Frequency"

- Resolution

Same as Marker Frequency Offset.

3.6 Measurement Results

Displays the measurement results of tested signals.




Figure 3.6-1 Marker function menu (Marker mode: Normal and OFF)




Figure 3.6-2 Marker function menu (Marker mode: Integral Noise, RMS Noise, Jitter, and Residual FM)

3.6.1 Graphical Results

Displays the result of single-sideband phase noise measurement in a log frequency graph.

3.6.2 Numerical Results

Displays the numeric results.

Carrier Power

■ Summary

Displays the carrier power.

Frequency Error

■ Summary

Displays the difference between the set carrier frequency and the measured carrier frequency.

3.6.3 Marker List

For the marker mode: Normal and OFF

Lists the measurement results at each marker. The list contains the marker number, marker offset frequency, and marker phase noise level.

Table 3.6.3-1 Displayed items for marker list

Item	Description
MKR	Displays the marker number.
Frequency	Displays the marker offset frequency.
Level	Displays the marker phase noise level.

For the marker mode: Integral Noise, RMS Noise, Jitter, and Residual FM

Lists the measurement results at each marker. The list contains the marker number, offset frequency of the center of marker range, phase noise level, marker mode, integral bandwidth, and calculation result.

Table 3.6.3-2 Displayed items for marker list

Item	Description
MKR	Displays the marker number.
Frequency	Displays the offset frequency of the center of marker range.
Level	Displays the phase noise level of the offset frequency.
Mode	Displays the marker mode.
Analysis Width	Displays the integral bandwidth.
Value	Displays the calculation result of the set marker mode.

3.7 Saving Measurement Results

This section describes how to save the measurement results to internal hard disk/SSD or USB memory stick.

<Procedure>

1. Press **Save** in the Phase Noise screen to display the Save menu shown in Figure 3.7-1.
2. Press **F1** (Device) to change the save destination.
3. When the Setting window is displayed, select the target drive and then press **F7** (Set) to set.
4. With the save destination set, press **F8** (Save Waveform CSV DATA).




Figure 3.7-1 Save menu

The sequential numbers suffixed to a file name are 0 to 999. No more files can be saved if the sequential numbers up to 999 are all used.

The saved files are stored in a folder according to the application. The application folders are located under the following directory in the saving target drive specified by **F1** (Device).

\Anritsu Corporation\Signal Analyzer\User Data\Trace Data\Phase Noise

Up to 1000 files can be saved in one folder.

Chapter 4 Other Functions

This chapter describes other functions of this application.

4.1	Selecting Other Functions	4-2
4.2	Setting Title	4-2
4.3	Erasing Warmup Message	4-2

4.1 Selecting Other Functions


Pressing  (Accessory) on the main function menu displays the Accessory function menu.






Table 4.1-1 Accessory function menu

Function Keys	Menu Display	Function
F1	Title	Sets the title character string.
F2	Title (On/Off)	Displays (On) or hides (Off) the title character string.
F4	Erase Warm Up Message	Erases the warmup message display.


4.2 Setting Title

A title of up to 32 characters can be displayed on the screen. (Character strings of up to 17 characters can be displayed on a function menu. The maximum number of characters to be displayed on the top of the function menu varies according to character string.)



<Procedure>

1. Press  (Accessory) on the main function menu.
2. Press  (Title) to display the character string input screen. Select a character using the rotary knob, and enter it by pressing .
Enter the title by repeating this operation. When the title is entered, press  (Set).
3. Press  (Title) and then select “Off” to hide the title.

4.3 Erasing Warmup Message

The warmup message () , which is displayed upon power-on and indicates that the level and frequency are not stable, can be deleted.

<Procedure>

1. Press  (Accessory) on the main function menu.
2. Press  (Erase Warm Up Message) to erase the warmup message.

Appendix A Error Message

Table A-1 Message Processing and Status

Message	Description
Out of range	The settable range is exceeded.
No file to read	There is no file that can be read.
File read error	File reading has failed.
File format error	The file format is invalid.
Empty Title Name	The title name is empty.
Empty File Name	The file name is empty.
Invalid character	–
Invalid operation because model names do not match.	–

Appendix B Default Value List

Common Parameter

Frequency		
Carrier Frequency		2.000 GHz
Start Offset		10 Hz
Stop Offset		10 MHz
External Mixer		Off
Band Select		VHP
Amplitude		
Reference Level		0.00 dBm
ATT		10 dB
Level Offset On/Off		Off
Level Offset Value		0.00 dB
Pre-Amp		Off
Amplitude-Scale		
Log Scale Line		10
Reference Value		-50 dBc/Hz

Phase Noise Basic Parameter

Common Setting		
Average Count		1
Phase Noise Optimization (MS2840A, MS2850A)		Auto

Marker

Active Marker		1
Marker1	Marker Mode	Normal
	Marker Frequency Offset	10 Hz
Marker2	Marker Mode	Normal
	Marker Frequency Offset	100 Hz
Marker3	Marker Mode	Normal
	Marker Frequency Offset	1 kHz
Marker4	Marker Mode	Normal
	Marker Frequency Offset	10 kHz
Marker5	Marker Mode	Normal
	Marker Frequency Offset	100 kHz
Marker6	Marker Mode	Normal
	Marker Frequency Offset	1 MHz
Marker7	Marker Mode	Normal
	Marker Frequency Offset	10 MHz
Marker8	Marker Mode	Off
	Marker Frequency Offset	10 MHz
Analysis Width		99 kHz
Start		1 kHz
Stop		100 kHz

Appendix B Default Value List

Accessory	Accessory	On
	Title	Phase Noise
	Title Entry	

References are to section numbers.

A

Accessory	3.1.2, 5.1
AC inlet	2.1.2
Amplitude	3.3
Application key	2.1.1
Application Switch	2.3.2
AUX connector	2.1.2
Average	3.4

B

Buffer Out connector	2.1.2
----------------------	-------

C

Calibration	2.4.2
Cal key	2.1.1
Cancel key	2.1.1
Carrier Frequency	3.2
Carrier Level	3.6.2
Common Setting	3.4
Continuous	3.1.3
Copy key	2.1.1
Cursor key	2.1.1

E

Enter key	2.1.1
Erase Warm Up Message	4.3
Ethernet	2.1.1
Ethernet connector	2.1.2

F

Frequency	2.1, 3.1, 3.1.2, 3.2
Frequency Error	3.6.2
Function keys	2.1.1

G

GPIB	2.1.1
GPIB connector	2.1.2
Graph window	3.1.1, 3.6.1

H

Hard disk access lamp	2.1.1
HDD slot	2.1.2

I

IF Out connector	2.1.2
------------------	-------

L

Level	2.1.1, 2.4, 3.3
Load Application Select	2.3.1
Local key	2.1.1

M

Main function keys	2.1.1
Marker	2.1, 3.1, 3.5, 3.6
Mixer	3.2
Modulation control key	2.1.1
Monitor Out connector	2.1.2

N

Numeric keypad	2.1.1
----------------	-------

O

Offset	3.3
Offset Value	3.3

P

Preamplifier	3.3.3
Power switch	2.1.1
Preset	2.4.1
Preset key	2.1.1

R

Recall key	2.1.1
Ref Input connector	2.1.2
Reference frequency signal	2.1.2
Remote lamp	2.1.1
Result window	3.1.1
RF Output control key	2.1.1
RF output connector	2.1.1
RF input connector	2.1.1
Rotary knob	2.1.1

S

SA Trigger Input connector	2.1.2
Save key	2.1.1
SG Trigger Input connector	2.1.2
Shift key	2.1.1
Single	3.1.3
Sweep Status Out connector	2.1.2

T

Title	4.2
Trigger Input connector	2.1.2

U

USB	2.1.1, 2.1.2
USB connector (type A)	2.1.1, 2.1.2
USB connector (type B)	2.1.2

W

Warmup message	4.3
----------------	-----