

# MP2100A

---

BERTWave

Procedure for Calculating Extinction Ratio Correction Factor

## Contents

1. Introduction.....	3
2. Measurement System .....	3
3. Procedure.....	4
3.1 Calibration.....	4
3.2 Measuring Extinction Ratio.....	5
4. Correcting Extinction Ratio.....	6
4.1 Comparing and Calculating Extinction Ratio.....	6
4.2 Extinction Ratio Correction Factor Procedure for BERTWave.....	7

## 1. Introduction

This document explains how to measure the extinction ratio using sampling oscilloscopes; it is necessary because the measured value must be synchronized with the measuring instrument acting as the reference. The measurement method, Correction Factor calculation and input procedure are described using the MP2100A BERTWave as an example.

## 2. Measurement System

The explanation of the measurement procedure assumes that the following measurement system is being used.




Fig. 1

### 3. Procedure

#### 3.1 Calibration

Allow the instruments to warm-up sufficiently (>1 hour) before measurement.

After warming-up, press the [O/E] button at the right side of the screen to set the measured Bit Rate filter and wavelength (Fig. 2).




Fig. 2

Move to the Eye/Pulse Scope screen and set Ch A to Off; press the [Setup] button and run Calibration from the Utilities tab (Fig. 3). At Calibration, disconnect all cables and fit the cap on the optical input (Ch B input) to ensure there is no optical input.




Fig. 3

### 3.2 Measuring Extinction Ratio

Press the Eye/Pulse Scope [Setup] button and set Number of Samples, Accumulation Type, and Limit Types at the General tab. In this example, measurement is performed by setting the Total Sample count to 1.35 Msa. To capture 1.35 Msa as the Total Sample, set Number of Samples to 1021 and the number of Waveforms to 1323 (Fig. 4).




Fig. 4

Press the [Measure] button to set Measure Item to Amplitude/Time and display the extinction ratio measurement results (Fig. 5).




Fig. 5

## 4. Correcting Extinction Ratio

### 4.1 Comparing and Calculating Extinction Ratio

To calculate the extinction ratio Correction Factor, prepare the target DUT and measure the extinction ratio under the exact same conditions such as temperature, Bit Rate, DUT, optical fiber, etc., for both the reference instrument and the instrument to be corrected. The Correction Factor is calculated from the following equation based on the measured extinction ratios.

$$ER[CF] = \left( \frac{1}{10^{\frac{ER[meas]}{10}}} - \frac{1}{10^{\frac{ER\{ref\}}{10}}} \right) * 100$$

ER[ref] = Reference instrument measured value (dB)

ER[meas] = Measured value (dB)

ER[CF] = ER Correction Factor (%)

The Correction Factor calculated from the above equation can be found easily using the appended spreadsheet (Excel file).

Input the measured extinction ratio values into the Excel spreadsheet Correction Factor Target Measured Value and Reference Measured Value columns to calculate the Correction Factor and the extinction ratio after correction. In addition, to ensure that the measured value always has the same measurement error as well as to minimize the measurement error, the mean Correction Factor is calculated from the average of five extinction ratio measurements and displayed automatically (Fig.6).




Fig. 6



#### 4.2 Extinction Ratio Correction Factor Procedure for BERTWave

Input the extinction ratio calculated from the extinction ratio spreadsheet to the BERTWave using the following procedure. In this example, an extinction ratio of 3.0% is input.

Press the [O/E] button at the right side of the screen, change the O/E Configuration [Extinction Ratio Correction] button to On and input the Extinction Ratio Correction Factor.

\*Corrected is displayed on the measurement screen, confirming that the extinction ratio value has been updated. Compare the updated extinction ratio with the extinction ratio of the reference instrument and confirm that they are about the same value (Fig. 7).




Fig. 7

● **United States**

**Anritsu Company**

1155 East Collins Blvd., Suite 100, Richardson,  
TX 75081, U.S.A.  
Toll Free: 1-800-267-4878  
Phone: +1-972-644-1777  
Fax: +1-972-671-1877

● **Canada**

**Anritsu Electronics Ltd.**

700 Silver Seven Road, Suite 120, Kanata,  
Ontario K2V 1C3, Canada  
Phone: +1-613-591-2003  
Fax: +1-613-591-1006

● **Brazil**

**Anritsu Eletrônica Ltda.**

Praça Amadeu Amaral, 27 - 1 Andar  
01327-010 - Bela Vista - São Paulo - SP - Brazil  
Phone: +55-11-3283-2511  
Fax: +55-11-3288-6940

● **Mexico**

**Anritsu Company, S.A. de C.V.**

Av. Ejército Nacional No. 579 Piso 9, Col. Granada  
11520 México, D.F., México  
Phone: +52-55-1101-2370  
Fax: +52-55-5254-3147

● **United Kingdom**

**Anritsu EMEA Ltd.**

200 Capability Green, Luton, Bedfordshire, LU1 3LU, U.K.  
Phone: +44-1582-433200  
Fax: +44-1582-731303

● **France**

**Anritsu S.A.**

12 avenue du Québec, Bâtiment Iris 1- Silic 612,  
91140 VILLEBON SUR YVETTE, France  
Phone: +33-1-60-92-15-50  
Fax: +33-1-64-46-10-65

● **Germany**

**Anritsu GmbH**

Nemetschek Haus, Konrad-Zuse-Platz 1  
81829 München, Germany  
Phone: +49-89-442308-0  
Fax: +49-89-442308-55

● **Italy**

**Anritsu S.r.l.**

Via Elio Vittorini 129, 00144 Roma, Italy  
Phone: +39-6-509-9711  
Fax: +39-6-502-2425

● **Sweden**

**Anritsu AB**

Kistagången 20B, 164 40 KISTA, Sweden  
Phone: +46-8-534-707-00  
Fax: +46-8-534-707-30

● **Finland**

**Anritsu AB**

Teknobulevardi 3-5, FI-01530 VANTAA, Finland  
Phone: +358-20-741-8100  
Fax: +358-20-741-8111

● **Denmark**

**Anritsu A/S**

Kay Fiskers Plads 9, 2300 Copenhagen S, Denmark  
Phone: +45-7211-2200  
Fax: +45-7211-2210

● **Russia**

**Anritsu EMEA Ltd.**

**Representation Office in Russia**

Tverskaya str. 16/2, bld. 1, 7th floor.

Russia, 125009, Moscow  
Phone: +7-495-363-1694  
Fax: +7-495-935-8962

● **United Arab Emirates**

**Anritsu EMEA Ltd.**

**Dubai Liaison Office**

P O Box 500413 - Dubai Internet City  
Al Thuraya Building, Tower 1, Suit 701, 7th Floor  
Dubai, United Arab Emirates  
Phone: +971-4-3670352  
Fax: +971-4-3688460

● **India**

**Anritsu India Private Limited**

2nd & 3rd Floor, #837/1, Binnamangla 1st Stage,  
Indiranagar, 100ft Road, Bangalore - 560038, India  
Phone: +91-80-4058-1300  
Fax: +91-80-4058-1301

● **Singapore**

**Anritsu Pte. Ltd.**

11 Chang Charn Road, #04-01, Shriro House  
Singapore 159640  
Phone: +65-6282-2400  
Fax: +65-6282-2533

● **P.R. China (Shanghai)**

**Anritsu (China) Co., Ltd.**

Room 2701-2705, Tower A,  
New Caohejing International Business Center  
No. 391 Gui Ping Road Shanghai, 200233, P.R. China  
Phone: +86-21-6237-0898  
Fax: +86-21-6237-0899

● **P.R. China (Hong Kong)**

**Anritsu Company Ltd.**

Unit 1006-7, 10/F., Greenfield Tower, Concordia Plaza,  
No. 1 Science Museum Road, Tsim Sha Tsui East,  
Kowloon, Hong Kong, P.R. China  
Phone: +852-2301-4980  
Fax: +852-2301-3545

● **Japan**

**Anritsu Corporation**

8-5, Tamura-cho, Atsugi-shi, Kanagawa, 243-0016 Japan  
Phone: +81-46-296-1221  
Fax: +81-46-296-1238

● **Korea**

**Anritsu Corporation, Ltd.**

5FL, 235 Pangyoyeok-ro, Bundang-gu, Seongnam-si,  
Gyeonggi-do, 463-400 Korea  
Phone: +82-31-696-7750  
Fax: +82-31-696-7751

● **Australia**

**Anritsu Pty. Ltd.**

Unit 21/270 Ferntree Gully Road, Notting Hill,  
Victoria 3168, Australia  
Phone: +61-3-9558-8177  
Fax: +61-3-9558-8255

● **Taiwan**

**Anritsu Company Inc.**

7F, No. 316, Sec. 1, NeiHu Rd., Taipei 114, Taiwan  
Phone: +886-2-8751-1816  
Fax: +886-2-8751-1817

Please Contact: