

User Guide

IQ Fiber Master™ MT2780A

Sensor and Analyzer for LTE RF over CPRI and PIM over CPRI

MT2780A-0752 (Option 752)

MT2780A-0754 (Option 754)

MT2780A-0755 (Option 755)



Anritsu

Unauthorized Use or Disclosure

Anritsu Company has prepared the product user documentation for use by Anritsu Company personnel and customers as a guide for the proper installation, operation, and maintenance of Anritsu Company equipment and software programs. The drawings, specifications, and information contained therein are the property of Anritsu Company, and any unauthorized use or disclosure of these drawings, specifications, and information is prohibited; they shall not be reproduced, copied, or used in whole or in part as the basis for manufacture or sale of the equipment or software programs without the prior written consent of Anritsu Company.

Export Management

The Anritsu products identified herein and their respective manuals may require an Export License or approval by the government of the product country of origin for re-export from your country. Before you export these products or any of their manuals, please contact Anritsu Company to confirm whether or not these items are export-controlled. When disposing of export-controlled items, the products and manuals must be broken or shredded to such a degree that they cannot be unlawfully used for military purposes.

Trademark Acknowledgments

The following trademark acknowledgments are listed for one or more of the products mentioned in this publication:

- Windows, Microsoft Paint, Microsoft Word, Microsoft Access, Microsoft Excel, Microsoft PowerPoint, and Visual Studio are registered trademarks of Microsoft Corporation.
- USB Type-C is a registered trademark of the USB Implementers Forum, Inc.
- Intel i7 and i3 are registered trademarks of Intel Corporation
- IQ Fiber Master is trademark of Anritsu company
- All other trademarks mentioned are the property of their respective companies.

Warranty

The Anritsu sensor described in this guide is warranted against defects in materials and workmanship for three (3) years from the date of shipment. The accessories are warranted against defects in materials and workmanship for one (1) year from the date of shipment. Anritsu's obligation covers repairing or replacing products which prove to be defective during the warranty period. Buyers shall prepay transportation charges for equipment returned to Anritsu for warranty repairs. Obligation is limited to the original purchaser. Anritsu is not liable for consequential damages.

Limitation of Warranty

The foregoing warranty does not apply to Anritsu connectors that have failed due to normal wear. Also, the warranty does not apply to defects resulting from improper or inadequate maintenance, unauthorized modification or misuse, or operation outside of the environmental specifications of the product. No other warranty is expressed or implied, and the remedies provided herein are the Buyer's sole and exclusive remedies.

Disclaimer of Warranties

To the maximum extent permitted by applicable law, Anritsu Company and its suppliers disclaim all warranties, either expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose, with regard to the product. The user assumes the entire risk of using the product. Any liability of provider or manufacturer will be limited exclusively to product replacement.

No Liability For Consequential Damages

To the maximum extent permitted by applicable law, in no event shall Anritsu Company or its suppliers be liable for any special, incidental, indirect, or consequential damages whatsoever (including, without limitation, damages for loss of business profits, business interruption, loss of business information, or any other pecuniary loss) arising out of the use of or inability to use the product, even if Anritsu Company has been advised of the possibility of such damages. Because some states and jurisdictions do not allow the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

Safety

To reduce the risk of personal injury or loss related to equipment malfunction, Anritsu Company uses the following symbols to indicate safety-related information. You may encounter them on your products and in documentation. For your own safety, please read the information carefully before operating the equipment.

Safety Notices Used in Manuals

Warning



Danger or Warning indicates a risk from a very hazardous condition or procedure that could result in light-to-severe injury or death, or loss related to equipment malfunction. Follow all safety precautions and procedures to minimize this risk.

Caution



Caution indicates a risk from a hazardous condition or procedure that could result in injury or loss related to equipment malfunction. Follow all safety precautions and procedures to minimize this risk.

Safety Symbols Used on Equipment and in Manuals

The following symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions and status. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions *before* operating the equipment. Some or all of the following symbols may or may not be used on Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in the manual.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates a compulsory safety precaution. The required operation is indicated symbolically in or near the circle.



This indicates a danger, warning, or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



This indicates a push button Out position (generally Off condition).



This indicates a push button In position (generally On condition).



This indicates an Off condition.



This indicates On condition.



This indicates Alternating Current (AC).



This indicates Direct Current (DC).

Safety Symbols and Notices

Warning



Always refer to the equipment manual when working near locations where the alert mark, shown on the left, is displayed. If equipment operation is conducted without heeding the advice in the manual, there is a risk of personal injury. In addition, the equipment performance may be reduced.

This alert mark is sometimes used with other marks and descriptions indicating other dangers.

Warning



This equipment may present a risk to electric shock. Only qualified service personnel should access areas where this alert mark is present. Ensure that precautions are taken and that appropriate lockout mechanisms are in place before proceeding to enter the areas presenting this risk.

Warning




Unless your equipment is rated for Ingress Protection (IP) or is otherwise ruggedized, it is not designed to withstand exposure to extreme environments or water. If your equipment gets wet or is dropped, remove external power and any user serviceable batteries from the equipment and contact Anritsu support for any additional precautions and instructions to bring the equipment back into service. Always follow the environmental operating and storage requirements listed in the product technical data sheet.

Warning



Before supplying power to this equipment, ensure that proper voltage and current source is connected as indicated on the equipment labeling. Your equipment may be supplied with an external power adapter or it may be connected directly to the mains supply. Be sure to always use the supplied external power adapter and cabling. If your equipment connects directly to the mains supply, the input may be auto sensing or require a switch setting to match your supplied voltage. If power is supplied to the equipment that does not match the input specifications printed on the equipment labeling, there is a risk of personal injury and damage to the equipment.

Warning




When supplying power to this equipment, connect the accessory 3-pin power cord to a 3-pin grounded power outlet. If required, ground the instrument chassis to a suitable earth ground. If power is supplied without grounding the equipment, there is a risk of receiving a severe or fatal electric shock.

Warning



This equipment cannot be repaired by the operator. Do not attempt to remove the equipment covers or to disassemble internal components. Only qualified service technicians with a knowledge of electrical fire and shock hazards should service this equipment. There are high-voltage parts in this equipment that present a risk of severe injury or fatal electric shock. In addition, there is a risk of damage to precision components.

Warning



Laser radiation may be present at fiber-optic cable connectors and ports. This laser radiation could present a nominal ocular hazard from either direct viewing or by diffuse reflection. Do not view the emitted laser radiation directly or indirectly because damage to the eye or permanent blindness may result.

Warning



This product may be supplied with a rechargeable battery. Only use batteries that are designed for your equipment and that are supplied by Anritsu Company. Using an incorrect battery could present a safety hazard and cause personal injury or damage to the equipment and other loss. Batteries can potentially leak hazardous compounds into the environment. These hazardous compounds present a risk of injury or loss due to exposure. Anritsu Company recommends removing the battery for long-term storage of the instrument and storing the battery in a leak-proof plastic container. Follow the environmental storage requirements specified in the product technical data sheet and always comply with your regional disposal regulations.

Warning



NEVER touch parts where the label shown on the left is attached. Such parts are hotter than 55 degrees Celsius and you risk receiving a burn.

Caution



Electrostatic Discharge (ESD) can damage the highly sensitive circuits in the instrument. ESD is most likely to occur as test devices are being connected to, or disconnected from, the instrument's front and rear panel ports and connectors. You can protect the instrument and test devices by wearing a static-discharge wristband. Alternatively, you can ground yourself to discharge any static charge by touching exposed, unpainted metal of the outer chassis of the grounded instrument before touching the instrument's front and rear panel ports and connectors. Avoid touching the test port center conductors unless you are properly grounded and have eliminated the possibility of static discharge.

Repair of damage that is found to be caused by electrostatic discharge is not covered under warranty.

Regulatory Compliance

Following compliance notices and declarations of conformity apply to the IQ Fiber Master.

This equipment is categorized as Class A devices as noted below:

- A device marketed for use in an industrial application and is not intended for use in the home or residential area is classified as Class A. Class A equipment, commonly known as ISM (industrial, scientific, and medical) equipment, are for professional use in engineering and scientific applications commanding specialized training and good understanding of the English language. Products being sold in a commercial market for such applications have significantly less stringent emissions limits than Class B (residential) devices.
- A device that is marketed for use in the home or a residential area by the customer is classified as a Class B device. Class B verification is for devices that are marketed for in-home use, but are not permanently connected to a personal computer.


Note	Depending on the economic region/area that your equipment is marketed for, certain labels may not be applicable. Please refer to the markings affixed to your equipment, the product data sheet, and its declaration of conformity on https://www.anritsu.com
-------------	---

CE Conformity Marking



Anritsu affixes the CE Conformity marking onto its conforming products in accordance with Council Directives of The Council Of The European Communities in order to indicate that these products conform to the EMC, LVD, RoHS, and RED directive of the European Union (EU).

European Parliament and Council Directive 2012/19/EC



Equipment Marked with the crossed-out Wheelie Bin symbol complies with the European Parliament and Council Directive 2012/19/EC (the “WEEE Directive”) in the European Union.

For products placed on the EU market after August 13, 2012, please contact your local Anritsu representative at the end of the product’s useful life to arrange disposal in accordance with your initial contract and the local law.

UKCA Conformity Marking



Anritsu affixes the UKCA Conformity marking onto its conforming products in accordance with the United Kingdom conformity assessment body (CAB) in order to indicate that these products conform to the market of Great Britain (England, Wales, and Scotland).

RCM Conformity Marking



Anritsu affixes the Regulatory Compliance Mark (RCM) onto its conforming products in accordance with the electromagnetic compliance regulations of Australia and New Zealand in order to indicate that these products conform to the EMC regulations of Australia and New Zealand.

KCC Conformity Marking



Anritsu affixes the Korean Communications Commissions (KCC) mark onto its conforming products in accordance with the electromagnetic compliance regulations of Korea.

Canadian ICES-001 and ICES-003 Conformity Marking

CAN ICES-1(A)/NMB-1(A)

Anritsu affixes the CAN ICES-1(A)/NMB-1(A) and CAN ICES-3(A)/NMB-3(A) compliance labels onto its conforming products in accordance with the following Canadian Interference-Causing Equipment Standards:

CAN ICES-3(A)/NMB-3(A)

ICES-001 — Industrial, Scientific and Medical (ISM) Radio Frequency Generators
ICES-003 — Information Technology Equipment (ITE).

Recycle Marking



Anritsu affixes the universal recycle symbol onto its products to indicate that the marked part is made from recyclable materials and should be recycled. Materials should be recycled in accordance with your local regulatory requirements.

Proposition 65 Notification

State of California Proposition 65 Notification: <https://www.p65warnings.ca.gov>

Notification for California customers: Chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm may be present in the product or its related accessories. For information, see: <https://oag.ca.gov/prop65>

Effective August 31, 2018, the State of California requires customer notification of products manufactured after August 31, 2018 that contain substances listed in the Proposition 65 substance list, in amounts exceeding *Significant Risk Levels/Dosage levels*, which are known in the state of California to cause cancer, or birth defects, or reproductive harm. This requirement applies to products sold in California or products that may be exposed to people in the state of California.

While Anritsu does not believe there is risk of significant exposure with our products, it is possible that some of the listed substances identified by Proposition 65 are present with the electronic components and instruments manufactured by Anritsu. Anritsu is providing this warning out of an abundance of caution to fully comply with the Proposition 65 Law and as an information service to our customers.

Please visit <https://oehha.ca.gov/proposition-65/chemicals> for a complete listing of chemicals considered or listed under Proposition 65 (this list and web site are maintained by the Office of Environmental Health Hazard Assessment [OEHHA], one of six agencies under the umbrella of the California Environmental Protection Agency [CalEPA]).

Perchlorate Material Notification – Special Handling May Apply

Notification for California customers: this product uses a small Lithium battery installed internally on the circuit board that may contain perchlorate. Disposal may be regulated due to environmental considerations. Please contact your local authorities for disposal or recycling information. For information, see: <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

Chinese RoHS Compliance Statement

产品中有毒有害物质或元素的名称及含量

YLNMD1B - 201707

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 [Cr(VI)]	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷线路板 (PCA)	×	○	×	○	○	○
机壳、支架 (Chassis)	×	○	×	×	○	○
LCD	×	○	×	×	○	○
电池 (Battery)	×	○	○	○	○	○
其他(电缆、风扇、 连接器等) (Appended goods)	×	○	×	×	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11364-2014 标准规定的限量要求以下。
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11364-2014 标准规定的限量要求。

环保使用期限



这个标记是根据 2016/1/21 公布的「电子信息产品污染控制管理办法」以及 SJ/T 11364-2014 「电子信息产品污染控制标识要求」的规定，适用于在中国销售的电子信息产品的环保使用期限。仅限于在遵守该产品的安全规范及使用注意事项的基础上，从生产日起算的该年限内，不会因产品所含有害物质的泄漏或突发性变异，而对环境污染，人身及财产产生深刻地影响。
注：电池的环保使用期限是 5 年。生产日期标于产品序号的前四码
(如 S/N 1628XXXX 为 16 年第 28 周生产)。

Product Compliance, and Safety

Warning




Laser radiation may be present at fiber-optic cable connectors and ports. This laser radiation could present a nominal ocular hazard from either direct viewing or by diffuse reflection. Do not view the emitted laser radiation directly or indirectly because damage to the eye or permanent blindness may result.

This family of product works in conjunction with class 1 laser products. Work should only be undertaken by trained individuals. Proper precaution should be taken when using class 1 lasers and fiber optics.



The CE mark is a registered trademark of the European Community.



The WEEE mark is a registered trademark of the European Community.



The RCM mark is a registered trademark of the Australian Communications and Media Authority.



Administrative Measure on the Control of Pollution Caused by Electronic Information Products is a Chinese government regulation to control hazardous materials.



Anritsu affixes the Korean Communications Commissions (KCC) mark onto its conforming products in accordance with the electromagnetic compliance regulations of Korea.

Notice

Anritsu Company has prepared this manual for use by Anritsu Company personnel and customers as a guide for the proper installation, operation, and maintenance of Anritsu Company equipment and computer programs. The drawings, specifications, and information contained therein are the property of Anritsu Company, and any unauthorized use is prohibited; they shall not be reproduced, copied, or used in whole or in part as the basis for manufacture or sale of the equipment or software programs without the prior written consent of Anritsu Company.

Updates

For additional information and literature covering your product, visit the product page of your instrument on <http://www.anritsu.com> and select the Library tab.

Updates, if any, may be downloaded from the Anritsu Website.

For the latest service and sales contact information in your area, please visit:

<http://www.anritsu.com/contact-us>.

Not all instrument models offer every option. Please refer to the Technical Data Sheet of your instrument for available options.

Table of Contents

Chapter 1—General Information

1-1	Introduction	1-1
	Before You Begin	1-1
	Additional Documentation	1-2
	Document Conventions	1-2
1-2	Instrument Description	1-2
	Available Options	1-2
1-3	Contacting Anritsu for Sales and Service	1-2

Chapter 2—Instrument Overview

2-1	Introduction	2-1
2-2	IQ Fiber Master and Optical Tap Connector Panels	2-2
	IQ Fiber Master and Optical Tap Front Connector Panel	2-2
	IQ Fiber Master Back Connector Panel	2-3
2-3	Installation of IQ Fiber Master Control Software (MX280020A)	2-4
	PC Requirements	2-4
	Connecting the IQ Fiber Master	2-5
	Connecting to the Tap	2-7
2-4	MX280020A Control Software GUI Overview	2-10
2-5	Main Menu	2-11
	File	2-11
	Upgrading IQ Fiber Master	2-11
	View	2-13
	Help	2-15
	Sensor	2-17
	Control Buttons	2-21
	Status Line	2-21
2-6	Preferences	2-22
	General	2-22
	dB Units	2-23
	Plot Settings	2-24
	Config Check Rules	2-25
	Heatmap Rules	2-27
2-7	Site Editor tab	2-28
2-8	Roster Editor tab	2-35
2-9	Run Tests tab	2-37
	Preliminary Configuration Checking	2-39
	Final Configuration Checking	2-41
2-10	Analyzer tab (Option 754)	2-42
2-11	PIM vs Time tab (Option 755)	2-43
2-12	PIM Distribution tab (Option 755)	2-44
2-13	PIM Daily tab (for PIM Failure) (Option 755)	2-45

Table of Contents (Continued)

2-14	Heat Map tab (Option 755)	2-46
2-15	PIM Location tab (Option 754)	2-47

Chapter 3—Making LTE RF over CPRI Measurements (Option 752)

3-1	Preparing the Site's Details (Site Editor)	3-1
	Auto-detect a Site's Configuration	3-1
	Loading Existing Site Configuration File	3-5
3-2	Starting the LTE RF over CPRI Mode.	3-6
3-3	Analyzer tab	3-16
	Settings	3-17
	Axes.	3-18
	Plot.	3-19
	Traces	3-19
	Markers	3-22
	Playback	3-25
	Advanced (Set the Noise Floor).	3-26
	Export Image...	3-30
	Zoom	3-31
3-4	Stopping/Restarting LTE RF over CPRI Mode	3-34

Chapter 4—Making PIM-over-CPRI Measurements (Option 754)

4-1	Preparing the Site's Details (Site Editor)	4-2
	Create Roster Files	4-2
	Loading Existing Site Configuration and Roster Files	4-3
4-2	Select a Test.	4-4
4-3	Configuration Check	4-4
	Report	4-7
4-4	PIM Measurement.	4-8
4-5	Analyzer: PIM over CPRI	4-10
	Main Buttons and Controls	4-11
	Context Menu	4-11
4-6	PIM Location, Distance, and Calibration.	4-15
	Introduction	4-15
	PIM Calibration	4-17
	Auxiliary PIM Location Information	4-20

Chapter 5—PIM Analytics (Option 755)

5-1	PIM vs Time (Long-term Monitoring)	5-1
	Events....	5-2
	Clear	5-3
	Load File....	5-3
	Save File....	5-3
	Previous/Next	5-3
	Date/Summary.	5-3
5-2	PIM Distribution.	5-4
5-3	PIM Daily.	5-5

Appendix A—Reports

A-2 LTE RF over CPRI A-9

Chapter 1 — General Information

1-1 Introduction

This user guide covers the instrument overview, system functions, and other common features, along with a brief guide to the basic measurement concepts and setups. Most of the instrument operations are covered in specific chapters of this manual as listed below. Additionally, the MT2780A uses the MX280020A control software installed on a PC or laptop for controlling the IQ Fiber Master hardware.

Note that whenever there is a new release of the control software, an Internet connection is required to verify the hardware license of the IQ Fiber Master Analyzer that is connected to your PC or laptop. Once the initial verification is confirmed the Internet connection is no longer required in performing necessary measurements/analysis.

The IQ Fiber Master User Guide provides setup instructions for the connection and usage of the PIM over CPRI and LTE RF over CPRI sensor and analyzer.

LTE RF over CPRI differs from PIM over CPRI in these ways:

- **LTE RF over CPRI (Option 752):** Provides full spectral analysis of CPRI IQ streams either in absolute or relative frequency, and of LTE UL and DL signals. This function is analogous to a spectrum analyzer.
- **PIM over CPRI (Option 754):** (Requires options 752) Supports multiple PIM configurations while measuring PIM power level. Provides distance-to-PIM (DTP). PIM over CPRI measures PIM against live traffic to provide a truer picture of the impact of PIM at a cell site.
- **PIM Analytics (Option 755):** (Requires options 752 and 754) Provides, PIM vs. Time, PIM distribution, PIM daily, and Heat Map data views. Reports include detailed pass/fail configuration check, long-term (24-hour) monitoring, a pass/fail of each UL showing the external or internal nature of failures, and UL and PIM spectra for each antenna branch.

Before You Begin

- Charge the instrument battery using the supplied battery charger until fully charged.

Note The instrument may reboot when the battery charge level is low and external power is removed.

The following chapters provide information on the software user interface, such as instrument settings, measurement features, and menu overviews, for the featured option:

- [Chapter 2, “Instrument Overview”](#) provides information about the physical instrument, connectors, and other hardware interfaces.
- [Chapter 3, “Making LTE RF over CPRI Measurements \(Option 752\)”](#) provides information on the software user interface, such as instrument settings, measurement features, and menu overviews, for the spectrum analyzer.
- [Chapter 4, “Making PIM-over-CPRI Measurements \(Option 754\)”](#) provides information on the software user interface, such as instrument settings, measurement features, and menu overviews, for the real-time spectrum analyzer.
- [Chapter 5, “PIM Analytics \(Option 755\)”](#) provides information on the software user interface, such as instrument settings, measurement features, and menu overviews, for the 5GNR analyzer.

Additional Documentation

Table 1-1 lists the additional documents available for MT2780A.

Table 1-1. Related Manuals

Document Part Number	Description
11410-01153	MS2780A IQ Fiber Master Technical Data Sheet

For additional information and literature covering your product, visit the product page of your instrument and select the Library tab:

<https://www.anritsu.com/en-us/test-measurement/products/mt2780a>

Document Conventions

The following conventions are used throughout the MT2780A documentation set.

Instrument Identification

When identifying a frequency option for the MT2780A, that option number is appended after the model number; example: MT2780A-0752.

User Interface

The MT2780A user interface consists of menus, buttons, toolbars, and dialog boxes.

User Interface Navigation

Elements in navigation paths are separated as follows: FILE > PREFERENCES > GENERAL.

1-2 Instrument Description

The IQ Fiber Master MT2780A PIM and RF analyzer is a CPRI-based solution that provides critical PIM diagnosis across multiple bands and sectors using live traffic. Cell sites remain active during testing as this instrument uses a non-invasive process to report real-time results. Identify PIM levels, locations, and conduct RF spectrum analysis to efficiently hunt and debug PIM and interference issues.

Available Options

Table 1-2 lists the frequency options available with the MT2780A.

Table 1-2. IQ Fiber Master Frequency Options

Model	Frequency Range
MT2780A-0752	Making LTE RF over CPRI Measurements
MT2780A-0754	Making PIM-over-CPRI Measurements
MT2780A-0755	PIM Analytics

1-3 Contacting Anritsu for Sales and Service

To contact Anritsu, visit the following URL and select the services in your region:

<http://www.anritsu.com/contact-us>

Chapter 2 — Instrument Overview

2-1 Introduction

This chapter provides an overview of the Anritsu MT2780A IQ Fiber Master. It describes the instrument hardware features, general system settings, instrument configurations, and the connector panels.

This guide helps those personnel familiar with computers, test and measurement equipment to understand the IQ Fiber Master analyzer, optical tap, and the accompanying software, and to understand detecting and locating PIM.

For detailed information on the instrument's user interface and functions, refer to the relevant chapter for your measurement:

- [Chapter 3, “Making LTE RF over CPRI Measurements \(Option 752\)”](#)
- [Chapter 4, “Making PIM-over-CPRI Measurements \(Option 754\)”](#)
- [Chapter 5, “PIM Analytics \(Option 755\)”](#)

2-2 IQ Fiber Master and Optical Tap Connector Panels

This section shows the front and back connector panels of MT2780A IQ Fiber Master analyzer and optical tap.

IQ Fiber Master and Optical Tap Front Connector Panel

Optical fiber cables are used to connect IQ Fiber Master and optical tap.


The front panel of the IQ Fiber Master analyzer consists of the following:

- SFP modules
- Status light indicators

A green STS light signifies a successful connection between the radio and the BBU (base band unit). The SPF status lights are turned green if the fiber master is successfully connected to the optical tap.

The front panel of the optical tap consists of the following ports:

- Base Band Unit (BBH)
- Remote Radio Head (RRH)
- Uplink (UL)
- Downlink (DL)




1. Power light
2. Status light
3. Status lights for Small Form Pluggables (SFPs)
4. Receive input of SFP module (input port where the optical fiber is connected)
5. SFP modules (optional; see the Technical Data Sheet 11410-01153 for specific, recommended SPFs)
6. Optical Tap ports (see the Technical Data Sheet 11410-01153 for the optical tap part numbers)

Figure 2-1. IQ Fiber Master Analyzer (top) and Optical Tap (bottom) Front Connector Panel

Note Note that your optical tap connections may differ.

IQ Fiber Master Back Connector Panel

The back panel of the IQ Fiber Master consists of power, USB and Ethernet ports. The Ethernet port is used to connect to the PC running the IQ Fiber Master control software.



1. USB Interface - Type-C®
2. USB Interface - Type A
3. Ethernet Ports (synchronization) (The remaining ports are reserved for future use.)
4. Ethernet Port (primary)
5. Power input port

Figure 2-2. IQ Fiber Master Back Connector Panel

2-3 Installation of IQ Fiber Master Control Software (MX280020A)

The IQ Fiber Master control software MX280020A is installed on a PC or laptop that is connected to the IQ Fiber Master analyzer through an Ethernet cable. The IQ Fiber Master Control Software is used to set up the monitored CPRI link between the RRH and BBU, configure the different measurement types needed to make RF over CPRI, PIM over CPRI and PIM over CPRI Analytics measurements.

PC Requirements

Ensure that the computer (laptop, desktop, or tablet) meets these minimum requirements:

- Windows 10, 64-bit (recommended; Windows 7 minimum)
- 10 GB RAM memory (recommended; 8 GB minimum)
- Intel CORE i7 (recommended; Intel i3-6100 or AMD FX4350 minimum)
- 16 GB long-term storage (recommended; 8 GB minimum) 142 MB free
- USB ports (A and C)
- Internet connection

Follow the steps below to install the IQ Fiber Master Control Software (Windows 10):

1. Navigate to Control Panel>Programs> Uninstall a Program to uninstall the previous version of the software.

Note

Save a copy of the site config and roster test data files in a different location because all the test data files will get deleted if a previous software version is uninstalled.

2. Download the latest version of IQ Fiber Master control software from the company's product page:

<https://www.anritsu.com/en-us/test-measurement/products/mt2780a>

3. Launch the IQ fiber master executable file and follow the on-screen instructions.

If you want to familiarize yourself with the PC software, select 3. Run Tests tab, then click Help>Walkthrough. You can click the arrows on the bottom right to navigate through the software. If you want to exit the walk through click the red X on the bottom right most corner.

Connecting the IQ Fiber Master

To connect the IQ Fiber Master follow the steps below:

1. Using an Ethernet cable connect the IQ Fiber Master analyzer with a PC or laptop connected to the Internet. You may also use an Ethernet hub to connect the computer and analyzer. Contact your local IT department in case of any applicable restrictions.
2. Power On the IQ Fiber Master and wait for status light (STS) to turn green.
3. Click the **Sensor** drop-down menu of the 1. Site Editor tab, and select the connected sensor identified by the serial number.

Note The sensor serial number will always be preceded by MT2780A.




Figure 2-3. Selecting Sensor Serial Number

4. Click the Connect button.




Figure 2-4. Connecting IQ Fiber Master

5. Click File> Licensing to verify the installed options. The Licensing dialog consists of License Key field, the sensor ID in the Machine ID field, and the licensed options:




Figure 2-5. License Key and Machine ID Location

6. Check the connection status of the Sensor and SFPs which are shown at the bottom of the application window. See “Status Line” on page 2-21 for more about status.




Figure 2-6. Sensor Connection Status

Note The LOS, LOF and CPRI status lights will be shown as green if the fiber connections to the SFPs /Tap are properly connected. Any unused SFP ports will have red status lights.

Connecting to the Tap

The Fiber Diagram button in 3. Run Tests tab shows the fiber-connectivity diagram using which the IQ Fiber Master analyzer and the optical tap are connected through optical fiber cables. The fiber-connectivity diagram is based on the Site Config and Roster data files loaded in the Site and Roster Editor tabs. The fiber-connectivity diagram is unique to the type of a run test.

Follow the steps below to connect the tap with the IQ Fiber Master:

1. Power on the IQ Fiber Master analyzer and verify if the sensor is connected (refer to the status line at its bottom). See [Figure 2-7](#).




Figure 2-7. IQ Fiber Master Sensor and Tap Connected to computer

2. Refer to [Chapter 3, “Making LTE RF over CPRI Measurements \(Option 752\)”](#) to configure the Site and Roster setup (CPRI test), if a pre-configured setup is not available.
3. Click the 3. Run Tests tab and load the site configuration and roster files for the site under test (pre-configured or new setup).
4. Select a test scenario listed under Roster Detail section, for example, Test ID #3.
5. Select the Config Check radio button and click Run: config check button on the top of window screen.




Figure 2-8. 3. Run Tests tab: Generating a Fiber Diagram

6. If Config Check test fails click the Fiber Diagram button to visually verify the fiber connections.

Green lines between the SFP and the tap indicate a good fiber connection, yellow or red lines indicate a wrong connection. The graphic also shows the site's Sector names, bands, and test name/number to assure the user the correct site is ready for test (if configured).




Figure 2-9. Sample Fiber Connection Diagram

2-4 MX280020A Control Software GUI Overview

The MS280020A control software is used to interface and control the IQ Fiber Master hardware. It consists of main menu, different measurement tabs along with control buttons that are unique to the selected tab.

The control software consists of the following:

- “Main Menu”
 - “File”
 - “View”
 - “Help”
 - “Sensor”
- “Site Editor tab”
- “Roster Editor tab”
- “Run Tests tab”
- “Analyzer tab (Option 754)”
- “PIM vs Time tab (Option 755)”
- “PIM Distribution tab (Option 755)”
- “PIM Daily tab (for PIM Failure) (Option 755)”
- “Heat Map tab (Option 755)”
- “PIM Location tab (Option 754)”
- “Control Buttons”

The display of control buttons is different for the several tabs.

- Site Editor tab – Auto-detect, CPRI Analysis, and Stop
- Roster Editor tab – (no buttons)
- Run Test and the rest of the tabs – Run: (test), Stop, Add to Report, Review Results, Save Report, and Fiber Diagram
- “Status Line”

The Status line consists of these fields:

- Connected/Not Connected: Shows whether the sensor is connected.
- Sensor: Contains various messages from the sensor.
- LOS (Loss of Signal): Shows whether the sensor has obtained a signal.
- LOF (Loss of Frame): Shows whether the sensor has lost a frame (from an SFP).
- CPRI: Shows whether CPRI data/traffic is present.
- Temp: Shows the current, internal, sensor temperature.
- Engine: Displays the PIM engine/processor status.

2-5 Main Menu

The main menu consists of File, View, Help, and Sensor menus.

File

The File menu is used for the following:


- Allows to check the installed options.
- Set preferences.
- Reset the default settings.
- Quit the application.

Licensing...

For information on licensing refer to [“Connecting the IQ Fiber Master” on page 2-5](#).

Upgrading IQ Fiber Master

If you get a message like this one, you need to upgrade your IQ Fiber Master.



THIS FEATURE REQUIRES THE MT2780A-0755 OPTION

Figure 2-10. Upgrade Feature Message

To upgrade an option the user must first purchase the option and after the order is processed (follow Anritsu customer service procedure) the option license is added to the MT2780A IQ Fiber Master license server, the user must open the IQ Fiber Master software while connected to their MT2780A Analyzer (HW has the licenses programmed in) with an Internet connection, the SW will check the server for active options (which can be found under File/Licensing) and will update the option licenses when it is found on the server.

Preferences...

Click File > Preferences to open Preferences dialog. Refer to [“Preferences” on page 2-22](#) for more information about IQ Fiber Master preferences.

Note	Anritsu recommends changing the Save directory to a preferred or other suitable directory.
-------------	--

Reset to Defaults...

Click File > Reset to Defaults to reset all the saved settings, calibration data etc. You are prompted with a warning message before confirming the reset.




Figure 2-11. Unstored Result Warning

Quit

A warning message is displayed when you try to exit the application without saving the test results. Click Keep Results button to save the test results, otherwise select Discard Results and Continue to exit without saving.




Figure 2-12. Unstored Result Warning

View

The View menu is used for the following:

- Allows to select Full Screen window.
- Generate a PIM report
- Load a new style-sheet (i.e. report appearance) or select an existing style sheets.
- Choose the GUI display color settings between Anritsu and Default.

Report

- Click View > Report to generate a PIM report consisting of site and instrument details. From the Report window you can create a new report, save the generated report, customize the report detail settings, preview and print the report.

The screenshot shows a window titled "Report [new]" with a close button (X) in the top right corner. Below the title bar is a toolbar with buttons: "New", "Save...", "Settings...", "Close", "Preview", and "Print". The main content area displays the title "Passive Intermodulation (PIM) Report" in large bold text. Below the title are two sections: "Site Details" and "Instrument Details", each with a table of information.

Site Details	
Site:	[Set site ID here]
Report Created:	January 26, 2022 10:21
Last Updated:	January 26, 2022 10:21
Operator:	S-XXXXXX
Contact Phone:	+
Company Name:	Anritsu

Instrument Details	
Software Version:	IQ Fiber Master v1.7.5.13 build 44
Firmware Version:	1 (build 1)
Sensor Id:	Sensor Emulation
Test Roster:	tr_0001.xml

Figure 2-13. Report Dialog

- Click **Settings** button found on top of the **Report** window to change the report settings.

See [Appendix A, “Reports”](#) for more information about report contents and printing.


The image shows a 'Report Settings' dialog box with a title bar containing a green icon, the text 'Report Settings', and standard window controls. The dialog has a light gray background. It contains several input fields and buttons. The 'Operator' field has the text 'user'. The 'Contact' field has a '+' sign. The 'Company' field has the text 'Anritsu'. The 'Company Logo' field is empty, followed by a green 'Load...' button. Below these are three more settings: 'Resolution' set to '120' with a dropdown arrow, 'Page Size' set to 'A4' with a dropdown arrow, and 'Font Size' set to '12' with a spinner box. At the bottom right are two green buttons labeled 'OK' and 'Cancel'.

Figure 2-14. Report Settings Dialog

Load

Click **View>Load** to load an existing stylesheet for generating PIM reports.

Anritsu and Default Color Theme

Click **View** menu and choose an appropriate color theme.

Help

Click Help menu to view Help files, check software updates, create or load diagnostics package etc.




Figure 2-15. Help Menu

Help Contents

Provides a detailed, searchable list of help topics related to the product. Click Help>Help Contents.

Walkthrough

Starts the product walk through on how to initiate a test. Click 3. Run Tests tab, then click Help>Walkthrough.

About IQ Fiber Master

Displays the release details (version and build information) in a dialog.




Figure 2-16. IQ Fiber Master Release Information Dialog

Check for Updates...

Checks for updates to the analytics application (this requires an Internet connection).





Figure 2-17. IQ Fiber Master Check for Updates Dialog


Create Diagnostics Package

Creates a file, which can be loaded later for troubleshooting by technical support personnel, including IQ vectors, log files, and configuration data.



Load Diagnostics Package

Loads a previously saved diagnostics file.



Sensor

The Sensor Main Menu choice provides these tasks.




Figure 2-18. Sensor Main Menu

Codeload... (Update the Sensor Firmware)

This command checks and if applicable, updates the sensor with new firmware (this requires an Internet connection). Browse to the file's location and click **Load**.




Figure 2-19. CodeLoad Firmware Dialog

When the software update is complete, the analyzer displays this dialog:




Figure 2-20. CodeLoad Finished.

Click **OK** to reboot the sensor (remember to click **Connect**) or **Cancel** to defer rebooting the sensor until a later time.

Save Captures

Select One shot radio button to save captures to a specified directory as single one-shot capture (with a variable capture period of 1ms to 10s)




Figure 2-21. One Shot Capture

Select Continuous radio button to save captures to a specified directory as continuous capture with a delay ranging from 1 to 99 minutes.




Figure 2-22. Capture and Save: Continuous

Idle Capture allows the capturing of data at the specified interval (period) from 1 to 10000 ms.



Figure 2-23. Idle Capture

Reboot Sensor

This option reboots the sensor.




Figure 2-24. Sensor Reboot Dialog

Note After a sensor is rebooted, click the Connect button.

About Sensor

Displays an information-only dialog containing data about the status of the sensor.




Figure 2-25. Sensor Information

Control Buttons

Run: testname

This button runs the test named in its label: Config Check, PIM Level, PIM Location, or Cross Sector.

Stop

This button stops or suspends the test currently running.

Add to Report

This button is modal: in PIM Level mode, adds all the report segments to the report; and in CPRI Analysis mode, is greyed out to show its inactive status. Use this button to save the screenshot to the report.

Note Ensure to click Add to Report button to save the screenshot to the report.

Review Results

Use this button to display Reports which are fully explained in [Appendix A, “Reports”](#).

Save Report

This button open the report window to allow you to edit the site details, header information etc. Refer to [“View” on page 2-13](#) for more information.

Status Line

The Status line consists of these fields:

- **Connected/Not Connected:** Shows a small green circle and displays the name or serial number of the sensor. Shows a small red circle if a sensor is not connected.
- **Sensor:** Sensor displays OK for a good sensor connection; it shows Remote disconnected when sensor is not connected.
- **LOS:** Displays the status of Loss of Signal. Small green circles mean everything OK.
- **LOF:** Displays the status of Loss of Frame. Small green circles mean everything OK.
- **CPRI:** Displays the status of CPRI data/traffic. Small green circles indicate the traffic is present.
- **Temp:** Displays the current internal sensor temperature in Celsius.
- **Engine:** Displays the PIM current engine/processor status:
 - Idle
 - CPRI Analyzer
 - Stopped CPRI Analyzer
 - Timing Search
 - Measuring PIMPower
 - Stopped PIMPower
 - Checking Config
 - Stopped ConfigCheck



Connected: localhost Sensor: OK LOS: ●●●●● LOF: ●●●●● CPRI: ●●●●● Temp: 66.6°C Engine: Stopped ConfigCheck

Figure 2-26. Status Line

2-6 Preferences

Click File>Preferences to access various settings such as General, Config Check and Heatmap. Click the Apply button to confirm the selections; click X to return to the application.

General

Click File > General to access General Setting, dB Units and Plot settings.

General Settings

Click File > Preferences > General > General settings to view the settings as shown the figure.




Figure 2-27. General Settings

The General Settings consists of the following:

- **CPU Throttle:** Defines the ability to reduce / set CPU usage from 8 to 100%, where 100% being the maximum. Allows the CPU to be fully used in order to provide best performance and to minimize the time taken to perform the measurements. However users may need to reduce this value, especially for slower processors to improve stability of the PC / laptop or improve the battery life and CPU temperature of laptop/PC. Can also reduce this value during long term monitoring where time critical measurements are not so important.
- **Measurement Interval:** Defines the minimum interval between subsequent PIM measurements (on the same antenna).
- **Observation Time:** Defines the amount of data used for each measurement.
- **Font Size:** Used to change the font size for all text on all tabs
- **Save Directory:** Defines the directory where reports are to be stored in the computer.
- **Test Vectors Directory:** Defines the directory where the vectors (IQ data) are saved, these vectors are used for 'offline' demo purposes.

dB Units

To modify the dB Unit settings follow the steps below:

- Click File > General > dB Units to view the noise floor for each vendor (and bandwidth).

The Advanced option in the RF over CPRI is used to measure noise floor of the RRH under test. See [“Advanced \(Set the Noise Floor\)” on page 3-26](#) for more about measuring noise floor.




Figure 2-28. dB Units for Noise Floor

- Check Use dBlsb box to tell the analyzer to use/display units in dBlsb.
- Check Factor per BW box to expand the list of dBm factors.
- Click Reset Defaults button to collapse the list. Note that this holds good only for the other vendors,

But for the default vendors such as ALU and Nokia, checking the Factor per BW box expands and unchecking the box collapses the dBm factor list. Similarly checking the Reset Defaults box collapses the list.

Note

The default values are reference values and can be adjusted by running the Noise Floor (Advanced CPRI Analysis) measurement during a maintenance window (low traffic).

Plot Settings

To modify the plot settings follow the steps below:

- Click File > General > Plot Settings.




Figure 2-29. General Plot Settings

- Click the Pen Width drop-down menu to increase or decrease the pen width.
- Click on the signal color under **Colors (Light)** section to choose a specific color of each signal for light view mode. Click on the color box to choose from the basic colors or slide the triangle to make a custom color.
- Click on the signal color under **Colors (Dark)** section to choose a specific color of each signal for dark view mode.
- Click **Reset** button to reset the selected width and color settings.
- Click **Apply** button to apply the settings.

Config Check Rules

To modify Config Check test settings follow the steps below:

- Click File > Preferences > Config Check > Rules to view the config check test results parameters.
- Click the + sign to view a short description of the option along with additional fields with values if any.




Figure 2-30. Config Check Rules

- Check Show full details in results box to view the complete details of all the rules in the Results pane.




Figure 2-31. Config Check results with full details

- Uncheck this box to view only the options listed as shown in [Figure 2-32](#).




Figure 2-32. Config Check Results

- Optical connectivity – Verify that the SFP is present, its data may be read, and it is receiving sufficient optical power. Adjust the minimum optical receive power and the maximum operating temperature.
- CPRI connectivity – Verify that the CPRI interface is synchronized, is receiving data, and no alarms are present. Note that this is the only rule that cannot be turned off.
- IQ Stream Capture – Check that the number of streams successfully captured match the number requested.
- RSSI/TSSI – Compare each IQ stream's RSSI/TSSI with a valid range.
- Bandwidth – Check that the sample rate and AirStd of the IQ stream match the expected values.
- LTE ID Tx Configuration – Check the validity of the LTE identifier and the Tx configuration decoded from the broadcast channels.

Heatmap Rules

Follow the steps below to modify the heatmap settings:

- Click File > Preferences > Heatmap > Rules.




Figure 2-33. Heatmap Rules

- Check All box to include all the PIM measurements in the heatmap summary.
- Check Internal/External box to include the details of the internal or external PIM in the heatmap summary.
- Click Apply button at the bottom of the window to apply the selected option.

2-7 Site Editor tab

The 1. Site Editor tab provides a way to define the equipment to be tested according to the testing protocol at a site. Notice the tabs numbered 1 through 3. These remind you of the order to set up a new site or start a new batch of measurements. Site Editor is the only tab that contains parameters needed to configure the CPRI Analysis test.

Note

An Internet connection is required for the first time a computer/laptop is connected and configured with MT2780A IQ Fiber Master, because the MT2780A software license will be verified with the license server. The Internet connection is not required after the initial configuration is completed.




Figure 2-34. 1. Site Editor tab

Note

Notice that after completing other measurements, the sequential order of the SFPs in Site Editor tab may be out of order.

Control Buttons

Auto-detect: Determines the CPRI line rate, the air std, number of AxC's. The user needs to select the number of system fibers and vendor name BEFORE starting auto-detect.

CPRI Analysis: Starts an LTE RF over CPRI test. This button becomes active when a sensor is selected and the CPRI link is configured. After configuring your CPRI setup, click this button to activate the RF over CPRI spectrum analyzer view.

Stop: Stops the CPRI Analysis testing. This button becomes active when a CPRI Analysis test or one of the Selected Tests is running.

Site Config Buttons

Details...: Site configuration details.

New: Starts a new site configuration. Be careful to not write over the existing site config name.

Load...: Loads a configuration from a file.

Save...: Saves the file. You may change the path and name if desired.

Apply: Applies the changes so that the testing will use them.

Note	All the Site Configuration files must be saved with si_ prefix for e.g. si_XXXXX.xml.
-------------	---

Sensor Buttons

Sensor: Select from the list of connected sensors using this drop-down list.

Connect: Connect the selected Sensor. Activates the Auto-detect and CPRI Analysis buttons.

Disconnect: Disconnect the sensor. (This button is only active after a successful connection).

Editing/Copy to Buttons

Editing Sector: Use this drop-down list to select a sector that needs to be tested.

Copy to: Use this drop-down list to select the sector to which the edited sector is to be copied.

Copy: Copies the sector selected in the Editing Sector to the Copy to sector.

CPRI (set up the CPRI interface)

- Number of system fibers: Select the number based on how many fibers are connected to the sensor, typically three: two DL and one UL.
- Fiber Mode: Select either Single or Multi Mode.
- Fiber: Select the fiber via the SFP module it is connected to.
- UL: Select UL (uplink) or DL (downlink) from this drop-down list.(SFP1 is always a UL)
- CPRI: Select the vendor by name or use Custom.
- Rate: Set the rate 1 through 8 associated with the fiber.
- Carriers: Set the carrier associated with the fiber.
- CPRI Settings: Set the Bit width, Reserve bits, and Idle bits.




Figure 2-35. CPRI Settings

- Air Std: Choose a broadband LTE standard. E1 and E2 are Ericsson optimized Down-Sampling/Compression sample rates, and S denotes a Samsung rate.




Figure 2-36. LTE Air Standard List Sampling Rate

These are the standard sampling rates:

- LTE 5 @ 7.68 MHz
- LTE 10 @ 15.36 MHz
- LTE 15 @ 23.04 MHz
- LTE 20 @ 30.72 MHz

These are the down-sampling (compressed) rates:

- LTE15_E1 @ 19.2 MHz (Ericsson Optimized Sampling Line Rate 8 only : 15 MHz LTE: Re-Sample/Compression from 6 to 5 AxC Containers per AxC Group)
- LTE15_E2 @ 15.36 MHz (Ericsson LTE15: Dpwm-Sample/Compression from 6 to 4 AxC Containers Per AxC Group)
- LTE20_E1 @ 23.04 MHz (Ericsson LTE20: Down-Sample/Compression from 8 to 6 AxC Containers Per AxC Group)
- LTE20_E2 @ 19.2 MHz (Ericsson Optimized Sampling Line Rate 8 only: 20 MHz LTE: Re-Sample/Compression from 8 to 5 AxC Containers per AxC Group)
- LTE20_S @ 30.72 MHz (Samsung have adopted the full 30.72 MHz sampling rate for an LTE20 air std)

AxC Groups: Activate up to eight antenna-carrier groups. Adjusts the number of table rows. The frequency is automatically adjusted.

Clear RF Links: Clears the RF Links.

AxC Table: Enter the Antenna name (if the default names Ant1 through 8 are not appropriate) and additional description.

CPRI Analysis (Option 752)

See [Figure 2-37](#), “Analyzer tab: LTE RF over CPRI Mode (Relative Spectrum)” and “Starting the LTE RF over CPRI Mode” on page 3-6 for more information on CPRI Analysis.




Figure 2-37. Analyzer tab: LTE RF over CPRI Mode (Relative Spectrum)

RF (set up carriers)

These are the parameters for this section:

Number of RF

systems: From 1 to 8.

System n: System number, 1 through n, depending upon the number selected in Number of systems.

Carriers: This field specifies how many carriers will be part of this site.

Carrier n: Depending upon how many are specified by the Carriers field, this heading marks the beginning of a carrier.

Band n: Choose a band from the drop-down list.

DL EARFCN: From 0 up to 99.

Freq: All 3GPP bands supported.

UL EARFCN: From 0 up to 99.

Freq: All 3GPP bands supported.

Clear CPRI Links: Clears the CPRI links.




Figure 2-38. 1. Site Editor tab: Number of RF systems

Frequency Band: Use this button to display the Frequency Band dialog and set whether the system is UL or DL. If you do not know the 3GPP band but know the frequency, you can look it up on the dialog




Figure 2-39. Frequency Band

2-8 Roster Editor tab

Use the 2. Roster Editor to set up the various tests for PIM over CPRI for a site including the downlinks (DL) and uplink (UL), the antennas, limits, and other measures. Refer to [Chapter 4, “Making PIM-over-CPRI Measurements \(Option 754\)”](#) and [Chapter 5, “PIM Analytics \(Option 755\)”](#) for more about the Roster Editor.




Figure 2-40. 2. Roster Editor tab

Note All the Roster files must be saved with tr_ prefix for e.g. tr_XXXXX.xml.

Site Config Buttons

Load: Loads a site information file. This file is maintained by the Site Editor.

Roster File Buttons

Auto Generate: Will generate a roster based on site information file.

Load: Loads a roster file.

Save: Saves the roster file.

Apply: Applies the changes but does not save the file.

Roster Detail

Site ID: The site ID defined in site configuration details.

Sector Table:

Sector: The name of the sector which this test runs against.

DL1: The primary downlink frequency.

DL2: The secondary downlink frequency.

UL: The uplink frequency.

Limit: The power limit for the PIM.

Desense: This is the amount of uplink noise floor rise due to PIM. It is an indication of the reduction in receive sensitivity of the receiving antenna.

IM: InterModulation scenarios can be manually created and edited, or automatically created by reading the Site information file and using the auto generate feature of the Roster Editor tab. The IM combinations (for e.g. IM1, IM3 etc.) can be obtained based on the defined carriers.

Antennas: Check the antennas to test.

Measure: Check the items that you want the test to measure.

Level: Specifies the dB and dBm value for spectrum and PIM.

Distance: Specifies that DTP will be measured.

Add Test

Click this button to add a test.

Delete Test

Click this button to delete a selected test.

2-9 Run Tests tab

Use the 3. Run Tests tab to run the PIM over CPRI analysis as specified in the Site and Roster Editor tabs.

Follow the steps below to select and run a test:

1. Load the site and roster files. Refer to “Site Editor tab” on page 2-28 and “Roster Editor tab” on page 2-35 sections on how to load the files.
2. Select a test under Roster Details section. Note that selected test will be highlighted in green.
3. Under Selected Test section, select Config Check radio button.
4. Click Run: config check button on the top of window to run the selected test.
5. If the config check test results fail click Fiber Diagram button on the top right corner of the window to verify the correctness of the optical fiber connection.
6. Fix the connection as shown in the fiber diagram dialog and run the test again.

Note

Ensure to run config check test before running any other available tests. Note that until the config check test is passed, the remaining tests will be disabled.




Figure 2-41. 3. Run Tests tab

Control Buttons

Run: test name: This button is active when a connection to a sensor is active, and it changes name and function depending upon whether the selected test is one of these:




Figure 2-42. Selected Test List

Stop: Stops the test in progress and resets all the controls to their pretest state.

Add to Report: Adds the results in the Selected Test > Results to the report.

Review Results: Displays the report.

Save Report: Saves the report.

Fiber Diagram: Displays the connection diagram for the site as given by the configuration file.

To run a test:

1. Click **Sensor:sensorname** to select the sensor to be involved in the test.
2. Click the **Connect** button. The **Selected Test > Config Check** control becomes active and so does the **Run: config check** button. The **Config Check** is based on the **Test ID** selected in **Roster Detail** section.
3. Click **Run: config check** button. The **Selected Test > PIM Level** control becomes active.

The analyzer performs the configuration check, then prepares to run the PIM Level test.

4. Select **Selected Test > PIM Level** and the **Run: button** changes to **Run: PIM level**.

The analyzer performs the test, and prepares the analysis for the selected tests.

5. Click **Run:PIM Level**. Results of this test display in the bottom of the app.




Figure 2-43. Selected Test Results

Preliminary Configuration Checking

Configuration checking for any test is accomplished by building and saving, or loading a Site Configuration (sector-mapping to optical-fiber) file and a Roster file (test). The Site Editor and Roster Editor tabs maintain contents of the files, which can be done ahead of time, if site data are known.

1. Connect the IQ Fiber Master analyzer with optical tap and PC/laptop. See [“Connecting the IQ Fiber Master”](#) on page 2-5.
2. Under 1. Site Editor tab, click Load...button to load the Site Config file and click Apply to save the file.




Figure 2-44. 1. Site Editor tab: Preliminary Configuration Test Suite

3. Under 2. Roster Editor tab, click Load...button to load the roster file and click Apply to save the file.




Figure 2-45. 2. Roster Editor tab: Preliminary Configuration Test Suite

4. Click 3. Run Tests tab.

The analyzer checks the tests and posts available or invalid test in the Status column.




Figure 2-46. 3. Run Tests tab: Preliminary Configuration Test Suite

Final Configuration Checking

After the preliminary configuration check and the fiber connections are complete, the system is ready for the final configuration check.

To final-check a configuration:

1. Select Config Check radio button.




Figure 2-47. Configuration Check Status

2. Click Run: config check button to check if the parameters pass.




Figure 2-48. Running a Configuration Check

See “[Configuration Check](#)” on page 4-4, and “[Control Buttons](#)” on page 2-21, for more information about the config check test.

2-10 Analyzer tab (Option 754)

The Analyzer tab is modal and the data and options it shows depend upon the path that displayed them. Use this tab to view the ongoing (or paused) test.

PIM over CPRI Tests

See [Figure 2-49, “Analyzer tab: PIM over CPRI Mode”](#) and [“PIM Measurement” on page 4-8](#) for more information on PIM over CPRI tests.



Figure 2-49. Analyzer tab: PIM over CPRI Mode

- The green trace is the actual uplink trace.
- The orange trace is the estimated PIM value.

2-11 PIM vs Time tab (Option 755)

Use PIM vs Time tab to compare PIM values to the time it took to detect them. See [“PIM vs Time \(Long-term Monitoring\)” on page 5-1](#) for more information about this report.




Figure 2-50. PIM vs Time tab

Run: PIM Level: This button is active when a connection to a sensor is active, and it changes function depending on whether Selected Test > Config Check or Selected Test > PIM Level is selected.

Stop: Stops the test in progress and resets all the controls to their pretest state.

Add to Report: Adds the results in the Selected Test > Results to the report.

Review Results: Displays the report.

Save Report: Saves the report.

Fiber Diagram: Displays the connection diagram for the site as given by the configuration file.

Events...: Events log is created and can be saved as a CSV file.

Clear: Clears the all the data in the graph?.

Load File...: Loads a saved file for replaying.

Save File...: Saves the data to a CSV file to enable replaying when needed.

Previous/Next: Allows the user to step back or forward to view a specific day's worth of data.

Date/Summary: Allows the user to select and display results for a specific day in the drop-down menu. Summary provides a summary for ALL days.

2-12 PIM Distribution tab (Option 755)

Use PIM Distribution tab to display the PIM measurements exceeding the PIM threshold level. See “PIM Distribution” on page 5-4 for more information about the distribution report.




Figure 2-51. PIM Distribution tab

2-13 PIM Daily tab (for PIM Failure) (Option 755)

Use PIM Daily tab to display a report that shows the results for a 24-hour period. See “PIM Daily” on page 5-5 for more information about the daily report.




Figure 2-52. PIM Daily tab

2-14 Heat Map tab (Option 755)

Use Heatmap to display the PIM values in a color-coded table with the strongest return in the reddest color. For information about heat map refer to “Heat Map” on page 5-6.




Figure 2-53. Heat Map tab

2-15 PIM Location tab (Option 754)

Use PIM Location tab to pinpoint the distance to a PIM source.



Figure 2-54. PIM Location tab

Chapter 3 — Making LTE RF over CPRI Measurements (Option 752)

The 1. Site Editor tab sets up all the CPRI measurements including the Option 752. This option provides the same capabilities for fiber systems that a spectrum analyzer does for RF.

3-1 Preparing the Site's Details (Site Editor)

The analyzer needs to know specific parameters for the cell site under test. These details can be entered or created as described in this section.

Auto-detect a Site's Configuration

Follow the steps below to configure Auto Detect in 1. Site Editor tab:

1. In 1. Site Editor tab select the sensor from **Sensor** drop-down menu and click the **Connect** button.




Figure 3-1. 1. Site Editor tab

2. Click **New** button to clear any pre-existing site configuration, if you may want to create a new site config file.

3. Under CPRI section select the number of system fibers connected to the SFPs installed in the MT2780A (for e.g. three fibers to represent 2 x DLs and 1 x UL). See [Figure 2-1, "IQ Fiber Master Analyzer \(top\) and Optical Tap \(bottom\) Front Connector Panel"](#).




Figure 3-2. 1. Site Editor tab: Auto-detect spectrum

4. Select the appropriate fiber mode (single mode/multi mode) from the drop-down menu.
5. Select the vendor from the CPRI drop-down menu. Selecting a vendor changes the CPRI settings.
 - If you set the vendor as Custom, click CPRI Settings button to set the Bit Width, Reserve Bits, and Idle Bits and click OK button.
6. Click Carrier drop-down menu to select the number of carriers on the fiber.
7. Click the Auto-detect button to detect the CPRI configuration that is displayed on the right side of the application. The detected CPRI configuration for each SFP includes the following:
 - CPRI line rate
 - PCI (Physical Cell ID) for the LTE carrier (DL: Downlink only)
 - LTE carrier bandwidth
 - Number of antenna branches
 - Starting AxC and subsequent AxCs
 - Number of AxC groups




Figure 3-3. Auto-detect completed dialog box

8. After Auto-detect has completed, follow the steps below to map the CPRI parameters onto the appropriate RF carriers:
 - a. Uncheck the **Show auto-detect spectrum** box on the right side of the window.
 - b. Under **RF (set up carriers)** section select the **Number of RF systems:** (for e.g. two).
 - c. Click the **+** to expand the RF system.
 - d. Select the required number of **Carriers**..




Figure 3-4. 1. Site Editor tab: Setting Up with Auto Detect

Note There can be more than one carrier in a single band

- e. Select the appropriate 3GPP band number from the **Set Band** drop-down menu.
- f. Select appropriate DL EARFCN and UL EARFCN numbers and/or center frequency. Similarly choose the appropriate parameters for all the RF systems.

9. Map the CPRI parameters to the RF carriers by selecting the Antenna (found under the CPRI section on the left) and dragging and-dropping across to the appropriate RF carrier DL or UL box.




Figure 3-5. 1. Site Editor tab: Setting Up with Auto Detect

10. Click the Save... button to save the current state of the site configuration.

Note All the Site Configuration files must be saved with si_ prefix for e.g. si_xxxxx.xml.

Loading Existing Site Configuration File

Click Site Editor tab and click Load...button next to Site Config to load the existing pre-configured file.

Note

When reusing the existing site config file make sure that the physical connections are identical to the original setup.




Figure 3-6. 1. Site Editor tab: Loading an Existing Site Config file

3-2 Starting the LTE RF over CPRI Mode

In Site Editor tab click CPRI Analysis button to activate the LTE RF over CPRI mode.

The the current tab automatically switches to the Analyzer tab and, after a short delay, the IQ streams enabled in the Site Editor should be visible, similar to what is shown in [Figure 3-7](#). Note that up to 12 traces can be viewed.




Figure 3-7. Analyzer tab: Standard Relative Spectrum View (dark) with side bars



Figure 3-8. Analyzer tab: Standard Relative Spectrum View (dark) with Markers and Side bars

Right click on the spectrum to view options to choose either Dark or Light view, Show Sidebars or Hide Sidebars and Show Marker Table or Hide Marker Table.



Figure 3-9. Analyzer tab




Figure 3-10. Analyzer tab: Standard Absolute Spectrum View (dark) with Sidebars




Figure 3-11. Analyzer tab: Standard Relative Spectrum view (dark) without sidebars



Figure 3-12. Analyzer tab: Standard Absolute Spectrum View (dark) without sidebars



Figure 3-13. Analyzer tab: Multi-window spectrum view (dark)



Figure 3-14. Analyzer tab: Standard Relative Spectrum View (dark) with Markers and no sidebars



Figure 3-15. Analyzer tab: Multi-window spectrum view (dark) with markers per plot



Figure 3-16. Analyzer tab: Multi-window spectrum view (dark) with Markers and no sidebars

Note The Layout drop-down menu will allow multiple window configurations that can be configured individually.




Figure 3-17. Analyzer tab: Standard Relative Spectrum View (light) with Sidebars




Figure 3-18. Analyzer tab: Standard Absolute Spectrum View (light) with sidebars




Figure 3-19. Analyzer tab: Standard Relative Spectrum View (light) without sidebars




Figure 3-20. Analyzer tab: Standard Absolute Spectrum View without sidebars and Markers




Figure 3-22. Analyzer tab: Standard Relative Spectrum View (light) with Markers and sidebars



Figure 3-23. Analyzer tab: Multi-window Spectrum View with Markers per plot and sidebars




Figure 3-24. Analyzer tab: Standard Relative Spectrum View (light) with markers and no sidebars



Figure 3-25. Analyzer tab: Multi-window Spectrum View (light) with markers and no sidebars

3-3 Analyzer tab

The Analyzer tab consists of the following sidebars:

- Export Image...button
- Traces button
- Markers button
- Menu
 - Settings
 - Axes
 - Plot
 - Traces
 - Markers
 - Playback
 - Advanced

Settings

Use the settings menu on the right of the window to adjust the LTE RF over CPRI settings.




Figure 3-26. Settings Dialog

(The current options are accessible in the Settings dialog shown in [Figure 3-26 on page 3-17](#).

- **Layout** – Click the drop-down menu to select a single/multiple plot layout. If 1x1 layout is selected, single plot is displayed, if 2x1 layout is selected two plots are displayed.
- **Sweep** – Define the update rate of the display (note that the update rate that can be achieved depends on many other factors). Use the slider with blue rectangle to adjust the sweep time.
- **RBW/#FFT** – These both define the amount of data used per sweep which are forced to a suitable power-of-2 for the FFT. The RBW is calculated assuming a fixed sample rate of 30.72 MHz so the actual RBW is lower for narrower channel bandwidths).
- **#Points** – The number of points calculated for each trace displayed (using the detector defined for that trace).
- **#Average** – The number of trace averages used when enabled (note that this uses exponential averaging, not uniform).
- **Frequency** – When set to **Absolute**, each trace is displayed at its absolute RF frequency in the display (provided that has been set in the site config). When set to **Relative**, the absolute RF frequencies are ignored and all traces are centered at 0Hz when displayed.

- Window – Select a suitable window style for applying to the source data prior to the FFT.




Figure 3-27. Selecting a Display Type

- Spectrogram – Allocates the given (lower) portion of the plot's vertical dimension to be used when the spectrogram is enabled.
- Reset to Defaults – This button resets all the parameters to their default values. Note that the currently set parameters are displayed under the Export Image button.
- Back: Click this button to go back to the main menu.

Axes

The scale and range of the plots are determined automatically when the LTE RF over CPRI mode is started but can be adjusted manually using the Axes menu.




Figure 3-28. Axes Settings

The auto-scale option chooses suitable values for each axis based on the traces currently displayed.

Restricting the frequency range causes the detector to automatically adapt so that the number of points calculated remains constant. This effectively improves the frequency resolution of the trace display up to the maximum of the RBW (limited by the #FFT points).

Plot

The plot menu allows convenient selection of which traces to display on the currently selected plot. The available options are shown below:




Figure 3-29. Plot Settings

The traces can be filtered by which SFP they are on, or, if they have been configured, by the center frequency of the streams.

Traces

The legend for the traces displayed by the current plot is located in the bottom of the left sidebar. When selected for traces, a maximum of 12 traces can be displayed as shown in the [Figure 3-30](#).




Figure 3-30. Trace Legend

Click Show All/Hide All to view/hide all the traces. Click the eye icon to show/hide the trace.

Click **Traces** menu under the **Menu** sidebar to access the detailed trace settings. Click on a desired trace listed in the left sidebar to view the corresponding trace details in the right sidebar as shown in [Figure 3-31](#).




Figure 3-31. Trace Options

The plot and trace can be selected using the drop-down lists or by clicking the plot (in a multi-plot layout) and trace button from the left-hand side.

The trace menu has the following options:

- **Display:** Check this box to enable **Spectrogram** and **Persistence** boxes.
- **Signal source:** Select the source CPRI stream from which the trace is generated.
- **Detector:** Select the appropriate detector to generate the #Points of the trace from the #FFT bins. RMS is the default but Sample, Max Peak and Min Peak are available too.
- **Trace:** Select the appropriate type of trace. The processing applied to the #Points trace before being displayed. This allows the trace to be averaged (#Average), max hold, min hold, hold (stop updating) and normal.
- **Spectrogram:** Displays a spectrogram in the bottom portion of the plot, as shown in the example screenshot below. This can only be enabled for ONE of the current traces per plot
- **Persistence:** Displays the combination of min/max trace information.
- **Restart This Trace:** Restarts the current spectrogram.
- **Default Trace Settings:** Reverts all of the settings for the current trace to their original defaults (RMS/normal, etc.).
- **Restart ALL Traces:** Restarts all the traces and the current spectrogram.




Figure 3-32. Analyzer tab: Spectrogram View

Markers

Click the Markers button next to Traces button in the left sidebar to view the legend of up to a maximum of 6 markers. Click the eye icon to enable/disable the marker details listed in the marker table under the selected plot.



Figure 3-33. Markers Legend

Click the Markers menu found on the right sidebar to access the detailed marker settings. Click the desired Marker in the left sidebar to view the marker settings in the marker menu on the right sidebar.



Figure 3-34. Markers Settings

The plot and marker can be selected using the respective drop-down lists or by clicking the plot (in a multi-plot layout) and trace button from the left-hand side.

The marker menu has the following options:

- **Display:** Check this box to view the marker details listed in the marker table. Select the desired trace, use the right mouse button to manually move the marker on the trace.
- **Marker Type:** Click this drop-down menu to select the type of marker. **Frequency Marker** is vertical, **Power Marker** is horizontal and **Combined Marker** includes both horizontal and vertical.
- **Trace:** Expand this drop-down menu to select a desired trace.
- **Marker Delta:** Expand this drop-down menu to select a desired marker.
- **Adjustments:** Adjustments include the following:
 - **Location:** Enter the desired specific frequency for this marker or click the up/down arrows to adjust.
 - **Sample:** The marker frequency may be incremented or decremented in sample steps by clicking the left or right arrows.
- **Functions:** The Functions include the following:
 - **Peak Search:** This button places the selected marker on the strongest signal of the selected trace. Click on right/left arrow heads to move the marker to locate the next peak signal.
 - **Marker to Center:** This centers the frequency axis at the marker position such that the marker will now appear at the center of the displayed plot.
 - **Marker to Ref:** This adjusts the amplitude axis so that the marker value will be at the top of the plot.
 - **Marker Delta to Span:** The span is set to cover the frequency range between the two markers involved in the delta marker selection.

The LTE RF over CPRI spectrum display shows the markers as numbered rectangles above the traces (1). The Markers list, at the lower left, of the display shows which markers are visible, the marker table (2), at the bottom, shows the frequencies and traces that the marker is involved in, and the Marker parameters (3), at the right of the display, govern the various aspects of the markers.



Figure 3-35. Analyzer tab: LTE RF over CPRI Markers

Enabling a marker displays a vertical line at the marker’s frequency and a cursor at the trace’s value for that frequency. Figure 3-35 shows two such markers, 1 and 3. The marker ID is displayed at the top of the plot, above its vertical line, and in the color for that marker.

Each marker can calculate a delta to any of the other markers as well as its absolute value (for which it needs the delta amplitude adding to the table).

The marker table is displayed at the bottom of the window.




Figure 3-36. Marker table

It can be pinned so that it always shows; unpinned it displays only when the Marker menu is selected.

Playback

Traces can be captured and played back (normal, fixed, or slow motion). A 'snapshot' screen image can also be saved.




Figure 3-37. Capture and Playback

- Save Capture:** Captures the entire trace data, that may not be fully visible on the screen, for playback in a file with your choice of name and path.
- Load Playback:** Lets you choose a file for playback from any accessible location. Note that the saved playback file is displayed under LOAD playback button.
- Playback Mode:** Normal playback mode—simulated live operation where each update is generated by randomly selecting a different point from the captured playback data.
- Fixed—effectively "stops" the playback at a specific point in the captured playback data by using a fixed start sample for each update. The start sample can be varied over one CPRI frame (10ms) 0-38400, units are CPRI basic frames (3.84 MHz).
- Slow Motion— each update is generated by automatically incrementing the start point of the captured playback data by a defined amount. The speed is adjusted by changing the size of the increment for each update. Units are in CPRI basic frames and the range of values from 2 to 500 (default of 100).

Advanced (Set the Noise Floor)

If the calibration factor for the uplink being measured is not known, the Advanced option can measure the noise floor of the RRH under test from the CPRI data. The measurement looks for quiet (minimum power, idle) periods within the LTE signal, and averages them to calculate the noise floor of the signal. When the calibration completes, you may transfer the measured value to the calibration settings.

To measure the noise floor:

1. Click Advanced menu.




Figure 3-38. Advanced Menu

2. Click Noise Floor button.
3. Click Select a Plot.
4. Set the options for the selected Plot.
 - Max Iterations: Increments of one from 10 to 10000 (default of 5000).
 - Timeout for Min: Increments of one second, from 1 to 60 seconds (default of 30).
 - Averaging: Increments of one from 10 to 1000 (default of 250).
5. Click the Reset to Defaults button to reset the set values.
6. Click the Measure Noise Floor button to start the measurement.

7. After the time set in the Timeout for Minimum elapses, Set dBm Calibration button appears.




Figure 3-39. Advanced Settings After Calibration Completes

8. Click Set dBm Calibration button to apply the noise floor (dBm) to the vendor and LTE air standard as specified in the current Site Editor file.
9. Click OK button to update the calibration setting.




Figure 3-40. Setting the Noise Floor with Calculated Noise floor

10. Click OK button to exit.




Figure 3-41. Calibration Updated Dialog box

11. Go to File > Preferences > General > dB Units to verify the new conversion value and click Apply button..




Figure 3-42. DB Units conversion

This is the LTE RF over CPRI trace display after the calibration is successful. Note the addition of the red line about -108 dBm.




Figure 3-43. Noise Floor Shown After Calibration

12. This message displays when the calibration is canceled:




Figure 3-44. Calibration Canceled Dialog box

Export Image...

In the Analyzer tab follow the steps below to capture the LTE RF over CPRI trace:

- Click Export Image... button at the top left of the window to view the Image Capture dialog box.




Figure 3-45. Image Capture Status




Figure 3-46. Image Capture for LTE RF over CPRI

- Click Change Filename... button to change the name or location of the captured file.
- Click Open File Location button to view the location of the file.
- Click one of the radio buttons under Image Selection section to choose the required portion of the application interface.
- Click Capture Image button to capture the screenshot of the plot.
- Notice a change in the status after the image capture is completed.




Figure 3-47. Image Capture Status

- Click OK button to close the dialog box.

Zoom

While the LTE RF over CPRI is running, it is possible to zoom into regions of the currently selected plot.

Note That this is a video zoom only so it does not change the way the trace is being determined.

To zoom:

1. Use the mouse to define the region while holding the left mouse button down.




Figure 3-48. Analyzer tab: Frequency Axis Zoom (Horizontal Axis)

Default is to zoom frequency-axis (horizontal) only.

- 2. To zoom the power axis (vertical) only, hold the SHIFT key down in addition to the mouse operation.




Figure 3-49. Analyzer tab: Power Axis Zoom (Vertical Axis)

3. To zoom both axes simultaneously, hold the CTRL key down in addition to the mouse operation and define a box.




Figure 3-50. Two-Axis Zoom

4. Double-click on the plot to reset the display to its normal view.

3-4 Stopping/Restarting LTE RF over CPRI Mode

Click the red **Stop** button on the top of the window, to stop the LTE RF over CPRI mode. This completely stops the data acquisition and the processing/display of all traces. Or use the red **Stop** button on the bottom right of the window.




Figure 3-51. Stopping LTE RF over CPRI

Click the green CPRI Analysis button on the top of the window or green START button in the bottom right to restart the processing and data acquisition.




Figure 3-52. Restarting LTE RF over CPRI

Chapter 4 — Making PIM-over-CPRI Measurements (Option 754)

Option 754 (requires Option 752) measures the PIM phenomena and Option 755 provides more in-depth analysis (analytics). See [“Upgrading IQ Fiber Master” on page 2-11](#) for information about upgrading to this option.

Start the PIM analysis with the 1. Site Editor tab to make sure that the analyzer correctly configures the sensor and correctly analyzes the data from the IQ and baseband streams. This information contains the vendor settings, AxCs, number of IQ streams, and the LTE air standard (bandwidth). Continue with setting up the test scenarios on the 2. Roster Editor tab then on the 3. Run Tests tab running tests on a selected scenario, optionally ending with PIM Location calculations and Cross Sector analysis.

4-1 Preparing the Site's Details (Site Editor)

Refer to [Section 3-1 “Preparing the Site's Details \(Site Editor\)” on page 3-1](#). The application needs to know specific parameters for the cell site under test. These details can be entered or created as described in this section.

Create Roster Files

To create the roster files follow the steps below:

1. Click 2. Roster Editor tab.
2. Load the saved Site Config file to test PIM.
3. Click the Auto Generate button.
4. Click the Save... button on the right most side of the window, to create and save the roster file.

Note All the Roster files must be saved with tr_ prefix for e.g. tr_XXXXX.xml.

To add or delete a test manually, click the Add Test or Delete Test buttons on the lower left of the window.




Figure 4-1. 2. Roster Editor tab

Loading Existing Site Configuration and Roster Files

To test PIM over CPRI measurements follow the steps below:

1. Click 3. Run Tests tab.
2. Click the Load... button next to the Site Config to load the correct si_xxxx.xml file for the current site.
3. Click the Load... button next to Roster File to load the correct tr_xxxx.xml file for the current site.
4. Select the appropriate test under the Roster Detail table.
5. Click the Config Check radio button under the Selected test section. Note that the other radio buttons will be disabled until the config check is passed. Refer to [Section 4-3 “Configuration Check” on page 4-4](#) for more information on the config check.
6. Click Run: config check button on the top of the window.
 - Select PIM Level radio button under the Selected Test after the config check is passed.
 - Click the Fiber Diagram button on the upper right of the window to verify if the optical fiber connections are correct.
 - Fix the connections that are shown in yellow/red color. Note that connections shown in green are correct.

Note

When reusing the existing site config and roster files make sure that the physical connections are identical to the original setup.




Figure 4-2. 3. Run Tests tab: Loading existing site config and roster files

4-2 Select a Test

When the text or analyzer instructs you to select a test, choose from this list:




Figure 5 Select a Test to Run

4-3 Configuration Check

To perform the configuration check follow the steps below:

1. Click 3. Run Tests tab, load the appropriate site config and test roster files.
2. Select an appropriate test scenario from the Roster Detail section.

Note

Choosing an appropriate test scenario facilitates the specific uplink and down link frequency combination(s) for PIM over CPRI measurements

3. Click the Config Check radio button.
4. Click Run: config check button on the top of the window.




Figure 4-1. 3. Run Tests tab: Config Check test

If the config check fails follow the steps below:

1. Click the Fiber Diagram button on the top right, to open the fiber diagram window relevant to the selected test.




Figure 4-2. Run: Config Check: Config Check test - Fail




Figure 4-3. 3. Run Tests tab: Fiber Diagram

2. Use the fiber diagram as a reference to fix the connections of the optical fibers between the IQ Fiber Analyzer and the optical tap as shown in the [Figure 4-4 on page 4-6](#).

3. In the fiber diagram click the SFP icon with a red connection to make the SPF LED to flash..

Note

Clicking on the SPF with a red connection on the fiber diagram will cause the SPF LED on the IQ Fiber Master to flash, and the red connection in the fiber diagram will also flash.

Note

Uplink (UL) fiber is ALWAYS connected to SFP1 on the IQ Fiber Master for PIM over CPRI measurement.




Figure 4-4. Fiber Diagram

4. After fixing the incorrect fiber connections click Run: config check button again to verify if the config check passes.




Figure 4-5. Run: Config Check: Config Check test - Pass

Report

You may add the results of a configuration check to the report. To add them, click the Add to Report button. The configuration results are added to the end of the report. See [Appendix A, “Reports”](#) for more information about reports.




Figure 4-6. 3. Run Test tab: Add to Report




Figure 4-7. Add to Report - Config Check Test Results

4-4 PIM Measurement

To run a PIM over CPRI measurement follow the steps below:

1. Select an appropriate test scenario under Roster Detail section.
2. Select PIM Level radio button under the Selected Test section.
3. Click the Run: PIM level button on the top of the window.
 - The PIM Level measurement begins for each antenna port (defined in the Roster Editor).




Figure 4-8. 3. Run Test tab: PIM Level Measurement

The PIM level test will take a little longer than a traditional RF PIM test, because the algorithm is synchronizing all of the down link signals to each individual uplink signal and determining if there are down link elements appearing in the uplink that are causing PIM.

The first PIM over CPRI measurement will take longer due to the synchronization, but each subsequent measurement will be much faster since it doesn't need to re-synchronize.




Figure 4-9. 3. Run Tests tab: PIM Level Measurement Test Results

PIM level test results consists of the following parameters:

- The Impacted UL/Antenna field column defines the results for each individual antenna (AxC) under test
- Pass/Fail result is based on the measured PIM level
- Measured PIM level
- RSSI
- Rx Desense is the amount of noise in the uplink due to PIM
- PIM source location determines if PIM is internal or external to the antenna system

4-5 Analyzer: PIM over CPRI

The PIM over CPRI test shows the (wanted) UL and PIM spectra and can be used as a visual indication of PIM impacting the UL carrier.

To see the individual uplink spectrum traces with their PIM components, follow the steps below:

1. Click the Analyzer tab.

By default, the Analyzer tab will display the worst PIM spectrum trace defined by the Antenna (AxC) Select radio button. The green trace is the actual RF uplink spectrum, the orange trace is the estimated PIM within the uplink spectrum.

2. Select a different Antenna Select radio button at the bottom of the window, to see a different uplink (AxC) trace.




Figure 4-10. Analyzer tab: PIM over CPRI

Main Buttons and Controls

You can see that the Stop button, Review Results, and Save Report buttons are activated (Fiber Diagram is not part of this topic). Click Stop to make data available to the report; click the now-active Add to Report button to add trace data to the report. See [Appendix A](#) for more about reports.

Context Menu

Right-click in the PIM over CPRI trace display to show the context menu that allows you to alter the appearance of the trace display.




Figure 4-11. Trace Context Menu

Signals

This switches on and off UL and PIM which also removes their entries from the legend.

Legend

Turns the Legend on and off.




Figure 4-12. Legend off (Display in Light Phase)

Light/Dark

Changes the display from colored-traces-on-black (the color scheme in which most of the figures in this publication are depicted) to -on-white. The colors of the remainder of the display are unchanged.




Figure 4-13. PIM Display: Light Phase

Zoom

- Zoom Full: Returns the display to its non-zoomed state.
- Zoom X-axis: Zooms the display only on the x-axis by the click-and-drag technique in the x-axis direction only.
- Zoom Y-axis: Zooms the display only on the y-axis by the click-and-drag technique in the y-axis direction only.
- Zoom Box: Zooms the display in the x- and y axes in a box defined by the click-and-drag technique in both the y- and x-axes direction.

Time-Power/Spectrum

These change the display mode between Spectrum (most of the figures in this chapter) and Time-Power.




Figure 4-14. Time-Power Display Mode of PIM over CPRI

Points

Changes the number of points displayed from several options, with 1 k the default (with a dot showing which option is selected).




Figure 4-15. Trace Points Selecting

AutoScale/Scaling

These change the trace display regardless of what mode it is in:

- **AutoScale** – Accommodates all of the data points. (Some data might not be displayed in this mode.)
- **Set Scaling** – (AutoScale must be off) displays a dialog so that the maximum Y-axis value (range -100 through 200) and the dB per division (range of 1 through 100) can be specified.

Yunits

(Available only with Time-Power.) This option changes the display mode between dB and Linear.

4-6 PIM Location, Distance, and Calibration

Introduction

To enable PIM location measuring follow the steps below:

1. Perform the config check and a PIM Level tests of the selected roster detail. If the tests detect PIM, it enables the PIM Location radio button.




Figure 4-16. 3. Run Test tab: PIM Location Test

2. Click the Run: PIM location button at the top to start a PIM Location (DTP) measurement. Notice the current tab automatically switches to PIM Location tab.
 - Notice that the center distance value shown in the figure 4-18 will be large since it is uncalibrated.
 - The center position is the antenna.




Figure 4-17. PIM Location tab: Live PIM Location- Uncalibrated

PIM Calibration

1. The software will select the antenna with the strongest PIM measurement by default. The PIM level is normalized to zero and a well-defined peak will be evident for a loud PIM source. The initial measurement is uncalibrated and will include any delay introduced by the RRH, filters and cabling etc.

Note

The antennas with PIM are determined from the PIM measurement and note that antennas with no PIM are not included in display

2. Place a known PIM source (as shown in the figure 4-19), on the antenna radome to calibrate (zero out) the system and account for any delays introduced by the RF path.



Figure 4-18. PIM Source (Calibration Device)

3. After calibrating remove the PIM source from the antenna radome.
4. Click the green **Restart Measurement** button to find the PIM location of internal or external PIM sources.
 - The Live PIM location measurement is shown in blue and the average PIM location measurement is shown in gray/green as shown in the figure 4-20.
 - A negative distance value indicates an internal PIM source (i.e. between RRH and antenna).
 - A positive distance value indicates an external PIM source.




Figure 4-19. PIM Location

5. Run the PIM location measurement 20 times to obtain a high confidence measurement.
 - The average PIM location measurement value turns green when the number of completed measurements reaches 20.
 - The software will keep track of the average number of measurements as shown in the figure 4-21.




Figure 4-20. PIM Location Progress

The calibrated data is shown as the red trace, the individual live trace is shown as a blue trace and the average of all the completed traces is shown as the green trace.



Figure 4-21. PIM Location tab: PIM Location New Data

Note

Calibration steps cannot be saved to the report.

After the PIM source has been mitigated click the **Restart Measurement** button to locate a different PIM source.

Note

The PIM location measurement is a synchronized time based measurement. It is necessary to click **Restart Measurement** button after locating and mitigating every single PIM source, as it requires a re-synchronization for each PIM source.

6. Click Add to Report to add the revised PIM Location display to the report.

The power delay profile is shown, with the position along the x-axis of the peak indicating the distance (given free space propagation) to the dominant PIM source.

Note

In the case of an internal fault, no correction is made to account for velocity factor within the cabling as that is specific to the cable type used.




Figure 4-22. PIM Location tab: Add to Report

Note

The Add to Report button is enabled after the PIM Location has completed at least one full measurement cycle.




Figure 4-23. PIM Report: PIM Location Data

Auxiliary PIM Location Information

The figures in this section show various states of the PIM Level testing results.




Figure 4-24. PIM Level Test Results: No PIM

The figure below shows a PIM failure (PIM found) and shows that PIM Location is activated.




Figure 4-25. PIM Level Test Results: One Antenna with PIM Failure

Select PIM Location, then click Run: PIM Location button for the analyzer to calculate distance to PIM. At this point you'll have sector and distance information to the strongest PIM source.




Figure 4-26. Selecting PIM Location Test

Chapter 5 — PIM Analytics (Option 755)

Option 755 (requires Option 752 and 754) provides deeper analysis for the PIM measurements. See [“Upgrading IQ Fiber Master” on page 2-11](#) for information about upgrading to this option.

5-1 PIM vs Time (Long-term Monitoring)

PIM vs Time tab shows PIM level against time for all antenna ports that are measuring PIM. The term for which the monitoring can run is limited only by the data space available on the computer. A daily graph is saved to a user-defined directory (see [File>Preferences>General Settings](#)). A summary report for the duration of the test is also saved detailing maximum, minimum, and mean PIM with duration, time and date. A saved file can be loaded and replayed.



Figure 5-1. PIM vs Time Graph

Events...

An events log is created and can be saved as a CSV file. Click **Events...** button to display the report, and click **Save...** button to save the report. (The report is saved independently of the PIM report.)

Events List

Load... Save... Close

Antenna	Type	Timestamp	Value
Ant1	start	19/Aug/2022 11:21:34	-102.400 dBm
Ant1	nopim	19/Aug/2022 11:21:42	-102.400 dBm
Ant2	nopim	19/Aug/2022 11:21:45	-102.400 dBm
Ant3	nopim	19/Aug/2022 11:21:47	-102.400 dBm
Ant4	nopim	19/Aug/2022 11:21:49	-102.400 dBm
Ant4	fail	19/Aug/2022 11:22:44	-80.802 dBm
Ant4	nopim	19/Aug/2022 11:22:47	-102.400 dBm

Figure 5-2. Events List

An Events file may also be loaded. This allows the user to load and check/analyze any previously saved events log. It is a CSV file so it may be loaded into Excel or any spreadsheet program.

Note

Note that the active buttons shown in figure 5-3 are enabled only after the PIM vs Time measurement has been stopped (at least one completed PIM measurement cycle is needed).




Figure 5-3. PIM vs Time active buttons

Clear

Clears the graph of all data and picks up recording from that moment.

Load File...

Loads a saved file for replaying.

Save File...

Saves data to a file for replaying later.

Previous/Next

Allows the user to step back or forward to view a specific day's worth of data

Date/Summary

Allows the user to select and display results for a specific day in the drop-down menu. Summary provides a summary for ALL days.

5-2 PIM Distribution

The PIM Distribution tab shows a CDF plot depicting the percentage of measurements that exceed the defined PIM level threshold, in dBm, for each antenna port under test.




Figure 5-4. PIM Distribution tab

5-3 PIM Daily

The PIM Daily tab shows a histogram, over a 24-hour period, for each antenna that has PIM. A summary of maximum and minimum PIM with duration is shown at the top left of the graph.




Figure 5-5. PIM Daily tab: PIM Daily Report

5-4 Heat Map

The heat map represents the relative contribution (in dB) of each transmitting antenna port to the total measured PIM power.



Figure 5-6. Heat Map tab

Click Interpret Heatmap button to view different scenarios and descriptions of the possible effects of how individual transmit ports can affect individual receive ports due to PIM. It can be used to complement the PIM Location measurement.




Figure 5-7. Interpret Heapmap: Hot Antennas on top - External PIM; Specific Antenna port below- Internal PIM

Appendix A — Reports

A-1 PIM over CPRI Reports

View the report at any time by clicking **Review Results** button. The reports for PIM are not automatically saved or written to a PDF format. Click the **Add to Report** button when an action completes to write its results to the report. Click **Save...** on the Report view or **Save Report** on the main window to save the report to a PDF file. The parts of the report are described in this section.



Figure A-1. Add to Report Buttons

New Report

1. Click the **Review Results** button to view the current report.
2. Click the **New** button to start a new report. You can add any results to a new (blank) report.




Figure A-2. New PIM Report

All results are appended to the end of the report.

Report Header

The report header contains the Site, Operator, and Instrument details. Note the footer -End of PIM Report- which marks the last entry of the report.

Report [new]

NewSave...Settings...Close

PreviewPrint

Passive Intermodulation (PIM) Report

Site Details

Site:	AA1234
Report Created:	December 10, 2019 09:02
Last Updated:	December 10, 2019 09:02
Operator:	bobobob
Contact Phone:	+
Company Name:	

Instrument Details

Software Version:	IQ Fiber Master v1.7.4.2 build 7
Firmware Version:	
Sensor Id:	Sensor Emulation
Test Roster:	tr_user.xml

- End of PIM Report -

Figure A-3. Report Header--Online Version

From the online version, you can save, preview, and print the PDF version.

Check Configuration

When a Config Check is performed prior to a PIM over CPRI test, the **Results** pane of the **Run Tests** tab display the results (which can be detailed or summarized). Click the **Add to Report** button to add Config Check results to the end of the report. Note the **TEST 1: alpha** highlighted, header line. Similar lines are added for other tests.




Figure A-4. Config Check Report (top and bottom portions)

The Config Check portion of the report contains an SFPn pass/fail header with details (measurements and expected values) about Optical Connectivity, CPRI Connectivity, IQ Stream Capture RSSI/TSSI, Bandwidth, and LTE ID and TX configuration. Note the line **Passed configuration check: Ready for test**.

PIM Level

After a PIM Level (PIM over CPRI) test is initiated, click **Add to Report** to write all of its results to the report. Note the time-stamp right after the PIM Level heading. Each time the **Add to Report** button is clicked a new PIM Level heading and data are added to the report.



Figure A-5. PIM Report: PIM Level

Pass/Fail

For each UL/Antenna, there are pass/fail status, PIM level, the PIM threshold (dBm or dBFS), and an indication of PIM location (internal/external).

PIM vs. Time

A PIM vs. Time report provides data about when a PIM occurs on the 24-hour clock.

To get a PIM-vs-Time report,

1. Run the PIM Level test.
2. Choose either a or b:
 - a. Click Add to Report and scroll down to the Long Term Monitor figure.
 - b. Click PIM vs Time tab.



Figure A-6. PIM Report: PIM versus Time

Report Parameters

Start: The time of the start of the PIM recording. The time is only reported to the nearest minute.

Stop: The time of the stop of the PIM recording. The time is only reported to the nearest minute.

Duration: The time elapsed for the PIM recording. The time given is in hour:minutes:seconds.

Antenna Table: Use the entries in the Antenna table to view detailed data about PIM events.

PIM Distribution

The PIM distribution tab shows all the PIM sources relative to the threshold. To view a PIM Distribution:

1. Run the PIM Level test.
2. Choose either **a** or **b**:
 - a. Click Add to Report and scroll down to the Long Term Monitor figure.
 - b. Click the PIM Distribution tab.




Figure A-7. PIM Report: Distribution

PIM Daily (Long-term Monitoring)

To get a meaningful PIM Daily report, the PIM Level test must run long enough.




Figure A-8. PIM Report: Daily (Long-term) Monitoring

The graph covers a 24-hour period.

Heat Map

The heat map is most useful for antennas that fail the PIM test. The report contains the heat map matrix with summaries.




Figure A-9. PIM Report: Heat Map

PIM Location

PIM location is not included in the prepared report. See“PIM Location, Distance, and Calibration” on page 4-15 for more information about PIM location.

A-2 LTE RF over CPRI

Here is a typical LTE RF over CPRI display.



Figure A-10. LTE RF over CPRI display

This view cannot be added to PIM report through the app; however, the image may be exported to a PDF file. You can zoom in on the x-axis to view more detail at a frequency, either click and drag or use the scroll wheel to adjust the zoom

To exit double-click anywhere in the trace area (or use the scroll wheel).



10580-00467



C



Anritsu utilizes recycled paper and environmentally conscious inks and toner.

Anritsu Company
490 Jarvis Drive
Morgan Hill, CA 95037-2809
USA
<http://www.anritsu.com>