/inritsu

Overcoming High-speed Interconnect Challenges

By Jon Martens and Bob Buxton

Overview

Cloud computing, smart phones, and LTE services are causing a large increase in network traffic. The instantaneous traffic rates at internet data centers have reached 1 Tbit/s. To support this increased traffic, speed of IT equipment – such as those used in high-end services in data centers – must be increased. Some of these higher rate standards are shown in Table 1. Device interconnects are causing transmission bottlenecks in many of these applications.

Standard	Data Rate	Number of Lanes	
CEI-25G-SR	19.90 to 28.05 Gbit/s	1 to N	
CEI-25G-LR	19.90 to 25.80 Gbit/s	1 to N	
IEEE802.3ba 100GBASE-LR/ER	25.78125 Gbit/s	4	
32G Fiber Channel	28.05 Gbit/s	1	
Infiniband 26G-IB-EDR	25.78125 Gbit/s	1 to N	



This white paper discusses challenges introduced at these higher data rates and how Vector Network Analyzers can help meet these challenges.

Challenges facing signal integrity engineers

The drive to higher bit rates and ensuring compliance with the standards raises many challenges for signal integrity engineers. These challenges may be summarized as follows:

Cost/performance Trade-Offs

Higher data rates introduce new design challenges such as conductor skin effects and dielectric losses on PC boards, along with the design trade-offs related to choices of vias, stackups, and connector pins. Evaluating a selection of backplane materials and the impacts of various structural designs requires accurate measurement in both frequency and time domain. Accurate measurements provide the confidence to make cost/performance trade-off decisions. The aim is to evaluate the impact of interconnects on eye closure. Figure 1 shows an example of backplane impact on the eye diagram.



Figure 1. Example of a data signal with integrity degradation caused by frequency-dependent loss and group delay effects in the higher frequency bands resulting from skin effects and dielectric losses on the PC board.

Locating Defects

Sometimes problems are caused by vias, stackup issues, and connector pins. However, frequency domain data alone is not enough; it is necessary to transform that data into the time domain in order to locate the position of particular problems. Passive components, as well as near-end and far-end points between daughter boards must be measured in the frequency and time domains to assure that the transmission characteristics at each measurement point meet the standards. Using the best resolution capability improves your ability to locate discontinuities, impedance changes and crosstalk issues. In addition, many of the structures today are electrically large and put pressure on the measurement solution's alias-free range.

Correlation Between Simulation and Measurement

Accurate models help accelerate your design cycle. However, models are only as good as the quality of data fed into them. Poor causality, where outputs can appear to happen in negative time, can be caused when there is insufficiently high frequency content in the data fed into models. Poor causality results in reduced confidence in simulations, potential convergence problems and inaccuracies. Conversely, poor low frequency information leading to DC extrapolation errors also degrades model accuracy and leads to poor agreement with 3-D EM simulators.

Fixture De-Embedding

There are many situations where it may not be possible to connect directly to the device under test. In this case it is necessary to de-embed the DUT from the surrounding test fixtures. The opposite is sometimes required: it may be useful to take a device and assess its performance when it is surrounded by other networks. Figure 2 illustrates this.



Figure 2. De-embedding can be used to remove test fixture contributions, modeled networks and other networks described by S-parameters (S2P files) from the measurements. Embedding is the reverse process.

However, many passivity and causality problems are due to poor calibration and de-embedding methods. In addition, high fixture loss may affect the accuracy and repeatability of de-embedding.

Solving Today's Challenges

Fortunately the latest Vector Network Analyzer technology can provide a solution to these challenges.

		Primary VNA Performance or Feature			
		Frequency Range	Time Domain	De-embedding techniques	
Challenge	Cost/performance Trade-Offs	Х			
	Location of defects	Х	Х	Х	
	Correlation Between Simula- tion and Measurement	Х	х		
	Fixture De-Embedding			Х	

Table 2. Relevance of aspects of VNA performance to SI Engineer Challenges.

Maximizing Available Frequency Range

The lower and the upper frequency limits of an S-parameter characterization of a backplane or other interconnect both have impacts on the quality of the data and any subsequent modeling, but for different reasons. The following will consider each in turn.

The upper frequency range is what usually comes to mind first and many people perform measurements to the 3rd or 5th harmonic of the NRZ clock frequency. For a 28 Gbps data rate this means either 42 GHz or 70 GHz stop frequency for an S-parameter sweep. There is another way to think about the requirement for the upper measurement frequency; that is from the viewpoint of causality. When S-parameter data is transformed into the time domain for use in further simulation, causality errors can arise; these are essentially where events appear to result in negative time. This can lead to convergence problems in the simulations and inaccuracies in modeling larger-scale subsystems. While massaging of the frequency domain data can reduce these problems, there are potential issues related to distorting the actual physical behavior of the device. It is therefore often safer and more accurate to use as wide a frequency range as possible up to the point where repeatability and related distortions (e.g., the DUT starts radiating efficiently making the measurement very dependent on the surroundings) obscure the results. The desire for wider frequency range data becomes more compelling as faster and more accurate transients are being studied in the higher level simulations.

The lower frequency bound of the sweep is just as important. Model accuracy generally improves the closer that data is acquired to DC. For example, consider the case where the measured S-parameter data for a backplane is fed into a software model in order to estimate the impact of that backplane on the eye diagram. Figure 3 shows what the eye diagram estimate will look like where the low frequency data has some error. In this example, it was found that a 0.5 dB error distribution at lower frequency (10 MHz) on transmission could take an 85% open eye to a fully closed eye. Since mid-band (10 GHz) transmission uncertainty may be near 0.1 dB depending on setup and calibration – and higher at low frequencies – this eye distortion effect cannot be neglected. Figure 4 shows what the resulting eye diagram will look like if the low frequency measurement data is of good quality. This prediction correlates very well with the actual eye diagram measured using an oscilloscope as shown in figure 5.



Figure 3. With 0.5 dB insertion loss error at 10 MHz.



Figure 4. Accurate low frequency S-parameter data reveals an open eye diagram.

Since the non-transitioning parts of the eyediagram are inherently composed of low frequency behavior, the sensitivity of the calculation to the low frequency S-parameter data makes sense. Because the low frequency insertion losses tend to be small, a large fixeddB error (which is how VNA uncertainties tend to behave) can be particularly damaging.



Figure 5. Measured eye diagram.

Optimizing Time Domain Resolution

The time domain performance of a VNA is critical when trying to locate defects. In general, the wider the frequency-sweep, the better the time and hence spatial resolution. Figure 6 shows the differences in time domain resolution for three different frequency spans, 40, 50 and 70 GHz.

Resolution is maximized when Low-Pass time domain mode is used. This mode also permits characterization of impedance changes on the backplane. Low-Pass mode requires a quasiharmonically related set of frequencies that start at the lowest frequency possible. A DC term is extrapolated that provides a phase reference, so the true nature of a discontinuity can be evaluated. Hence, the lower frequency that the sweep can commence, the better the extrapolation of the DC term.



Figure 6. Getting the best time domain resolution requires the most data points, narrowest frequency step size, and widest possible frequency bandwidth.

Using Flexible De-Embedding Techniques

Fixtures and connectors to devices under test come in many forms and poor de-embedding can lead to both passivity and causality errors. Causality errors were discussed above while passivity errors occur when it appears that a passive device has gain or is otherwise converting energy. The passivity error caused by small de-embedding problems can be subtle but it can have large effects on follow-on modeling or simulation as suggested by the earlier eye-diagram example. The solution is to have a wide range of techniques available that can handle different situations. The following table lists several extraction methods for de-embedding.

Method	Standards complexity	Fundamental accuracy	Sensitivity to standards	Media preferences
Type A (adapter removal)	High	High	High (refl.)	Need good reflect and thru stds
Type B (Bauer-Penfield)	Medium	High	High (refl.)	Only need reflect standards, not great for coupled lines
Type C (inner-outer)	High	High	Medium (refl.)	More redundant than A so less sensitive but need good stds still
Type D (2-port lines)	Medium	Low for low-loss or mismatched fixtures	Medium (line def'n.)	Only need decent lines; match relegated to lower dependence; can handle coupled lines
Type E (4 port inner-outer)	High	High	Medium (refl.)	Somewhat redundant (like C) but need decent standards. Best for uncoupled multiport fixtures
Type F (4-port uncoupled)	Medium	Low for low-loss or mismatched fixtures	Medium (line def'n.)	Only need decent lines; match relegated to lower dependence; can handle coupled lines
Type G (4-port coupled)	Medium	Low for low-loss or mismatched fixtures	Medium (line def'n.)	Only need decent lines; match relegated to lower dependence; can handle coupled lines well

Table 3. De-embedding Methods.

As can be seen there are many extraction methods available and the choice is somewhat context dependent. For signal integrity applications, the most likely will be type F or G. There is not space in this white paper to go into the details for all of these methods. They will be covered in more detail in a future white paper.

Conclusion

Higher data rates require accurate measurements to provide the confidence needed to make performance/cost decisions. Measurement tools must help shorten design times and ensure stable signal integrity in mass production. Vector Network Analyzers play a key role in helping the signal integrity engineer to meet the challenges of increasing data rates, making appropriate cost/performance trade-offs, achieving correlation between simulations and measurement and extracting the effect of fixtures. When selecting a VNA, the user should be looking at characteristics such as upper and lower frequency limits, performance in time domain and a wide selection of advanced calibration and de-embedding techniques.

<u>/inritsu</u>

United States

Anritsu Company 1155 East Collins Blvd., Suite 100, Richardson, TX 75081, U.S.A. Toll Free: 1-800-267-4878 Phone: +1-972-644-1777 Fax: +1-972-671-1877

Canada

Anritsu Electronics Ltd.

700 Silver Seven Road, Suite 120, Kanata, Ontario K2V 1C3, Canada Phone: +1-613-591-2003 Fax: +1-613-591-1006

Brazil

Anritsu Eletrônica Ltda. Praça Amadeu Amaral, 27 - 1 Andar 01327-010 - Bela Vista - São Paulo - SP - Brazil Phone: +55-11-3283-2511 Fax: +55-11-3288-6940

Mexico

Anritsu Company, S.A. de C.V. Av. Ejército Nacional No. 579 Piso 9, Col. Granada 11520 México, D.F., México Phone: +52-55-1101-2370 Fax: +52-55-5254-3147

United Kingdom

Anritsu EMEA Ltd. 200 Capability Green, Luton, Bedfordshire, LU1 3LU, U.K. Phone: +44-1582-433280 Fax: +44-1582-731303

France
 Anritsu S.A.

2 avenue du Québec, Bâtiment Iris 1- Silic 612, 91140 VILLEBON SUR YVETTE, France Phone: +33-1-60-92-15-50 Fax: +33-1-64-46-10-65

Germany
 Anritsu GmbH

Nemetschek Haus, Konrad-Zuse-Platz 1 81829 München, Germany Phone: +49-89-442308-0 Fax: +49-89-442308-55

Italy Apritsu

Anritsu S.r.I. Via Elio Vittorini 129, 00144 Roma, Italy Phone: +39-6-509-9711 Fax: +39-6-502-2425

Sweden
Anritsu AB
Borgarfjordsgatan 13A, 164 40 KISTA, Sweden
Phone: +46-8-534-707-00
Fax: +46-8-534-707-30

 Finland Anritsu AB

Teknobulevardi 3-5, FI-01530 VANTAA, Finland Phone: +358-20-741-8100 Fax: +358-20-741-8111

Denmark
 Apritsu A/S (Sorvi

Anritsu A/S (Service Assurance) Anritsu AB (Test & Measurement) Kay Fiskers Plads 9, 2300 Copenhagen S, Denmark Phone: +45-7211-2200 Fax: +45-7211-2210

• Russia Anritsu EMEA Ltd. Representation Office in Russia Tverskaya str. 16/2, bld. 1, 7th floor. Russia, 125009, Moscow

Russia, 125009, Moscow Phone: +7-495-363-1694 Fax: +7-495-935-8962

• United Arab Emirates Anritsu EMEA Ltd.

Dubai Liaison Office P O Box 500413 - Dubai Internet City Al Thuraya Building, Tower 1, Suite 701, 7th Floor Dubai, United Arab Emirates Phone: +971-4-3670352 Fax: +971-4-3688460

Singapore
 Anritsu Pte. Ltd.
 O Alexandra Terrace, #02-08, The Comtech (Lobby A)

60 Alexandra Terrace, #02-08, The Comtech (Lobby A Singapore 118502 Phone: +65-6282-2400 Fax: +65-6282-2533

India

Anritsu India Private Limited 2nd & 3rd Floor, #837/1, Binnamangla 1st Stage, Indiranagar, 100ft Road, Bangalore - 560038, India Phone: +91-80-4058-1300 Fax: +91-80-4058-1301

• P.R. China (Shanghai)

Anritsu (China) Co., Ltd. Room 1715, Tower A CITY CENTER of Shanghai, No.100 Zunyi Road, Chang Ning District, Shanghai 200051, P.R. China Phone: +86-21-6237-0898 Fax: +86-21-6237-0899

P.R. China (Hong Kong)

Anritsu Company Ltd. Unit 1006-7, 10/F., Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong, P.R. China Phone: +852-2301-4980 Fax: +852-2301-3545

Japan

Anritsu Corporation 8-5, Tamura-cho, Atsugi-shi, Kanagawa, 243-0016 Japan Phone: +81-46-296-1221 Fax: +81-46-296-1238

Korea

Anritsu Corporation, Ltd.

502, 5FL H-Square N B/D, 681 Sampyeong-dong, Bundang-gu, Seongnam-si, Gyeonggi-do, 463-400 Korea Phone: +82-31-696-7750 Fax: +82-31-696-7751

Australia

Anritsu Pty. Ltd. Unit 21/270 Ferntree Gully Road, Notting Hill, Victoria 3168, Australia Phone: +61-3-9558-8177 Fax: +61-3-9558-8255

Taiwan

Anritsu Company Inc. 7F, No. 316, Sec. 1, NeiHu Rd., Taipei 114, Taiwan Phone: +886-2-8751-1816 Fax: +886-2-8751-1817



®Anritsu All trademarks are registered trademarks of their respective companies. Data subject to change without notice. For the most recent specifications visit: www.anritsu.com