

## Upgrading Firmware

The Network Master series (MT9090A hereafter) has a firmware upgrade function for adding new functionality and solving operation bugs. The new firmware upgrade is executed when the MT9090A reads an update installer file released by Anritsu. This document explains how to update the firmware of the following products connected to the MT9090A.

**MU909060A1, MU909060A2, MU909060A3**

**Note:**

- When upgrading firmware, ALWAYS refer to the operation manual for the MT9090A Network Master Series Gigabit Ethernet Module.
- Always perform firmware upgrades with the AC adapter connected.

## Download Files

The latest firmware for the modules can be downloaded as zip files from the Anritsu home page at <http://www.anritsu.com/en-US/test-measurement/support/downloads?model=MU909060A>.

**Example:** When the **NM-GIGE-x\_xx\_E.zip (x\_xx = version; Example: NM-GIGE\_1\_00.zip)**

file is unzipped (expanded), the following files are created:

- ① NM-GIGE-x.xx.bbm (MU909060 firmware update file, Version x.xx)

The NM-GIGE-x.xx.bbm file is the updater file that should be copied to a USB memory stick.

## Firmware Upgrade Procedure

Upgrade the firmware by following the procedure described in Chapter 6 Upgrading Firmware of the MU909060A operation manual.