


Firmware Install

Simple Operation Guide

Vector Signal Generator MG3710A/MG3710E
Analog Signal Generator MG3740A

This guide explains how to install firmware in the Vector Signal Generator MG3710A/MG3710E and Analog Signal Generator MG3740A.

- Copy the firmware files (a below) to the root or following folder (b below) on a USB memory stick.




b) x:\¥Anritsu¥MG3710A¥User Data¥Install (x: USB drive letter)

- Insert the above-described USB memory stick into the Vector Signal Generator MG3710A/MG3710E or Analog Signal Generator MG3740A and install the firmware using the procedure described on the following page.

(Supplementary Explanation) Method for confirming installed firmware version

[Procedure]



- ① Press [Utility].
- ② Press [F3: Instrument Info].
- ③ Press [F1: Product Info].
- ④ Check "Firmware Version".





[Procedure]

- ① Press [Utility].
- ② Press [F4: Install].
- ③ Press [F1: Firmware].
- ④ Re-check the version to install.
- ⑤ Press [F7: Install].
- ⑥ Firmware installation starts and the unit restarts automatically.



Old or same as current

Note: If the firmware to be installed is the same or older version than the currently installed firmware, the message "Old or same as current" is displayed.