



## VP F-to-F Adapter (bullet) VP102F



Figure 1. VP102F F-to-F Adapter

### 1. Tools and Materials

This tool is needed to install and remove the VP102F adapter.

Name	Vendor and Model/Part Number
Insertion and Removal Tool	Anritsu 01-501

### 2. Connecting to Shroud

- a. Grasp the center portion of the adapter with the 01-501 tool.
- b. Push the adapter into a shroud. There will be a click as it snaps into place.



Figure 2. 01-501 Insertion and Removal Tool

### 3. Removing the Adapter from a Shroud

- a. Grasp the center portion of the adapter with the 01-501 tool.
- b. Gently pull the adapter until it disconnects from the shroud.

#### NOTE

We strongly recommend using the 01-501 tool to both install and remove the adapter. This will assure the longest possible life for the adapter.