


# MU909060A GigE Operation Example Screen Map



## Basic Operations

### Basic Operations


- Use the **Menu/Power** key to switch the power ON/OFF. To switch OFF, select **Power Down** from the menu.
- Open the operation menu using the **F1 to F4** soft keys or the **Menu** key.
- Select items using the **Up/Down/Left/Right** keys and select the menu using **Set**.
- To cancel an open menu, use the same **F1 to F4** soft keys as when opening a menu and press the **Menu** key once.
- Move within a screen using the **Up/Down/Left/Right** keys and press **Set** to make settings etc.
- Use the **Start** key to start a test and to stop the test procedure manually.




## Key Operation Points

### Key Points to Remember About Operation


- Sets ports to be used to **ON** and unused ports to **OFF**. Move the cursor to **Setup/Interface/Port** and set **ON/OFF** using **Set**. Take care to note **Port A/B** displayed at the bottom right of the screen



- The send source address is set at **Setup/Interface**.
- The destination address is set within each test screen using **Setup/Test Automator**.
- When the MU909060A-002 Multistream Option is installed, up to 8 send source and destination addresses can be set. The stream numbers are displayed at the bottom right of the screen.




- The ON/OFF settings for each stream of the Multi-stream Option are set at **Setup/Test Automator/Generator Test/Line Load**



- At **Default Setting**, the test results are saved automatically following test completion. The **Auto Save Mode** can be set to **OFF** at **Setup/General Setup** for saving time



## Setup



## Test Start

