

General Caution

You must use Ethernet connection to perform any firmware updates.
Updating via USB may result in a failure to finish loading the OS and the unit will not reboot.

All is not lost, Recovery is possible using the Emergency Repair feature with Ethernet connection.

What will the Customer See in this release?

MP1026B Application Package V1.29 10/19/2009

General Features

- No Changes

Operating System

- No changes

Scope mode

Added support:

- Added SCPI commands for trace math, O/E configuration, mask testing, and save JPEG.
- Updated MEASure SCPI commands to set the unit to RUN mode before getting new measurements.
- Added button to re-lock the CRU if it originally locked to the wrong frequency.

Performance enhancement:

- Mask can be updated to track the center of the eye.
- Improvements to autoscale routine.

GUI changes:

- No changes