

# **MP1763C-08**

## **Pulse Pattern Generator**

### **Operation Manual**

**Second Edition**

- **Read this manual before using the equipment.**
- **To ensure that the equipment is used safely, read the "For Safety" in the MP1763C Pulse Pattern Generator Operation Manual first.**
- **Keep this manual with the equipment.**

**ANRITSU CORPORATION**

MP1763C-08  
Pulse Pattern Generator  
Operation Manual

1 March 2004 (First Edition)  
21 May 2004 (Second Edition)

---

Copyright © 2004, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

## Addition of MP1763C-08

When using the MP1763C with the MP1763C-08 option installed, add the specifications shown in the table below to the specifications described in the MP1763C Pulse Pattern Generator Operation Manual (Function/Operation) (M-W1848AE).

The front panel and rear panel of the MP1763C have changed due to the addition of the MP1763C-08 option. See the figures on the following pages.

The operation method remains the same. Refer to the MP1763C Operation Manual.

### Option 08 1/4 Differential Data Output Function

|                                |   |
|--------------------------------|---|
| Operating frequency range      | 1/4 SPEED: 100 MHz to 3.125 GHz   |
| 1/4 CLOCK output               | 2, differential, non-independent settings   |
| Amplitude                      | 0.5 to 2.0 Vp-p/Step 2 mV<br>Setting error: Within $\pm 15\%$ (1.5 to 2.0 Vp-p) or<br>Within $\pm 25\%$ (0.5 to 1.5 Vp-p)   |
| Offset voltage                 | -1.5 to +1.5 V ( $V_{OH}$ )/Step 1 mV<br>(Termination condition: 50 $\Omega$ /GND)<br>-1.5 to +1.0 V ( $V_{OH}$ )/Step 1 mV<br>(Termination condition: 50 $\Omega$ /GND)<br>Setting error: $\pm 15\%$ , $\pm 15\%$ of amplitude, or $\pm 100$<br>mV whichever is larger   |
| Rise/fall time                 | 90 ps or less (20 to 80%), typ. 40 ps (typical value<br>at 3.125 GHz)   |
| Waveform distortion            | $\pm 15\%$ or 150 mV, whichever is larger   |
| Load impedance/<br>termination | 50 $\Omega$ (with back termination)/GND or -2 V   |
| Connector                      | SMA   |
| 1/4 DATA output                | 8, differential, non-independent settings   |
| Amplitude                      | 0.5 to 2.0 Vp-p/Step 2 mV<br>Setting error: Within $\pm 15\%$ (1.5 to 2.0 Vp-p) or<br>Within $\pm 25\%$ (0.5 to 1.5 Vp-p)   |
| Offset voltage                 | -1.0 to +2.5 V ( $V_{OH}$ )/Step 1 mV<br>(Termination condition: 50 $\Omega$ /GND)<br>-1.5 to +1.5 V ( $V_{OH}$ )/Step 1 mV<br>(Termination condition: 50 $\Omega$ /-2 V)<br>Setting error: $\pm 15\%$ , $\pm 15\%$ of amplitude, or $\pm 100$<br>mV, whichever is larger |
| Rise/fall time                 | 90 ps or less (20 to 80%), typ. 45 ps (typical value<br>at 3.125 GHz)   |
| Pattern jitter                 | 50 ps or less (p-p), typ. 20 ps (typical value at<br>3.125 GHz)   |
| Waveform distortion            | $\pm 15\%$ or 150 mV, whichever is larger   |
| Impedance/termination          | 50 $\Omega$ (with back termination)/GND or -2 V   |
| Connector                      | SMA   |

\* 1/8 output is disabled when the MP1763C-08 option is installed.

---

Refer to the following Figs. 1 to 4 for the details of output amplitude and offset settings:

Option 08 Accessories

| Model No. | Name                  | Q'ty |
|-----------|-----------------------|------|
| J1137     | Coaxial terminator    | 10   |
| M-W2339AE | Operation manual      | 1    |
| M-W2340AE | GPIB Operation manual | 1    |

## CAUTION

---

When using either output of the differential outputs (either output of  $\overline{\text{CLOCK}}$  and  $\overline{\text{CLOCK}}$ , or  $\overline{\text{DATA}}$  (1, 2, 3, 4) and  $\overline{\text{DATA}}$  (1, 2, 3, 4)), the other not-used output must be terminated with the same termination condition as that set at the front panel. Or it must be terminated with the 50- $\Omega$  terminator of an accessory supplied. If the other not-used output is not terminated properly with such as Open or Short termination, the used-output cannot output the correct signal.


When using both outputs of the differential output pair, they must be terminated with the same termination condition as that set at the front panel. If one is terminated with 50  $\Omega$ /GND, and the other is terminated with ECL condition, these setting is not allowed.

Make sure to turn On or Off the power after removing the connections of the MP1763C input/output connectors to any DUTs or external equipment.


---

---


Setting range of Output amplitude and Offset




**Fig. 1** Setting range of CLOCK Output amplitude and Offset  
(Termination condition:  $50 \Omega/\text{GND}$ )



**Fig. 2** Setting range of CLOCK Output amplitude and Offset  
(Termination condition:  $50 \Omega/-2 \text{ V}$ )




**Fig. 3 Setting range of DATA Output amplitude and Offset  
(Termination condition: 50  $\Omega$ /GND)**




**Fig. 4 Setting range of DATA Output amplitude and Offset  
(Termination condition: 50  $\Omega$ /-2 V)**

Front Panel

1/4 SPEED (OPTION.03) → 1/4 SPEED (OPTION.08)



## Rear Panel



|     |                  |   |
|-----|------------------|---|
| (1) | 1/4 CLOCK output | 1/4 CLOCK / $\overline{\text{CLOCK}}$ output connector            |
| (2) | 1/4 DATA output  | 1/4 DATA / $\overline{\text{DATA}}$ (1, 2, 3, 4) output connector |