

MG3710A Vector Signal Generator

Product Introduction



Version 1.00

March 2012

ANRITSU CORPORATION

MG3710A Features

Supports Various Communication Systems

Pre-installed Waveform Patterns:

LTE-FDD/TDD (E-TM1.1 to E-TM3.3),
W-CDMA/HSDPA, GSM/EDGE, PDC, PHS,
CDMA2000 1x/1xEV-DO, AWGN,
WLAN (IEEE802.11a/11b/11g), Mobile WiMAX,
Bluetooth®, GPS,
Digital Broadcast (ISDB-T/BS/CS/CATV)

Waveform Patterns [Software & license optional]

DFS Radar Pattern [for TELEC/FCC]
DFS(ETSI) Waveform Pattern
ISDB-Tmm Waveform Pattern

IQproducer [Software license optional]

Waveform generation software

3GPP LTE (FDD), 3GPP LTE (TDD)
HSDPA/HSUPA, W-CDMA, TD-SCDMA,
WLAN 11a/b/g/n/j/p, Mobile WiMAX,
TDMA (PDC, PHS, ARIB, etc.)
CDMA2000 1xEV-DO, DVB-T/H,
Multi-carrier, Fading

AWGN generator [Opt.049/079]

AM/FM/φM/PM Functions

Key Performance and Functions

Frequency range: [Option]

100 kHz to 2.7/4.0/6.0 GHz

Wide vector modulation bandwidth

120 MHz (Internal baseband generator)

SSB Phase noise

<−140 dBc/Hz nominal (100 MHz, 20-kHz offset, CW)

<−131 dBc/Hz typ. (1 GHz, 20-kHz offset)

ACLR performance

−71 dBc (W-CDMA, TestModel1, 64DPCH, 2 GHz)

High power output [Opt.041/071]

+23 dBm (CW, 400 MHz to 3 GHz)

Fast switching speed

<600 μs (List/Sweep Mode)

High level accuracy

±0.5 dB (Absolute level accuracy)

±0.2 dB typ. (Linearity)

Multi RF output [option]

Two RF outputs @ RF x 2

Baseband signal combine function @ RF x 1

Large-capacity baseband memory [option]

64/256/1024 Msamples

BER test function [Opt.021]

Input Bit Rate: 100 bps to 40 Mbps

Supports Various Communication Systems

Pre-installed waveform patterns



LTE-FDD/TDD (E-TM1.1 to 3.3)
W-CDMA, GSM/EDGE,
CDMA2000 1x/1xEV-DO
WLAN (IEEE802.11a/b/g)
Mobile WiMAX, AWGN,
Bluetooth®, GPS, PDC, PHS,
Digital Broadcast (ISDB-T/BS/CS/CATV)

Anritsu product

Customer's item



Any IQ data
- C language
- MATLAB
-Microwave Office
etc.



DFS Radar Pattern (for TELEC, FCC)
DFS (ETSI) Waveform Pattern
ISDB-Tmm Waveform Pattern



W-CDMA, HSDPA/HSUPA,
TDMA, Multi-carrier,
Mobile WiMAX, DVB-T/H,
Fading, 3GPP-LTE (FDD),
XG-PHS, 3GPP-LTE (TDD)
TD-SCDMA

Waveform Pattern [option]

Waveform patterns
with fixed parameters

IQproducer [option]

PC application software to generate
waveform patterns by setting
parameters at PC

**The waveform patterns
are arbitrarily generated.**

IQ sample data files (in ASCII format)
programmed by using general EDA
(Electronic Design Automation) tools
such as MATLAB® can also be
converted to waveform patterns for
MG3710A. And a custom-made
waveform pattern file can be
generated arbitrarily.

Basic Performance (1/5)

Frequency Range [Option]

100 kHz to 2.7/4.0/6.0 GHz

[1stRF: Opt-032/034/036]

[2ndRF: Opt-062/064/066]

The MG3710A supports two built-in vector signal generators with two RF units (1stRF and optional 2ndRF).

Not only different frequencies but also different levels and waveform patterns can be set independently at each SG while each is tracking the other.

1: Supported frequency bands cannot be changed after shipment.

2: IQ input/output is supported only by SG1 (1stRF) and requires Opt-017.

Wide Vector Modulation Bandwidth:

120 MHz (using internal baseband signal generator)


160 MHz (using external IQ input)

An RF modulation bandwidth of 120 MHz is supported using internal baseband signal generation. A modulation bandwidth of 160 MHz is supported when using external IQ input.

Level Accuracy:

Absolute level accuracy: ± 0.5 dB

Linearity: ± 0.2 dB typ.



SSB Phase Noise

< -140 dBc/Hz nominal (100 MHz, 20-kHz offset, CW)



< -131 dBc/Hz typ. (1 GHz, 20-kHz offset, CW)

< -125 dBc/Hz typ. (2 GHz, 20-kHz offset, CW)

Basic Performance (2/5)

RF Vector Modulation Bandwidth: Performance Graph


Vector Modulation Bandwidth (Using Internal baseband generator)




Basic Performance (3/5)

Level Accuracy: Performance Graph

Frequency Characteristics



Linearity



Basic Performance (4/5)

SSB Phase Noise: Performance Graph


SSB phase noise is an important performance index for signal generators.

For example, when using a signal generator for the following purposes, it is important to pre-confirm that the signal generator performance satisfies the measurement specifications.

- ◆ Communications with narrow bandwidth of several kHz
- ◆ OFDM Signals with narrow subcarrier gap
- ◆ CW interference waveforms


Frequency: 60/150/260/400 MHz

(Mod = On, with Opt.002,
Phase Noise Optimization < 200kHz)



Frequency: 850 MHz, 1/1.9/2.2/3.5/5.8 GHz

(Mod = On, with Opt.002,
Phase Noise Optimization < 200kHz)




Basic Performance (5/5)

SSB Phase Noise: Impact on Adjacent Channel Leakage Power

[Example of Measurement: ACLR for Narrow band system]


(Example) Frequency: 400 MHz, Channel Spacing: 6.25 kHz, Channel BW: 4.8 kHz

Conventional Anritsu model (MG3700A)



L1: -71.1 dBc U1: -71.4 dBc

MG3710A



L1: -77.7 dBc U1: -79.0 dBc

Example: Performance not warranted. Data actually measured by randomly selected measuring instruments.



ACLR Performance (1/2)

Top-class ACLR
-71 dBc


Reference Signal Generator



Transmitter Test





Large measurement margin



Stable meas.

Improve yield



Conventional
Anritsu model
(MG3700A)
-63 dBc typ.


MG37xxA
-71 dBc*

*: At W-CDMA, TestModel1, 64DPCH, 2 GHz

Top-class ACLR performance supports measurement closer to the DUT original ACLR performance. High ACLR performance increases margin specifications and improves measurement stability and yield.


ACLR Performance (2/2)

Evaluation of base station amplifiers, etc., requires excellent adjacent channel leakage power (ACLR) performance. Normally, the signal from the vector signal generator is inserted to an amplifier, and the amplifier output signal ACLR characteristics, etc., are measured with a spectrum analyzer. Instruments for these measurements require high ACLR performance.




[Measurement Example: ACLR]

W-CDMA 1 carrier (Test Model 1 64DPCH)



L1: -72.4 dBc U1: -73.3 dBc
L2: -74.5 dBc U2: -74.2 dBc

W-CDMA 4 carrier (Test Model 1 64DPCH x 4 carrier)



L1: -65.6 dBc U1: -66.4 dBc
L2: -67.2 dBc U2: -66.8 dBc

LTE-FDD 1 carrier (E-TM1.1 BW = 20 MHz)



L1: -66.7 dBc U1: -66.7 dBc
L2: -67.5 dBc U2: -67.5 dBc

Example: Performance not warranted. Data actually measured by randomly selected measuring instruments.

High Power Output (1/2)

High power output
+23 dBm @ CW


No External Amp

Cuts cost

Stable level accuracy

Reduces risk of damage to DUT


High Power Extension for 1stRF [Opt-041]
High Power Extension for 2ndRF [Opt-071]




Reference Signal Generator



Path loss
(switches,
couplers,
combiners,
isolators, etc.)



Transmitter Test



In conventional measurement systems, path loss is increased by the various external equipment. An external amp is required when the output of the general signal source is insufficient.

The MG3710A High Power Extension option supports signals required for measuring path loss. It eliminates the cost of an external amp, supports stable level accuracy measurements and reduces risk of damage to the DUT from the external amp.

High Power Output (2/2)

High-Power Extension Option

High Power Extension for 1stRF [Opt-041]


High Power Extension for 2ndRF [Opt-071]

These options expand the MG3710A RF output upper limit.

Generally, an external amplifier is used when managing path losses occurring in measurement systems as well as when the signal generator has inadequate output power, such as when inputting high-level modulation signals for evaluating amp distortion. In these cases, not only must the external amp output accuracy be assured, but it must also be checked with a power meter each time the frequency and level change. Moreover, sometimes operating mistakes when using an external amp can damage the device under test (DUT). The MG3710A High Power Extension options output the signal level required by the DUT without requiring compensation for path losses. In addition, the assured accuracy range supports stable measurements. And finally, there is no risk of unexpected damage to the DUT even when used at the output setting limit.

Assured level accuracy at high levels (CW)

Frequency Range	Standard	Opt-041/071
$100 \text{ kHz} \leq f < 10 \text{ MHz}$	+5 dBm	+5 dBm
$10 \text{ MHz} \leq f < 50 \text{ MHz}$	+10 dBm	+10 dBm
$50 \text{ MHz} \leq f < 400 \text{ MHz}$	+13 dBm	+20 dBm
$400 \text{ MHz} \leq f \leq 3 \text{ GHz}$		+23 dBm
$3 \text{ GHz} < f \leq 4 \text{ GHz}$		+20 dBm
$4 \text{ GHz} < f \leq 5 \text{ GHz}$		+13 dBm
$5 \text{ GHz} < f \leq 6 \text{ GHz}$	+11 dBm	+11 dBm



Low-Power Output Reverse Input Power Protection

Low-Power Extension

Low Power Extension for 1stRF [Opt-042]
Low Power Extension for 2ndRF [Opt-072]

This option expands the MG3710A RF output lower limit.

The lower limit of the standard level setting range –110 dBm.
Adding this option expands the limit to –144 dBm.
Refer to the appended data sheet for the level accuracy.

Level Setting Range

Option	Setting Range [dBm]	
	without Opt-043/073	with Opt-043/073
Standard	–110 to +17	–110 to +17
With Opt-041/071	–110 to +30	–110 to +25
With Opt-042/072	–144 to +17	–144 to +17
With Opt-041/071 & Opt-042/072	–144 to +30	–144 to +25

Reverse Input Power Protection

Reverse Power Protection for 1stRF [Opt-043]
Reverse Power Protection for 2ndRF [Opt-073]

This option protects the 1stRF and 2ndRF signal output connector from reverse input power.

Maximum Reverse Input Power:

DC: ±50 Vdc max.

AC: 20 W nom. (1 MHz < f ≤ 2 GHz)

10 W nom. (2 GHz < f ≤ 6 GHz)

Installing Opt-043/073 does not provide 100% assured protection against damage from reverse input power, so take care not to impress reverse input power whenever possible.

Installing Opt-043/073 lowers ACLR performance. Refer to the appended data sheet for details.

Choice of Reference Oscillators

Pre-installed Reference Oscillator

Aging Rate	$\pm 1 \times 10^{-7}/\text{day}$, $\pm 1 \times 10^{-6}/\text{year}$
Temperature stability	$\pm 2.5 \times 10^{-6}$ (5° to 45°C)

High Stability Reference Oscillator [Opt-002]

Aging Rate	$\pm 1 \times 10^{-8}/\text{day}$, $\pm 1 \times 10^{-7}/\text{year}$
Temperature stability	$\pm 2 \times 10^{-8}$ (5° to 45°C)
Start-up characteristics*	$\pm 5 \times 10^{-7}$ (2 minutes after power on) $\pm 5 \times 10^{-8}$ (5 minutes after power on)

Rubidium Reference Oscillator [Opt-001]

Aging Rate	$\pm 1 \times 10^{-10}/\text{month}$
Temperature stability	$\pm 2 \times 10^{-9}$ (5° to 45°C)
Start-up characteristics*	$\pm 1 \times 10^{-9}$ (7.5 minutes after power on)


*Compared to frequency after 24-h warm-up, at 23°C

Three reference oscillator options are supported. Select the High-Stability Reference Oscillator option [Opt-002] when requiring high accuracy, depending on the measurement conditions; for even higher accuracy, select the Rubidium Reference Oscillator option [Opt-001]. However, if external high-accuracy reference signals are available, selecting the standard reference oscillator option helps reduce unnecessary costs.


High-Speed Switching (1/2)

Fast switching speed
Frequency &
Amplitude
<600 μ s


Reference Signal Generator




Transmitter Test



High-speed switching



Cuts test times



Switching target: Frequency, amplitude, waveform data

**Switching timing: External trigger, dwell time,
remote command, panel operation**


The MG3710A supports high-speed switching in the sweep/list mode separately from normal remote control. It is ideal for production lines requiring short test times.

High-Speed Switching (2/2)

Sweep/List mode

Sweep mode


In this mode, the dwell time per point or number of points is split between the frequency range and level range (Start/Stop). This mode is used when matching dwell time per point and frequency/level steps.



Example: Points: 10; Dwell Time: 500 μs


List mode

In this mode, the frequency, level and dwell time can be set for each of up to 500 points. This mode is used when wanting to set any dwell time, and frequency/level step per point.




Example: Points: 5; Dwell Time: Random

One Unit Supports Two Separate RF Outputs (1/3)




One unit supports Two RF outputs

Modulated signal x 2, CW x 2,
Modulated signal + CW



Cuts costs



The MG3710A supports two separate built-in RF outputs (option). The frequency can be selected from 2.7/4.0/6.0 GHz. The two RF outputs can be set to different frequencies, levels and waveform data/CW. As a result, there is no need for two expensive vector signal generators.


One Unit Supports Two Separate RF Outputs (2/3)

Two separate
RF outputs

Multi-system Rx
characteristics tests


Interference
signal

Wanted
signal




Example: LTE + WLAN, LTE + Bluetooth, ISDB-T + WLAN, etc.

One unit supports Two RF outputs
Wanted signal + Interference signal




Cuts costs



The MG3710A supports two separate built-in RF outputs (option). Each can output a different frequency, level, and waveform data/CW and is ideal for Rx tests using two frequency offset signals that cannot be set using the baseband combine function.

One Unit Supports Two Separate RF Outputs (3/3)



Frequency Range:

2ndRF 100 kHz to 2.7 GHz [MG3710A-062/162]

2ndRF 100 kHz to 4 GHz [MG3710A-064/164]

2ndRF 100 kHz to 6 GHz [MG3710A-066/166]

*Any frequency option can be selected.

*One of these options can be retrofitted only if the 2ndRF option is not installed.

Frequency Range:

1stRF 100 kHz to 2.7 GHz [MG3710A-032]

1stRF 100 kHz to 4 GHz [MG3710A-034]

1stRF 100 kHz to 6 GHz [MG3710A-036]

*One of these must be installed.

This is convenient in the R&D phase for evaluating interference between two different systems using different frequency bands.

For example, considering WLAN 11b/g as the wanted signal, LTE-FDD, LTE-TDD, W-CDMA, GSM, etc., mobile signals are interference waveforms. Usually, this requires hardware and software costs for a second separate signal generator to create these interference signals. However, selecting one MG3710A model with different frequencies for the 1stRF and 2ndRF outputs supports efficient interference waveform testing using WLAN+LTE-FDD, ISDB-T+W-CDMA signals under realistic service conditions at greatly reduced total costs.

1: Supported frequency bands cannot be changed after shipment.

2: IQ input/output is supported only by SG1 (1stRF) and requires Opt-017.


Local Signal I/O as MIMO Signal Source

Phase adjustment and local signal synchronization

Common Setting

Number of Slaves: 3

LO Sync: On



Universal Input/Output [Opt-017]

This option installs connectors for the following I/O signals on the main-frame rear panel, supporting local frequency sync for MIMO applications.

Baseband Reference Clock Input/Output

Sweep Output (only supports SG1)

Local Signal Input/Output

*Bundled with J1539A AUX Conversion Adapter for Opt-017/117 to use rear-panel AUX connector.

The Sync Multi SG function shares local signals, baseband clocks and trigger signals between multiple MG3710A units to output phase coherency signals with synchronized signal output timing. An 8x8 MIMO test system can be configured from one Master and three Slave MG3710A units.

Synchronization mode: Master, Slave, SG1 & 2

No. of Slaves: 1 to 3

Slave position: 1 to 3

Local synchronization: On/Off

IQ phase adjustment: -360° to $+360^{\circ}$, resolution 0.01°


IQ output delay: -400 to 400 ns, resolution 1 ps

Refer to the Application Note for details.

[Adjusting MIMO Phase Coherence using Vector Signal Generator]

One RF Outputs Wanted + Interference Signals (1/6)

Outputs two signals at one RF
(Baseband Signal Combine function)




Combination of Baseband Signal function:

Waveform data = 2 patterns (dual memory);
modulated signal x 2, CW x 2, modulated signal + CW, etc.


Setting: Frequency offset, level offset, delay time

Frequency offset range: < baseband bandwidth (± 60 MHz max.)

One RF outputs
Wanted + Interference signals



Cuts costs



The MG3710A has two waveform memories for each RF output for setting and outputting different waveform data. One RF outputs the combined wanted + interference signals for the baseband bandwidth.

One RF Outputs Wanted + Interference Signals (2/6)

Combination of Baseband Signal Function

Combination of Baseband Signal for 1stRF [Opt-048]

Combination of Baseband Signal for 2ndRF [Opt-078]

The Combination of Baseband Signal option installs two waveform memories for either the 1stRF (or 2ndRF) SG to combine two waveform patterns as the baseband for output, eliminating the need for two separate and expensive vector signal generators.

Level Setting Setting Range: -80 to +80 dB
Resolution: 0.01 dB

Frequency Offset Setting Range Setting Range: -80 to +80 MHz
Resolution: 1 Hz

CW Selection
A: Pattern A center
B: Pattern B center
Baseband DC:
Centered at baseband DC position

Time offset Setting Range Setting Range:
0 ~ pattern B sampling data count - 1

Waveform pattern A
Example:
Wanted Signal

Waveform pattern B
Example:
Interference Signal,
Delay Signal

The screenshot displays the MG3710A Vector Signal Generator interface. The main display shows the combination of two baseband signals (A and B) into a single output. The interface includes fields for Frequency, Amplitude, Level, and Freq Offset, as well as buttons for ARB Setup, CW Selection, and Time offset. The example shows Pattern A (W-CDMA BS Rx test) and Pattern B (W-CDMA BS Rx test) being combined.

Combination of Baseband Signal Example

One RF Outputs Wanted + Interference Signals (3/6)

[Combination of Baseband Signal Function Example]



**Wanted Signal
+ Modulated Interference Signal**

Parameters:

- Frequency offset: 5 MHz
- Level offset: -63 dB
- Center carrier: Wanted signal = Memory A



MG3710A Settings for Wanted Signal + Modulated Interference Signal



MG3710A Settings for Wanted Signal + Modulated Interference Signal (Spectrum)

One RF Outputs Wanted + Interference Signals (4/6)

[Combination of Baseband Signal Function Example]


**Wanted Signal
+ Delayed Signal**

Parameters:

- Frequency offset: 0 Hz
- Level offset: 15 dB
- Time offset (Delay): 30 μ s




**MG3710A Settings for
Wanted Signal + Delayed Signal**



**Wanted Signal + Delayed Signal
(Delay Profile)**

One RF Outputs Wanted + Interference Signals (5/6)

[Rate Matching Function]



The conventional MG3700A only supports combination of two waveform patterns at the same sampling rate in memory A and and memory B. The sampling rate of the two waveform patterns must be matched in advance using Multi-Carrier IQproducer (MX370104A).

Combining two signals with the MG3710A rate matching function performs combination by matching the sampling rates and data point counts automatically, eliminating a great deal of time and effort matching the waveform pattern sampling rates before waveform combination.


One RF Outputs Wanted + Interference Signals (6/6)

[Rate Matching Function]

[Baseband Signal Combine Function Example]

Yellow: MG3710A

Blue: Anritsu conventional model (MG3700A) Note



Example:

Bluetooth DH1: Sampling Rate 12 MHz
WLAN 11a 54 Mbps: Sampling Rate 40 MHz

Combine Waveforms with Different Sampling Rate

Using the MG3710A Rate Matching function, two signals are output at each true spectrum.

Note: With the conventional MG3700A, the sampling rates are pre-matched using the Adjust Rate function of Multi-Carrier IQproducer.

One RF Outputs Wanted + AWGN Signals (1/2)

AWGN Generator

Built-in AWGN Generator

AWGN for 1stRF [Opt-049]

AWGN for 2ndRF [Opt-079]

This option adds internally generated AWGN to wanted signals. The On/Off button switches the AWGN output.

When there is no carrier, only AWGN is output (ARB = Off).



Waveform pattern A
Example:
Wanted Signal

AWGN Generator

Select AWGN On/Off

Noise Bandwidth

AWGN Flat Bandwidth part

Carrier Level

Noise (AWGN) Level

(Enabled when no wanted signal)

Carrier/Noise Ratio

Setting Range: -40 to +40 dB

Resolution: 0.01 dB

C/N Set Signal

Sets change target when setting C/N Ratio

Carrier: Changes carrier (fixed AWGN)


Noise: Changes AWGN (fixed carrier)

Constant: Fixes output level and change carrier and AWGN

Example of AWGN Generator



One RF Outputs Wanted + AWGN Signals (2/2)

Example: Wanted Signal + AWGN



When adding AWGN to the wanted signal, Noise Level on the screen displays the noise level in the wanted signal band.


Example: AWGN only



When outputting only AWGN, Noise Level on the screen displays the set noise bandwidth level. In the above setting example, it is the power in the 7.68-MHz band.

Large Memory Cuts Measurement Times (1/2)

**Large memory
4 GB max**




Example: Testing with many waveforms with different bandwidths and parameters

Testing with waveforms for many systems with multi-system terminals

With large waveform memory

1. Switch loaded waveform data instantaneously
2. Load multiple test waveforms → Reduce number of reloads → Cuts time



The MG3710A can save up to 1024 Msa (4 GB) per one RF output. Memory size is one of the most important specifications for an arbitrary waveform signal generator. Large memory can load multiple waveform data, cutting reload and measurement times.

Large Memory Cuts Measurement Times (2/2)

ARB Memory Upgrade

64 Msample for 1stRF [with 1stRF]

ARB Memory Upgrade 256 Msample for 1stRF [Opt-045]

ARB Memory Upgrade 1024 Msample for 1stRF [Opt-046]

64Msample for 2ndRF [with 2ndRF]

ARB Memory Upgrade 256 Msample for 2ndRF [Opt-075]

ARB Memory Upgrade 1024 Msample for 2ndRF [Opt-076]

Memory size is the most important specification for arbitrary waveform memory. If the memory is small, large waveform patterns cannot be handled and the number of cases when multiple waveform patterns cannot be loaded increases. When this happens, the time to reload another waveform pattern wastes evaluation time and lowers efficiency.

1stRF (Opt-032/034/036)

Combination of Baseband Signal (Opt-048)	ARB Memory Upgrade 256 Msample for 1stRF [Opt-045] ARB Memory Upgrade 1024 Msample for 2ndRF [Opt-046]		
	without Opt-045/046	with Opt-045	with Opt-046
Without Opt-048	64 Msa x 1 pc	256 Msa x 1 pc	1024 Msa x 1 pc
With Opt-048* ²	64 Msa x 2 pcs 128 Msa x 1 pc	256 Msa x 2 pcs 512 Msa x 1pc	1024 Msa x 2 pcs* ¹

2ndRF (Opt-062/064/066)

Combination of Baseband Signal (Opt-078)	ARB Memory Upgrade 256 Msample for 2ndRF [Opt-075] ARB Memory Upgrade 1024 Msample for 2ndRF [Opt-076]		
	without Opt-075/076	with Opt-075	with Opt-076
Without Opt-078	64 Msa x 1pc	256 Msa x 1 pc	1024 Msa x 1 pc
With Opt-078* ²	64 Msa x 2pcs 128 Msa x 1pc	256 Msa x 2 pcs 512 Msa x 1 pc	1024 Msa x 2 pcs* ¹

*1: The MG3710A supports a maximum waveform pattern size of 1024 Msa.


*2: The Combination of Baseband Signal option supports two arbitrary waveform memories and can either set two different waveform patterns or combine them in one memory to support one large waveform pattern.

Two Signal Flowcharts (1/2)


Pressing the on-screen  button toggles instantly between the Hardware Block Chart and the ARB Info screens.

The Hardware Block Chart is a quick-and-easy way to grasp the status of each block (ARB, AWGN, I/Q, Analog Mod, Pulse Mod, Local) at a glance.

The ARB Info screen displays more details about the ARB/AWGN block showing the baseband signal combine status of memory A + memory B, memory A + AWGN, etc.













ARB Info Screen



Hardware Block Chart Screen





Two Signal Flowcharts (2/2)

Hardware Block Chart Display Contents (explanation)

No.	Display Example	Display	Description
1		ARB	ARB block
		On/Off	Indicates On/Off of ARB (function to generate modulated signals with arbitrary waveform patterns).
		Out:	Indicates On/Off of the arbitrary waveform pattern output.
2		AWGN	AWGN block
		On/Off	Indicates On/Off of AWGN addition.
3		Analog Mod	Analog Modulation block
		AM/FM/φM	Indicates the analog modulation (AM/FM/φM) during modulation.
4		I/Q	I/Q block
		Src: Internal/ Analog I/Q In	Indicates the I/Q signal source.
		Out: RF/ Analog I/Q Out	Indicates the output destination for baseband signals.
5		Local Oscillator	Local Oscillator block
		Src: Int/Ext/Sync	Indicates the Local signal source.
		Out: ---/On/Off	Indicates On/Off of the Local signal external output.
6		Pulse Mod	Pulse Modulation block
		On/Off	Indicates On/Off of Pulse modulation.
7		---	Indicates that inputs from two function blocks of the left side and bottom side are combined and output to the function block of the right side.
8		---	Indicates that the input Local signal from the bottom side is modulated with the input signal from the left side and output to the function block of the right side.
9		---	Indicates the RF Output is On.
10		Analog I/Q Out	Indicates the Analog I/Q signal is set to the external output.

Hardware Block Chart (explanation)



No.	Display Example	Display	Description
11		Analog I/Q In	Indicates the Analog I/Q signal is set to the external input.
12		LO In (For SG1)	Indicates the SG1 Local signal source is set to Ext (input from the rear LO Input connector).
		SG1 (For SG2)	Indicates the SG2 Local signal source is set to Sync and the signal is input from SG1.
13		SG2 (For SG1)	Indicates the SG1 Local signal external output setting is On and the signal is output to SG2. If SG2 is not installed, "LO Out" (output from the rear LO Output connector) is displayed.
		LO Out (For SG2)	Indicates the Local signal external output setting (output from the rear LO Output connector) is On.
14		---	Click to switch Hardware Block Chart and ARB Info display.


Analog IQ Input/Output (1/2)

Analog IQ Input/Output [Opt-018]

This option adds analog IQ input and output connectors to the front and rear panels, respectively

This function supports SG1 (1stRF) only when Opt-018 is installed.

Page 1/2



[1] I/Q signal Source



I/Q signal with the internal baseband

Signal input from analog I/Q In connector (SG1 can only be selected when Opt-018 is installed.)

[2] Output destination for BB signals



Output RF signal

Output I/Q signal
SG1 can only be selected when Opt-018 is installed.)

*The RF output signal is CW.

[3] Baseband in-band correction

Enable/Disables baseband in-band correction.

When it is set to On, the in-band flatness is improved. However, the switching time for the frequency and pattern change becomes longer because the correction filter recalculation time and filter passing time become longer. If the in-band characteristics are not important, setting this function to Off supports high-speed operation. This function is disabled at CW output.

Input: I Input, Q Input

Output: I Output, I⁻ Output, Q Output, Q⁻ Output

[4] I/Q Calibration



Executes calibration for the IQ gain balance, Origin offset and IQ quadrature angle.

DC: Executes optimal adjustment with currently specified frequency (default). For other frequency points, the existing correction value is used without change.

Full: Executes calibration with range of all frequencies.


[5] Switching mode for RF bandwidth

Off: Harmonics distortion characteristic has priority (Default).

On: In-band flatness has priority. This function allows using the maximum modulation bandwidth with low frequency. (The harmonics cut filter is disabled.)

Analog IQ Input/Output (2/2)

Page 2/2



[6] Analog I/Q Input Adjustments

Analog I/Q Input Adjust	
I Offset	I-phase Offset
0.000 V	Range: -100 mV to +100 mV
Q Offset	Q-phase Offset
0.000 V	Range: -100 mV to +100 mV

[7] Analog I/Q Output Adjustments

Analog I/Q Output Adjust	I Level Trimming	I-phase level adjustment
100.0 %	Range: 0% to 120%	
Q Level Trimming	Q-phase level adjustment	
100.0 %	Range: 0% to 120%	
I/Q Common Offset	I/Q Common Offset	
0.0000 V	Range: -2.5 to +5 V	
I Diff Offset	I-phase differential offset	
0.0000 V	Range: -50 to +50 mV	
Q Diff Offset	Q-phase differential offset	
0.0000 V	Range: -50 to +50 mV	

[8] Internal Baseband Adjustments

Internal Baseband Adjust	I Offset	I-phase offset
0.000 %	Range: -20% to +20%	
Q Offset	Q-phase offset	
0.000 %	Range: -20% to +20%	
Gain Balance	Gain Balance	
0.000 dB	Range: -1 to +1 dB	
Quad. Angle	Quadrature angle of I/Q phase*1	
0.00 deg	Range: -10 to +10deg	
I/Q Phase	I/Q phase adjustment*1	
0.00 deg	Range: -360 to +360 deg	
I/Q Skew	I/Q phase time difference*2	
0.000000000000 s	Range: -800 to +800 ns	
I/Q Delay	I/Q output timing*2	
0.000000000000 s	Range: -400 to +400 ns	


*1: Resolution 0.01 deg

*1: Resolution 0.01 deg

*2: Resolution 1 ps

Built-in BER Measurement Function (1/4)

Built-in BER Measurement Function



Returns Data/Clock/Enable demodulated by DUT to MG3710A BER function

BER Test Function [Opt-021]

Input bit rate: 100 bps to 40 Mbps

Input signal: Data, Clock, Enable
(Polarity inversion enabled)

Input level: TTL

Measurable patterns:

PN9/11/15/20/23, ALL1, ALL0,
Alternate (0101...), User Data,
PN9fix/11fix/15fix/20fix/23fix

Count mode: Data, Error

Number of measurable bits:

$\leq 2^{32}-1$ (4,294,967,295 bits)

Measure mode: Single, Continuous, Endless

This option installs a BER measurement function for measuring error rates between 100 bps and 40 Mbps using the DUT demodulated Data/Clock/Enable signals. The results are displayed on the MG3710A screen.

Built-in BER Measurement Function (2/4)

BER Measurement Example

Error Rate points to 1.000E-002

Error Bit points to 569

BER Test Start or Stop points to Start and Stop buttons

Clears measurement result points to Clear button

Measure Mode points to Measure Mode button

Count Mode points to Count Mode button

Data Type points to Data Type button

Measurement bit points to 56900

PN9/11/15/20/23, ALL1, ALL0, Alternate (0101...), User Data, PN9fix/11fix/15fix/20fix/23fix

Measure Mode

Single: Measures selected data patterns until result reaches specified number of bits or specified number of error bits

Continuous: Repeats single measurements (default)

Endless: Measures data until result reaches upper limit of measurement count bit

Count Mode

Data: Specifies number of measurement bits (default)


Error: Specifies number of measurement error bits

Built-in BER Measurement Function (3/4)

[PN Fix pattern]

At BER measurement, special PN patterns called PN_Fix patterns can be used. A PN Fix pattern consists of repeated parts of PN patterns, and PN patterns with a shorter length than 1 cycle.

Even when the PN data part of the waveform pattern output from the MG3710A has no periodicity, BER measurement is supported by selecting PN Fix at the BER measurement function.



Initial Pattern

Data Type	Initial Pattern Setting Range		Resolution	Default
	Binary	Hex		
PN9Fix	000000000 to 111111111 (9 bits)	000 to 1FF	1	1FF
PN11Fix	00000000000 to 11111111111 (11 bits)	000 to 7FF	1	7FF
PN15Fix	000000000000000 to 111111111111111 (15 bits)	0000 to 7FFF	1	7FFF
PN20Fix	000000000000000000 to 111111111111111111 (20 bits)	00000 to FFFF	1	FFFF
PN23Fix	00000000000000000000 to 11111111111111111111 (23 bits)	000000 to 7FFFF	1	7FFFF

Pattern Length

Setting Range:
96 to 134217728 bit (0 x 8000000)
Resolution: 1 bit

Built-in BER Measurement Function (4/4)



[User Defined Pattern]

The BER measurement can use a user-defined pattern, which is an arbitrary binary string that is 8- to 1024-bits long and consists of a data bit string to determine whether synchronization is established plus a data bit string used as measurement data. A PC can be used to create a user-defined pattern in text file format. Load the file from USB memory or MG3710A internal hard disk.

Length: 8 to 1024 (Binary)

Extension: ***.bpn**

Saved Folder: *:\Anritsu\MG3710A\User Data\BERT BitPattern




Example of User-Defined Pattern

Supports USB Type Power Sensor (1/4)

**Supports two USB
power sensors max.**



USB Connection



**Example:
MA24106**

**Up to two USB power sensors can be
connected to the MG3710A to display the
measurement results on the MG3710A
screen.**

USB Power Sensor [Sold Separately]

Frequency Range: 50 MHz to 6 GHz [MA24106A]
10 MHz to 18 GHz [MA24118A]
10 MHz to 26 GHz [MA24126A]

Level Offset: -100 to +100 dB

Average: 1 to 2048

Unit: dBm, W

COM Port: 2 to 8



Power Meter Measurement Screen

Supports Two USB Power Sensors (2/4)

[Power Meter Setting]

Measurement Frequency: Channel Freq (See Table 1.)

Select Level Offset On/Off

Level Offset Value
Range: -100 to +100 dB
Resolution: 0.01 dB

Select Averaging On/Off

Average Count
Range: 1 to 2048
Resolution: 1

Measurement Units
dBm, W

Table 1: Channel Freq

Power Sensor	MA24106	MA24118	MA24126
Upper limit	6 GHz	18 GHz	26 GHz
Lower limit	50 MHz	10 MHz	10 MHz
Resolution	1 Hz	100 kHz	100 kHz
Default	1 GHz		

COM Port: 2 to 8

Model: MA24106A, MA24118A, MA24126A

Zero Sensor: Zero adjusts for power sensor

Supports Two USB Power Sensors (3/4)



[Checking Com Port]

1. Display Windows


Press [Shift] + [Context(Windows)] or
right-click mouse > Show Desktop

2. Display Device Manager

Start > My Computer > Properties > Hardware > Device Manager




3. Check Ports (COM & LPT)



Supports Two USB Power Sensors (4/4)

[Correction Table Creation Function]

This function supports creating a correction table for specified frequency range, such as pass-loss using USB power sensor.



This function can be used from [Level]. It cannot be used when a USB power sensor is not connected.

[Top] > [Level] > (P.2)[F2: Configure Correction] > [F5: Use Power Sensor]

Frequency	Correction
1.0000000000 GHz	0.57 dB
1.0100000000 GHz	0.57 dB
1.0200000000 GHz	0.58 dB
1.0300000000 GHz	0.58 dB
1.0400000000 GHz	0.59 dB
1.0500000000 GHz	0.59 dB
1.0600000000 GHz	0.58 dB
1.0700000000 GHz	0.60 dB
1.0800000000 GHz	0.60 dB
1.0900000000 GHz	0.59 dB
1.1000000000 GHz	0.61 dB

Frequency Setting Range

Power Sensor	Minimum Value	Maximum Value		
		MG3710A Options		
		032/062/162	034/064/164	036/066/166
MA24106A	50 MHz	2.7 GHz	4 GHz	6 GHz
MA24118A	10 MHz	2.7 GHz	4 GHz	6 GHz
MA24126A	10 MHz	2.7 GHz	4 GHz	6 GHz

Level Offset Setting

Sets loss/gain correction values included in measurement path.
Setting Range: -100 to +100 dB
Resolution: 0.01 dB

No. of Measurement Point for Correction Data

Setting Range: 2 to 4096

Average of Correction Data

Setting Range: 1 to 2048


Example of Creating Correction Table

AM/FM/ ϕ M/PM (1/5)

◆AM/FM/ ϕ M/PM

This function executes analog modulation (AM/FM/ ϕ M) for modulated signals created using a CW signal or ARB. However, analog modulation cannot be executed using an external input signal. When using with a low output frequency, the impact of the second harmonic wave cut filter may degrade the characteristics of the high-frequency wave.

Pulse modulation is executed at any frequency and timing setting. Pulse modulation using external input signals is also supported. The RF Gate function, which runs in tandem with the waveform pattern and the pulse modulation, can be applied simultaneously, and pulse modulation is executed because of OR.



**Example of Analog Modulation Block Chart Screen
(ARB = On, AM = On)**

AM/FM/φM/PM (2/5)

AM Setting Screen

SG2 Frequency: 1.000 000 000 00 GHz, Amplitude: -20.00 dBm

SG1 Frequency: 1.000 000 000 00 GHz, Amplitude: -144.00 dBm

Analog Modulation Info

Modulation	State	Depth/Deviation	Source	Rate	Delay	Width
AM	On	10.0 %		1.0000 kHz		
FM	Off	1.0000 kHz		400.0 Hz		
φM	Off	0.000 rad		400.0 Hz		
Pulse	Off		Freerun	400.0 Hz	0.00000000 s	2.00 μs
Pulse 2	Off		Freerun	400.0 Hz	0.00000000 s	2.00 μs

ARB
On
CW

Power Meter
A : Off
B : Off


BER
Stop 0.000E+000 0 %
0 / 0

AM Settings (Right Sidebar):


- Select AM On/Off: AM On
- Select AM Modulation Scale: Lin (Linear format), Exp (Exponential format (Log))
- AM Depth (Lin): 10.0 % (Range: 0% to 100%, Resolution: 0.1%)
- AM Depth (Log): 3.00 dB (Range: 0 to 10 dB, Resolution: 0.1 dB)
- AM Rate: 1.0000 kHz (Range: 0.1 Hz to 50 MHz, Resolution: 0.1 Hz)

2/19/2012 09:38:12

AM Setting Screen




AM Image (Lin)



AM Image (Log)

AM/FM/ ϕ M/PM (3/5)

FM/ ϕ M Setting Screen



Select FM On/Off

FM Deviation:

Range: 0 Hz to 40 MHz or (50 MHz-FM Rate)
Resolution: 0.1 Hz

FM Rate:

Range: 0.1 Hz to 40 MHz or (50 MHz-FM Deviation)
Resolution: 0.1 Hz

Select ϕ M On/Off


ϕ M Deviation:

Range: 0 to 160 rad
or (40 MHz/ ϕ M Rate) rad
Resolution: 0.1 Hz


ϕ M Rate:

Range: 0.1 Hz to 40 MHz
or (40 MHz/ ϕ M Deviation)
Resolution: 0.1 Hz

FM/ ϕ M Setting Screen



FM Image



ϕ M Image

AM/FM/φM/PM (4/5)

PM Setting Screen



Select PM On/Off

Pulse Source:
(See next slide.)

Pulse Rate:
Range: 0.1 Hz to 10 MHz
Resolution: 0.1 Hz

Pulse Period:
Range: 10 ns to 20 s
Resolution: 10 ns

Pulse Delay from trigger:
Range: 0 to 20s – Pulse Width
Resolution: 10 ns

Pulse Width:
Range: 10 ns to Pulse Period*1
10 ns to 20 s – Pulse Delay*2
Resolution: 10 ns

Delay time from first to second Pulse:
Pulse 2 Delay
Range: 0s to 20s – Pulse 2 Width – Pulse Delay
Resolution: 10ns

Second pulse width: Pulse 2 Width
Range: 10 ns to 20 s – Pulse 2 Delay – Pulse Delay
Resolution: 10 ns

*1: When Pulse Source is [Free run] or [Gated]


*2: When Pulse Source is [Triggered], [Adjustable], [Doublet] or [Trigger Doublet].

AM/FM/ ϕ M/PM (5/5)

PM: Pulse Source


Square

Internal freerun pulse string with 50% of duty cycle.
The period is set with Pulse Rate.




Freerun

Internal freerun pulse string (Default)
The period and pulse width are set with Pulse Period and Pulse Width.




Triggered

Generates the pulse in synchronization with the trigger event.
The delay time after the trigger event and pulse width are set with Pulse Delay and Pulse Width.




Adjustable Doublet

Generates two pulses in synchronization with the trigger event.
The delay time after the trigger event and pulse width are set with Pulse Delay and Pulse 2 Delay, and Pulse Width and Pulse 2 Width. The second pulse delay is based on the first pulse rise.




Trigger Doublet

Generates two pulses in synchronization with the trigger event.
The delay time after the trigger event and pulse width are set with Pulse Delay and Pulse Width. The first pulse synchronizes with the external trigger signal. The second pulse delay is based on the first pulse rise.




Gated

Generates the internal pulse string. However, pulses are valid only when the trigger is being input.
The period and pulse width are set with Pulse Period and Pulse Width.



Ext Pulse


Generates the pulse signal in synchronization with the external trigger signal.



Simple Touch-Panel Operation

Touching the easy-to-use GUI with hierarchical menus fetches related function and numeric input keys for simple fast settings.

For Modulation (Mode) Screen



Security

2ndaryHDD [Opt-011]

Removable HDD [Opt-313]

This option is useful for saving sensitive waveform pattern data, etc., used at evaluation that cannot be allowed to leave the laboratory, workplace, factory, etc. The 2ndary HDD can be removed from/installed in the rear-panel slot when wanting to keep this saved data secure when the MG3710A is sent for service, used by third parties, etc.

The 2ndary HDD does not includes an OS. It is for user data backup.

The Removable HDD includes the OS. We recommend it when wanting full management including the C drive. The OS is Windows XP Embedded.


*Windows 7 is not supported.

OS Upgrade to Windows7 [Opt-029]

The shipped MG3710A runs the Windows XP OS but this can be upgraded at ordering to Windows 7.

***This option can be applied only at ordering and cannot be retrofitted. Opt-313 cannot be selected at the same time.**

MG3710A



**2ndary HDD
[Opt-011]**

**Exchange HDD
[Opt.313]**

Remote Control

GPIB

Conforms to IEEE488.1/IEEE488.2 standard
SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT0, C0, E2

Ethernet

Conforms to VXI-11 protocol using TCP/IP
SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT0, C0


USB

Conforms to USBTMC-USB488 protocol
SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT0, C0n

The MG3710A has GPIB, Ethernet and USB interfaces as standard. The following functions are supported via these interfaces:

- Control of all functions, except power switch
- Reading of all status conditions and settings
- Interrupts and serial polls

External controller (PC)



The interface to be used is determined automatically according to the communication start command received from the external controller (PC) while in Local status. It enters Remote status when the interface is determined. "Remote" on the front panel goes off in the Local status and lights up in the Remote status.

To change the interface, the MG3710A must enter Local status again. Press "Local" on the front panel to enter Local status, then send a command via the desired interface.

MG3710A Vector Signal Generator

Waveform Generation Software

IQproducer Introduction

Some of these functions require a separate charged license.

IQproducer (1/11)

◆IQproducer Functions

IQproducer is PC software for generating waveform patterns mainly for the MG3710A. There are four types. Some require a paid option license (license in below []).

For the waveform pattern generation function (black), refer to the “IQproducer catalog” or each Product Introduction.

This explains IQproducer basic functions (blue).

System (Cellular)

LTE FDD	[MX370108A]
LTE TDD	[MX370110A]
HADPA/HSUPA DL/UL	[MX370101A]
TD-SCDMA	[MX370112A]
W-CDMA DL/UL	
1xEV-DO FWD/RVS	[MX370103A]
XG-PHS	[MX370109A]

System (Non-Cellular)


WLAN	[MX370111A]
Mobile WiMAX	[MX370105A]
DVB-T/H	[MX370106A]

General Purpose

TDMA	[MX370102A]
Multi-Carrier	[MX370104A]
Fading	[MX370107A]
Convert	
Clipping	
AWGN	

Simulation & Utility

CCDF, FFT, Time Domain
Transfer & Setting Panel/Wizard



IQproducer (2/11)

Convert function

This function converts waveform patterns for the MG3710A based on three types of data files.


The waveform pattern bit width can be selected as 14, 15, or 16 bits.

Bit Width	Specifiable RMS Value Range	Usable Marker Signals
14 bit	1 to 8191	Marker 1 to 3, RF Gate
15 bit	1 to 16383	Marker 1, RF Gate
16 bit	1 to 32767	None


The specifiable bit widths differ for each conversion file format as follows.

Input File Format	Selectable Bit Width
ASCII1	14/15/16 bit
ASCII2	15/16 bit
ASCII3	14/15 bit
MS269x/MS2830A Digitizer	14/15/16 bit
MG3710/MS269x/MS2830A (to MG3700)	14 bit
MG3700/MS269x/MS2830A (to MG3710)	14 bit
MG3710/MG3700A/MS2830A (to MS269x)	14 bit
MG3710/MG3700A/MS269x (to MS2830A)	14 bit


(1) ASCII-format IQ data created by other general-purpose EDA [Electronic Design Automation] tools, such as MATLAB, can be converted into MG3700A waveform pattern files.



(2) Data files captured with Anritsu MS269xA Signal Analyzer and the capture function of the MS2830A Signal Analyzer can be converted to waveform pattern files used by the MG3710A.



(3) Waveform patterns created by other Anritsu vector signal generators (MG3700A, MS269xA-020, MS2830A-020/021) can be converted to waveform pattern files used by the MG3710A and *vice versa*.



IQproducer (3/11)

Convert Function

Input file selection → 1000_with_Marker.csv

Sampling rate → 20000.000 Hz
Range: 20 kHz to 160 MHz

File format → ASCII1
(See previous slide.)

Normalizing → ☒ Normalizing
Sets amplitude value for converting waveform pattern to RMS (Root Mean Square), which is a standard waveform pattern used for MG3710A.

Package name → Convert_IQproducer

Comment → Comment Line 1, Comment Line 2, Comment Line 3

Waveform Pattern parameters

- Sampling Rate: 20000.000 Hz
- RMS Value: 4628
- Peak Value: 4628
- Memory Option: Memory 64M samples
- Package: Convert_IQproducer
- Bandwidth: 20000.000 Hz
- Unit symbol: sample
- Spectrum: Normal
- Data Points: 1000

☐ Marker Name

Marker 1 Name: Marker 2 Name:

Marker 3 Name:

☒ Burst Setting

Frame Length: 1000

Gap Length: 0

☐ RF Gate

RF On/Off Threshold: 10.00 %

Minimum RF Gate Length: 10

Diagram:

The diagram illustrates the relationship between the Waveform Pattern and the Output signal. The Waveform Pattern is a sequence of Data points (Data #1, Data #2, ..., Data #n) with a total length of n = Data points / Frame length. The Output signal is a sequence of Data points (Data #1, Data #2, ..., Data #n) with a total length of n = Data points / Frame length. The diagram shows the Frame length and Gap length for both the Waveform Pattern and the Output signal.

Convert Setting Screen

IQproducer (4/11)

Convert Function: ASCII 1, 2, 3 format

The followings are descriptions of each format (ASCII1, ASCII2, ASCII3) that can be entered in Convert.

ASCII 1

The ASCII 1 format is composed of a file of waveform patterns before conversion. One line indicates one piece of data. The data is separated by commas in the order of I-phase data, Q-phase data, Marker 1, Marker 2, Marker 3 and RF Gate. “0” or “1” must be specified for Marker 1~3 and RF Gate. Marker 1~3 and RF Gate can be omitted. In this case, however, Marker1~3 is regarded as “0” (LO level), and RF Gate (RF output On) as “1”. Also, a line that does not begin with numbers, “+” and “-” is disregarded as a comment line. I-phase data and Q-phase data is decimally described or described with exponents using an “e” or “E”, such as “2.0E+3”.

// IQ Data

Comment Line

– 0.214178, – 0.984242

– 0.187286, – 1.245890

– 0.073896, – 1.368888

0.091758, – 1.316199

– 0.073896, – 1.368888,1 # Marker1=1

0.091758, – 1.316199,0,1 # Marker2=1

0.248275, – 1.089333,0,0,1 # Marker3=1

0.331432, – 0.729580,0,0,0 # RF output=Off

0.331432, – 0.729580,,0,0,1 # Marker1=0, RF output=On

ASCII 2

The ASCII 2 format is composed of two files of I-phase data and Q-phase data excluding a Marker data file from ASCII 3. While this format is used, Marker 1~3=0 and RF Gate=1 are specified. Also, Marker output is all “0” and pulse modulation is not used. Therefore, RF output is On in all sample waveform patterns. I-phase data and Q-phase data is decimally described or described with exponents using an “e” or “E”, such as “2.0E+3”.

ASCII 3

The ASCII 3 format is composed of three files of waveform patterns before conversion. I-phase data, Q-phase data and “Marker 1 to 3 & RF Gate” is divided into three separate files. Marker 1~3 and RF Gate can specify “0” and “1” only. Marker 1 to 3 and RF Gate can be omitted. In this case, however, Marker1 to 3 is regarded as “0”, and RF Gate as “1”. Also, I-phase data, Q-phase data and Marker 1 to 3 & RF Gate data is combined among the same line numbers in each file where line feeds are inserted by <cr> <lf>. If a comment line is added to the head of any file, the number of lines in the other files must be conformed accordingly by adding a comment line or , <cr> <lf> to the head of the file. An error occurs unless the number of lines is conformed between I-phase data and Q-phase data. Even if Marker 1 to 3 & RF Gate data exists in a line that does not include I-phase data and Q-phase data, the line is regarded as having no data. A data line of the other file, allocated to a line corresponding to the comment line of one file, is disregarded. Also, a line that does not begin with numbers, “+” and “-” is disregarded as a comment line. I-phase data and Q-phase data is decimally described or described with exponents using an “e” or “E”, such as “2.0E+3”.

File 1 (I-phase data)

// I Data

Comment Line

– 0.214178

– 0.187286

– 0.073896

0.091758

0.248275

0.331432

...

File 2 (Q-phase data)

// Q Data # The number of lines must be conformed accordingly because two comment lines are added in I-phase data.

<cr><lf>

– 0.984242

– 1.245890

– 1.368888

– 1.316199

– 1.089333

– 0.729580

File 3 (Marker data)

<cr><lf>

<cr><lf>

<cr><lf>

Marker1 to 3=0 and RF Gate=1 are specified for the 3rd and 4th lines.

<cr><lf>

1 # Corresponds to the 5th line data of I-phase and Q-phase data.

0,1

0,0,1

1,0,0,1

...


IQproducer (5/11)

Clipping function

This function performs clipping for a waveform pattern generated by each signal generation application. Filter, bandwidth, and number of repetitions are set to generate a clipped waveform pattern.

Clipping is used when restricting the input signal peak, such as at amplifier evaluation.

In addition, it can also be used to filter unwanted signals at the adjacent channel for Rx test interference patterns.



Input File

Selects waveform pattern for clipping

Threshold Level

Level for clipping

Setting Range: 0 to 20 dB
Resolution: 0.1 dB

Repetition

Repeat count for clipping and filtering

Setting Range: 1 to 20
Resolution: 1

Filter Type

Ideal,
None,
Nyquist,
Root Nyquist,
Gaussian

Bandwidth

Setting Range: Sampling Rate/1000 or 0.001
~ Sampling Rate

Roll Off/BT

(Enabled for Nyquist, Root Nyquist, Gaussian)
Setting Range: 0.10 to 1.00
Resolution: 0.01


Clipping Setting Screen

IQproducer (6/11)

CCDF Function

The Complementary Cumulative Distribution Function (CCDF) of a waveform pattern generated by a signal generation application can be displayed.


In a CCDF graph, the signal peak/average power is displayed on the x-axis, and the cumulative probability that the signal peak/average power is equal to or less than the value on the x-axis is displayed on the y-axis. As a result, the distribution of peak powers of various modulation signals are displayed on the screen. This is convenient for estimating the output waveform distortion characteristics when a generated signal is input from the MG3710A to a power amplifier or other devices.



IQproducer (7/11)

FFT Function

The Fast Fourier Transform (FFT) of the waveform pattern are displayed as a graph using the Blackman-Harris window function.




FFT Screen

IQproducer (8/11)


Time Domain Function

The waveform pattern generated by each signal generation application is displayed as a time domain graph.

When “I, Q, Marker” is selected from the Graph Type drop-down, the time domain waveform of the I-phase, Q-phase, and marker data of the selected waveform pattern are displayed. When “Power, Marker” is selected, the time domain waveform of the marker data and the power based on the rms value (in the wvi file) of the selected waveform pattern are displayed.



Time Domain Screen
Graph Type: I, Q, Marker






Time Domain Screen
Graph Type: Power, Marker

IQproducer (9/11)

Time Domain: Marker Edit

A new waveform pattern can be created by reading an existing waveform pattern and editing the marker data and name using this function.



Marker Edit Screen

IQproducer (10/11)

Transfer & Setting Function

When changing the MG3710A network setting to DHCP Off and connecting the MG3710A and PC using a LAN crossover cable, restart the MG3710A after changing the network setting before connecting the LAN cable.

PC



LAN Crossover Cable



MG3710A



Input MG3710A IP address.

Connection to instrument

Input instrument name (Host name or IP address) and push connect button to connect to new instrument.

Target instrument

MG3700 MG3710

Instrument name
(Host name or IP address): 100.100.100.1

Advanced

Connect Close

Advanced

Host name or IP address: 100.100.100.1

FTP user ID: ANRITSU

FTP password: *****

FTP port: 21

Remote port: 49158

Remote wait: 10 msec

Default OK Cancel

IQproducer (11/11)

Transfer & Setting: Operation

Transfers file

Installs license key

Loads and clears waveform pattern in waveform memory

Starts waveform pattern output

Deletes file

Connects/Dis connects

The screenshot shows the 'Transfer & Setting Panel' window. The top menu bar includes 'Connection', 'Edit', 'View', 'Transfer', and 'SG'. Below the menu is a toolbar with icons for file operations (copy, paste, delete, etc.) and waveform controls (load, clear, start, stop). The main area is divided into two panes: 'PC side' and 'MG3710A side'. The 'PC side' pane shows a list of files and folders, including '1xEVDO_FWD', '1xEVDO_RVS', 'AWGN', 'CCDF', 'Clipping', 'Convert', 'DVB-T_H', 'Fading', 'FFT', 'HSDPA', 'LTE', 'LTE_TDD', 'mesa', 'MultiCarrier', 'MwWiMAX', 'TD-SCDMA', 'TDMA', 'TimeDomain', 'Transfer', and 'W_CDMA'. The 'MG3710A side' pane shows a list of files and folders, including 'Bluetooth', 'CDMA2000', 'CDMA2000_1xEV-DO', 'Convert_IQproducer', 'Digital_Broadcast', 'GPS', 'GSM', 'LTE_FDD', 'LTE_FDD(BS Tx test)', 'LTE_FDD-Interfere', 'LTE_FDD-wanted', 'LTE_TDD(BS Tx test)', 'MobileWiMAX', 'PDC', 'PDC_CMB', 'PHS', 'PHS_CMB', 'Tone', and 'W-CDMA(BS Rx test)'. The status bar at the bottom shows 'Ready' and system information: '100.100.100.1 HDD:81,865,436KB/103,811,996KB MemA:4,294,889,520B/4,294,967,296B MemB:4,294,967,296B/4,294,967,296B'.

PC side

MG3710A side